


■ ■ Custom Settings

Reset custom settings
Autofocus
a1: AF-C priority selection
a2: Built-in AF-assist illuminator
a3: Rangefinder
Exposure
b1: EV steps for exposure cntrl.

Timers/AE lock
c1: Shutter-release button AE-L
c2: Auto off timers
c3: Self-timer
c4: Remote on duration
Shooting/display
d1: Beep
d2: ISO display
d3: File number sequence
d4: Exposure delay mode
d5: Print date

Bracketing/flash
e1: Flash cntrl for built-in flash
e2: Auto bracketing set
Controls
f1: Assign  /Fn button
f2: Assign AE-L/AF-L button
f3: Reverse dial rotation
f4: Slot empty release lock
f5: Reverse indicators



■ ■ Setup Menu Options

Format memory card
Monitor brightness
Info display format
Auto info display
Clean image sensor
Lock mirror up for cleaning
Video mode

HDMI
Flicker reduction
Time zone and date
Language
Image comment
Auto image rotation
Image Dust Off ref photo

GPS
Eye-Fi upload*
Firmware version

* Only available when compatible Eye-Fi memory card is inserted.

■ ■ Retouch Menu Options


D-Lighting
Red-eye correction
Trim
Monochrome
Filter effects
Color balance
Image overlay

NEF (RAW) processing
Resize
Quick retouch
Straighten
Distortion control
Fisheye
Color outline

Color sketch
Perspective control
Miniature effect
Selective color
Edit movie

■ ■ Recent Settings/ My Menu (Defaults to Recent Settings)

For More Information

Information on individual menu options is available using the camera's on-board help ( 8) and in the *Reference Manual* on the supplied reference CD (for information on viewing the *Reference Manual*, see the inside front cover of this booklet).