

DWM3001CDK Quick Start Guide

Introduction

The Qorvo® DWM3001CDK is a certified development kit to evaluate the capabilities of the low cost Qorvo® UWB & Bluetooth Low Energy module DWM3001C.

DWM3001C module contains a Qorvo® DW3110 non-PDoA UWB transceiver and a Nordic® nRF52833 SoC.




Fig. 1.1: DWM3001CDK board

More details about DWM3001CDK board can be found on Qorvo® website on [DWM3001CDK page](https://www.qorvo.com/products/p/DWM3001CDK)¹ and [DWM3001C page](https://www.qorvo.com/products/p/DWM3001C)².

¹ <https://www.qorvo.com/products/p/DWM3001CDK>

² <https://www.qorvo.com/products/p/DWM3001C>

Required Tools

Hardware Tools

Development kit board is equipped with Segger J-Link OB (on-board programmer), no additional hardware tool is needed to flash the device.

Software Tools

To flash the development kit, you can use the [Segger J-Flash Lite](#)³, which is a component of the **J-Link Software and Documentation Pack**. Follow the instructions below to download and install J-Flash Lite:

1. Go to the [Segger downloads page](#)⁴.
2. Choose the latest version of the J-Link Software and Documentation Pack which is compatible with your operating system.
3. Download and execute the installer, then follow the installation procedures.
4. Once the software is installed, you can proceed with flashing your development kit.

Flashing the development kit

Warning: DWM3001CDK boards are not shipped preprogrammed. UCI version needs to be flashed to continue.

1. To flash the board, connect a micro-USB cable to the board (J9 USB connector shown in the figure [DWM3001CDK board](#).)
2. Locate the JFlashLite tool in your installation directory (e.g. C:\Program_Files\SEGGER\FlashLite.exe in Windows or /usr/bin/JFlashLite in Ubuntu) and launch the application.

Note: When you connect the development kit for the first time, you may be prompted to update firmware of the on-board programmer. Please approve the update by clicking **OK** and wait for the update to complete.

3. Upon starting JFlashLite, the Device and Interface selection dialog will appear. Select **NRF52833_xxAA** device by clicking on “...” button. On the right side of dialog window, select **SWD** Interface with clock speed of **4000 kHz**. Click **OK** to proceed.



Fig. 1.2: Select CPU settings.

4. Next, select the firmware file you wish to flash onto the board. Click the “...” button to browse for the firmware (e.g. DW3_QM33_SDK/Binaries/DWM3001CDK-DW3_QM33_SDK-UCI-FreeRTOS.hex). After selecting the file, click **Program Device** to start the flashing process.

³ https://wiki.segger.com/J-Flash_Lite

⁴ <https://www.segger.com/downloads/jlink/>

Note: To evaluate the board with the Qorvo One TWR GUI application please ensure that you flashed the **UCI** hex file.




Fig. 1.3: Select .hex file to flash.

5. Once the progress bar is completed, the device has been successfully flashed. Perform a power cycle by disconnecting and reconnecting the power supply to reset the board. Your device should be now ready to use.




Fig. 1.4: Programming progress window.

DWM3001CDK Setup

Connect the DWM3001CDK board to a PC beside an AoA-capable board (such as Qorvo® QM33120WDK1 AoA system) using micro-USB cables.

Note: Make sure that the antennas face each other during the evaluation.

Ranging and AoA Evaluation

Install **Qorvo One TWR GUI** evaluation software included in the package and start the application. Please check *Qorvo Software License* and click **Next** if you agree to the terms and conditions.

Warning:

- If you got the error:
`dlopen(): error loading libfuse.so.2`
Install libfuse2 using the following commands:
`sudo apt update`
`sudo apt install libfuse2`
- On Ubuntu 20.04, you may also need to install qt5-default:
`sudo apt update`
`sudo apt install qt5-default`
- On Ubuntu 22.04 & Ubuntu 24.04, you may also need to install qtbase5-dev:
`sudo apt update`
`sudo apt install qtbase5-dev`




Fig. 1.5: Welcome screen

The boards will be detected and displayed on the main screen.




Fig. 1.6: Boards detection

FiRa Configuration

Use **FiRa Configuration** button to setup the ranging parameters. A new window will appear, allowing you to modify various FiRa settings, such as **UWB Channel** or **Ranging duration**.

FiRa Configuration

Initiator and Responder

Session ID

0x0000002A

Measurement scheme ⓘ

DS-TWR-deferred

Peer mode

One-to-Many

Pulse Repetition Freq. (PRF)

BPRF

UWB Channel

9

SFD ⓘ

2

Frame preamble code

9

Ranging duration (ms)

200

Slot duration (ms)

2

Num. of slots in ranging rounds ⓘ

25

Ranging Frame (RFRAME)

SP3

vendor ID

0x0708

Static STS config

0x060504030201

Vupper64

0x0605040302010708

Ranging round hopping

☐

Report angle

☒

Reset all Configuration

Save

Fig. 1.7: FiRa configuration

Apply desired setting and click **Save** button. You can also use **Reset all Configuration** to restore the default values.

Device configuration

To setup the device parameters of each board, click the **Configure** button located in the **Device Configuration** column. A new window will appear, allowing you to modify various device settings, such as **TX Power** or **Antenna delay**.

▲ Device Configuration Node 0x474d3932 ✕

Initiator

Device	DW3110 (0xdeca0302)	Import Calibration	Export Calibration
ID	0x474d3932	Automatic address definition <input checked="" type="checkbox"/>	
Firmware Version	1.0.0		
TX Power	Max: 0x00000000		
Antenna type	Jolie non AoA		
Antenna delay	16405		
Pulse shape	Standard		
LNA activation	<input type="checkbox"/>		

Reset all Configuration Save

Fig. 1.8: Device configuration

To ensure optimal ranging performance, the board's UWB chip requires calibration.

To understand calibration settings, refer to the **Calibration and Configuration** section in **DW3000 QM33 SDK Developer Manual**. However, to quickly evaluate the system you can use preset settings provided in the SDK.

Note:

- Configuration and calibration settings are non-volatile, they are retained after power cycle or firmware update.
 - If you perform a Non-Volatile Memory (NVM) erase, such as a chip erase, it is crucial to reapply calibration and configuration to the device.
-

Warning: It is mandatory to perform the configuration procedure of the UWB chip when the development kit is used for the first time or when the SDK is upgraded to a higher version since the compatibility of the calibration data from one firmware version to another is not guaranteed.

To load the calibration, click the **Import Calibration** button.

In the new dialog, select appropriate calibration file:

DW3_QM33_SDK_1.0.0/Tools/uwb-qorvo-tools/scripts/device/load_cal/calib_files/
DWM3001CDK/dual-hoe_non_aoa.json




Fig. 1.9: Device calibration file

Press **Save** button in **Device configuration** window to apply configuration and calibration. When calibration has changed, saving may take up to 10 seconds.

TWR Ranging

Press **Save and start** to start the ranging experience.




Fig. 1.10: Real Time Location

Auto Calibration

The Qorvo One TWR GUI software provides an auto calibration feature that simplifies the calibration process on the development boards. This feature automatically adjusts the antenna delay and the PDoA offset in the NVM of the MCU.

Note: As antenna delay and PDoA offset values are stored in a specific section of the NVM, they are retained after power cycle or firmware update.

It is highly recommended to perform auto calibration as it improves distance and AoA performances.

Click on the **Auto Calibration** button located in the left bar.



Fig. 1.11: Auto calibration icon

A new tab will appear, listing the different devices.




Fig. 1.12: Auto Calibration tab

Click on the **Calibrate** button of the device to calibrate. A new window will appear, explaining the auto calibration process.

Note: It is important to follow the instructions displayed in the window as precisely as possible to ensure improved performance.




Fig. 1.13: Auto Calibration window

Click on the **Calibrate** button to start the auto calibration. Once the auto calibration process is complete, the software will display a message indicating the success of the calibration.




Fig. 1.14: Auto Calibration completed

The device will be marked as calibrated in the Auto Calibration tab.




Fig. 1.15: Auto Calibration tab with device calibrated

After completing the auto calibration, you can proceed with the TWR ranging or AoA evaluation as described in the previous section.

Revision History

Version	Date	Comment
DW3_QM33_SDK_1.0.0	2024-11-06	<ul style="list-style-type: none">• Added <i>Required Tools</i> section.• Added <i>Flashing the development kit</i> section.• Updated <i>Ranging and AoA Evaluation</i> section:<ul style="list-style-type: none">– Content divided into subsections: <i>FiRa Configuration</i>, <i>Device Configuration</i> and <i>TWR Ranging</i>.– Added information about calibration and configuration.– Updated GUI images to the latest version.• Updated target board images and their descriptions.
DW3_QM33_SDK_0.1.1	2022-11-03	Initial release