



How to Use the Panasonic VCR and Sony Video Presentation Stand with the Mitsubishi LVP-X300 Projection System

To Power Up

1. Turn on the Mitsubishi LVP-X300 Projection System first. The Mitsubishi LVP-X300 Projection System's remote has a **BLUE Power** button. Point the remote at either the projection screen or the projection system, and hold the button down for 2 seconds.
2. Turn on the Sony Video Presentation Stand.
 - Pull the drawer on the right side of the Presentation Podium out to reach the Sony Video Presentation Stand.
 - The **Power** button is a rocker switch located towards the back on the top edge furthest from you.
 - If needed to reach the **Power** button, bring the Camera Arm up to clear the drawer lip and pull the stand towards the drawer lip.
*NOTE: The **UNLOCK** lever for the Camera Arm is in the middle of the base of the arm. Press down to **UNLOCK**.*
 - When powered on, the Sony Video Presentation Stand's lights will come on.
3. Press the **Video1** button in the center of the Sony Video Presentation Stand's front panel. *NOTE: It is NOT necessary for the Sony Video Presentation Stand to come further out of the drawer and can now be adjusted so the drawer can close.*
4. Turn on the Panasonic VCR, located on the very bottom shelf of the Presentation Podium. The **Power** button is the left most button on the front of the unit.
5. Insert the video tape and press the  **PLAY** button either on the right front of the Panasonic VCR or on the Panasonic VCR Remote Control.

To Power Down

1. When finished, press the  **STOP** button and then the



REWIND button. Eject the video tape. *NOTE: The **EJECT** button is next to the **Power** button on the front of the unit.*

2. Turn off the Sony Video Presentation Stand and Panasonic VCR via their respective **Power** buttons.
3. Turn off the Mitsubishi LVP-X300 Projection System via its remote control. You must hold the **BLUE Power** button down for 3 seconds to turn the projection system off.