

## **How to Use the Egan White Board**

### **To Power Up**

- ❑ Turn the **POWER** switch on the left side to the | position to turn the power on.
- ❑ Allow 5 seconds for the Egan White Board to warm up.

### **To Write On**

- ❑ Use **Dry Erase Markers** Only. Anything else will destroy the Egan White Board's features.
- ❑ Press the **ADVANCE** button to go to the next screen (there are a total of 2 screens).
- ❑ If you are going to print a copy of what you write on the Egan White Board, then write with **BOLD, DARK** marker strokes.
- ❑ If you are going to print a copy of what you write on the Egan White Board, then avoid using the **Green** Dry Erase Markers (**Green** does NOT show up well on the printout).

### **To Print a Copy from**

- ❑ Press the **PRINT** button to print the screen showing.
- ❑ Press the **PRINT BOTH SCREENS** button to place both screens on one printout.
- ❑ To print 2-9 copies, press the **MULTIPLE COPIES** button until you have selected the desired number of copies.
- ❑ Press the **DARKER COPY** button to print a darker copy.