

How to Use the CD-ROM/DVD Drive in the PC Pentium III computer

To Use a DVD disc

1. Select the DVD Player (Version 1.5 – Gateway supplied) software from the **Start** button**Program****DVD Player**.
2. Once the program is open and the DBD window appears, you can insert your DVD disc. Press the button near the top of the PC Pentium III's CPU tower and below the word "**6X**" on the right. This opens the CD-ROM/DVD combination Drive.
3. Place you DVD disc in the tray and press the button again. This will close the Drive.
4. In a minute the small DVD window will display your DBD disc's opening screen. Clicking the window's size box will cause it to fill the screen.
*NOTE: There are additional size choices – See **5.I. Video Window Size** below.*
5. To reach the DVD Player's options, you can Right-Click in the DVD window.

- | | |
|-------------------------|---|
| A. Panel Control | Displays a horizontal panel of icon buttons representing your options that move you to Title menu, Root menu, Activate button, Pause/Play , Stop , Scan Backwards , Scan Forwards , Chapter Rewind , Go Up , Previous Program , Next Program , Slow Motion , Change Audio Language , Change Subtitle Language , Change Time info , and Eject DVD . In addition, there are arrow keys to move about in the menus. |
| B. Navigational Control | Displays a vertical panel of icon buttons representing your options that move you to Title menu, Root menu, Activate button, Pause/Play , Stop , Scan Backwards , Scan Forwards , Chapter Rewind , Go Up , Previous Program , Next Program , Slow |

Motion, Change Audio Language, Change Subtitle Language, Change Time info, and Eject DVD. In addition, there are arrow keys to move about in the menus.

- | | |
|-------------------------|---|
| C. Angle Control | Changes the camera angle if allowed by the DVD disc. |
| D. Time Search | Provides a window with a time slider to move to another time spot in the DVD display. |
| E. Chapter/Title Search | Provides a window with chapter/title headings and buttons to move to another chapter/title in the DVD display. |
| F. Numerical Keypad | Provides a window with a numerical keypad – options are determined by the DVD disc used. |
| G. Settings | Tabs are Parental, Display, Picture, Spoken Language, and SubTitle. Parental allows Password protection. Spoken Language allows change to an alternative language, if the DVD disc provides one. SubTitle allows change to a Director's narration, if the DVD disc provides one. |
| H. Subtitles | Enables or Disables the use of SubTitles. |
| I. Video Window Size | Choices are Default, Full Screen, Window, and Cinema. Default is a medium size window, while Window is a large size window; Both allow desktop area to be seen. Full Screen and Cinema seem to be the same, unless the DVD disc offers Letter-box view. |
| J. Exit | Closes the DVD Player program. |