

[Home](#) / [Care and Use](#)

# Care and Use

## Support

[Customer Service](#)[Contact Us](#)[FAQs](#)[Returns](#)[Shipping](#)[Warranty](#)[Affiliates](#)[Register Your Products](#)

Each piece from our extensive range of high-quality cookware is designed for versatility and ease of use. Please read these care and use guidelines before using your cookware for the first time. The information here will help you achieve the best possible cooking results.

[Cookware](#) | [Bakeware: Stoneware & Metal](#) | [Tabletop & Glassware](#) | [Utensils, Cutlery & Accessories](#) | [Wine Tools & Accessories](#)



# Cookware

## Enameled Cast Iron



### COOKING WITH ENAMELED CAST IRON

Enameled cast iron is a remarkable and robust material that performs well with modern requirements for food preparation and cooking. Whether you choose to stir-fry, slow-cook a casserole, sear a steak or bake a cake, there is a shape that is suitable. Cast iron performs well for either slow cooking or high-temperature searing.

Enameled cast iron has the ability to retain heat efficiently, which allows for use of lower heat settings in stovetop and oven cooking. On the table, a hot covered dish will keep food hot for second servings. Cast iron should not be used in microwave ovens.

Cast iron can also be used to keep foods cold. A chilled dish becomes an ideal cold food server on a hot summer day. It can also be placed in the freezer for food storage or advanced food preparation.

### BEFORE FIRST USE

Remove all packaging materials, clips, labels and stickers. Check both the bottom and the sides of the product for labels. Wash the pan in hot, soapy water, then rinse and dry thoroughly. Your pan is now ready to be used and does not require any further preparation.

### HEAT RECOMMENDATIONS

Le Creuset enameled cast iron cookware can be used on a variety of heat sources. Check the Care & Use manual that came with the product for a list of approved heat sources, as they can vary by product. Enameled cast iron should not be used in microwave ovens. If approved for use on a glass-topped stove, always lift the pan when moving it; never slide it, as this may damage the stovetop or the base of the pan.

Medium or low heat will provide the best results for cooking, including frying and searing. Allow the pan to heat gradually and thoroughly for even and efficient cooking results. Once the pan is hot, almost all cooking can be continued on lower settings.

Medium-high heat temperatures should only be used for boiling water for vegetables or pasta, or for reducing the consistency of stocks or sauces. High heats should never be used to preheat a pan before lowering the heat for cooking. Cast iron retains heat so efficiently that overheating will cause food to burn or stick.

Always match the pan's base size to the stovetop heat zone to maximize efficiency, and to prevent overheating of the pan sides or damage to the handles.

Flames must always be confined to the base area, and must never extend around the sidewalls of the pan. Long handles should be positioned safely where they do not hang over the front of the

stove or other heat zones.

Cast iron handles, stainless steel knobs and phenolic knobs will become hot during stovetop and oven use. Always handle the product by the handles, lid and knob. Always use a dry heat-resistant hand protector when handling a hot product during and after cooking.

Always place a hot pan on a wooden board, trivet or Le Creuset silicone mat—never on an unprotected surface.

## OILS AND FATS

With the exception of Grills, the enamel surface is not ideal for dry cooking.

Your choice of liquid, oil, fat or butter should completely cover the base before heating begins. Do not leave the pan unattended, and do not allow a pan to boil dry, as this may permanently damage the enamel.

For deep frying, the maximum oil level must not exceed 1/3 full. This depth allows sufficient height above the oil for it to rise once foods are added. An oil frying thermometer should be used for safety, and a lid should be readily available in case of overheating or flaring.

## FOOD STORAGE AND MARINATING

The vitreous enamel surface is impermeable and therefore ideal for raw or cooked food storage, and for marinating with acidic ingredients such as wine.

## TOOLS TO USE

For stirring comfort and surface protection, Le Creuset silicone tools are recommended. Wooden or heat-resistant plastic tools may also be used. Metal tools, spoons or balloon whisks may be used, but require special care – they should not be scraped over the enamel surface. Do not knock these on the rim of the pan.

Hand-held electric or battery-operated beaters should not be used. Their blades will damage the enamel. Knives or utensils with sharp edges should not be used to cut foods inside a pan.

## OVEN USE

The black phenolic lid knobs on our Signature range of enameled cast iron are heat-resistant to 500°F / 250°C. The black phenolic lid knobs on our Classic range of enameled cast iron are heat-resistant to 390°F / 190°C. Products with integral cast iron handles or stainless steel knobs can be used at any oven temperature. Pans with wooden handles or knobs must not be placed in the oven.

Do not place any cookware on the floors of ovens with cast iron linings. This will increase the cooking temperature inside the oven, resulting in an increased cooking rate with detrimental effects on food. Do not drag cookware across the floor of the liners. For best results always place on a shelf or rack.

## COOKING TIPS FOR GRILLING

Products with our Black Satin enamel or Matte Black enamel may be preheated empty for up to five minutes to reach a hot enough surface temperature for searing and caramelization. This advice does not apply to any other products.

For correct grilling and searing, it is important that the cooking surface is sufficiently hot before cooking begins. Sear lines from ribbed grills will not be produced if the pan surface is too cool, or if the food is too wet. Place the empty pan on medium heat and allow it to heat for about five minutes. Do not add oil to the cold pan—the oil may become too hot and smoke.

Take a few drops of water on your fingers and scatter over the hot surface. If they sizzle and evaporate almost immediately it is hot and ready for use. If the water produces steam and has no sizzle, heat the pan a little longer and repeat the water test again. When the surface is hot enough, lightly oil by brushing it with oil using a Le Creuset silicone basting brush. Vegetable, ground nut or corn oils are recommended. Olive oil may be used but may cause smoking.

Over time, a patina will develop on the surface of the pan, and once the patina covers the cooking surface very little oil will be necessary. For distinct sear lines, leave the food undisturbed on the surface for several minutes. If the food is moved too quickly the lines will be poor, and steam from the food may be released onto the surface.

Any food for grilling or searing must be quite dry before it is placed on the hot surface. Wet foods will not achieve good sear lines and may result in a steamed appearance and flavor. Use paper towels to pat off excess moisture from foods. Oil can then be brushed over the food if desired. Foods that have been marinated should also have excess moisture removed with paper towels.

#### COOKING TIPS FOR SHALLOW FRYING AND SAUTEING

For frying and sauteing, the fat should be hot before adding food. Bring the pan and fat or oil to the correct temperature together.

Oil is hot enough when there is a gentle ripple in its surface. For butter and other fats, bubbling or foaming indicates the correct temperature. If either begins smoking, or if butter begins browning, it is too hot and should be cooled slightly before proceeding. The quickest way to do this is to remove the pan from the heat source for a few moments. For longer shallow frying a mixture of oil and butter gives excellent results.

#### BLACK SATIN ENAMEL

#### MATTE BLACK ENAMEL

#### GENERAL CLEANING AND CARE

Always cool the product to room temperature before washing.

Do not plunge a hot pan into cold water. While Le Creuset's enamel is designed to be the most durable on the market, thermal shock may still occur, resulting in cracking or loss of enamel.

If there are food residues, fill the pan with warm water and let soak for 15 to 20 minutes before washing. A brush can be useful for removing small food deposits, or for cleaning between the ribs on grills. Do not use scourers or abrasive cleaners on the cooking surface. Nylon or soft abrasive pads or brushes can be used to remove stubborn residues. To avoid damaging the enamel, do not

use metallic pads or harsh abrasive cleaning agents.

All pans with integral cast iron, phenolic handles or stainless steel knobs can be washed in the dishwasher. However, constant dishwashing may lead to some dulling of the enamel finish. This is not harmful and will not impair performance. When using the dishwasher always allow the cycle to finish before opening the door. This will ensure the pans are dried thoroughly.

Metallic-toned knobs are finished with an exclusive coating that is not dishwasher-safe. We recommend washing the knobs by hand to ensure the finish stays beautiful for years to come.

Pans with Black Satin and Matte Black interior can be washed in the dishwasher, but this greatly reduces the development of a patina; as a result, grills and skillets will require oiling for a longer period. Pans with wooden handles are not dishwasher-safe.

Light stains or metal marks caused by metal tools can be removed with Le Creuset cookware cleaner. An occasional cleaning with this product will also retain the new appearance of your pans. It can be purchased on this website or from your local retailer.

Never store pans while they are still damp. Store pans in a dry cupboard or airy space away from steam.

Maintain the tightness of all handles and knobs by checking and retightening them regularly.

Le Creuset enameled cast iron is extremely durable but it may be damaged if accidentally dropped or knocked against a hard surface. Please note that this is not covered by our Lifetime Warranty.

Stainless Steel ▼

Toughened Nonstick ▼

Enamel on Steel Stockpots ▼

Enamel on Steel Kettles ▼



# Bakeware

Ceramic Stoneware



Nonstick Metal Bakeware



# Tableware & Glassware

Ceramic Stoneware



Everyday Enamelware



Glassware



# Utensils, Cutlery & Accessories

- Silicone ▼
- Wood ▼
- Revolution Stainless Steel ▼
- Bi-Material ▼
- Mills ▼
- Textiles ▼
- Cutlery ▼



# Wine Tools & Accessories

- Wine Tools ▼

SHOP

- [Dutch Ovens](#)
- [Best Sellers](#)
- [Specials](#)
- [Registry](#)
- [Factory to Table Sale](#)
- [Find a Store](#)
- [Promotions](#)

EXPLORE

- [About Le Creuset](#)
- [Our Colors](#)
- [Our Materials](#)
- [Recipes](#)
- [Blog](#)
- [Careers](#)

SUPPORT

- [Customer Service](#)
- [Contact Us](#)
- [Returns](#)
- [Frequently Asked Questions](#)
- [Warranty](#)
- [Affiliates](#)
- [Special Markets](#)
- [California Chemical Disclosures for Cookware \(AB1200\)](#)

MY ACCOUNT

- [Log In](#)
- [Order Tracking](#)
- [My Favorites](#)
- [Edit Email Options](#)
- [Text Alerts](#)



Enter your email (Required field)

SUBSCRIBE

© 1977-2024 Le Creuset of America, Inc. All Rights Reserved.

[Terms](#) | [Privacy Policy](#) | [Accessibility](#)

United States ▾