



V2/V2B User's Guide

The V2 keyboard features a DIP switch on the backside of the keyboard to enable or disable various modes of function.

The keyboard must be powered off to switch modes.

Switch State	Function	Notes
SW1 Off, SW2 Off	Standard QWERTY mode	
SW1 On, SW2 Off	Mac mode	Switches the default position of the Command and Option keys
SW1 Off, SW2 On	Dvorak mode	
SW1 On, SW2 On	Colemak mode	
SW3 Off	Caps Lock = Caps Lock, (L) Ctrl = (L) Ctrl	
SW3 On	Caps Lock = (L) Ctrl, (L) Ctrl = (L) Ctrl	Caps Lock function is removed
SW4 Off	Scroll Lock = Scroll Lock	
SW4 On	Scroll Lock = OS Key Lock	Use this key to enable/disable your OS keys
SW5 Off	OS Keys Enabled	
SW5 On	OS Keys Disabled	If OS Keys are disabled, OS Key Lock mode will be disabled
SW6 Off	Menu Key = Menu Key	
SW6 On	Menu Key = Fn Key	Used to access built-in function commands

Function Commands*		Notes
Fn + Insert	Play / Pause	
Fn + Home	Stop	Not supported by OSX
Fn + Delete	Previous Track	
Fn + End	Next Track	
Fn + Page Up	Volume Up	
Fn + Page Down	Volume Down	
Fn + Pause	Mute	
Fn + F11	Adjust LED backlight brightness	LED models only
Fn + F12	Turn LED backlight on / off	LED models only
Fn + F13 / Print Screen	Eject	Mac mode only

**SW6 must be On for Function Commands to work*