

DA Subfunctions Responding to a Call Sequence

Subfunction	Description	When the node will respond to a call sequence
000	Release Unit	After the release function to the disk drive is complete.
010	Reserve Unit	After the reserve function to the disk drive is complete.
020	Clear Fault Flags	After the clear fault function to the disk drive is complete.
030	Return to zero	After the RTZ function to the disk drive is complete.
040	Select Margin Condition	After the margin select function to the disk drive is complete.
050	Read Sector #	N/A
060	Read Disk Status Register	After the controller reads the drive's fault register into the controller's status register.
061	Read Disk Cylinder Register	After the controller reads the drive's cylinder register into the controller's status register.
062	Read Disk Head Group	After the controller reads the drive's head register into the controller's status register.
063	Read Disk Margin/Difference Register	After the controller reads the drive's margin/difference register into the controller's status register.
064	Read Disk Interlock Register	After the controller reads the drive's interlock register into the controller's status register.
100	Select Disk Cylinder	After a cylinder select function and a read of a I.D. into the controller's status register is complete.
110	Select Disk Head Group	After the head select function to the drive is complete.
120	Read Disk Controllers Status Register	N/A

C0001C0416