



INSTRUCTION SUMMARY

014-j- JUMP TO CONSTANT PARCEL IF S_j IS ZERO
 015-j- JUMP TO CONSTANT PARCEL IF S_j IS NONZERO
 016-j- JUMP TO CONSTANT PARCEL IF S_j IS POSITIVE
 017-j- JUMP TO CONSTANT PARCEL IF S_j IS NEGATIVE

SIGN TEST WIRED FROM THE VR MODULE CONTAINING THE UPPER EIGHT BITS OF SCALAR DATA.

A-1959B