



NOTE:

INSTRUCTION 000,001 (EXIT),
006,007 (SET/CLEAR SEMAPHORE)
WILL ALWAYS INDICATE A BRANCH
FALL THROUGH CONDITION.

IB MODULE BRANCH CONDITION CHECKS (02-5,10-17 INSTRUCTIONS)