

"A" Automatic Test Mode

test steps are automatically read from the input file and executed until either an error occurs or an end of file condition is encountered. also typing ESC breaks the loop. after an error occurs the received buffer is displayed with the error showing. subsequent A's continue testing with next test step from the input file.

"U" Loop Until Error

continuously runs the current test step until either an error occurs or ESC is typed.

"J" Accumulate Performance Statistics

Continuously runs the current test step until an ESC is typed in. a running count of Passes and Fails is kept and displayed.

"Z" Edit Mode

Use to change Transmitt buffer. Type M for list of commands under Z.