

# Product Manual

Dante Electric Broom. Model: Stickler4. Product ID: #1A2EB.

This appliance uses these parts: Belt Number, 5C; Filter Type, 9A.

Find authentic parts on our website at [www.examplesite.com](http://www.examplesite.com).

# Dante.



STICKLER4  
ELECTRIC BROOM

We recommend that you read this guide thoroughly before using your electric broom. If questions arise while preparing it for use, don't hesitate to contact our customer service staff. In North America, phone: 1-800-765-4321.

## Dante Stickler4 Electric Broom Maintenance and Care Guide

### Table of Contents:

#### Introduction

#### Safety Precautions

#### Tool Overview

#### Basic Maintenance

##### A.1 Cleaning the Dust Cup

##### A.2 Filter Maintenance

##### A.3 Brush Roll Cleaning

#### Electrical Qualities

##### B.1 Power Source

##### B.2 Charging Instructions

##### B.3 Battery Life and Replacement

#### Troubleshooting

#### Conclusion

*This is an example  
document. There is no such  
company or product.*

## Introduction

We appreciate that you have chosen to make Dante your preferred brand of electric cleaning appliances. To guarantee the optimal performance of your Stickler4 Electric Broom, we have put together a care and maintenance manual that will aid you in keeping it running smoothly for longer.

### Safety Precautions:

When preparing to operate your electric broom or perform maintenance on it, it is essential to observe the following safeguards:

- Read the user manual thoroughly before you start.
- Unplug the electric broom before performing maintenance tasks.
- Keep the electric broom away from children and pets.
- Do not immerse the appliance in water or any other liquids.
- If you experience an electrical issue, take your electric broom to a qualified, Dante-approved technician.

### Tool Overview:

The Dante Stickler4 Electric Broom was designed for quick and easy cleaning on the go. It offers a lightweight design with a robust motor, a rechargeable battery, a detachable dust cup, a washable filter, and a rotating brush roll that eliminates debris.

### Basic Maintenance:

#### A.1 Cleaning the Dust Cup:

The dust cup requires regular emptying and washing to maintain robust suction and prevent clogs. Follow these steps for efficient cleaning:

1. Power off the electric broom and unplug it.
2. Use the dust cup release button to detach the dust cup.
3. Empty the cup contents into a trash bin.
4. Gently clean the dust cup by rinsing it with water and mild detergent.
5. Let the dust cup dry completely before reattaching it to the electric broom.

## **A.2 Filter Maintenance:**

Occasionally cleaning and replacing the filter on your electric broom will improve its performance. Here's a straightforward guide:

1. Turn off and unplug the electric broom.
2. Locate the filter compartment and remove the filter.
3. Tap the filter gently to remove excess dirt or debris.
4. If the filter is old or damaged, replace it.
5. To clean the filter, run it under cool running water.
6. Let the filter air dry completely before reinserting it into the electric broom.

**A.3** Regular inspection and cleaning of the brush roll are essential for maintaining your appliance. The instructions:

1. Turn off and unplug the electric broom.
2. Find the brush roll and check for any debris, such as hair or threads, that might be tangled around it. Carefully remove any debris you find.
3. Carefully use scissors or a brush to remove accumulated dirt.
4. Reinstall the brush roll securely.

**- End truncated example document -**