

Introduction


This guide covers the basic installation and configuration setup of the JETSTREAM 8500. It is intended for systems administrators familiar with UNIX and Windows NT operating systems, Ethernet TCP/IP networks and the RADIUS protocol.

For further information please refer to the JETSTREAM installation manual 5500023 and the JETSTREAM configuration manual 5500024 on the Serial/Console Server CD.


Summary of installation

- 1. Mount your JETSTREAM 8500 on a rack, desk, or wall.
- 2. Connect it to the network using the 10BaseT port.
- 3. Enter an IP address into the JETSTREAM: connect a terminal or PC to the Admin Port on the rear panel, and key in an ip address, or use dhcp, bootp or rarp to send the unit an IP address.
- 4. In both cases enter other network information into the unit; e.g. broadcast address, subnet mask.
- 5. Configure the JETSTREAM using one of the following:
 - a. a PC to run JETset - a web browser program; it connects to your unit using http.
 - b. a PC to run JETstart - a browser based 'Wizard' program that creates a basic configuration file.
 - c. a terminal or PC to type in commands using command line interface, or to select menu options using text-based menus
 - d. bootp or snmp
- 6. Attach your equipment (e.g. modems, printers) into the front-mounted ports.
- 7. Test communications with your attached devices. If communications are OK, your JETSTREAM is ready to use.

LEDs on RJ45 ports (after bootup)



Rack Mounting



Admin Port, pin-outs

The pin-outs of a 25-way Admin Port connector are shown below. They are suitable for a straight-through cable to a PC.

Pin	Signal	Function
2	RXD	Receive
3	TXD	Transmit
7	S/GND	Signal Ground
all others	-	do not connect

Connection examples

JETSTREAM				Modem	
RJ45 serial port (RS232)				DB25	
RXD	6	<-----	3	RXD	
TXD	5	----->	2	TXD	
RTS	8	<-----	5	CTS	
CTS	7	----->	4	RTS	
DSR	2	----->	20	DTR	
S/GND	4	-----	7	S/GND	
DCD	1	<-----	8	DCD	
DTR	3	<-----	6	DSR	

JETSTREAM				Terminal	
RJ45 serial port (RS232)				DB25	
RXD	6	<-----	2	TXD	
TXD	5	----->	3	RXD	
RTS	8	<-----	4	RTS or	
				20	
CTS	7	----->	5	CTS	
S/GND	4	-----	7	S/GND	

JETSTREAM				Printer	
RJ45 serial port (RS232)				DB25	
RXD	6	<-----	2	TXD	
TXD	5	----->	3	RXD	
S/GND	4	-----	7	S/GND	

Entering network details

- 1. Set your terminal or PC with terminal emulation to emulate VT100 (if you cannot do this, see note 1.)
- 2. On your terminal/PC set : 9600 baud, 8 data bits, no parity and software flow control.
- 3. Connect your terminal/PC to the DB9 or DB25 port marked 'ADMIN' on the rear of the unit. Note: the Admin port is VT100 emulation only.

You can also connect to any RS232 serial port; here you can also use emulation types of ANSI or Wyse 60. Connection examples for a terminal are shown in the previous column.
- 4. Connect your JETSTREAM to mains power. After power up, press <return> on your terminal/PC. You should see a login prompt. If you do not see a login prompt, refer to note 2.
- 5. At the login prompt type 'admin'; at the password prompt press the <return> key.
- 6. At the command line prompt, type 'set line <line number> termtype <termtype>' where *termtype* is either VT100, ANSI or Wyse60 (same as your terminal/PC).
- 7. Type 'screen' then press the return key; you should be presented with the main text menu, see note 5. If you cannot see the main menu refer to note 3.
- 8. Enter your JETSTREAM network details; see note 4.

Notes:

- 1. If your terminal/PC cannot emulate VT100, ANSI or Wyse 60 you will not be able to use the text menuing system during this installation; instead you will have to use the command line interface (cli). After installation you can download additional terminal definitions; some are contained on the accompanying CDROM.
- 2. If you do not see the login prompt you may have a problem with terminal settings (emulation type, baud rate, data bits, etc.). Also, check your cabling.
- 3. If typing 'screen' does not take you into the menu system, you may not be able to use the menus because of your terminal emulation. Use the command line interface (cli).
- 4. Enter your JETSTREAM network configuration details:

server name - the name you want to give your JETSTREAM, e.g. socrates
internet address - the ip address you will use for your JETSTREAM, in dot notation, e.g. 192.65.132.6
broadcast address - the address which will reach all the necessary hosts. e.g. 192.65.132.255
subnet mask - e.g. 255.255.255.0
domain name - e.g. perle.com
ip_host - enter a default host ip address which can be used for all users; enter in dot decimal notation
authentication - how users will be authenticated; you have a choice of 'both' (by JETSTREAM, then if necessary by the RADIUS host), 'local' (JETSTREAM only) or 'RADIUS' (by the RADIUS host only).
gui_access - whether you want to allow web browsers to access the GUI configuration program, named JETset.

- 5. The main menu in the text menu system is shown in the next picture:



Configuration using JETset

If you want to use JETset - the full configuration program proceed as follows (this uses a PC with terminal emulation);

- 1. Open your web browser and enter the ip address of your JETSTREAM in dot decimal notation.

The JETset home page now appears where you can now set the admin password.

- 2. Within JETset, go to the **User** area.
- 3. Within the text menus, go to the **Users Menu** and select **Set Password**. Alternatively, within the cli, type **set password**.

Configuration using JETstart

For configuration you can also use **JETstart** - the configuration ‘wizard’. **JETstart** is a java applet which you run inside your web browser.

You open **JETstart** by opening file jetstart.htm, which is supplied on the Serial/Console Server CD. You need either Netscape version 4.05 (minimum) or Microsoft’s Internet Explorer version 4 (minimum).

Using **JETstart** you create a configuration file. You then download the file from your local machine to the JETSTREAM using tftp; see the JETSTREAM’s cli command ‘netload’.

What do you want to do next?

You can now perform one of the following tasks:

- Configure lines for terminal server connections
- Configure lines for remote access (SLIP/PPP) connections
- Configure users you will be able to set your screen display into other languages
- Configure BOOTP
- Use SNMP to configure and manage some of the JET-STREAM parameters

For further information on performing these tasks please refer to the configuration manual 5500024 on the Serial/Console Server CD.



Perle support offices worldwide

Telephone and Fax
USA
<i>Telephone: (905) 946 5097 (24hrs)</i>
<i>Fax: (905) 944 2070</i>
<i>Email: ptac@perle.com</i>
<i>Multilingual</i>
Europe
<i>Telephone: +44 (0) 1932 792555 (24hrs)</i> <i>(redirected to worldwide support number)</i> <i>Telephone: +1 (905) 946 5097 (24hrs)</i>
<i>Fax: +44 (0) 1932 792554</i>
<i>Email: ptac@perle.com</i>
<i>Multilingual</i>
Asia
<i>Telephone: +65 749 1700</i> <i>Telephone: +1(905) 946 5097 (24hrs)</i>
<i>Fax: +65 749 2003</i> <i>Fax: (905) 944 2070</i>
<i>Email: ptac@perle.com</i>
<i>English and Mandarin speaking</i>

Internet
www.perle.com

JETSTREAM 8500 Quick Start Guide Part No: 5500011-24 Copyright © Perle Systems Limited, 2001
--



JETSTREAM
8500

Network Access Server

Quick start guide



- Remote access
- Terminal server connections
- RADIUS authentication and accounting