


Cliquez sur Internet Explorer pour ouvrir une nouvelle fenêtre.
Dans la barre d'adresse (en haut) saisissez l'adresse suivante: **192.168.178.1**



Dans la colonne de gauche, **cliquez sur "Internet", puis sur "Account Information"**

Configurez comme suivant:

Cochez "Use one Internet connection for all computers (router)"

Cochez "Account information required"

Entrez le Username: 1349*****

Entrez et confirmez le mot de passe: 134lo*****

Cochez "Maintain Internet connection permanently"

Cochez "Detect all ATM parameters automatically"


--> **Cliquez APPLY**

FRITZ!Box - Mozilla Firefox

File Edit View Go Bookmarks Tools Help

http://192.168.178.1/ Go .htm

Getting Started Latest Headlines >Status>Connection...



FRITZ!Box

- Overview
- Internet
 - Online Meter
 - Account Information
 - Port Forwarding
 - DSL Information
- System
- Help

Operating Mode

☒ **Use one Internet connection for all computers (router)**
All connected network devices share one connection to the Internet

☐ **Use FRITZ!Box as a DSL modem**
Each connected computer establishes its own Internet connection using its own access software

Account Type

Specify whether account information such as a 'User name' and 'Password' is required for Internet access.

☒ **Account information required (PPPoE/PPPoA connection)**

☐ **No account information required (in accordance with RFC1483 / RFC2684)**

Connection Settings

User name:

Password:

Password confirmation:

Clearing Internet Connections Automatically

☐ Hang up after seconds

☒ **Maintain Internet connection permanently**

☐ Connected network devices are also allowed to establish their own Internet connections (PPPoE Passthrough)

☒ **Use Traffic Shaping**
Traffic shaping optimizes DSL transmission and makes it possible to take advantage of full DSL speed even when data is being downloaded and uploaded simultaneously.

Traffic Shaping requires data about the speed of your DSL line:

☒ **Set the speeds of the DSL line automatically**

☐ **Set the speeds of the DSL line manually**

Upstream: kBit/s

Downstream: kBit/s

DSL ATM Settings

Please note that manual settings are required only in special cases. Your DSL provider can tell you which values are required.

☐ Detect all ATM parameters automatically

☒ **Define ATM parameters manually**

VPI:

VCI:

Encapsulation: ☒ PPPoE

☐ PPPoA/LLC

☐ PPPoA/VC-Mux

Apply Cancel Help

Fermer la fenêtre. **C'est terminé.**