

INT 10,2 - Set Cursor Position

AH = 02
BH = page number (0 for graphics modes)
DH = row
DL = column

returns nothing

- positions relative to 0,0 origin
- 80x25 uses coordinates 0,0 to 24,79; 40x25 uses 0,0 to 24,39
- the 6845 can also be used to perform this function
- setting the data in the BIOS Data Area at location 40:50 does not take immediate effect and is not recommended
- see VIDEO PAGES 6845 BDA