



MUMBAI OFFICE :
116-D, Govt. Industrial Estate,
Charkop, Kandiwali (West),
Mumbai - 400067,
Maharashtra.
Cell : [+91 73595 95577](tel:+917359595577)
E-mail : inquiry@rajwater.com
info@rajwater.com

AHMEDABAD OFFICE :
B/9, Sumel-7, Business Park,
Opp. Soni ni Chal,
BRTS Bus Stop, N.H.-8
Ahmedabad - 382325.
Cell : [+91 70432 55777](tel:+917043255777)
E-mail : inquiry@rajwater.com
info@rajwater.com

HEAD OFFICE :
Plot No. : 27, Survey No. 47, Jivraj Industrial Area,
Nr. Falcon Pump, Vavdi, Gondal Road, Rajkot - 360004.
Tel : [+91 281 - 2922777](tel:+912812922777)
Telefax : [+91 281 - 2922481](tel:+912812922481)
Cell : [+91 74050 50444](tel:+917405050444) / [+91 70439 55777](tel:+917043955777)
Website : www.rajwater.com
Email : inquiry@rajwater.com / info@rajwater.com

Instruction For Air Dryer

Power Switch: Press ○ (Power) key for 2 seconds to switch **ON/OFF** the controller.
(Select Models)

Set Point: Press and hold '**SET**' key for 2 seconds and release when display flashes.

Use **UP/DOWN** Key to get desired value. Press '**SET**' Key to save settings.

Other parameters: Hold '**prg**' Key for 2 seconds.

Controller will enter in Programming mode and first parameter will flash.
Press '**SET**' key followed with **UP/DOWN** keys to modify parameter value.
To scroll through other parameters, use **UP/DOWN** keys and to modify follows
above procedure.

P1 : 0=Cooling / 1 = Heating	P2 : High temperature limit
P3 : Low temperature limit	US : MAX set point limits
LS : MIN Set point Limit	P4 : Differential
P5 : Probe calibration	P6 : Time Delay In minutes
E1 = If Probe fails 0 = Relay off / 1 = Relay on / 2 = Relay on for Cy min. & off for Cn min.	
Cn : Compressor OFF Time During probe fail	Cy : Compressor ON Time during probe fail
CF : Measurement unit , °C & °F	
PO : 0=Power switch disable / 1 = Power switch enable / 2 = To restore the last status	
LP : 0 =Keypad active / 1 = Locked	r5 : Resolution parameter
FS : 1 = Restore factory defaults	
Error Message: PP =Probe fail. Check probe connection and wire.	
Lt : Low temp / Ht : High temp	

FLASHING: COMP. IN TIME DELAY

LP FLASHING: KEYPAD IS LOCKED

Note: Parameters may vary as per model