



GSTIN 24AAECR3013M1ZJ

MUMBAI OFFICE :
116-D, Govt. Industrial Estate,
Charkop, Kandiwali (West),
Mumbai - 400067,
Maharashtra.
Cell : [+91 73595 95577](tel:+917359595577)
E-mail : inquiry@rajwater.com
info@rajwater.com

AHMEDABAD OFFICE :
B/9, Sumel-7, Business Park,
Opp. Soni ni Chal,
BRTS Bus Stop, N.H.-8
Ahmedabad - 382325.
Cell : [+91 70432 55777](tel:+917043255777)
E-mail : inquiry@rajwater.com
info@rajwater.com

HEAD OFFICE :
Plot No. : 27, Survey No. 47, Jivraj Industrial Area,
Nr. Falcon Pump, Vavdi, Gondal Road, Rajkot - 360004.
Tel : [+91 281 - 2922777](tel:+912812922777)
Telefax : [+91 281 - 2922481](tel:+912812922481)
Cell : [+91 74050 50444](tel:+917405050444) / [+91 70439 55777](tel:+917043955777)
Website : www.rajwater.com
Email : inquiry@rajwater.com / info@rajwater.com

Blow Moulding Machine Check Points

- 1) Drain air after use or Before Shut Down.
- 2) Oil & Grease all the moving parts.
- 3) Maintain Stretch rod distance.
- 4) Set the required pressure with the help of control valves provided.
- 5) Tight screwball if it's loose.
- 6) Check the proper center alignment of Mould at the time of mounting.
- 7) Check Electric Supply.
- 8) Check all the silencer if they are choked or Not.
- 9) Clear of the dust on & surrounding of machine every morning.