


# DFW • DFWL

TECHNICAL MANUAL - v4

ENGLISH





<b>1. Introduction and warnings .....</b>	<b>4</b>
<b>2. Technical features .....</b>	<b>4</b>
<b>3. Approval.....</b>	<b>5</b>
<b>4. Connections .....</b>	<b>6</b>
Single channel .....	6
Multichannel.....	7
<b>5. Programming.....</b>	<b>8</b>
How to access the programming menu.....	8
How to save the programming and exit the menu .....	8
Programming menu .....	9
<b>6. Communication strings.....</b>	<b>41</b>
<b>7. Communication controls .....</b>	<b>42</b>
<b>8. Wiring schemes .....</b>	<b>44</b>
DFWLxxx, WLB, TPWNxxx, TPWLxxx, MCWNxxx.....	44
DFWLIDxxx.....	44
DFWxxx, TPWxxx, MCWxxx.....	45
<b>9. Programming errors .....</b>	<b>46</b>
<b>10. FAQ - Frequently Asked Questions .....</b>	<b>47</b>
<b>11. Summary of the parameters .....</b>	<b>48</b>

## CONTENTS BY TOPIC

### Calibration

Quick calibration .....	10
Complete calibration .....	37

### Equalisation

Multichannel connection .....	7
Equalisation procedure.....	36

### Safety

Protection of the configuration menu via PIN.....	40
Protection of the user menu via PIN .....	40

### Communication

Configuration of the serial port for PC.....	12
Configuration of the serial port for printer .....	14
Wiring schemes .....	44
Communication strings.....	41
Communication controls .....	42

### Approval

Approval seal.....	5
Display of the metrological version .....	5

### Reset

Factory configuration reset .....	33
Complete reset of memory .....	40

# 1. INTRODUCTION AND WARNINGS

This product represents the best solution for multi-function weighing applications, offering ease of use, high precision in reading the weight and many functions to speed-up and simplify everyday work.

This manual provides an overview of the product's potentials: through the configuration menu, you can adapt the product functionality to the weighing application to be realised.



## WARNINGS:


- Do not make repairs or replace electronic components of the instrument boards.
- Only use original spare parts.
- Any tampering with the equipment or use of non-original spare parts voids the warranty and relieves the manufacturer of any liability.
- Before any installation or repair that involves access to electronic parts, turn off the device and disconnect any source of power supply (battery, 230V network or other).
- Always use network power supply sources regulated within  $\pm 10\%$  of the rated voltage;
- In applications in connection with third parties, always follow the specifications given on the approval decree of the equipment.
- Do not immerse in water.
- Do not wash with water jets (except versions with specific IP protection degree).
- Protect from direct rainfall (except versions with specific IP protection degree).
- Do not use aggressive cleaning solvents or substances.
- Do not install in potentially explosive environments.
- Earth connect any earth socket located on the equipment casing, using a cable with a diameter of at least 16 mm<sup>2</sup>.

# 2. TECHNICAL FEATURES

Power supply via mains / Battery charger		110-230Vac
MAX consumption		5VA
Analog channels for reading of load cells		4
Managed / displayed scales		1
Connectable cells		16 da 350 Ohm
Load cells power supply		5V
Maximum load cells power supply current		20mA
Maximum operating temperature range CE-M - OIML		-10°C + 40°C
Maximum operating temperature range		-10°C + 60°C LCD/-20°C + 60°C LED
OIML divisions		10000e 3x3000e
Divisions for internal use		100d ... 1.000.000d
Optional Digital relays (only for DFW family)	Number	2 / 4
	Features	48 Vac, 60 Vdc, 15 mA, 10 $\Omega$ Max
Optional Digital inputs (only for DFW family)	Number	2 / 4
	Features	12 / 24 Vdc, 5:20 mA
Optional analog output (only for DFW family)		0:10 Vdc, 0:20 mA
Serial ports		2




### 3. APPROVAL




#### How to display the metrological version of the instrument




#### 1. Turn off the scale



#### 2. Follow the procedure:




# 4. CONNECTIONS



## Single channel



Connect the scale to the main terminal board using the first reading channel of the A/D converter.



## Terminal board of reference for connection to 1 channel


### NOTES:


- For connection with 6 wires with "Sense", remove jumpers J2 and J3.
- For connection with 4 wires, install jumpers J2 and J3.



### WARNING:

Make the connections with indicator off and feeder disconnected. Comply with the electronic specifications indicated in the table on page 4





## Multichannel with digital equalisation




You can use the 4 channels of the converter to connect 2, 3 or 4 independent scales/cells, digitally equalising them without using junction boxes.

## Terminal boards of reference for connection to 4 channels

### NOTES:

- Install jumpers J2 and J3.




## 5. PROGRAMMING


### How to access the programming menu



#### 1. Turn off the scale



#### 2. Follow the procedure:




### How to save the programming and exit the menu












To save the programming changes made, repeatedly press the key **C** browsing the menu in reverse, until the message **SAVE?** appears: press **←** to save or **C** to exit without saving.

Example (read from right to left):





## PROGRAMMING MENU

	CAL	Quick calibration.....	10
	↓		
	DCAL	Reset of Pre-Tare (zero calibration).....	11
	↓		
	GRAV	Area of gravity of the place of use.....	11
	↓		
	SERIAL	Configuration of the serial ports.....	12
	↓		
	LAYOUT	Print customisation.....	17
	↓		
	FILTER	Weighing filter.....	25
	↓		
	SCREEN	Adjusting the display.....	26
	↓		
	BATT	Using the battery.....	27
	↓		
	ECO.BATT	Energy saving.....	27
	↓		
	AUTOFF	Auto off.....	28
	↓		
	REMOTE	Using the remote control.....	28
	↓		
	AN.out	Analog output.....	29
	↓		
	INPUTS	Digital inputs.....	31
	↓		
	OUTPUT	Digital outputs.....	32
	↓		
	RESET	Factory configuration reset.....	33
	↓		
	DIAG	Diagnostics.....	33
	↓		
	ADVANC	Advanced.....	34





# MENU

How to enter

1. Off
2. On
- 3.

Page 8

How to browse

- ↑ =
- ↓ =
- =
- ← =

How to save and exit




Page 8

- A **CAL**
- B 0.CAL
- C GrAU
- D SEr iAL
- E LAYout
- F iLteR
- G SCrEEen
- H bAtte
- I ECo.bAt
- J AutoFF
- K rENotE
- L An.out
- M inPutS
- N outPut
- O rESEt
- P d iAG
- Q AdUAnC

## CAL Quick calibration



Start of the calibration procedure:





## MENU

How to enter

1. Off
2. On
- 3.

Page 8

How to browse

- ↑ =
- ↓ =
- =
- ← =

How to save  
and exit



Page 8

A CAL

B O.CAL

C GrAU

D SEr iAL

E LAYout

F iLteR

G SCrEEen

H bAtte

I ECo.bAt

J AutoFF

K rENotE

L An.out

M inPutS

N outPut

O rESEt


P d iAG

Q AdUAnC

## O.CAL Reset of the Pre-Tare




Acquisition of the zero point



## GrAU Area of gravity of the place of use



Once the calibration is completed, for proper operation set the area of use in this pitch (if different from that of calibration).



Area of gravity  
(9.7500 1...9.84999)

How to set the value



or





## MENU

### How to enter

1. Off
2. On
- 3.

Page 8

### How to browse

- ↑ =
- ↓ =
- =
- ← =

### How to save and exit



Page 8

A

B

C

D

E

F

G

H

I

J

K

L

M

N

O

P

Q

1

2

3

1

2

3

4

## SEr iAL Configuration of the serial ports



### CoN.PC Communication with PC, PLC or Repeater

#### Selection of the communication mode

D-1-1

On request (\*)

On request with code 485  
(0...99)

Continuous transmission  
(8 tx /sec)

Automatic stability trans-  
mission

Transmission when  
pressing

For repeater

For use by the  
manufacturer

\* For communication strings and controls, see page 41 - 42.

For the string selection, see step **D-3-1**.



# MENU

How to enter

1. Off
2. On
- 3.

Page 8

How to browse

- ↑ =
- ↓ =
- =
- ← =

How to save and exit



Page 8

A CAL

B 0.CAL

C GrAU

D SEr iAL

E LAYout

F F iLteR

G SCrEEen

H bAtte

I ECo.bAt

J AutoFF

K rENotE

L An.out


M inPutS

N outPut

O rESEt

P d iAG

Q AdUAnC



1 CoN.PC

2 CoN.Prn

3 AdUAnC

1 Node

2 CoN.SEL


3 bAud

4 b it

Selecting the COM port for connection with PC/PLC

D-1-2


CoN.SEL



Communication speed (Baud rate)

D-1-3


bAud



Configuration of the serial protocol

D-1-4

b it





# MENU

How to enter

1. Off
2. On
- 3.

Page 8


How to browse

- ↑ =
- ↓ =
- =
- ← =

How to save and exit




Page 8



## SEr iAL Configuration of the serial ports


### CoN.Prn Communication with printer or repeater or PC

Selection of the communication mode



For communication strings and controls, see page 41 - 42.

Communication speed (Baud rate)





## MENU

How to enter

1. Off
2. On
- 3.

Page 8

How to browse

- ↑ =
- ↓ =
- =
- ← =

How to save  
and exit



Page 8

A CAL

B 0.CAL

C GrAU

D SEr iAL

E LAYout

F F iLteR

G SCrEEen

H bAtte

I ECobAt

J AutoFF

K rENotE

L An.out

M inPutS

N outPut

O rESEt

P d iAG

Q AdUAnC

1 CoN.PC

2 CoN.Prn

3 AdUAnC

1 Node

2 bAud

3 b it


4 CtS

5 PObEr.P

### Configuration of the serial protocol

D-2-3


b it



### Printer control signal

D-2-4


CtS



### Printer power supply / Radio-frequency module

D-2-5

PObEr.P



For use by the  
manufacturer

Printer power supply  
from indicator via Vaux  
connector.

Visible only in modules  
equipped with Vaux, ref.  
Wiring schemes (see page 44).





# MENU

How to enter

1. Off
2. On
- 3.

Page 8

How to browse

- ↑ =
- ↓ =
- =
- ← =

How to save and exit



Page 8

A

B

C

D

E

F

G

H

I

J

K

L

M

N

O

P

Q

1

2

3

1

2

3

4


## SEr iAL Configuration of the serial ports

### AdUAnC Advanced configurations



Communication protocol


D-3-1



For communication strings and controls, see page 41 - 42.


Connection port of radio-frequency module (for use by the manufacturer)

D-3-2



TTL port / Inclinometer activation (for use by the manufacturer)


D-3-3



Only for DFWL models.

Closing character of each print line

D-3-4







# MENU

How to enter

1. Off
2. On
- 3.

Page 8

How to browse

- ↑ =
- ↓ =
- =
- ← =

How to save and exit




Page 8

- |          |           |
|----------|-----------|
| <b>A</b> |           |
| <b>B</b> |           |
| <b>C</b> |           |
| <b>D</b> |           |
| <b>E</b> |           |
| <b>F</b> | <b>1</b>  |
| <b>G</b> | <b>2</b>  |
| <b>H</b> | <b>3</b>  |
| <b>I</b> | <b>4</b>  |
| <b>J</b> | <b>5</b>  |
| <b>K</b> | <b>6</b>  |
| <b>L</b> | <b>7</b>  |
| <b>M</b> | <b>8</b>  |
| <b>N</b> | <b>9</b>  |
| <b>O</b> | <b>10</b> |
| <b>P</b> | <b>11</b> |
| <b>Q</b> | <b>12</b> |
|          | <b>13</b> |
|          | <b>14</b> |
|          | <b>15</b> |
|          | <b>16</b> |
|          | <b>17</b> |
|          | <b>18</b> |


## LAYout Print customisation



Parameters for receipt/label mode



Additional parameters for label mode





# MENU

How to enter

1. Off
2. On
- 3.

Page 8

How to browse

- ↑ =
- ↓ =
- =
- ← =

How to save and exit



Page 8

A CAL

B O.CAL

C GRAU

D SEr iAL

E LAYout

F F iLteR

G SCrEEen

H bAtt

I ECobAt

J AutoFF

K rENotE

L An.out

M inPutS

N outPut

O rESEt

P d iAG

Q AdUAnC

1 LANG

2 CHAR

3 HEAdEr

4 dAtA

5 HE iGhS

6 t iCREt

7 CLoCh

8 bARCL39

9 bARCLuP

10 bARCL

11 bARCh

12 bARCLdt

13 CoP iES

14 Endt iC

15 bLi nE

16 LABEL

17 Lb.SAVE

18 tEST

Setting of the print language ( iAL, EnGL, dEuT, FrAn, ESPA, Ch iNES )

E-1

LANG

EnGL



Ch iNES



CHAR

Character dimensions

E-2-1

CHAR 1

Main character

Label mode

Font.1

1 x 1,5 mm

Font.1d

1 x 3 mm

Font.2

1,5 x 2,5 mm

Font.2d

1,5 x 5 mm

Font.3

2 x 3 mm

Font.3d

2 x 6 mm

Font.4

3 x 4 mm

Font.4d

3 x 8 mm

Font.5

4 x 6 mm

Font.5d

4 x 12 mm

Receipt mode

norMAL

double

CHAR 2

E-2-2

CHAR 2

See CHAR 1





## MENU

How to enter

1. Off
2. On
- 3.

Page 8

How to browse

- ↑ =
- ↓ =
- =
- ← =

How to save and exit



Page 8

A

B

C

D

E

F

G

H

I

J

K

L

M

N

O

P

Q

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

1

2

3

4


5

## LAYout Print customisation


### hEADer Print header




Enables header printing



Contents of the header lines



How to set the value



Repeat the operation to program L inE 2, L inE 3 and L inE 4. Select no to disable them.





# MENU

How to enter

1. Off
2. On
- 3.

Page 8

How to browse

- ↑ =
- ↓ =
- =
- ← =

How to save and exit



Page 8

A

B

C

D

E

F

G

H

I

J

K

L

M

N

O

P

Q

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

1


2

3


4

5

How to print/delete the row being programmed



Programming example



List of characters

(\*)

32		47	/	62	>	77	M	92	\	107	k	122	z
33	!	48	0	63	?	78	N	93	]	108	l	123	{
34	"	49	1	64	@	79	O	94	^	109	m	124	
35	#	50	2	65	A	80	P	95	_	110	n	125	}
36	\$	51	3	66	B	81	Q	96	'	111	o	126	~
37	%	52	4	67	C	82	R	97	a	112	p		
38	&	53	5	68	D	83	S	98	b	113	q		
39	'	54	6	69	E	84	T	99	c	114	r		
40	(	55	7	70	F	85	U	100	d	115	s		
41	)	56	8	71	G	86	V	101	e	116	t		
42	*	57	9	72	H	87	W	102	f	117	u		
43	+	58	:	73	I	88	X	103	g	118	v		
44	,	59	;	74	J	89	Y	104	h	119	w		
45	-	60	<	75	K	90	Z	105	i	120	x		
46	.	61	=	76	L	91	[	106	j	121	y		





# MENU

How to enter

1. Off
2. On
- 3.

Page 8

How to browse

- ↑ =
- ↓ =
- =
- ← =


How to save  
and exit




Page 8

- A **CAL**
- B **O.CAL**
- C **GrAU**
- D **SEr iAL**
- E **LAYout**
- F **F iLteR**
- G **SCrEEen**
- H **bAtt**
- I **ECobAt**
- J **AutoFF**
- K **rENotE**
- L **An.out**
- M **inPutS**
- N **outPut**
- O **rESEt**
- P **d iAG**
- Q **AdUAnC**
- 1 **LANG**
- 2 **CHAR**
- 3 **hEAdEr**
- 4 **dAtA**
- 5 **WE iGhS**
- 6 **t iCREt**
- 7 **CLoCh**
- 8 **bArC39**
- 9 **bArCwP**
- 10 **bArCL**
- 11 **bArCh**
- 12 **bArCdt**
- 13 **CoP iES**
- 14 **Endt iC**
- 15 **bLi nE**
- 16 **LABeL**
- 17 **LbSAUE**
- 18 **tEST**


Selection of the weight data



Progressive weighed



Receipt/label progressive





# MENU

How to enter

1. Off
2. On
- 3.

Page 8

How to browse

- ↑ =
- ↓ =
- =
- ← =


How to save and exit




Page 8

- |                  |                    |
|------------------|--------------------|
| <b>A</b> CAL     |                    |
| <b>B</b> O.CAL   |                    |
| <b>C</b> GRAU    |                    |
| <b>D</b> SEr iAL |                    |
| <b>E</b> LAYout  |                    |
| <b>F</b> iLteR   | <b>1</b> LAng      |
| <b>G</b> SCrEEen | <b>2</b> CHAr      |
| <b>H</b> bAtt    | <b>3</b> hEADer    |
| <b>I</b> ECo.bAt | <b>4</b> dAtA      |
| <b>J</b> AutoFF  | <b>5</b> HE iGhS   |
| <b>K</b> rENotE  | <b>6</b> t iCkEt   |
| <b>L</b> An.out  | <b>7</b> CLoCh     |
| <b>M</b> inPutS  | <b>8</b> bArC.39   |
| <b>N</b> outPut  | <b>9</b> bArC.wP   |
| <b>O</b> rESEt   | <b>10</b> bArC.L   |
| <b>P</b> d iAG   | <b>11</b> bArC.h   |
| <b>Q</b> AdVAnC  | <b>12</b> bArC.dt  |
|                  | <b>13</b> CoP iES  |
|                  | <b>14</b> End.t iC |
|                  | <b>15</b> b.L inE  |
|                  | <b>16</b> LAbEL    |
|                  | <b>17</b> Lb.SAVE  |
|                  | <b>18</b> tEST     |

Date and time




Bar code 39




Barcode top margin (mm)

Visible only if bArC.39 (E-8) is active




Barcode left margin (mm)

Visible only if bArC.39 (E-8) is active



Barcode height (mm)

Visible only if bArC.39 (E-8) is active





# MENU

How to enter

1. Off
2. On
- 3.

Page 8

How to browse

- ↑ =
- ↓ =
- =
- ← =

How to save and exit




Page 8


- |   |         |             |
|---|---------|-------------|
| A | CAL     |             |
| B | O.CAL   |             |
| C | GRAU    |             |
| D | SEr iAL |             |
| E | LAYout  | ↓           |
| F | F iLteR | 1 LANg      |
| G | SCrEEen | 2 CHAr      |
| H | bAtt    | 3 hEAdEr    |
| I | ECobAt  | 4 dAtA      |
| J | AutoFF  | 5 HE iGhS   |
| K | rENotE  | 6 t iCkEt   |
| L | An.out  | 7 CLoCh     |
| M | inPutS  | 8 bARc.39   |
| N | outPut  | 9 bARc.uP   |
| O | rESEt   | 10 bARc.L   |
| P | d iAG   | 11 bARc.h   |
| Q | AdVAnC  | 12 bARc.dt  |
|   |         | 13 CoP iES  |
|   |         | 14 End.t iC |
|   |         | 15 b.L inE  |
|   |         | 16 LAbEL    |
|   |         | 17 Lb.SAVE  |
|   |         | 18 tEst     |

Selection of the weight data


Visible only if bARc.39 (E-8) is active




Multi-copy prints



Paper outlet for end of label/receipt



White pre-heating line of the print head  
(for thermal printer only)





# MENU

How to enter

1. Off
2. On
- 3.

Page 8

How to browse

- ↑ =
- ↓ =
- =
- ← =

How to save and exit




Page 8

- |                  |                   |
|------------------|-------------------|
| <b>A</b> CAL     |                   |
| <b>B</b> O.CAL   |                   |
| <b>C</b> GRAU    |                   |
| <b>D</b> SERIAL  |                   |
| <b>E</b> LAYOUT  |                   |
| <b>F</b> FILTER  | <b>1</b> LANG     |
| <b>G</b> SCREEN  | <b>2</b> CHAR     |
| <b>H</b> BATT    | <b>3</b> HEADER   |
| <b>I</b> ECOBATT | <b>4</b> DATA     |
| <b>J</b> AUTOFF  | <b>5</b> HEIGHT   |
| <b>K</b> RESET   | <b>6</b> TICKET   |
| <b>L</b> ANOUT   | <b>7</b> CLOTH    |
| <b>M</b> INPUTS  | <b>8</b> BARCL39  |
| <b>N</b> OUTPUT  | <b>9</b> BARCLUP  |
| <b>O</b> RESET   | <b>10</b> BARCL   |
| <b>P</b> DIAG    | <b>11</b> BARCLH  |
| <b>Q</b> ADVANC  | <b>12</b> BARCLdt |
|                  | <b>13</b> COPIES  |
|                  | <b>14</b> Endt IC |
|                  | <b>15</b> BL INE  |
|                  | <b>16</b> LABEL   |
|                  | <b>17</b> Lb.SAVE |
|                  | <b>18</b> tEST    |


Label configuration

Visible only if ModE (D-2-1) = LABEL




Saving of labels in the printer memory

Visible only if ModE (D-2-1) = LABEL



Saving of labels in the printer memory (for label mode only) and test print of ALL FORMATS







# MENU

How to enter

1. Off
2. On
- 3.

Page 8

How to browse

- ↑ =
- ↓ =
- =
- ← =

How to save and exit



Page 8

A

B

C

D

E

F

G

H

I

J

K

L

M

N

O

P

Q

1

...

4

5

...

12

13

...

16

17

...

20

21

...

24

25

...

28

## F iLteR Weighing filters



Edits scale reactivity.

Useful to adjust the scale to your needs.



With the approved instrument, you can select only some of the filters listed below (StAnd.0...3, h i.rES.0 - 1, dYn.0 - 1, SLoB.0 - 1).



To weigh live animals, you must also activate the additional filter no iSE in AdUAnC.

Premise:

The "0" represents minor filtering incidence.

Increasing the incidence give the weight more stability.



We recommend weighing several times, changing the incidence until you obtain the best compromise between reactivity and stability.

Table and floor scales and piece counters

F-1

...

F-4



High precision scales

F-5

...

F-12



Suspended and oscillating load weighing

F-13

...

F-16




Liquid weighing, weighbridges and weighing with vibrations

F-17

...

F-20



Metering, filling, level check and overloads


F-21

...

F-24



Automatic



Manual

Filter for specific applications for use by the manufacturer

F-25

...

F-28





# MENU

How to enter

1. Off
2. On
- 3.

Page 8

How to browse

- ↑ =
- ↓ =
- =
- ← =

How to save and exit



Page 8


- A
- B
- C
- D
- E
- F
- G
- H
- I
- J
- K
- L
- M
- N
- O
- P
- Q

- 1
- 2
- 3
- 4


## SCrEEen Adjusting the display




Backlighting




Brightness



Display lock (for use by the manufacturer)



Backlighting colour



Only in version with colour display.





# MENU

How to enter

1. Off
2. On
- 3.

Page 8

How to browse

- ↑ =
- ↓ =
- =
- ← =


How to save and exit



Page 8


- A **CAL**
- B **O.CAL**
- C **GrAU**
- D **SEr iAL**
- E **LAYout**
- F **FiLteR**
- G **SCrEEen**
- H **bAtte**
- I **ECo.bAt**
- J **AutoFF**
- K **rENotE**
- L **An.out**
- M **inPutS**
- N **outPut**
- O **rESEt**
- P **d iAG**
- Q **AdUAnC**

## bAtte Power supply via battery



**WARNING:**  
only use original rechargeable batteries.

## ECo.bAt Energy saving for battery operation





# MENU

How to enter

1. Off
2. On
- 3.

Page 8

How to browse

- ↑ =
- ↓ =
- =
- ← =


How to save and exit




Page 8

- A **CAL**
- B **O.CAL**
- C **GrAU**
- D **SEr iAL**
- E **LAYout**
- F **FiLteR**
- G **SErEEr**
- H **bAtte**
- I **EECo.bAt**
- J **AutoFF**
- K **rENotE**
- L **An.out**
- M **inPutS**
- N **outPut**
- O **rESEt**
- P **d iAG**
- Q **AdUAnC**

## AutoFF Auto off



## rENotE Remote control



The broadcast mode allows sending the control to multiple scales simultaneously.





## MENU

How to enter

1. Off
2. On
- 3.

Page 8

How to browse

- ↑ =
- ↓ =
- =
- ← =

How to save  
and exit



Page 8

A **CAL**

B **O.CAL**

C **GrAU**

D **SEr iAL**

E **LAYout**

F **F iLteR**

G **SCrEEEn**

H **bAtte**

I **ECobAt**

J **AutoFF**

K **rENotE**

L **An.out**

M **inPutS**

N **outPut**

O **rESEt**

P **d iAG**

Q **AdUAnC**

1 **nEt**

2 **Pnt.und**

3 **HGt.1**

4 **Pnt.1**

5 **HGt.2**

6 **Pnt.2**

7 **HGt.3**

8 **Pnt.3**


9 **Pnt.oUr**

## An.out Analog output



Visible only in the presence of optional analog board.

Operation proportional to the net/gross weight



L-2 **Pnt.und** ← **00000** ← Analog value relative to weight in "underload" (0...65535)

L-3 **HGt.1** ← **000.000** ← First value of linearisation weight (-99999...999999)

L-4 **Pnt.1** ← **0 1300** ← Analog value relative to HGt.1 (0...65535)

L-5 **HGt.2** ← **000.000** ← Second value of linearisation weight (-99999...999999)

L-6 **Pnt.2** ← **63250** ← Analog value relative to HGt.2 (0...65535)

L-7 **HGt.3** ← **000.000** ← Third value of linearisation weight (not mandatory) (-99999...999999)

L-8 **Pnt.3** ← **00000** ← Analog value relative to HGt.3 (not mandatory) (0...65535)

L-9 **Pnt.oUr** ← **65535** ← Analog value relative to weight in "overload" (0...65535)

Thanks to the real-time upgrading of the output, using a tester you can check the value entered (see example page 30).

Value to be entered	Output volts	Output mA
1200	~ 0 V	~ 0 mA
11250		~ 4 mA
52200		~ 20 mA
62300	~ 10 V	





## MENU

How to enter

1. Off
2. On
- 3.

Page 8

How to browse

- ↑ =
- ↓ =
- =
- ← =

How to save  
and exit



Page 8

A **CAL**

B **O.CAL**

C **GrAU**

D **SEr iAL**

E **LAYout**

F **FiLteR**

G **SCrEEen**

H **bAtte**

I **ECobAt**

J **AutoFF**

K **rENotE**

L **An.out**

M **inPutS**

N **outPut**

O **rESEt**

P **d iAG**

Q **AdUAnC**

1 **nEt**

2 **Pnt.und**

3 **HGt.1**

4 **Pnt.1**

5 **HGt.2**

6 **Pnt.2**


7 **HGt.3**

8 **Pnt.3**


9 **Pnt.oUr**

Programming example:

we want to program a linearisation point so that at 1000kg, the analog output supplies 10V.





Enter **62300** (the reference value in the table) and check the analog output using a tester.



Adjust the analog output by increasing or decreasing the value. We recommend minimal changes of at least 10 points, (**62310**, **62320**, **62330**, etc.)

How to set the value



Once the desired adjustment has been made, confirm the value with .





# MENU

How to enter

1. Off
2. On
- 3.

Page 8

How to browse

- =   
 =   
 =   
 =

How to save and exit



Page 8

A **CAL**

B **O.CAL**

C **GrAU**

D **SEr iAL**

E **LAYout**

F **FiLteR**

G **SCrEEen**

H **bAtte**

I **ECobAt**

J **AutoFF**

K **rENotE**

L **An.out**

M **inPutS**

N **outPut**

O **rESEt**

P **d iAG**


Q **AdVAnC**

1 **inP.b.1**

2 **inP.b.2**

3 **inP.b.3**

4 **inP.b.4**




## inPutS Digital inputs



Visible only in the presence of optional inputs/outputs electronic board.

Input 1 configuration



Repeat the same operation for **inP.b.2**, **inP.b.3** e **inP.b.4**.



# MENU

How to enter

1. Off
2. On
- 3.

Page 8

How to browse

- ↑ =
- ↓ =
- =
- ← =

How to save and exit



Page 8

A CAL

B O.CAL

C GrAU

D SEr iAL

E LAYout

F iLEtEr

G SCrEEEn

H bAtE

I ECo.bAt

J AutoFF

K rENotE

L An.out

M inPutS

N outPut

O rESEt

P d iAG

Q AdUAnC

1 rELb.1

2 rELb.2

3 rELb.3

4 rELb.4

1 FunCt

2 Node

3 d iREct


4 h iStEr

## outPut Digital outputs



Visible only in the presence of optional inputs/outputs electronic board.

Operation on net weight, gross weight or dosage




### For dosage / filling:


- Start the **doSAGE** mode
- Set the **unLoAd** unladen weight.

The output is activated only after having set the unladen weight of the container (by key or via external button) and is turned off once the set target (setpoint) has been achieved. To perform fills at two speeds, you must programme two outputs in **doSAGE** mode.

Normally open (n.o.) or closed (n.c.) operation



Output activation mode




Direct, when weight is table or unstable

Only when weight is stable


Double threshold operation

(activation weight threshold ≠ from output deactivation weight threshold)




### Operation:

**YES** (Double threshold)



**no** (Single threshold)



Repeat the same operation for **rELb.2**, **rELb.3** and **rELb.4**.







# MENU

How to enter

1. Off
2. On
- 3.

Page 8

How to browse

- ↑ =
- ↓ =
- =
- ← =

How to save and exit



Page 8

A

B

C

D

E

F

G

H

I

J

K

L

M

N

O

P

Q

1

2

3

4

5

6

7

8

9

10


11

12

13

14

## rESEt Factory configuration reset



Function resetting the factory configurations while maintaining the calibration in the memory unchanged.

## d iAG Diagnostics



P-1

Converter. Check of input signal in  $\mu V$ . In case of more equalised channels, press or to examine all the selected channels.

P-2

Display. Integrity check of all segments and icons.

P-3

Keyboard. Press any key to verify its correct operation, with beep and code on display.

P-4

CTS. Check of status of the control signal from the printer.

P-5

Optional digital outputs. Check the activation and deactivation of each contact.

**Example:** activates output 1. Press to select the next output.

**WARNING:** before entering the pitch, verify that the activation of the output does not cause dangerous conditions for people, animals or property.

P-6

Optional digital inputs. Check the activation and deactivation of each input.

**Example:** input not active

**Example:** input active

Press to select the next input.

P-7

Analog output. Enter the digital value and using a tester check the response of the analog output.

P-8

Serial number of the scale.

P-9

Hardware revision (e.g. ) followed by software version (e.g. )

P-10

For use by the manufacturer.

P-11

For use by the manufacturer.

P-12

For use by the manufacturer.

P-13

For use by the manufacturer.

P-14

For use by the manufacturer.





# MENU

How to enter

1. Off
2. On
- 3.

Page 8

How to browse

- ↑ =
- ↓ =
- =
- ← =

How to save and exit



Page 8

A **CAL**

B **0.CAL**

C **GrAU**

D **SEr iAL**

E **LAYout**

F **F iLteR**

G **SCrEEen**

H **bAtt**

I **ECobAt**

J **AutoFF**

K **rENotE**

L **An.out**

M **inPutS**

N **outPut**

O **rESEt**

P **d iAG**

Q **AdUAnC**

1 **CAL.PAr**

2 **EQuALP**

3 **CALAdU**

4 **no iSE**

5 **NEtrol**

6 **REYb**

7 **t iLt**

8 **rEACt**

9 **LoCFAb**

10 **AL iB iR**

11 **P in.tEC**

12 **P in.uSE**

13 **dFLt.t**

1 **dEC iN**

2 **d iU**

3 **uN.**

4 **rAnGE 1**

5 **rAnGE 2**

6 **rAnGE 3**

7 **EQuAL**

8 **nChAn**

## AdUAnC

Advanced



### CAL.PAr


Calibration parameters



Configuration of the decimal point (0...3)

Q-1-1


**dEC iN**



Reading division

Q-1-2


**d iU**



Unit of measure

Q-1-3

**uN.**





# MENU

How to enter

1. Off
2. On
- 3.

Page 8

How to browse

- ↑ =
- ↓ =
- =
- ← =

How to save and exit



Page 8

A **CAL**

B **O.CAL**

C **GrAU**

D **SEr iAL**

E **LAYout**

F **F iLteR**

G **SCrEEen**

H **bAtte**

I **ECobAt**

J **AutoFF**

K **rENotE**

L **An.out**

M **inPUtS**

N **outPUt**

O **rESEt**

P **d iAG**

Q **AdUAnC**

1 **CAL.PAr**

2 **EQuALP**

3 **CALAdU**

4 **no iSE**

5 **NEtroL**

6 **REYb**

7 **t iLt**

8 **rEAct**

9 **LoCFAb**

10 **AL ib iR**

11 **P in.tEC**

12 **P in.uSE**

13 **dFLt.t**

1 **dEC iN**

2 **d iU**

3 **u.N.**

4 **rAnGE 1**


5 **rAnGE 2**

6 **rAnGE 3**

7 **EQuAL**


8 **n.ChAn**

Scale capacity. Set Max or Range 1 (Max range = **800.000**)




Range 2

For multirange scales, set the second weighing range.



Range 3

For multirange scales, set the third weighing range.



Example of multirange configuration at 1500/3000 kg, division 0.5/1 kg.

Set:


**dEC i = 0.0**

**d iU = 5**

**rAnGE 1 = 1500.0**

**rAnGE 2 = 3000.0**


Equalisation function



Connection diagram on page 7.  
Equalisation procedure on page 36.

Equalised analog channels

Visible only if **EQuAL** (Q-1-7) = **YES**





# MENU

How to enter

1. Off
2. On
- 3.

Page 8

How to browse

- ↑ =
- ↓ =
- =
- ← =

How to save and exit



Page 8

A **CAL**

B **O.CAL**

C **GrAU**

D **SEr iAL**

E **LAYout**

F **F iLteR**

G **SCrEEen**

H **bAtte**

I **ECobAt**

J **AutoFF**

K **rENotE**

L **An.out**

M **inPutS**

N **outPut**

O **rESEt**

P **d iAG**

Q **AdUAnC**

1 **CALPAR**

2 **EQUALP**

3 **CALAdU**

4 **no iSE**

5 **NEtrol**

6 **REYb**

7 **t iLt**

8 **rEACt**

9 **LoCkAb**

10 **AL iB iR**

11 **P in.tEC**

12 **P in.uSE**

13 **dFLt.t**

1 **E9.0**

2 **E9.1**

3 **E9.2**

4 **E9.3**

5 **E9.4**







## EQUALP Equalisation



**EQUALP** is only visible if the function **E9uAL** (Q-1-7) is activated in the menu **CALPAR** (Q-1).

The equalisation wizard asks to acquire the zero point with scale unloaded and to later place a weight of about 1/8 of the maximum capacity (Max) on each individual cell, in the required order. After the procedure the message **E9.off** will appear.

Proceed with the calibration.





# MENU

How to enter

1. Off
2. On
- 3.

Page 8

How to browse

- ↑ =
- ↓ =
- =
- ← =

How to save and exit



Page 8

A **CAL**

B **O.CAL**

C **GrAU**

D **SEr iAL**

E **LAYout**

F **F iLteR**

G **SCrEEen**

H **bAtte**

I **ECobAt**

J **AutoFF**

K **rENotE**

L **An.out**

M **inPutS**

N **outPut**

O **rESEt**

P **d iAG**

Q **AdUAnC**

1 **CALPAR**

2 **EQUALP**

3 **CALAdU**

4 **no iSE**

5 **NEtroL**

6 **REYb**

7 **t iLt**

8 **rEAct**

9 **LoCFAb**

10 **AL ib iR**

11 **P in.tEC**

12 **P in.uSE**

13 **dFLt.t**

1 **ZEro**



## CALAdU Complete calibration



- Before calibrating, configure the decimals (**dEE** - Q-1-1), the division (**d iU** - Q-1-2) and the capacity (**rAnGE** - Q-1-4,5,6).

Start of the calibration procedure:

Q-3-1

**ZEro**

Unload the plate, press and wait for the message **-oH-**.

**-oH-**



kg

**CAL.Pnt**

Now acquire the calibration points (up to 3):

n 1

I. Set the calibration points (1...3)

How to set the value



000.000

II. Enter the calibration weight

How to set the value



III. Load the weight and wait

**-oH-**

000.000

Repeat the steps from II. for the next points

**CAL.oH**

**CAL.Pnt**



# MENU

## How to enter

1. Off
2. On
- 3.

Page 8

## How to browse

- ↑ =
- ↓ =
- =
- ← =

## How to save and exit



Page 8

A **CAL**

B **O.CAL**

C **GrAU**

D **SEr iAL**

E **LAYout**

F **FiLteR**

G **SCrEEen**

H **bAtte**

I **ECobAt**

J **AutoFF**

K **rENotE**

L **An.out**

M **inPutS**

N **outPut**

O **rESEt**

P **d iAG**

Q **AdUAnC**

1 **CALPAR**

2 **EQUALP**

3 **CALAdU**

4 **no iSE**

5 **NEtrol**

6 **KEYb**

7 **t iLt**

8 **rEAct**

9 **LoCFAb**

10 **AL ib iR**

11 **P in.tEC**

12 **P in.uSE**

13 **dFLt.t**

1 **OPeRC**

2 **d iUSbb**

3 **0.t.rH**


4 **on.2Ero**

5 **CALAdU**

6 **CALiAn**

7 **d.SALE**

Additional filter for weighing in the presence of vibrations and for weighing live animals.




To weigh live animals, we recommend the combination with filter **StAnd** (F-1,2,3,4) or **SLoB** (F-17,18,19,20). (See page 25)

**NEtrol** Metrological parameter




Reset percentage via key



Sensitivity of the weight stability control



Zero hold function (tracking)





# MENU

How to enter

1. Off
2. On
- 3.

Page 8

How to browse

- ↑ =
- ↓ =
- =
- ← =

How to save and exit



Page 8

A **CAL**

B **0.CAL**

C **GrAU**

D **SEr iAL**

E **LAYout**

F **F iLtEr**

G **SCrEEen**

H **bAtt**

I **ECobAt**

J **AutoFF**

K **rENotE**

L **An.out**

M **inPutS**

N **outPut**

O **rESEt**

P **d iAG**

Q **AdUAnC**

1 **CALPAR**

2 **EQuALP**

3 **CALAdU**

4 **no iSE**

5 **NEtrol**

6 **KEYb**

7 **t iLt**

8 **rEACt**

9 **LoCkAb**

10 **AL ib iS**

11 **P iNtEC**

12 **P iNtSE**

13 **dFLt.t**

1 **0PERC**

2 **d iUSTb**

3 **0t.rH**

4 **on.2Ero**


5 **CALAdJ**

6 **CALMAN**


7 **d.SALE**



Reset at power and reset percentage



Re-acquisition / change of the calibration points in memory.




Repeat the same operation for **Po iNt.1**, **Po iNt.2** e **Po iNt.3**


Q-5-6 **CALMAN** For use by the manufacturer.

Q-5-7 **d.SALE** For use by the manufacturer.

Type of keyboard



Inclinometer (for use by the manufacturer)





# MENU

How to enter

1. Off
2. On
- 3.

Page 8

How to browse

- ↑ =
- ↓ =
- =
- ← =

How to save and exit



Page 8

A **CAL**

B **O.CAL**

C **GrAU**

D **SEr iAL**

E **LAYout**

F **FiLteR**

G **SCrEEen**

H **bAtte**

I **ECobAt**

J **AutoFF**

K **rENotE**

L **An.out**

M **inPUtS**

N **outPUt**

O **rESEt**

P **d iAG**

Q **AdUAnC**

1 **CALPAR**

2 **EQUALP**

3 **CALAdU**

4 **no iSE**

5 **NEtrol**

6 **REYb**

7 **t iLt**

8 **rEAct**

9 **LoCkAb**


10 **AL ib iR**

11 **P in.tEC**


12 **P in.uSE**

13 **dFLt.t**


Reactivation of the totalisation or print function



Permanent keyboard lock (excluding key )




Reset of fiscal memory (alibi memory, optional)



Visible only if the alibi memory option is present

Reset is not possible if the instrument is approved


Access PIN to programming menu



Access PIN to user menus



Total reset of memory and of calibration, with reset of the factory settings.





## 6. COMMUNICATION STRINGS

### Short string

**01ST,GS, 0.0,kg<CR><LF>**

where

<b>01</b>	Code 485 of the instrument (2 characters), only if communication mode 485 is enabled
<b>ST</b>	Scale status (2 characters): <u>US</u> - Weight unstable <u>ST</u> - Weight stable <u>OL</u> - Weight overload (out of range) <u>UL</u> - Weight underload (out of range) <u>TL</u> - Scale not level (inclinometer active)
<b>,</b>	ASCII 044 character
<b>GS</b>	Type of weight data (2 characters)
<b>,</b>	ASCII 044 character
<b>0.0</b>	Weight (8 characters including the decimal point)
<b>,</b>	ASCII 044 character
<b>kg</b>	Unit of measurement (2 characters)
<b>&lt;CR&gt;&lt;LF&gt;</b>	Transmission terminator, characters ASCII 013 and ASCII 010

### Extended string

**01ST,1, 0.0,PT 20.8, 0,kg<CR><LF>**

where

<b>01</b>	Code 485 of the instrument (2 characters), only if communication mode 485 is enabled
<b>ST</b>	Scale status (2 characters): <u>US</u> - Weight unstable <u>ST</u> - Weight stable <u>OL</u> - Weight overload (out of range) <u>UL</u> - Weight underload (out of range) <u>TL</u> - Scale not level (inclinometer active)
<b>,</b>	ASCII 044 character
<b>1</b>	ASCII 049 character
<b>,</b>	ASCII 044 character
<b>0.0</b>	Net weight (10 characters including the decimal point)
<b>,</b>	ASCII 044 character
<b>PT</b>	Indication of pre-set manual tare (2 characters)
<b>20.8</b>	Tare weight (10 characters including the decimal point)
<b>,</b>	ASCII 044 character
<b>0</b>	Number of pieces (10 characters)
<b>,</b>	ASCII 044 character
<b>kg</b>	Unit of measurement (2 characters)
<b>&lt;CR&gt;&lt;LF&gt;</b>	Transmission terminator, characters ASCII 013 and ASCII 010

## 7. COMMUNICATION CONTROLS

Premise:

in the serial controls and in the relative responses

<b>nn</b>	Address 4B5 of the instrument (2 characters) (only if communication mode 4B5 is activated)
<b>&lt;CR&gt;</b>	Terminator character ASCII 13 (0D) (1 character)
<b>&lt;LF&gt;</b>	Terminator character ASCII 10 (0A) (1 character)

### Reading of simple weight

<b>Control</b>	<b>nnREAD&lt;CR&gt;&lt;LF&gt;</b>
<b>Response</b>	Short string (see page 41)

### Reading of complete weight

<b>Control</b>	<b>nnREXT&lt;CR&gt;&lt;LF&gt;</b>
<b>Response</b>	Extended string (see page 41)

### Execution of a semi-automatic tare

<b>Control</b>	<b>nnTARE&lt;CR&gt;&lt;LF&gt;</b>
<b>Response</b>	<b>OK&lt;CR&gt;&lt;LF&gt;</b> indicates that the control was received correctly

### Setting of the tare value (PT)

<b>Control</b>	<b>nnTMANTttttttt&lt;CR&gt;&lt;LF&gt;</b> Where <b>t...t</b> is the tare, with decimal points, max 8 characters.
<b>Response</b>	<b>OK&lt;CR&gt;&lt;LF&gt;</b> indicates that the control was received correctly
<b>Examples</b>	<b>TMAN1,56&lt;CR&gt;&lt;LF&gt;</b> set a tare of 1.56 <b>TMAN100&lt;CR&gt;&lt;LF&gt;</b> set a tare of 100

### Deleting the tare in memory

<b>Control</b>	<b>nnCLEAR&lt;CR&gt;&lt;LF&gt;</b>
<b>Response</b>	<b>OK&lt;CR&gt;&lt;LF&gt;</b> indicates that the control was received correctly

### Scale reset (function of the ZERO key)

<b>Control</b>	<b>nnZERO&lt;CR&gt;&lt;LF&gt;</b>
<b>Response</b>	<b>OK&lt;CR&gt;&lt;LF&gt;</b> indicates that the control was received correctly

## SPECIFIC CONTROLS FOR ALIBI MEMORY (OPTIONAL)

### Storage requests

<b>Control</b>	<b>nnPID&lt;CR&gt;&lt;LF&gt;</b> request to store the weight
<b>Response</b>	recording successful <b>nnPIDss,c,wwwwwwwwwwuu,ppttttttttuu,xxxxx-yyyyyy&lt;CR&gt;&lt;LF&gt;</b>  no recording <b>nnPIDss,c,wwwwwwwwwwuu,ppttttttttuu,NO&lt;CR&gt;&lt;LF&gt;</b>
where:	
<b>ss</b>	status of weight (2 characters) <b>TL</b> Error of condition of $\epsilon_{IL\epsilon}$ (NO RECORDING) <b>OL</b> Condition of $\sigma_{JErL\sigma R d}$ (NO RECORDING) <b>UL</b> Condition of $\sigma_{ndErL\sigma R d}$ (NO RECORDING) <b>ST</b> Weight stable <b>US</b> Weight unstable (NO RECORDING)
<b>c</b>	Scale number (1 character)
<b>w...w</b>	Gross weight (10 characters)
<b>uu</b>	Unit of measurement (2 characters)
<b>pp</b>	Type of tare: double space " " if semi-automatic, "PT" if pre-set (2 characters)
<b>t...t</b>	Tare value (10 characters)
<b>xxxxx</b>	Number of rewriting (5 characters)
<b>yyyyyy</b>	Progressive weighted (6 characters)
<b>Examples</b>	PIDST,1, 1500,0kg,PT 2,8kg,00000-000158<CR><LF> PIDUS,1, 1500,0kg,PT 2,8kg,NO<CR><LF>


### Reading of a weighing in memory

<b>Control</b>	<b>nnALRDxxxxx-yyyyyy&lt;CR&gt;&lt;LF&gt;</b> Where <b>xxxxx</b> is the rewriting number, <b>yyyyyy</b> is the progressive weighted.
<b>Response</b>	<b>s, w w w w w w w w u u , p p t t t t t t t t u u&lt;CR&gt;&lt;LF&gt;</b>  where: <b>s</b> Number of scales (always 1) <b>w...w</b> Gross weight (10 characters) <b>uu</b> Unit of measurement ("g", "kg", "t", "lb") <b>pp</b> Type of tare: double space " " if semi-automatic, "PT" if pre-set (2 characters) <b>t...t</b> Tare value (10 characters)
<b>Examples</b>	ALRD00000-000158<CR><LF> 1, 1500,0kg, 2,8kg<CR><LF>





## 8. WIRING SCHEMES

DFWL<sub>xxx</sub>, WLB, TPWN<sub>xxx</sub>, TPWL<sub>xxx</sub>, MCWN<sub>xxx</sub>.



DFWLID<sub>xxx</sub>





## 9. PROGRAMMING ERRORS

MESSAGE	DESCRIPTION	SOLUTION
<i>AL.Err</i>	Board "alibi memory" (optional) not detected.	Check the presence of the board inside the indicator. If present, check it is not damaged and is installed correctly.
<i>Er.1b.H</i>	Board "inputs/outputs" (optional) not detected.	Check the presence of the board inside the indicator. If absent, deactivate any inputs or outputs (parameter " <i>inPut5</i> " or " <i>outPut</i> ", see page 31-32). If present, check it is not damaged and is installed correctly.
<i>Er.r.b.H</i>		
<i>E9.Err</i>	Impossible to perform equalisation.	Check the cells are connected properly. Check the signal of each cell in the diagnostic menu (menu <i>d.AG</i> , parameter <i>AdC.uU</i> , see page 33).
<i>Pr.EC.</i>	Calibration error.	First calibrate the zero point, then proceed with the next points.
<i>Err.Pnt</i>	Calibration error.	Check the connection of the load cell. Check that the cell signal is stable, valid and greater than that of the previously acquired point.
<i>Er 11</i>	Calibration error.	Increase the calibration weight.
<i>Er 12</i>	Calibration error.	Check that the signal coming from the cell increases upon the increasing of the weight loaded on the scale. When acquiring the calibration points, use the increasing calibration weights.
<i>Er 37</i>	Calibration error.	Repeat the calibration, checking that the capacity and division have been correctly set.
<i>Er 39</i>	Instrument not configured.	Reset the factory configurations (menu <i>AdUAnC</i> , parameter <i>dFLtL</i> , see page 40).
<i>Er 85</i>	Instrument configured but not calibrated.	Perform calibration.
<i>CEr.36</i>	Calibration error.	Check that the signal coming from the load cell is not negative.
<i>Err.Not</i>	Weight unstable.	Check in menu <i>d.AG</i> , parameter <i>AdC.uU</i> (see page 33) that the signal is stable and re-try. If the connection of the cells is with 4 wires, check that the sense jumpers are inserted.

# 10. FAQ - FREQUENTLY ASKED QUESTIONS

## Calibration

---

### Can I change the maximum capacity without recalibrating?

Yes, you must change the parameters [rANGE 123](#) (Q-1-4,5,6). (See page 35)

### Can I change the division without recalibrating?

Yes, you must change the parameter [dIU](#) (Q-1-2). (See page 35)

### Can I change the position of the decimal point without recalibrating?

Yes, you must change the parameter [DEC 11](#) (Q-1-1) and the value of the calibration points via the pitch [CAL 111](#) (Q-5-6). (See page 35 and 39)

### Can I calibrate the instrument in “multi-division” mode?

Yes, through advanced configuration from PC with Dinitools program.

## Communication

---

### Scale doesn't answer

- Check the good condition of the cable and that there are no failures (using a multimeter).
- Check that the PC communication port or of the device used is not compromised. If necessary, try with another device/PC
- Make sure to have connected the cable on the correct serial port.
- Check the configuration of the pitches [bAud](#) and [bIt](#). (See page 13)
- Temporarily activate the continuous communication and retry receiving the string. If the string has been received correctly, carefully check the syntax of the control sent, the communication time-outs and the presence of the terminator.

## Generic

---

### The scale does not switch on

- Check that the input voltage level to the mother board is correct.
- Try the forced power by inserting the “ON BOOT” jumper present on the mother board. If the indicator lights up, check the correct operation of the keyboard, using the diagnostic menu [d 111](#). (See page 33)
- Possible failure of the internal rechargeable battery (if present).

# 11. SUMMARY OF THE PARAMETERS

<b>CAL</b>	Calibration.....	10
<b>dIU</b>	Division .....	10
<b>DCAL</b>	Reset of Pre-Tare (zero calibration).....	11
<b>GRAU</b>	Area of gravity of the place of use.....	11
<b>SERIAL</b>	Configuration of the serial ports .....	12
<b>CONPC</b>	Communication with PC, PLC or repeater .....	12
<b>MODE</b>	Selection of the communication mode .....	12
<b>CONSEL</b>	Selecting the COM port for connection with PC/PLC.....	13
<b>BAUD</b>	Communication speed (baud rate).....	13
<b>BIT</b>	Configuration of the serial protocol .....	13
<b>CONPRN</b>	Communication with printer or repeater or PC.....	14
<b>MODE</b>	Selection of the communication mode.....	14
<b>BAUD</b>	Communication speed (baud rate).....	14
<b>BIT</b>	Configuration of the serial protocol .....	15
<b>CTS</b>	Printer control signal .....	15
<b>POWERP</b>	Printer power supply / radio-frequency module .....	15
<b>ADVANC</b>	Advanced configurations .....	16
<b>PROTOC</b>	Communication protocol.....	16
<b>RADIO</b>	Connection port of radio-frequency module (for use by the manufacturer).....	16
<b>TTLTIL</b>	TTL port / Inclinomater activation (for use by the manufacturer).....	16
<b>ENTER</b>	Closing character of each print line.....	16
<b>LAYOUT</b>	Print customisation .....	17
<b>LANG</b>	Setting of the print language ( <i>ITAL, ENGL, DEUT, FRAN, ESPA, CHINESE</i> ) .....	18
<b>CHAR</b>	Setting the character .....	18
<b>HEADER</b>	Print header.....	19
<b>DATA</b>	Selection of the weight data.....	21
<b>WEIGHT</b>	Progressive weighed .....	21
<b>RECEIPT</b>	Receipt / label progressive .....	21
<b>CLOCK</b>	Date and time.....	22
<b>BARC39</b>	Bar code 39.....	22
<b>BARCUP</b>	Barcode top margin (mm) .....	22
<b>BARCL</b>	Barcode left margin (mm).....	22
<b>BARCH</b>	Barcode height (mm).....	22
<b>BARCDB</b>	Selection of the weight data.....	23
<b>COPIES</b>	Multi-copy prints.....	23
<b>ENDTIL</b>	Paper outlet for end of label / receipt.....	23
<b>BLINE</b>	White pre-heating line of the print head (for thermal printer only).....	23
<b>LABEL</b>	Label configuration.....	24
<b>LSAVE</b>	Saving of labels in the printer memory.....	24
<b>TEST</b>	Saving of labels in the printer memory and test print of all formats .....	24
<b>FILTER</b>	Weighing filters.....	25
<b>SCREEN</b>	Adjusting the display.....	26
<b>BACKLIT</b>	Backlighting .....	26
<b>BRIGHT</b>	Brightness.....	26
<b>LOCK</b>	Display lock (for use by the manufacturer) .....	26
<b>COLOUR</b>	Backlighting colour (in versions with colour display) .....	26



bAtt	Power supply via battery.....	27
ECo.bAt	Energy saving for battery operation .....	27
AutoFF	Auto off .....	28
rENotE	Remote control .....	28
An.out	Analog output .....	29
inPuTs	Digital inputs .....	31
outPut	Digital outputs .....	32
rESEt	Factory configuration reset.....	33
d iAG	Diagnostics .....	33
AdC.uU	Converter .....	33
d iSPLA	Display.....	33
KEyb	Keyboard.....	33
AdUAnC	Advanced.....	34
CALPAR	Calibration parameters.....	34
dEC iN	Configuration of the decimal point.....	34
d iU	Reading division .....	34
u.N.	Unit of measure .....	34
rAnGE 1	Scale capacity (maximum capacity / first weighing range) .....	35
rAnGE 2	For multirange scales (second weighing range).....	35
rAnGE 3	For multirange scales (third weighing range).....	35
EquAL	Equalisation function.....	35
n.ChAn	Equalised analog channels .....	35
EquALP	Equalisation .....	36
CALAdU	Complete calibration.....	37
no iSE	Additional filter for weighing in the presence of vibrations and for weighing live animals .....	38
MEtroL	Metrological parameters .....	38
OPeErC	Reset percentage via key (⬇).....	38
d iUStb	Sensitivity of the weight stability control .....	38
0.t.r.h	Zero hold function (tracking).....	38
on.2Ero	Reset at power and reset percentage .....	39
CALAdU	Re-acquisition / change of the calibration points in memory .....	39
CAL.NAn	For use by the manufacturer.....	39
d.SALE	For use by the manufacturer.....	39
KEyb	Type of keyboard .....	39
t iLt	Inclinometer (for use by the manufacturer).....	39
rEACt	Reactivation of the totalisation or print function .....	40
LoCk.Fb	Permanent keyboard lock (excluding key (C) ).....	40
AL i.b i.r	Reset of fiscal memory (alibi memory, optional) .....	40
P in.tEE	Access PIN to programming menu.....	40
P in.uSE	Access PIN to user menus .....	40
dFLt.t	Total reset of the memory and of calibration .....	40

## NOTES

[illegible]



**HEAD OFFICE**

Via Della Fisica, 20  
41042 Spezzano di Fiorano, Modena - Italy  
Tel. +39.0536 843418 - Fax. +39.0536 843521  
info@diniargeo.com

**SERVICE ASSISTANCE**

Via Dell'Elettronica, 15  
41042 Spezzano di Fiorano, Modena - Italy  
Tel. +39.0536 921784 - Fax. +39.0536 926654  
service@diniargeo.com

Authorized service center stamp

