


Configuration of the Drive for Operation in I/O Profile

Description

For the I/O profile, here is a simple example, which can be extended with additional features. The command word is made of run forward (bit 0 of CMd), run reverse (bit 1 of CMd), and the function fault reset (bit 7 of CMd). The reference frequency value is given by Graphic Display Terminal.



The settings are the following:

[Ref Freq 1 Config] <i>F r 1</i>	[HMI] <i>H P 1</i>
[Control Mode] <i>C H C F</i>	[I/O profile] <i>1 0</i>
[Command switching] <i>C C 5</i>	[Cmd Channel 1] <i>C d 1</i>
[Cmd channel 1] <i>C d 1</i>	[Modbus] <i>P d b</i>

The bits of the command word can now be configured.

In the menu configure: **[INPUTS / OUTPUTS CFG]** *1 0* - menu configure:

[Reverse Assign] <i>r r 5</i>	[CD01] <i>C d 0 1</i>
--------------------------------------	------------------------------

In the **[FAULT MANAGEMENT]** *F L E* - menu, **[FAULT RESET]** *r 5 E* - ?submenu, configure:

[Fault Reset] <i>r 5 F</i>	[CD07] <i>C d 0 7</i>
-----------------------------------	------------------------------