

Replace the defective pressure sensor

Does this solve the problem?

1] Yes

2] No

3] I don't know


- **Explanation**
AT NACELLE

If the Yaw Brake pressure shows the negative values,

Check the loose connection in yaw brake pressure switch connection socket.

Replace Pressure switch If necessary

AVN Combi Hydraulic (POS 12).



Relevant spare parts	
Description	Item No.
PR TRANSDUCER SCP-200-34-06	60104065

Replace Defective varistor

Does this solve the problem?

1] Yes


2] No

3] I don't know

- Explanation**
 Check W518 cable continuity and check loss connection in F09 Varistor at AN1 Junction Box

Terminal no

F09 Varistor 4 &5 terminals



Relevant spare parts	
Description	Item No.
VARISTOR BOX X8 (Discontinue)	60015847
VARISTOR BOX X8 (New)	51706201
Mounted PCB VARISTOR BOX X8	60015268

Replace the Defective TOI

Does this solve the problem?


1] Yes

2] No

3] I don't know

- **Explanation**

Check the Loose connection in Nacelle TOI Input terminal U01 Terminal no 203.



Replace TOI If required

Relevant spare parts

Description	Item No.
TOI-II INTERF EXT POC	51701601