

This error will auto reset, when the grid is ok again. Nothing needs to be done

Does this solve the problem?

1] Yes

2] No

3] I don't know

- **Explanation**

The voltage on L2 “Phase to neutral” is greater than max limit. See alarm list (stop and reset functions) for the specific turbine type.

See VGA guide for alarm 060

Does this solve the problem?

1] Yes

2] No

3] I don't know

- **Explanation**

Grid spike can be provoked by the Low Frequency alarm ([60](#)).