

## Troubleshoot hydraulic station

### Does this solve the problem?

- 1] Yes
- 2] No
- 3] [I don't know](#)

- **Explanation**

For MkII and above turbines with separate Yaw and HSS brake hydraulics, a comprehensive troubleshooting guide exists within the service document- WKI: 1001388. The guide covers troubleshooting accumulators, valves, hoses and pressure transducers.

Check reservoir oil level (replenish if low).

Low oil level in reservoir:




Parker yaw hydraulic unit:



For earlier units with combined Yaw and HSS brake hydraulics, a comprehensive troubleshooting guide exists within the service document- WKI 1001076. The guide covers troubleshooting accumulators, valves, hoses and pressure transducers.

Combined Yaw and HSS hydraulic unit:



Pay close attention to the quality of oil in the return lines and reservoir sight glass. Poor quality of oil can cause damage to yaw hydraulic system components and should be flushed and replenished as soon as practical.

Use WKI 0034-5670 for instructions on flushing, cleaning and replenishing the yaw system.

Poor quality oil observed in return lines:




Poor quality oil observed in reservoir sight glass:





If the pump fails to reach stop pressure, remove the pump as broken key/keyway have been observed:



Relevant documentation	
Description	DMS No.
SI-Parker yaw brake hydraulics	<a href="#">1001388</a>
Service disc brake/yaw brake hydraulics	<a href="#">1001076</a>
Flushing the Yaw Brake Callipers	<a href="#">0034-5670</a>

Relevant spare parts	
Description	Item No.
GEAR PUMP P1 AAn 0050 FL 20-B0	<a href="#">60103470</a>

**Isolate and repair leak**  
**Does this solve the problem?**

- 1] Yes
- 2] No
- 3] I don't know

- **Explanation**  
Inspect the yaw deck and area around the Yaw stations for leaking connections and hoses.

Oil leaking onto Yaw Deck:




Leaking pressure hose:



Leaking return line:





If a leak is found, repair or replace the component.

**\*IMPORTANT\***- If the yaw brake disk is in any way contaminated, it must be thoroughly cleaned per the service manual. Use document [1001618](#) for additional instructions on cleaning the yaw area.

Relevant documentation	
Description	DMS No.
Cleaning the yaw system area	<a href="#">1001618</a>

### Replace caliper seals and adjust pads

Does this solve the problem?

- 1] Yes
- 2] No
- 3] I don't know

- **Explanation**

Observe return lines from calipers to tank. If oil can be observed in the return lines, there are leaking seals. Isolate and lock the yaw system. Remove the calipers and replace the seals using WKI 0032-1749

Caliper piston seals:





Caliper pistons:



**\*IMPORTANT\***- When the seals are replaced and the calipers are re-installed, the brake pads must be carefully adjusted. Use WKI 0032-1749 and WKI 1001480 to adjust the brake pad end stops.

Closely inspect the pistons for wear or damage. If wear or damage is observed, replace pistons along with the seals.

Seal kit:





Relevant documentation	
Description	DMS No.
Yaw brake Caliper Rebuild V82-1.65MW	<a href="#">0032-1749</a>
Replacement of yaw pistons and gaskets	<a href="#">1001480</a>

Relevant spare parts	
Description	Item No.
GASKET SET, FCHR90A-GF-B-828	<a href="#">60107597</a>
PISTON FCHR 90GF	<a href="#">60113057</a>

## Replace Tower TOI

### Does this solve the problem?

- 1] Yes
- 2] No
- 3] I don't know

- Explanation**  
 In some instances a power surge can cause a fault in the Tower TOI. If it is suspected that the TOI has failed, replace with new:



**Replace cable or connector**

**Does this solve the problem?**

- 1] Yes
- 2] No
- 3] I don't know

- **Explanation**

It have been observe on a MK3 that the alarm was caused by a bad connector on the "yaw brake pressure" sensor (B18)(Parker: pos. 022) plug and solved by changing the connector (cable W518):



Relevant spare parts	
Description	Item No.
CONN PLUG F SOLENOID VALVE	<a href="#">60006607</a>
CABLE -W518 NM30T. MODUL 2X1	<a href="#">60103196</a>