



This error will auto reset, when the grid is ok again. Nothing needs to be done

Does this solve the problem?

- 1] Yes
- 2] No
- 3] I don't know

- [Explanation](#)

The voltage on L1 "Phase to neutral" is greater than max limit. See alarm list (stop and reset functions) for the specific turbine type.

9 - Grid spike L1 - NM72,NM82,V82 Mk1-5



See VGA guide for alarm 060

Does this solve the problem?

- 1] Yes
- 2] No
- 3] I don't know

- [Explanation](#)

Grid spike can be provoked by the Low Frequency alarm ([60](#)).