

## G90 MICROPHONE BASICS

MIC Button	Default Action	Notes	
Spch / Lock	Nothing		
Tuner / Call	Press to enable or disable the tuner.	<ul style="list-style-type: none"> <li>Press and hold to initiate the tuning action</li> </ul>	
XFC	Nothing		
Tune Up / Tune Down	Tunes G90 up or down by the current tuning step size	<ul style="list-style-type: none"> <li>Holding the button down 1 second will initiate a fast tune action of about ten tuning steps per second.</li> <li>If the G90 Tune button is pressed to enable the 100 KHZ tuning rate, then pressing and holding one of these buttons will zip along</li> <li>These buttons may also be reprogrammed in the system menu to select from: Freq CH +/-, Band +/-, or Volume +/-</li> </ul>	
V/M	Toggle between VFO or memory action		
MW	Nothing		
F1	Press to select Attenuator, Preamp or nothing	<ul style="list-style-type: none"> <li>This button may also be reprogrammed in the system menu to select from: PRE/ATT, SPLT (Split operation), NB (noise blanker), COMP (speech compressor), or AGC</li> </ul>	
F2	Press to enable or disable the split mode operation	<ul style="list-style-type: none"> <li>This button may also be reprogrammed in the system menu to select from: PRE/ATT, SPLT (Split operation), NB (noise blanker), COMP (speech compressor), or AGC</li> </ul>	
MODE	Press to select operating mode		
FIL	Nothing		
GENE	Nothing		
Numeric Keypad	Press a key to directly tune to the indicated band (160 to 10 meters)	<ul style="list-style-type: none"> <li>Will either tune to the last frequency used on the selected band or the beginning frequency of the selected band</li> </ul>	
F-INP / ENT	Toggles the main numeric keypad to allow keying in a frequency.	<ul style="list-style-type: none"> <li>Press the button</li> <li>Enter MM.KKK format .. use the decimal</li> <li>Entering just the MM part will tune to that whole megahertz frequency</li> <li>Press again to complete the entry and tune to that frequency</li> <li>CE clears the entry to allow reentering</li> </ul>	