

4.1.11 MCAPI\_NODE\_CONNECT (ABB Extension)

NAME

mcapi\_node\_connect – Initialize and connect message topology.

SYNOPSIS

```
#include <mcapi_abb.h>

void mcapi_node_connect( MCAPI_IN
    mcapi_domain_t domain_id, MCAPI_IN
    mcapi_node_t node_id, MCAPI_OUT
    mcapi_config_t* config, MCAPI_IN
    mca_timeout_t timeout, MCAPI_OUT
    mcapi_status_t* mcapi_status
);
```

DESCRIPTION

mcapi\_node\_connect() makes the necessary runtime calls to initialize the endpoints and connect the channels for the MCAPI node specified by domain\_id and node\_id. The call to mcapi\_node\_connect must be preceded by a successful call first to mcapi\_node\_collect to obtain the configuration for this node. The mcapi\_node\_connect routine waits for the connections to be completed, and returns with an status error if the timeout is exceeded.

RETURN VALUE

On success, \*mcapi\_status is set to MCAPI\_SUCCESS. On error, \*mcapi\_status is set to the appropriate error code defined below.

ERRORS

MCAPI_TIMEOUT	The MCAPI remote endpoints we in the specified time limit.
MCAPI_ERR_NODE_INVALID	The parameter is not a valid node
MCAPI_ERR_NODE_CONFFAILED	The node endpoints or channels could not be configured