

#### 4.3.1.2 MRAPI\_MUTEX\_INIT\_ATTRIBUTES

##### NAME

mrapi\_mutex\_init\_attributes

##### SYNOPSIS

```
void mrapi_mutex_init_attributes(
    MRAPI_OUT mrapi_mutex_attributes_t* attributes,
    MRAPI_OUT mrapi_status_t* status
);
```

##### DESCRIPTION

This function initializes the values of an `mrapi_mutex_attributes_t` structure. For non-default behavior this function should be called prior to calling `mrapi_mutex_set_attribute()`. You would then use `mrapi_mutex_set_attribute()` to change any default values prior to calling `mrapi_mutex_create()`.

##### RETURN VALUE

On success `*status` is set to `MRAPI_SUCCESS`. On error, `*status` is set to the appropriate error defined below.

##### ERRORS

MRAPI_ERR_PARAMETER	Invalid attributes parameter.
MRAPI_ERR_NODE_NOTINIT	The calling node is not initialized.

##### NOTE

##### SEE ALSO