

4.2.1.2 MRAPI_NODE_SET_ATTRIBUTE

NAME

mrapi_node_set_attribute

SYNOPSIS

```
void mrapi_node_set_attribute(  
    MRAPI_OUT mrapi_node_attributes_t* attributes,  
    MRAPI_IN mrapi_uint_t attribute_num,  
    MRAPI_IN void* attribute,  
    MRAPI_IN size_t attribute_size,  
    MRAPI_OUT mrapi_status_t* status  
);
```

DESCRIPTION

This function is used to change default values of an `mrapi_node_attributes_t` data structure prior to calling `mrapi_initialize()`. Calls to this function have no effect on node attributes once the node has been created/initialized.

At this time there are no MRAPI pre-defined node attributes.

RETURN VALUE

On success `*status` is set to `MRAPI_SUCCESS`. On error, `*status` is set to the appropriate error defined below.

ERRORS

MRAPI_ERR_ATTR_READONLY	Attribute cannot be modified.
MRAPI_ERR_PARAMETER	Invalid attribute parameter.
MRAPI_ERR_ATTR_NUM	Unknown attribute number
MRAPI_ERR_ATTR_SIZE	Incorrect attribute size

NOTE

SEE ALSO