

4.8.7 MRAPI_ATOMIC_INC (ABB Extension)

NAME

mrapi_atomic_inc

SYNOPSIS

```
void mrapi_atomic_inc(  
    MRAPI_OUT void* sync, MRAPI_IN void* dest,  
    MRAPI_IN void* result, MRAPI_IN size_t size,  
    MRAPI_OUT mrapi_status_t* status  
);
```

DESCRIPTION

mrapi_atomic_inc() performs atomic integer increment. Atomic decrement is provided by mrapi_atomic_dec(). The operation is only valid for memory locations within shared memory, where the synchronization can be across real-time processes. The integer value at destination address is incremented by one and the new integer result returned if that argument is non-NULL. Different integer widths are supported based on the platform. The desired *size* is passed as input and returned status indicates if the operation succeeded.

RETURN VALUE

None.

ERRORS

MRAPI_ERR_NODE_NOTINIT	The calling node is not initialized
MRAPI_ERR_ATOM_OP_FAILED	The local atomic operation failed

NOTE

Supported integer types:

Windows – uint16_t, uint32_t, uint64_t
Unix - uint8_t, uint16_t, uint32_t, uint64_t

SEE ALSO