

#### 4.4.2.6 MRAPI\_RMEM\_ATTACH

##### NAME

mrapi\_rmem\_attach

##### SYNOPSIS

```
void mrapi_rmem_attach(
    MRAPI_IN mrapi_rmem_hndl_t rmem,
    MRAPI_OUT mrapi_status_t* status
);
```

##### DESCRIPTION

This function attaches the caller to the remote memory segment. Once this is done, the caller may use the `mrapi_rmem_read()` and `mrapi_rmem_write()` functions. The caller should call `mrapi_rmem_detach()` when finished using the remote memory.

##### RETURN VALUE

On success, `*status` is set to `MRAPI_SUCCESS`. On error, `*status` is set to the appropriate error defined below.

##### ERRORS

MRAPI_ERR_RMEM_INVALID	Argument is not a valid remote memory segment handle.
MRAPI_ERR_RMEM_ATTACHED	The calling node is already attached to the remote memory.
MRAPI_ERR_NODE_NOTINIT	The calling node is not initialized.

##### NOTE

##### SEE ALSO

Section 3.5.2