

4.1.13 MCAPI_NODE_RUNDOWN (ABB Extension)

NAME

`mcapi_node_rundown` – Mark node as running down

SYNOPSIS

```
#include <mcapi_abb.h>

void mcapi_node_rundown(
    MCAPI_OUT mcapi_status_t* mcapi_status
);
```

DESCRIPTION

`mcapi_node_rundown()` marks the calling MCAPI node as running down. This call can be used in conjunction with testing other nodes to see if they are in rundown as well. This mechanism can be used to ensure all the configured MCAPI nodes are finalized together.

RETURN VALUE

On success, `*mcapi_status` is set to `MCAPI_SUCCESS`. On error, `*mcapi_status` is set to the appropriate error code.

ERRORS