

FLEX CPU09CMI Utilities

2. BOOTON
3. CMILINK
4. CMISTEP
5. FDRIVES
6. IDEFMT
7. PLIST
8. RAMDSK
9. RAMDSK3
10. RBRDSK
11. RBRDSKM
12. RDSKTST
13. SET
14. VDISK
15. VIRTUAL
16. RWTST09
17. FORMAT5 FORMAT8

BOOTON - Version 7

Show {change} floppy disk cable type.

SYNTAX

BOOTON

DESCRIPTION

If FLEX did boot from floppy drive:
it show the disk drive cable type.

1 = Straight FLEX cable
5 = PC cable (twisted)

If the disk driver can use the cable type flag then it show:
"Try a cable change."

And works the same as the boot from IDE drive.

If FLEX did boot from IDE drive:
it show the cable type and will ask if you want change it.
And if de cable type is not 1 or 5
it will ask to set the correct type.

```
+++BOOTON
No BOOT cable found
Set cable code 1/5 ?1
+++

+++BOOTON
BOOT on Straight cable (code=1)
Change cable code y/n ?y
+++BOOTON
BOOT on PC cable (code=5)
Change cable code y/n ?
+++
```

NOTE:

When FLEX boot from IDE and there is no floppy in drive 0
or no image loaded on GoTek 0,
the device will not give a ready signal the cable will be type 5.
Use BOOTON to check and change the cable type.

Manual change the cable type:

```
+++MON
cmi-bug 1.5 - 60k

>M F7EE
- F7EE 05 01
- F7EF 00
>
WARM start FLEX
```

CMILINK - Version 1.0

Links FLEX to BOOT loader.

SYNTAX

CMILINK <file spec>

DESCRIPTION

Links FLEX on a IDE drive in the boot loader on sector 0.

Links FLEX on a Floppy drive in the boot loader on sector 1.

+++CMILINK 0.FLEXIDE.SYS

+++CMILINK 2.FLEXFLP.SYS

CMISTEP - Version 6.0

Change Floppy drive step rate.

SYNTAX

CMISTEP

DESCRIPTION

Depending on the FLEX disk driver:

cmi_io2
cmi_io4
cmi_io4x
cmi_io4A

It will set the disk step rate for all the floppy drives.

cmi_io4B
cmi_ide
cmi_ide2

It will set the disk step rate for each floppy drive separate.
And set double step for each floppy drive separate.

FDRIVES - Version 6.1

Show all drives in FLEX.

SYNTAX

```
FDRIVES [<options>]
```

DESCRIPTION

FDRIVES will report current settings and can swap partitions.

Command line format:

```
report current settings
fdrives<cr>
```

hard drive parameters

```
fdrives n t d p    n = logical drive
                   t = type W or F
                   d = physical strapped drive
                   p = partition on hard drive
```

floppy drive parameters

```
fdrives n t d      n = logical drive
                   t = type W or F
                   d = physical strapped drive
```

When VIRTUAL is loaded, FDRIVES has a message telling you what to do.

SEE ALSO

IDEFMT, PLIST

IDEFMT - Version 6.1

FLEX IDE Disk formatter.

SYNTAX

IDEFMT,<drive>

DESCRIPTION

Format IDE logical drive.
Maximum track number = 255

When formatting logical drive 0 it will ask for writing the BOOT loader.
Formatting other partitions can be done
by swapping the partitions with FDRIVES.

Note:

IDE FMT does not format a floppy or virtual disk.

SEE ALSO

FDRIVES, PLIST

PLIST - Version 6.0

Show IDE drives information.

SYNTAX

PLIST

DESCRIPTION

It will show all the following data on the IDE device:

PART number	VOL Name	VOL Number	Description
-------------	----------	------------	-------------

Then the program allows updating of this information.

"SPACE Bar - Exit, <CR> - Change Description, (M)ount, (K)ill, (U)ndo ? "

Note: A <CR> will leave the entry unchanged

Enter a single space to blank VOLNAM or Description

The program will check if the IDE driver is loaded.

RAMDSK

CPU09RAM memory page test.

SYNTAX

RAMDSK

DESCRIPTION

RAMDSK - Will show the switch setting.
Then the program will check if all pages are unique.
It will write and read each page full with a unique code.

```
+++RAMDSK
Switch setting: CB
Write chip: 01234567
Read  chip: 01234567
+++
```

Any RAMDSK Error looks like:

```
Read  chip: 012
Error at:
WRITE READ PAGE Chip
0803 0800 0003 U6
Read  chip: 34567
```

NOTE: It use FLEX calls and return to FLEX.

SEE ALSO

RAMDSK3, RDSKTST

RAMDSK3

CPU09RAM memory test.

SYNTAX

RAMDSK3

DESCRIPTION

RAMDSK - Will show the switch setting.
The first run will check if all pages are unique.
The second one will write all 0000 to the ram,
you can change the 0000 at \$0142.
The third one will write all FFFF to the ram,
you can change the FFFF at \$0157.

```
+++RAMDSK3
Switch setting: CB
  > Page select test <
Write chip: 01234567
Read  chip: 01234567
  > Write/read $0000 <
Write chip: 01234567
Read  chip: 01234567
  > Write/read $FFFF <
Write chip: 01234567
Read  chip: 01234567
+++
```

Any RAMDSK3 Error looks like:

```
Read  chip: 012
Error at:
WRITE READ PAGE Chip
0803 0800 0003 U6
Read  chip: 34567
```

NOTE: It use FLEX calls and return to FLEX.

SEE ALSO

RAMDSK, RDSKTST

RBRDSK - Version 1.0

CPU09RAM disk memory test.

SYNTAX

RBRDSK

DESCRIPTION

This is a rotating bit memory test.
Each good test will print '+' on the screen.

Any RBRDSK Error looks like: Error at: 48CB ECAA

48CB is the address stored at \$ED00 and \$ED01.
ECAA is the address in the RAM space EC00-EDFF.

NOTE: It use FLEX calls and return to FLEX.

SEE ALSO

RBRDSKM

RBRDSKM - Version 1.0

CPU09RAM memory test.

SYNTAX

RBRDSKM

DESCRIPTION

This is a rotating bit memory test.
Each good test will print '+' on the screen.

Any RBRDSKM Error looks like: Error at: 48CB ECAA

48CB is the address stored at \$ED00 and \$ED01.
ECAA is the address in the RAM space EC00-EDFF.

NOTE: It use MONITOR calls and ends in the MONITOR.

SEE ALSO

RBRDSK

RDSKTST

CPU09RAM memory test.

SYNTAX

RDSKTST

DESCRIPTION

RDSKTST - Will show the switch setting.
The first run will check if all pages are unique.
The second one will write all 0000 to the ram,
you can change the 0000 at \$0142.
The third one will write all FFFF to the ram,
you can change the FFFF at \$0157.

```
+++RDSKTST
Switch setting: CB
> Page select test <
Write chip: 01234567
Read  chip: 01234567
> Write/read $0000 <
Write chip: 01234567
Read  chip: 01234567
> Write/read $FFFF <
Write chip: 01234567
Read  chip: 01234567
cmi-bug 1.5 - 60k

>
```

Any RDSKTST Error looks like:

```
Read  chip: 012
Error at:
WRITE READ PAGE Chip
0803 0800 0003 U6
Read  chip: 34567
```

NOTE: It use MONITOR calls and ends in the MONITOR.

SEE ALSO

RAMDSK, RAMDISK3

SET

Show - change floppy and virtual drives number and type.

SYNTAX

SET <options>

DESCRIPTION

Command is added by loading VIRTUAL driver.
Command for resetting drive type and local drive number
for each of the Floppy and Virtual drives.

SET 0=V0 1=D0 2=D1 3=D2 ?

NOTE = 'S', COMMAS, & SPACES ARE OPTIONAL AND IGNORED

WILL EQUATE FLEX DRIVE 0 TO VIRTUAL DRIVE 0

1 TO REGULAR DISK DRIVE 0

3 TO REGULAR DISK DRIVE 1

4 TO REGULAR DISK DRIVE 2

/ - WILL SUPPRESS PRINT OF CURRENT STATUS

< - WILL CLEAN UP THE VIRTUAL PROGRAM

EG RESTORE MEMORY FOR FLEX.

NOTE - SCAN STOPS AT FIRST ENCOUNTER OF <, /, <CR>

"S" AND "W" WILL ASSIGN SYSTEM AND WORK DRIVES

EG.

IF S APPEARS BEFORE DISK ASSIGNMENT WILL SET SYS TO ALL

IF S APPEARS AFTER DISK ASSIGNMENT WILL SET SYS TO THAT DRV

SAME FOR W - WORK ASSIGNMENT

+++SET S 0=V0

WILL EQUATE THE SYSTEM DRIVE TO "ALL" AND

EQUATE FLEX DRIVE 0 TO VIRTUAL DRIVE 0 AND PRINT

+++SET 0=V0 S 3=W

WILL EQUATE THE VIRTUAL DRIVE TO FLEX DRV0 AND

EQUATE THE WORK DRIVE TO PREVIOUSLY DEFINED FLEX #3 WITH NO PRINT

+++SET

WILL RESET THE PROCESSOR DP REGISTER TO 0 AND PRINT

NOTE:

WHEN USING THE IDE DISK DRIVER, SET WILL SHOW A H0, H1 DRIVE
DON'T USE SET TO CHANGE THE Hx DRIVES.

THE VIRTUAL DISK WILL BE PUT ON THE HIGHEST LOGICAL NUMBER.

DON'T USE FDRIVES TO CHANGE THE Dx AND OR V0 DRIVES AFTER
THE VIRTUAL DRIVER IS LOADED.

SEE ALSO

VIRTUAL

VDISK - Version 9.7

FLEX RAM disk formatter.

SYNTAX

VDISK

DESCRIPTION

When the virtual disk driver is loaded it can format the virtual disk(s).

If there is only one virtual drive it will format V0.

If there are 2 virtual drives it will ask the number to format:

0 = format V0

1 = format V1

A = format both

If the Format protection switch SW2-4 on the RAM card is on

VDISK will tell that, to overrule the protection type: Yes

If the Battery low switch SW1-1 is on or the 'UPS RAM' gives a low signal

VDISK will start automatically after loading the VIRTUAL driver.

NOTE:

The size of the Disk(s) will be set by VIRTUAL depending on the RAM card DIP switch settings.

SEE ALSO

VIRTUAL

VIRTUAL - Version 9.7

FLEX Virtual Disk driver.

SYNTAX

VIRTUAL [,<drive>=W][,<drive>=S]

DESCRIPTION

VIRTUAL will scan the RAM card DIP switch settings and set the data for VDISK.

+++VIRTUAL 3=W
Sets the virtual drive on FLEX drive 3 as work drive .

After first time loading VIRTUAL de drive(s) needs to be formatted, when removing virtual with 'SET <' or a WARM FLEX boot only VIRTUAL has to be loaded again.

Any COLD FLEX boot with the SYSTEM power on
or any COLD FLEX boot after a SYSTEM power off
but with a RAM card 'UPS RAM' needs only a VIRTUAL reload.

If the Battery low switch SW1-1 is on or the 'UPS RAM' gives a low signal VDISK will start automatically after loading the VIRTUAL driver.

NOTE: On all non IDE disk drivers if SW2-2 = ON Virtual set:

Boot, 0=D0 1=D1 2=V0 3=V1

VIRTUAL will overrule the RAM DIP switch SW2-2 status if the IDE disk driver is loaded:

Boot from IDE, 0=H0 1=H1 2=D2 3=V0
Boot from FLP, 0=D0 1=V0 2=H0 3=H1

SEE ALSO

SET, VDISK

RWTST09

Floppy disk, GoTek image and VIRTUAL disk Read/Write test.

SYNTAX

RWTST09

DESCRIPTION

Load the rwtst09.s1 file start \$0100 or run it from FLEX.

Program prompts user for function (F?)
To witch the user can respond 'R' (READ)
or 'W' (WRITE).
Then it prompts for single digit drive number (D?),
Two digit HEX track number (T?)
And two digit HEX sector number (S?).

After performing the function,
test repeats the prompting for another function,
or a 'F' (Return to FLEX),
or a 'M' (Exit to monitor).

To read the boot loader from a GoTek images:

```
+++RWTST09
F?R
D?2
T?00
S?01
```

```
86 F1 20 09 61 00 00 00 0A 0A 0C 00 00 1F 8B 32
8D 03 2D A6 8C EE 85 20 26 06 A6 8C EC A7 8C E8
86 02 97 02 30 8D 00 D8 17 00 6A 26 48 EC 8C D5
10 27 00 DC 33 8D 02 C8 EF 8C D0 17 00 A3 81 02
27 12 81 16 26 F5 17 00 98 A7 E3 17 00 93 A7 61
4F 1F 8B 39 17 00 8A A7 E3 17 00 85 A7 61 35 20
17 00 7E 27 D6 1F 89 34 04 17 00 75 A7 A0 35 04
5A 26 F4 20 C6 30 8C 08 AD 9F F8 12 6E 9F F8 00
2D 20 43 61 6E 27 74 20 72 65 61 64 20 73 65 63
2E 32 0A 0A 04 86 8C 97 00 30 8D 01 63 20 04 96
03 A7 80 96 08 2B F8 27 FA D6 00 C5 9C 39 D7 02
E1 8D FF 54 34 01 E6 8D FF 4A 35 01 23 02 CA 10
D7 04 91 01 27 0A 97 03 86 1B 97 00 D6 08 27 FC
D6 00 C5 98 39 33 8D 01 27 EC C4 ED 8D FF 26 33
44 11 A3 8D FF 25 27 03 A6 C0 39 EC 8D FF 16 27
19 8D BB 17 FF 9F 27 DD 86 0B 97 00 8D CE 6A 8D
```

```
F?F
+++
```

NOTE:

This will not work on the IDE driver's SD card, use DPACH.
FLEX must be loaded.

FORMAT5 - Version 5.2

FORMAT8 - Version 8.2

FLEX Floppy Disk formatter.

SYNTAX

FORMAT5,<drive>
FORMAT8,<drive>

DESCRIPTION

FORMAT5 will format a floppy disk or GoTek image and write a BOOT loader.
There are the following options:

35, 40, 80 tracks
Single/Double Sided
Single/Double Density

FORMAT8 will format a floppy disk or GoTek image and write a BOOT loader.
There are the following options:

77 tracks
Single/Double Sided
Single/Double Density

The formatter will give the message "Not a Floppy disk"
on an IDE or VIRTUAL disk number.

- If FLEX is booted on a version without the IDE drivers then all logical
drive numbers can be formatted. Also if VIRTUAL is loaded and with SET
the drives are swapped then there is no problem,
the formatter then uses both the logical and physical drive number.

- If FLEX is booted on the IDE driver then the formatter uses
both the logical and physical drive number.
Even if the drives are swapped with FRDRIVES.

- If FLEX is booted on the IDE driver and VIRTUAL is loaded
the formatter works with logical and physical drive number.
Unless SET and/or FRDRIVES is used to swap drives.
Then unload VIRTUAL with "SET <' then run FRDRIVES and reload VIRTUAL.

Note:

FORMAT5 and FORMAT8 have been rewritten to work on the 16MHz CPU09CMI
card and with the IDE/VIRTUAL driver and with PC/Straight cable.
**But the PC cable is not an option because then only logical drive
numbers 0 and 1 can be used.**

SEE ALSO

FRDRIVES, SET