



### INTERNAL SYSTEM TO ADJUST

Place J1 to 2-1  
Connect system or 5V adapter (Power)  
Wait 30 seconds  
Reset, until LED go OFF

1 Adjust P1 to 3.0V on J1-2  
Adjust P2, LED must go ON  
Adjust P1 to 3.3V press Reset, LED go OFF  
Adjust P1 LED must go ON at 3.0V  
Redo 1, redo 1

Remove J1  
Adjust P1 to 4.1 Volt max. on J1-2

Put J1 to 2-3  
Connect JP1 to JP2  
Connect JP3 to RAM  
Reset

### < OR > EXTERNAL VOLTAGE TO ADJUST

Place jumper J1 to 2-3  
Place jumper J2 to 2-3

Connect J3 to 5V supply  
Adjust P1 for 4.10V on J2 pin 2

Remove 5V supply from J3  
Connect 5V supply to JP2 pin 2  
Reset (LED must be off)

1 Adjust voltage 3.5V  
Reset (LED must be off)  
Lower voltage to 3.00V  
Adjust P2 so LED go on at 3.00V  
Redo 1

Connect JP1 to JP2  
Connect JP3 to RAM  
Reset

Title <b>CPU09RAM - UPS</b>		
Size B	Number	Revision
Date: 10-Sep-2024	Sheet of	Revision
File: C:\ISO\Li Backup RAM\Li Backup.ddb	Drawn By:	