



Note:

- DYN4 servo drive enable logic default is active high/enabled when high
- DYN4 servo drive alarm is active low, output is low when servo drive fault/alarm
- Set DYN4 servo drive to PULSE/DIR command input mode, position servo mode



7i77 Reference: <http://www.mesanet.com/pdf/parallel/7i76man.pdf>

Document#
dyn4_7i76_V1.0
Version 1.0

| Responsible dep. | Technical reference | Created | Approved | | |
|--|---------------------|----------------------------|-----------------|-------|-------|
|  | | Document type | Document status | | Rev. |
| | | Title, supplementary title | Scale | | |
| | | | Date of issue | Lang. | Sheet |
| | | | 2017/4/4 | | 1/1 |