




How to Install Software And Driver

When we get control board, we need to download Arduino IDE and driver firstly.

You could download Arduino IDE from the official website:

<https://www.arduino.cc/>, click the **SOFTWARE** on the browse bar, click

“DOWNLOADS” to enter download page, as shown below:



There are various versions for Arduino, just download a suitable version for your system, we will take WINDOWS system as an example to show you how to download and install.



Download the Arduino IDE

ARDUINO 1.8.12
The open-source Arduino Software (IDE) makes it easy to write code and upload it to the board. It runs on Windows, Mac OS X, and Linux. The environment is written in Java and based on Processing and other open-source software.
This software can be used with any Arduino board. Refer to the [Getting Started](#) page for installation instructions.

Windows Installer, for Windows XP and up
Windows ZIP file for non admin install

Windows app Requires Win 8.1 or 10
[Get](#)

Mac OS X 10.8 Mountain Lion or newer

Linux 32 bits
Linux 64 bits
Linux ARM 32 bits
Linux ARM 64 bits

[Release Notes](#)
[Source Code](#)
[Checksums \(sha512\)](#)

There are two versions for WINDOWS system, one is installed version, another one is download version, you just need to download file to computer directly and unzip it. These two versions can be used normally. Choose one and download on your computer.

Consider supporting the Arduino Software by contributing to its development. (US tax payers, please note this contribution is not tax deductible). [Learn more on how your contribution will be used.](#)

SINCE MARCH 2015, THE ARDUINO IDE HAS BEEN DOWNLOADED **40,995,500** TIMES. (IMPRESSIVE!) NO LONGER JUST FOR ARDUINO AND GENUINO BOARDS, HUNDREDS OF COMPANIES AROUND THE WORLD ARE USING THE IDE TO PROGRAM THEIR DEVICES, INCLUDING COMPATIBLES, CLONES, AND EVEN COUNTERFEITS. HELP ACCELERATE ITS DEVELOPMENT WITH A SMALL CONTRIBUTION! REMEMBER: OPEN SOURCE IS LOVE!

\$3 **\$5** **\$10** **\$25** **\$50** **OTHER**

[JUST DOWNLOAD](#) [CONTRIBUTE & DOWNLOAD](#)


You just need to click JUST DOWNLOAD, then click the downloaded file to install it. And when the ZIP file is downloaded, you can directly unzip and start it.



Installing driver

Let's install the driver of keyestudio PLUS control board. The USB-TTL chip on PLUS board adopts CP2102 serial chip. The driver program of this chip is included in Arduino 1.8 version and above, which is convenient. Plug on USB port of board, the computer can recognize the hardware and automatically install the driver of CP2102.


If install unsuccessfully, or you intend to install manually, open the device manager of computer. Right click Computer----- Properties----- Device Manager




There is a yellow exclamation mark on the page, which implies installing the




driver of CP2102 unsuccessfully. Then we double click the hardware and update the driver.




Click "OK" to enter the following page, click "browse my computer for updated driver software", find out the installed or downloaded ARDUINO software. As shown below:



There is a **DRIVERS** folder in **Arduino software installed package**

( arduino-1.8.12) , open driver folder and you can see the driver of **CP210X** series chips.

We click "Browse", then find out the **driver** folder, or you could enter "driver" to search in rectangular box, then click "next", the driver will be installed successfully. (I place Arduino software folder on the desktop, you could follow my way)



Open device manager, we will find the yellow exclamation mark disappear. The driver of CP2102 is installed successfully.

