



How to Update the Firmware

Hardware is the physical part of a micro:bit.

Software is made up of the programs you write and run on your micro:bit.

Firmware is in the middle: a special kind of software that makes devices function properly. It's physically stored in the micro:bit's interface chip and doesn't change when you write programs or turn your micro:bit off, but it can be updated.

The micro:bit will work with the firmware it came with, but there may be times when you may want to update the firmware to use new features like [WebUSB](#).

Checking your firmware version

To find out what version of the firmware you have on your micro:bit, **Plug it in via USB**, open up the **DETAILS.TXT** file from the **MICROBIT** drive and look for the number on the line that begins 'Interface Version'. In this example, the firmware version is 0254:

```
# DAPLink Firmware - see https://mbed.com/daplink
Unique ID: 9904360249624e45004a601400000027000000009796990b
HIC ID: 9796990b
Auto Reset: 1
Automation allowed: 0
Overflow detection: 0
Incompatible image detection: 1
Page erasing: 0
```



Daplink Mode: Interface
Interface Version: 0254
Bootloader Version: 0254
Git SHA: ec3fec91e815b1fe27cefb8bc4ffa85ca3317502
Local Mods: 0
USB Interfaces: MSD, CDC, HID, WebUSB
Bootloader CRC: 0xdb256cca
Interface CRC: 0xd0f0bacf
Remount count: 0
URL: <https://microbit.org/device/?id=9904&v=0254>



How to update the firmware

The latest firmware(0255) is shown below:

<https://www.microbit.org/get-started/user-guide/firmware/>

Disconnect the USB cable and battery pack from the micro:bit.



Hold the reset button at the back of the micro:bit and plug the USB lead into the device. You should see a drive appear in your file manager called **MAINTENANCE** (instead of MICROBIT).





The **MAINTENANCE** drive will look like this, depending on your computer:

Windows



- Download the hex file from this page to your computer.
- Drag and drop the new firmware .HEX file you downloaded from this page onto the **MAINTENANCE** drive and wait for the yellow LED on the back of the device to stop flashing. When the upgrade is completed, the micro:bit will reset, ejecting itself from the computer and re-appear in normal **MICROBIT** drive mode.
- Finally, check the **DETAILS.TXT** file that is on the **MICROBIT** drive and make sure that it has the same version number as the .HEX firmware that you just downloaded and flashed to the interface chip.