

---

# User Manual

For S32K1XX MCAL Sample Application

Document Number: UMSAASR4.3R1.0.0  
Rev. 1.2



# Contents

| Section number                                 | Title  | Page |
|--|--|------|
| <b>Chapter 1</b>                               |  |      |
| <b>Revision History</b>                        |  |      |
| <b>Chapter 2</b>                               |  |      |
| <b>About this Manual</b>                       |  |      |
| 2.1  | Acronyms and Definitions.....                          | 7    |
| 2.2  | Reference List.....                                    | 7    |
| <b>Chapter 3</b>                               |  |      |
| <b>Installation Steps</b>                      |  |      |
| 3.1  | Hardware Installation.....                             | 9    |
| 3.2  | Software Installation.....                             | 10   |
| 3.2.1  | Tresos Project Installation.....                       | 11   |
| 3.2.2  | MCAL Application Configuration.....                    | 13   |
| <b>Chapter 4</b>                               |  |      |
| <b>Sample Application Example Description</b>  |  |      |
| 4.1  | The application software functionality.....            | 15   |
| 4.2  | Description of the LEDs and Buttons functionality..... | 16   |
| <b>Chapter 5</b>                               |  |      |
| <b>Building the Sample Application Example</b> |  |      |
| 5.1  | Building the Sample Application example.....           | 19   |
| 5.2  | Building with different compilers.....                 | 19   |
| 5.3  | Building for different run-modes.....                  | 20   |
| 5.4  | Clean Object and Linker Output Files.....              | 20   |
| 5.5  | Modifying the Configuration in Tresos Studio.....      | 21   |



# Chapter 1

## Revision History

**Table 1-0. Revision History**

| Revision | Date       | Author        | Description   |
|----------|------------|---------------|---------------|
| 1.0      | 9.11.2018  | Stefan Tataru | 1.0.0 Release |
| 1.1      | 15.12.2018 | Stefan Tataru | 1.0.1 Release |

# Chapter 2

## About this Manual

This User Manual describes utilization of the sample application for S32K2XX microcontroller with Autosar MCAL 4.3 version EAR 0.8.1

### 2.1 Acronyms and Definitions

Table 2-1. Acronyms and Definitions

| Abbreviation / Acronym | Description                       |
|------------------------|-----------------------------------|
| DIO                    | Digital Input Output Driver       |
| PORT                   | Port Driver                       |
| BSW                    | Basic Software                    |
| ADC                    | Analog Digital Converter          |
| FEE                    | Flash EEPROM Emulation            |
| DEM                    | Diagnostic Event Manager          |
| DET                    | Development Error Tracer          |
| ECU                    | Electronic Control Unit           |
| ISR                    | Interrupt Service Routine         |
| OS                     | Operating System                  |
| GUI                    | Graphical User Interface          |
| API                    | Application Programming Interface |
| EcuM                   | ECU state Manager                 |
| WDG                    | Watchdog Driver                   |
| PLL                    | Phase Lock Loop                   |
| LED                    | Light Emitting Diode              |
| PB Variant             | Post Build Variant                |
| LT Variant             | Link Time Variant                 |
| PC Variant             | Pre Compile Variant               |

#### Reference List

### 2.2 Reference List

Table 2-2. Reference List


| # | Items                    | Version               |
|---|--------------------------|-----------------------|
| 1 | S32K2xx Reference Manual | S32K2xx_RM_Rev1DraftJ |

# Chapter 3

## Installation Steps

### 3.1 Hardware Installation

The hardware installation describes setup of the Evaluation Board.



**Figure 3-1. SCH-31431 Rev B Mother Board**

**SCH -32120 Rev A3 Daughter Card**



## 3.2 Software Installation

Please install the MCAL package on your computer. The Integration Framework Sample Application package is delivered as a MCAL-type plugin:

*IntegrationFramework\_TS\_T40D17M8I1R0*

The Application plugin has the following folder structure:

### Chapter 3 Installation Steps

| Folder or file            | Description  |
|---------------------------|--|
| -autosar                  | contains the IntegrationFramework.epd file   |
| -auxiliary                | contains files and folders required to build and start the framework application   |
| -build                    | Contains the cmm folder and the batch files required to start build system   |
| -bin subfolder            | generated object files and linker output files are stored into this folder   |
| -cmm subfolder            | contains Lauterbach T32 cmm script files   |
| -toolchains subfolder     | contains linker-scrips folder, make folder and startup folder  |
| -linkfiles subfolder      | contains linker-scrips files   |
| -make folder              | contains make-files needed to build the application for all available CPU cores and compilers  |
| -startup folder           | contains source files and headers needed to start the application (startup code and interrupt vector definitions for each CPU type and available compiler) |
| -config folder            | contains the configuration XDM template file for EB tresos.  |
| -generate_PC              | contains the configuration generation templates  |
| - src folder              | contains the source code files for all components of the framework application   |
| - include folder          | contains header files for all components of the framework application  |
| - makefile file           | the framework application makefile   |
| - make.bat file           | launches the make command  |
| - launch.bat file         | contains path to the Tresos Studio installation and launches the make.bat file   |
| - Tresos folder/workspace | contains the Tresos project with the application configuration   |

**Note:** Since the application framework is NOT production code it is not delivered in the same plugins folder as the rest of the MCAL drivers. In order to build and run the application the user must copy the application plugin folder

*“IntegrationFramework\_TS\_T40D17M8I1R0”* in the same folder where the rest of the MCAL plugins are located.




## 3.2.1 Tresos Project Installation


The following procedure requires that the user has EB Tresos Studio installed.

### **Procedure:**

1. Make sure that all MCAL plugins are already installed in the Tresos Studio pluginsdirectory
2. Open Tresos Studio
3. Import Sample application project
  - a. Click on "File" and select "Import"
  - b. Select "Existing Projects into Workspace" and click on "Next" button as shown in Figure 4-3. Import Window - the First View
  - c. Next steps are depicted in Figure 4-4. Import Window - the Second View
    - Select "Select root directory" and click on "Browse"
    - Select the location of the [project] folder in the installed Sample application packagefolder (Tresos/workspace/[project])
    - Select "Copy projects into workspace"
    - Click on "Finish" button



**Figure 3-3. Import Window - the First View**



**Figure 3-4. Import Window - the Second View**

### 3.2.2 MCAL Application Configuration

The following procedure requires that the user has EB Tresos Studio installed and the toolchains versions specified in the MCAL Release Notes.

The toolchain that will be used needs to be installed for correct operation and the path to the installation location shall be added into the system environment variable(s):

- GHS\_DIR

*Ex: SET GHS\_DIR= C:/tools/ghs/ARM\_MULTI\_7.1.4COMPILER\_2017.1.4*

- GCC\_DIR

*Ex: SET LINARO\_DIR= C:/tools/GCC/gcc-6.3-arm32-eabi*

- IAR\_DIR

*Ex: SET IAR\_DIR= C:/tools/IARSystem/EmbeddedWorkbench8.0/arm*

- TRESOS\_DIR for setting up the path to installed EB Tresos folder

*Ex: TRESOS\_DIR=C:/Tools/EB/v24.0.1*

- PLUGINS\_DIR for defining the path to all source file to be build

*Ex: SET PLUGINS\_DIR=C:/Tools/EB/v24.0.1/plugins*

- TRESOS\_WORKSPACE\_DIR for defining the path to all generated configuration files

*Ex: TRESOS\_WORKSPACE\_DIR=C:/Tools/EB/v25.0.0/workspace/*

*lighting\_S32K2XX\_4.3\_EAR 0.8.1 /output*

**Note** The path to the toolchain must not contain spaces. In case the compiler is installed into a path with spaces, the variable must be set with the "short" folder name (8.3 version of the file name that can be displayed with dir /X in command prompt)

## Procedure:

1. Open launch.bat file in a text editor and specify the EB Tresos Studio location in the TRESOS\_DIR parameter as shown in Figure 4-5. Configuration of the Tresos Studio Location.
2. Make sure that installation location of the compiler is added in the system environment variable (GHS, GCC, IAR)
3. Setup the plugins folder location if the plugins are not installed in the Tresos plugins folder (PLUGINS\_DIR)
4. Setup the workspace folder location plugins folder (TRESOS\_WORKSPACE\_DIR).

```
:: uncomment line below if you do not set TRESOS_DIR over environment
:: SET TRESOS_DIR=
:: SET GHS_DIR=
:: SET IAR_DIR=
:: SET LINARO_DIR=
:: SET PLUGINS_DIR=
```

## Chapter 4

### Sample Application Example Description

This application demonstrates an example of usage for the MCAL modules. It is not part of the production code deliverables

#### 4.1 The application software functionality

Initializes MCU module

- Initializes PLL and configures it to 80MHz.
- Checks whether PLL is locked
- Activates the PLL clock to the MCU clock distribution

Initializes PORT module. Pins configuration is show in section PORT and DIO Modules - Pin Configuration and DioChannel Assignment for keys and leds, and in PORT Configuration excluding Leds and Keys

Initialize ADC driver.

Initialize the GPT driver. Gpt channel 0 (PIT\_0\_CH\_RTI) is used to trigger the internal round-robin scheduler.

Initializes the PWM driver and Sample application specific data for this driver.

Initializes the OCU driver. In the configuration provided by the sample application framework the OCU driver is used to trigger ADC at user-configured moments of time.

Initializes Integration Framework components and starts internal round-robin scheduler. The internal scheduler

Once the scheduler is started the following tasks are executed cyclically:

- IO Driver Abstraction (IoDal) task is called every 10 ms.
- System Driver Abstraction (SysDal) task is called every 10 ms.
- Run Time Environment (Rte) task is called every 20 ms.
- Run Time Environment Initialization (Rte\_Init) is called just once.

### **a. Basic Software - IO Driver Abstraction task**

IODAL component main purpose is to handle and control all I/O capable drivers: ADC, DIO, OCU, ICU, PWM.

IODAL handles Digital I/O's and PWM channels by calling the underlaying drivers directly.

ADC Channels are handled by using SW trigger conversion which is executed at precise moments of time define by using a Time-trigger table in OCU. For each ADC group two time-events are required:

- Start conversion event: defined in configuration as a Time Trigger scheduling point
- Read results event: define in configuration as “conversion time”

**Note.** IoDal configuration is based around IO channel descriptors. For analog channels each descriptor is defined as a unique combination of an ADC group and an ADC channel; for digital/pwm channels each descriptor is define by a single dio/pwm channel.

### **b. Basic Software - System Driver Abstraction task**

SYSDAL component main purpose is to implement core system functionalities (i.e. the internal round-robin scheduler, user interrupt enablement) and to implement the power-up and power-down sequences (similarly to ECUM from AUTOSAR).

User Interrupts and Power Modes are also, defined and configured in SysDal.

The round-robin scheduler is based around a GPT timer and is used to execute application functionality at predefined moments of time. (i.e. every 10 ms call IoDal\_Main()... )

### **c. Basic Software - Communication Driver Abstraction task**

COMDAL component main purpose is to handle and control all external communication capable drivers: CAN, LIN, UART (etc.)

For each driver the handling of the communication is done either in polling mode (CAN) or interrupt driven (CAN, UART) depending on the driver capabilities.

In case of CAN, the COMDAL also implements the CanIf functions (CanIf\_TxConfirmation and CanIf\_RxIndication)

#### d. Lighting Application task

Application task is used to process command inputs signals and calculate outputs values for the all output channels of each lighting instance using the following logic.

- If Output signal is PWM and If Input command signal is ANALOG\_INPUT, the duty cycle value for all outputs for that application instance is proportional to the value read from the analog input (i.e. Analog value read from a Potentiometer)
- If Output signal is PWM and If Input command signal is DIGITAL\_INPUT, the duty cycle value for all outputs for that application instance is increased by 12.5% every-time the digital input is set from LOW to HIGH. When the duty-cycle value exceeds 100% the duty-cycle is reset to 0% and the cycle will start from that. Basically every-time a button is pressed the duty is increased by 12.5% until it reaches 100%.
- If Output signal is DIGITAL\_OUTPUT and If Input command signal is DIGITAL\_INPUT, the output signal shall be toggled between LOW and HIGH every time the digital input is set from LOW to HIGH. Basically every-time a button is pressed the output is toggled between LOW and HIGH.

#### e. Using the Virtual Data Router

The Virtual Data Router (VDR) is a SW components (SWC) that has the main purpose to handle data messages between different SWCs. In a sense, VDR's scope is to act as a network manager and route data from either from host ECU to a remote location (i.e. other ECU or Host PC) and vice-versa.

#### ❖ VDR Communication protocol – RX handling.

When used to exchange data over communication lines (UART, CAN etc), the VDR works by handling RX messages with a fixed format. Each RX Message is composed of 3 or more bytes of data, and each byte has a fixed meaning as described below.

| <i>Byte 0</i>     | <i>Byte 1</i>       | <i>Byte 2</i>              | <i>Byte 3</i>             | <i>Byte 4</i>            | <i>Byte 5</i> | <i>Byte 6</i> | <i>...</i> | <i>Byte n</i>   |
|-------------------|---------------------|----------------------------|---------------------------|--------------------------|---------------|---------------|------------|-----------------|
| <i>Message ID</i> | <i>Message Type</i> | <i>Message Response ID</i> | <i>Instance Id/Data 0</i> | <i>Channel Id/Data 1</i> | <i>Data 2</i> | <i>Data 3</i> |            | <i>Data n-3</i> |



**Table 3-1. RX Message format**

**Message ID** – Represent the unique ID given to each handled message for a given direction.

**Note:** It is possible for a RX and TX message to have ID with the same value.

**Message Type** – Represent the scope associated with that message. Basically, the Message type instructs how that message will be processed and what type of response will be given to that message (if a response is expected).

- REQUEST\_STATUS (*Byte\_1* = 1U): **VDR** has receive a request to send the status of a given application instance (indicated by *Byte\_3*). Data shall be packed and routed to TX\_Replay message with the id given in *Byte\_2*.
- REQUEST\_OUTPUT\_UPDATE (*Byte\_1* = 2U): **VDR** has receive a request to update output values of a given application instance (indicated by *Byte\_3*). This message does not require a Reply.
- REQUEST\_SYS\_GO\_SLEEP (*Byte\_1* = 4U): **VDR** has receive a request to change the run-mode of the host ECU or print the value of the current mode. The action required is indicated by *Byte\_3* had has the following parameters:
  - o ‘R’ – requests ECU to execute a SW Reset.
  - o ‘S’ – requests ECU to change run-mode to the value indicated by *Byte\_4*.
  - o ‘P’ – requests ECU to ‘print’ the current value of the run-mode. This value will be packed into the TX\_Replay message with the id given by: *Byte\_2*.
- REQUEST\_SYS\_CHANGE\_HW\_VARIANT (*Byte\_1* = 8U): **VDR** has receive a request to change the HW variant configured of the host ECU or print the current variant ID which is in use. The action required is indicated by *Byte\_3* had has the following parameters:
  - o ‘V’ – requests ECU to change HW variant to the value indicated by *Byte\_4*.
  - o ‘P’ – requests ECU to ‘print’ the current value of the running HW variant. This value will be packed into the TX\_Replay message with the id given by: *Byte\_2*.
- REQUEST\_FORWARD\_MSG (*Byte\_1* = 16U): **VDR** has receive a request to forward a given message to a different host ECU (or PC). The request will be packed into the TX\_Replay message with the id given by: *Byte\_2*.
- REQUEST\_PRINT\_RTM\_MEAS (*Byte\_1* = 32U): **VDR** has receive a request to ‘print’ the result from a RUN-TIME Measurement.

**Message ID** – Represent the unique ID of the TX\_Replay message associated with the current RX Message ID.

**Instance ID/Communication Type** – Represent the unique ID of the TX\_Replay message associated with the current RX Message ID. This byte is a Bit-wise-OR operation between Instance ID (bit5 .. bit 0) and Communication type (bit7 and bit 6).

When REQUEST\_OUTPUT\_UPDATE was received for a “Lighting” instance that uses COM as method of changing the output value, the VDR will update the internal output buffers of the given instance as following:

- For a single output channel (with the id given by *Byte\_4*) if *bit7* and *bit6* are ‘0’.
- For a set of channels (with the mask value given by *Byte\_4*) if *bit7* = ‘0’ and *bit6* = ‘1’
- For all channels of the given instance if *bit7* = ‘1’ and *bit6* = ‘0’.

**Channel ID Byte.** – Only used in certain cases. See above for details

❖ **VDR Communication protocol – TX data format.**

VDR will send data from the host ECU either as a reply to a received message or based on an internal event.

Events type message are setup by VDR and sent whenever the given event was raised by other applications (i.e. Lighting generated event to inform user that it detected a critical error like OPEN LOAD or SHORT TO GROUND on a certain output channel).

VDR will also sent cyclic data messages if such messages were configured (TX messages configured as APP\_EVENT\_FORWARD\_MSG)

| Byte 0     | Byte 1       | Byte 2 | Byte 3 | Byte 4 | Byte 5 | Byte 6 | ... | Byte n   |
|------------|--------------|--------|--------|--------|--------|--------|-----|----------|
| Message ID | Message Type | Data 0 | Data 1 | Data 2 | Data 3 | Data 4 |     | Data n-2 |

❖ **Table 3-2. TX Message format**

**Message Type** – Represent the scope associated with that message. In case of TX messages the Type has the following values:

- TX\_SEND\_MSG – if the given message is of type: APP\_EVENT\_FORWARD\_MSG
- RX\_FORWARD\_MSG – if the given message is a reply to a received RX\_FORWARD\_MSG
- TX\_ON\_REQUEST – if the given message is a reply to any other RX REQUEST messages.

- TX\_ON\_EVENT– if the given message is generated by an event. This message will send the status of the associated instance ID.

### Note:

TX\_ON\_EVENT and TX\_ON\_REQUEST (when is a reply to REQ\_STATUS message) will requires a considerable data payload. Basically, each message will require a minimum of: 5bytes + (17byte \* N\_channels) (where N\_channels = number of output channels configured on the given instance). The user must make sure that the associated physical channel for that message, is capable of handling messages with the required data length.

The 'STATUS' messages are constructed using ASCII encoding and have the following format:

|                                |  |
|--------------------------------|--|
| Byte 0                         | Message Id   |
| Byte 1                         | Tx Type (On_Event or On_Reqeust)   |
| Byte 2                         | Instance type: 'L' - lighting  |
| Byte 3                         | Instance Id (0, 1, 2 .. )  |
| Byte 4                         | ' ' (empty space for formatting)   |
| Byte 5 +<br>repeating_offest*  | 'C'  |
| Byte 6 +<br>repeating_offest*  | <i>Channel Id</i> (0, 1, 2... )  |
| Byte 7 +<br>repeating_offest*  | ' ' (empty space for formatting)   |
| Byte 8 +<br>repeating_offest*  | 'S'  |
| Byte 9 +<br>repeating_offest*  | <i>Status Info</i> read from Lighting App. for that channel (Idle = 0, Active = 1, Stopped = 2, S2G = 4, OL = 8) |
| Byte 10 +<br>repeating_offest* | ' ' (empty space for formatting)   |
| Byte 11 +<br>repeating_offest* | 'A'  |

|                                    |  |
|------------------------------------|--|
| Byte 12..13 +<br>repeating_offest* | Active Command: Expected output command given on that channel (Percentage value – i.e. 50%)      |
| Byte 14 +<br>repeating_offest*     | ' % '  |
| Byte 15 +<br>repeating_offest*     | ' ' (empty space for formatting)   |
| Byte 16 +<br>repeating_offest*     | ' F '  |
| Byte 17..18 +<br>repeating_offest* | Feedback Voltage value: Current analog voltage value if feedback was configured on that channel. |
| Byte 19 +<br>repeating_offest*     | ' m '  |
| Byte 20 +<br>repeating_offest*     | ' V '  |
| Byte 21 +<br>repeating_offest *    | ' ' (empty space for formatting)   |

\* **repeating\_offest** is calculated considering that the status is requested for all channels of a lighting instance with more than one channel. **repeating\_offest = channel\_id \* 17** (channel\_id = 1, 2, 3);

## 4.2 Description of the LEDs and Buttons functionality

The detailed description of the LEDs and Buttons functionality is depicted in the following table:

| PortPin Name      | Pin ID (PCR ID) | Pin Mode                   | Pin Direction | Pin Level | Connected HW | Channel Assignment |
|-------------------|-----------------|----------------------------|---------------|-----------|--------------|--------------------|
| PortPin_Pwm1      | 48              | EMIOS_0_eMIOS_0_CH_4_G_OUT | Out           | Low       | RGB_BLUE     | -                  |
| PortPin_Pwm2      | 49              | EMIOS_0_eMIOS_0_CH_5_G_OUT | Out           | Low       | RGB_RED      | -                  |
| PortPin_DigOut1   | 12              | GPIO                       | Out           | Low       | RGB_GREEN    | Dio_out1           |
| PortPin_DigKey1   | 43              | GPIO                       | In            | Low       | SW3          | Dio_DigKey1        |
| PortPin_PwmKey2   | 62              | GPIO                       | In            | Low       | SW2          | Dio_DigKey2        |
| PortPin_AnalogPot | 144             | ADC0_ADC0_P4               | In            | -         | POT          | -                  |

**Table 4-1. PORT and DIO Modules - Pin Configuration and DioChannel Assignment for S32K2XX**

| LEDs and Buttons | Functionality  |
|------------------|--|
| D76(led)         | Each time SW7 is pressed the duty cycle controlling this led increase with 12% until it reach 100% than starts again from 0% |
| D81(led)         | When SW7 is pressed the led turns on, when SW3 is pressed again led turn off   |
| D79 (led)        | It's duty cycle is control by the Analog Potentiometer (R409)  |
| SW3 (button)     | Input for controlling the duty cycle of led D76  |
| SW7 (button)     | Input for controlling led D81(On/Off)  |
| R409 (button)    | Input for controlling the duty cycle of led D79  |

**Table 4-2. LEDs and Buttons Functionality for S32K2XX**

## Chapter 5

# Building the Sample Application Example

This section describes the build procedure.

## 5.1 Building the Sample Application example

### Procedure:

1. Open the Windows command prompt window
2. Change the current directory to the sample application folder
3. To build the sample, execute the following command to run launch.bat: launch.bat
4. The object files and linker output file (sample\_app\_mcal.elf) shall be generated in the /bin subdirectory
5. To execute the sample application, load the executable file placed in the /bin subdirectory to the evaluation board using the Lauterbach debugger and run.cmm script.

### Note

The launch.bat file calls the make.bat file and then the GNU make utility is called from the Tresos Studio bin directory.

## 5.2 Building with different compilers

To build the sample application with a different compiler, use the following parameter for the launch command:

launch.bat TOOLCHAIN=[toolchain]

where [toolchain] can have the values:

- \* ghs - default - use the GreenHills Multi compiler
- \* linaro - use the Gcc compiler
- \* iar - use the Iar compiler

## 5.3 Building for different run-modes

To build the sample application for a different run-mode, use the following parameter for the launch command:

launch.bat MODE=[run\_mode] where

[run\_mode] can have the values: \* SUPR

- default - run in Supervisor mode

\* USER - un in User mode

### Note

In order to run in USER mode, all drivers that need to be executed in this mode should have the "Enable User Mode Support" parameter set to 'true' and their configuration files regenerated from Tresos.

### Note

In order to run in USER mode, AUTOSAR OS should not be used since it does not allow other run-modes except Supervisor

## 5.4 Building for different controller derivatives

To build the sample application for a either 3M or 6M derivative, use the following parameter for the launch command:

launch.bat DERIV=[derivative] where [derivative] can have the values:

\* 118 – build for S32K118 variant

\* 144 – build for S32K144 variant

### Note

In order to run for either of the variants the user should make sure that the correct resource was selected in Tresos and configurations were correctly generated for that derivative.

### Note

User Manual, Rev. 1.2

It is possible to build with different option by using a command line with more than one parameter.

For instance: running “*launch.bat* TOOLCHAIN=ghs MODE=SUPR CORE=m7 “ will build the code for GHS compiler, Supervisor Mode running on core m7

## 5.5 Clean Object and Linker Output Files

To clean the object and linker output files from the folder /bin, execute the following steps


### Procedure:

1. Open the Windows command prompt window
2. Change the current directory to sample application folder
3. Execute the following command *launch.bat clean*
4. The object files and linker output files shall be cleared from the /bin and from the sample application root folders.




# 5.6 Framework Configuration Parameters

1. **IntegrationAppGeneral** Container – holds driver enablement parameters.




**Note:** For this version of application only Adc, Dio, Mcu, Gpt, Port, Pwm and Ocu drivers are supported.

2. **IntegrationAppFeaturesConfig** Container – holds application enablement parameters.




**Note:** For this version of application only Lighting App is supported.

3. **AppConfig/LightingControlApp** Container – holds parameters for configuring each lighting instance.



- LightCtrlOutputSignalType: specifies what type of output current instance shall use (supported values: PWM, DIGITAL\_OUTPUT)
- LightCtrlInputSignalType: specifies what type of input current instance shall use (supported values: ANALOG, DIGITAL\_INPUT)
- **LightingChannels** Container – holds parameters for configuring each output channel for the current instance (and their corresponding feedback channels)



- **VDR Message configuration logic.**

Each VDR Message has a unique ID based on the given “direction” as following:

- To store data to current ECU, the VDR requires a RX\_MESSAGE to be configured.
- To send data from current ECU, the VDR requires either a TX\_MESSAGE or a TX\_REPLY to be configured.

Each direction type requires a certain “signal type” to be configured:

- All RX Messages require a signal of type: APP\_REQUEST\_[action], where [action] may be: STATUS, MSG\_FORWARD, OUTPUT\_UPDATE etc. If [action] is different from ‘OUTPUT\_UPDATE’ the given RX Message will also require a TX\_REPLY message to be configured.
- All TX Messages require a signal of type: APP\_EVENT\_[action], where [action] may be: NOTIFICATION, FORWARD\_MSG.

Each message requires to have a COMDAL channel configured (see ComDal)

The default data length for each message must be equal or less then the underlying ComDal channel data length. (i.e. if the message is expected to be routed on the CAN interface, than the data length for than message is given by the CAN Payload configuration attribute (‘MBDSR’)

Default Tx Data is only configurable if the message is of type: APP\_EVENT\_FORWARD\_MSG

Sample App VDR Features

|  |   |  |
|--|---|--|
| Message Id (0 -> 255)                  | <input type="text" value="1"/>  |  |
| Signal Direction                       | <input type="text" value="RX_MESSAGE"/>   |  |
| Signal Type                            | <input type="text" value="APP_REQUEST_STATUS"/>   |  |
| Default Tx Data                        | <input type="text"/>  |  |
| Default Data Length                    | <input type="text" value="8"/>  |  |
| Communication Port                     | <input type="text" value="ionFramework/IntegrationAppFeaturesConfig/IntegrationAppDataConfig_0/BswConfig_0/GeneralConfig_0/ComDAL_0"/>    |  |
| Reference to Used Application Instance | <input type="text"/>  |  |
| Replay message reference               | <input type="text" value="egrationFramework/IntegrationAppFeaturesConfig/IntegrationAppDataConfig_0/AppConfig_0/VirtualDataRouterApp_3"/> |  |

VirtualDataRouterApp | LightingControlApp | MotorControlApp

VirtualDataRouterApp

| Index | Name                   | Message Id | Signal Direct... | Signal Type               | Def... | Communication Port             | Replay message re...     |
|-------|------------------------|------------|------------------|---------------------------|--------|--------------------------------|--------------------------|
| 1     | VirtualDataRouterApp_1 | 0          | RX_MESSAGE       | APP_REQUEST_MSG_FORWARD   | 8      | /IntegrationFramework/Integ... | /IntegrationFramework... |
| 2     | VirtualDataRouterApp_3 | 0          | TX_REPLY         | APP_REQUEST_STATUS        | 50     | /IntegrationFramework/Integ... | /IntegrationFramework... |
| 0     | VirtualDataRouterApp_0 | 1          | RX_MESSAGE       | APP_REQUEST_STATUS        | 8      | /IntegrationFramework/Integ... | /IntegrationFramework... |
| 7     | VirtualDataRouterApp_5 | 1          | TX_MESSAGE       | APP_EVENT_NOTIFICATION    | 50     | /IntegrationFramework/Integ... | /IntegrationFramework... |
| 3     | VirtualDataRouterApp_6 | 2          | RX_MESSAGE       | APP_REQUEST_OUTPUT_UPDATE | 8      | /IntegrationFramework/Integ... | /IntegrationFramework... |
| 4     | VirtualDataRouterApp_7 | 2          | TX_REPLY         | APP_REQUEST_MSG_FORWARD   | 8      | /IntegrationFramework/Integ... | /IntegrationFramework... |
| 5     | VirtualDataRouterApp_2 | 3          | TX_MESSAGE       | APP_EVENT_FORWARD_MSG     | 8      | /IntegrationFramework/Integ... | /IntegrationFramework... |
| 6     | VirtualDataRouterApp_4 | 3          | RX_MESSAGE       | APP_REQUEST_MSG_FORWARD   | 16     | /IntegrationFramework/Integ... | /IntegrationFramework... |

#### 4. BswConfig/GeneralConfig/IoDAL Container holds IoDal channel descriptor configuration for each BSW IO signal.

General

Referenced Signal Direction

Referenced Signal Type

UseExternalDevice

DigitalSignalLevel

Analog Group Reference

Analog Channel Reference

Analog channel conversion time (in ticks) (0 -> 4294967295)

Analog channel trigger type

SW trigger for Analog input

DioRef

PwmRef

PWM Type

Sync PWM Channel Mask (0 -> 4294967295)

OcuRef

Input

Analog

☐

STD\_LOW

'Adc/AdcConfigSet/AdcHwUnit\_0/AdcPotGroup

dc/AdcConfigSet/AdcHwUnit\_0/AdcPotChannel

50

SW

rConfig\_0/TimeTriggerTable\_0/SchedulePoints\_0

NORMAL

0

- ReferenceDirection: determines I/O channel direction (input/output)
- ReferenceType: determines signal type (analog, digital, pwm)

For analog signals, each descriptor is determined by unique combination of references to an Analog Channel and an Analog Group. Also for analog signals conversion time, trigger type and time are required.

For pwm and digital signals only references to underlying drivers are needed.

5. **BswConfig/GeneralConfig/ComDAL** container holds ComDal channel descriptor configuration for each BSW Communication signal.

General

Channel Type

CAN

Can HW Object Reference

/Can/Can/CanConfigSet/CanHardwareObject\_3

Can Tx Timeout (0 -> 65000)

10000

Uart Channel Reference

NFC Channel Reference

LIN Channel Reference

6. **BswConfig/UartDriverConfig** Container holds the configuration for the internal UART driver.

UART Driver ConfigUART Driver Config

Uart Hw Unit Index (0 -> 1)

1

Baud Rate

BR\_115200

Uart Word length [bits] (5 -> 10)

8

Uart Stop Bits (1 -> 2)

1

Uart parity

NONE

Uart Data Payload Size [bytes] (4 -> 64)

50

Uart clock prescaler (1 -> 4)

1

UartMcuClockRef

uration/McuClockSettingConfig\_0/McuClockReferencePoint\_LPUART1\_CLK

EOT Char (127 -> 255)

254

UART Driver ConfigUART Driver Config

UART Driver Config

| Index | Name         | Uart Logi... | Signal Type |
|-------|--------------|--------------|-------------|
| 0     | UartChann... | 0            | RX_SIGNAL   |
| 1     | UartChann... | 1            | TX_SIGNAL   |
| 2     | UartChann... | 2            | TX_SIGNAL   |
|       |              |              |             |
|       |              |              |             |
|       |              |              |             |

7. **BswConfig/GeneralConfig/SysDAL/General** Container holds SysDal global configuration, including the configuration on the internal scheduler.

IntegrationAppOSConfig

Name

IntegrationAppOSConfig

OS Scheduler Time [us] (10 -> 4294967295)

100

GptTimer

/Gpt/Gpt/GptChannelConfigSet/GptChannelConfiguration\_1

8. **BswConfig/GeneralConfig/SysDAL/InterruptList** Container holds the interrupt handlers that need to be activated at system level. (in our case only GPT, OCU and ADC interrupts are enabled)

General

InterruptList

PowerManagement

IntegrationAppTaskList

InterruptList

</

9. **BswConfig/GeneralConfig/SysDAL/PowerManagement/InitList** Container hold the list of API's that need to be called by SysDal during initialization.

| Index | Name                   | Parameter List       | Callout Header | Callout Applicability |
|-------|------------------------|----------------------|----------------|-----------------------|
| 0     | Port_Init              | &PortConfigSet       | Port.h         | InitBlockZero         |
| 1     | Adc_Init               | &AdcConfigSet        | Adc.h          | InitBlockOne          |
| 2     | Gpt_Init               | &GptChannelConfigSet | Gpt.h          | InitBlockOne          |
| 3     | Gpt_EnableNotification | 1                    | Gpt.h          | InitBlockOne          |
| 4     | Pwm_Init               | &PwmChannelConfigSet | Pwm.h          | InitBlockOne          |
| 5     | Ocu_Init               | &OcuConfigSet        | Ocu.h          | InitBlockOne          |
| 6     | IoDal_Init             | &IoDal_Config[0]     | IoDal.h        | InitBlockOne          |

10. **BswConfig/GeneralConfig/SysDAL/IntegrationAppTaskList** Container hold the configuration of the tasks for the internal round-robin scheduler. Up to 7 cyclic tasks and one sigle-shot pre-hook task can be enabled.

General | InterruptList | PowerManagement | IntegrationAppTaskList

IntegrationAppTaskList

| Index | Name     | Predefined Task List | Task Activation Tim... | Ref... |
|-------|----------|----------------------|------------------------|--------|
| 0     | IoDal    | INTAPP_TASK_2        | 100                    |        |
| 1     | Rte      | INTAPP_TASK_3        | 200                    |        |
| 2     | Rte_Init | INTAPP_PREHOOK_TASK  |                        |        |
| 3     | SysDal   | INTAPP_TASK_1        | 100                    |        |
|       |          |                      |                        |        |
|       |          |                      |                        |        |


- For each defined task the user can configure a list of API's that will be called by it.

## 5.6 Modifying the Configuration in Tresos Studio

Users may change the application configuration according to their needs.

### Procedure:

1. Open the EB Tresos Studio GUI
2. Open previously imported Sample Application project
3. Use the Tresos Studio GUI to modify configuration parameter values and save the changes. The value of the External Crystal Frequency parameter can be changed as depicted in Figure 5-1: Modifying the External Crystal Frequency
4. Select the Sample Application project and click on "Generate" button to generate the configuration files.
5. Copy the generated configuration files from workspace/[project]/output/includedirectory into the Sample Application folder /cfg/include.



**Figure 5-1. Modifying the External Crystal Frequency**



## 5.7 Examples of Communication Data

The following messages are configured:

| <i>Message Id</i> | <i>Direction</i> | <i>Type</i>               | <i>Source</i> | <i>Reply Id</i> | <i>Payload</i> |
|-------------------|------------------|---------------------------|---------------|-----------------|----------------|
| 0                 | RX_MESSAGE       | APP_REQUEST_MSG_FORWARD   | CAN0 – HO2    | 2               | 8              |
| 1                 | RX_MESSAGE       | APP_REQUEST_STATUS        | CAN0 – HO3    | 0               | 8              |
| 2                 | RX_MESSAGE       | APP_REQUEST_OUTPUT_UPDATE | CAN1 – HO4    | -               | 8              |
| 3                 | RX_MESSAGE       | APP_REQUEST_MSG_FORWARD   | UART Ch0      | 2               | 16             |
| 0                 | TX_REPLY         | APP_REQUEST_STATUS        | UART Ch1      | -               | 50             |
| 1                 | TX_MESSAGE       | APP_EVENT_NOTIFICATION    | UART Ch2      | -               | 50             |
| 2                 | TX_REPLY         | APP_REQUEST_MSG_FORWARD   | CAN1 – HO5    | -               | 8              |
| 3                 | TX_MESSAGE       | APP_EVENT_FORWARD_MSG     | CAN0 – HO0    | -               | 8              |

**Figure 5-2. Example of a list of configured messages.**

Having the message list configured as above, the following list of messages can be handled by the host ECU.

| <i>Source</i> | <i>Byte</i> |           |          |           |           |            |           |           | <i>Comment</i>  |
|---------------|-------------|-----------|----------|-----------|-----------|------------|-----------|-----------|---|
|               | <i>0</i>    | <i>1</i>  | <i>2</i> | <i>3</i>  | <i>4</i>  | <i>5</i>   | <i>6</i>  | <i>7</i>  |   |
| <i>CAN0</i>   | <i>0</i>    | <i>16</i> | <i>2</i> | <i>15</i> | <i>10</i> | <i>11</i>  | <i>10</i> | <i>15</i> | <i>Request Forward message with payload 0xF, 0xA, 0xB,0xA, 0xF on Tx Reply Id:2</i>   |
| <i>CAN0</i>   | <i>1</i>    | <i>1</i>  | <i>0</i> | <i>0</i>  | <i>0</i>  | <i>0</i>   | <i>0</i>  | <i>0</i>  | <i>Request Status Info on Lighting Instance 0. Message will be packed in the Tx Reply with the id 0.</i>                                  |
| <i>CAN1</i>   | <i>2</i>    | <i>2</i>  | <i>0</i> | <i>2</i>  | <i>1</i>  | <i>100</i> | <i>0</i>  | <i>0</i>  | <i>Request Output Update on Lighting instance 2, Unicast - Channel 1, New Value: 100%</i>   |
| <i>UART</i>   | <i>3</i>    | <i>16</i> | <i>2</i> | <i>50</i> | <i>16</i> | <i>15</i>  | <i>16</i> |           | <i>Request Forward message with payload 0x32, 0x10, 0xF,0x10, on Tx reply Id:2. Message will be packed in the Tx Reply with the id 2.</i> |

**Figure 5-2. Example Rx Messages to be handled by host ECU**

**How to Reach  
Us:**

**Home Page:**  
[nxp.com](http://nxp.com)

**Web Support:**  
[nxp.com/support](http://nxp.com/support)

Information in this document is provided solely to enable system and software implementers to use NXP products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits based on the information in this document. NXP reserves the right to make changes without further notice to any products herein.

NXP makes no warranty, representation, or guarantee regarding the suitability of its products for any particular purpose, nor does NXP assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in NXP data sheets and/or specifications can and do vary in different applications, and actual performance may vary over time. All operating parameters, including "typicals," must be validated for each customer application by customer's technical experts. NXP does not convey any license under its patent rights nor the rights of others. NXP sells products pursuant to standard terms and conditions of sale, which can be found at the following address: [nxp.com/SalesTermsandConditions](http://nxp.com/SalesTermsandConditions).

NXP, the NXP logo, NXP SECURE CONNECTIONS FOR A SMARTER WORLD, COOLFLUX, EMBRACE, GREENCHIP, HITAG, I2C BUS, ICODE, JCOP, LIFE VIBES, MIFARE, MIFARE CLASSIC, MIFARE DESFire, MIFARE PLUS, MIFARE FLEX, MANTIS, MIFARE ULTRALIGHT, MIFARE4MOBILE, MIGLO, NTAG, ROADLINK, SMARTLX, SMARTMX, STARPLUG, TOPFET, TRENCHMOS, UCODE, Freescale, the Freescale logo, Altivec, C-5, CodeTest, CodeWarrior, ColdFire, ColdFire+, C-Ware, the Energy Efficient Solutions logo, Kinetis, Layerscape, MagniV, mobileGT, PEG, PowerQUICC, Processor Expert, QorIQ, QorIQ Qonverge, Ready Play, SafeAssure, the SafeAssure logo, StarCore, Symphony, VortiQa, Vybrid, Airfast, BeeKit, BeeStack, CoreNet, Flexis, MXC, Platform in a Package, QUICC Engine, SMARTMOS, Tower, TurboLink, and UMEMS are trademarks of NXP B.V. All other product or service names are the property of their respective owners. ARM, AMBA, ARM Powered, Artisan, Cortex, Jazelle, Keil, SecurCore, Thumb, TrustZone, and  $\mu$ Vision are registered trademarks of ARM Limited (or its subsidiaries) in the EU and/or elsewhere. ARM7, ARM9, ARM11, big.LITTLE, CoreLink, CoreSight, DesignStart, Mali, mbed, NEON, POP, Sensinode, Socrates, ULINK and Versatile are trademarks of ARM Limited (or its subsidiaries) in the EU and/or elsewhere. All rights reserved. Oracle and Java are registered trademarks of Oracle and/or its affiliates. The Power Architecture and Power.org word marks and the Power and Power.org logos and related marks are trademarks and service marks licensed by Power.org.

© 2017 NXP B.V.

Document Number UM5AASR4.3R1.0.0  
Revision 1.2