

U-Boot v2017(next-dev) Developer Guide

ID: RK-KF-YF-45

Release Version: V2.31.0

Release Date: 2024-09-23

Security Level: ☐Top-Secret ☐Secret ☐Internal ☒Public

DISCLAIMER

THIS DOCUMENT IS PROVIDED "AS IS". ROCKCHIP ELECTRONICS CO., LTD. ("ROCKCHIP") DOES NOT PROVIDE ANY WARRANTY OF ANY KIND, EXPRESSED, IMPLIED OR OTHERWISE, WITH RESPECT TO THE ACCURACY, RELIABILITY, COMPLETENESS, MERCHANTABILITY, FITNESS FOR ANY PARTICULAR PURPOSE OR NON-INFRINGEMENT OF ANY REPRESENTATION, INFORMATION AND CONTENT IN THIS DOCUMENT. THIS DOCUMENT IS FOR REFERENCE ONLY. THIS DOCUMENT MAY BE UPDATED OR CHANGED WITHOUT ANY NOTICE AT ANY TIME DUE TO THE UPGRADES OF THE PRODUCT OR ANY OTHER REASONS.

Trademark Statement

"Rockchip", "瑞芯微", "瑞芯" shall be Rockchip's registered trademarks and owned by Rockchip. All the other trademarks or registered trademarks mentioned in this document shall be owned by their respective owners.

All rights reserved. ©2024. Rockchip Electronics Co., Ltd.

Beyond the scope of fair use, neither any entity nor individual shall extract, copy, or distribute this document in any form in whole or in part without the written approval of Rockchip.

Rockchip Electronics Co., Ltd.

No.18 Building, A District, No.89, software Boulevard Fuzhou, Fujian, PRC

Website: www.rock-chips.com

Customer service Tel: +86-4007-700-590

Customer service Fax: +86-591-83951833

Customer service e-Mail: fae@rock-chips.com

Preface

Overview

The document aims to guide readers on how to develop projects in U-Boot v2017(next-dev) version.

Chip feature support

Chipset	Miniloader + RKIMG u-boot	SPL + FIT u-boot
RV1108	✓	
RK3036	✓	
RK3126C	✓	
RK3128	✓	
RK3229	✓	
RK3288	✓	
RK3308	✓	
RK3326/PX30	✓	
RK3328	✓	
RK3368/PX5	✓	
RK3399	✓	
RK1808	✓	
RV1126/RV1109		✓
RK3566/RK3568		✓
RK3588		✓
RV1106/RV1103		✓
RK3528		✓
RK3562		✓
RK3576		✓
RV1106B/RV1103B		✓
RK3506		✓

Target Reader

This document (this Guide) applies primarily to the following engineers:

Technical Support Engineer

Software Development Engineer

Revision History

Version	Author	Date	Change Description
V1.00	Joseph Chen	2018-02-28	Initial version
V1.01	Jason Zhu	2018-06-22	fastboot description, OPTEE Client description
V1.10	Joseph Chen	2018-07-23	Document improvement, including updates and adjustments to most chapters
V1.11	Jon Lin	2018-07-26	Improved descriptions of Nand、 SFC SPI Flash
V1.12	Liang Chen	2018-08-08	Added descriptions of HW-ID
V1.13	Qing Zhang	2018-09-20	Added CLK instructions
V1.20	Joseph Chen	2018-11-06	Added/Updated defconfig/rktest/probe/interrupt/kernel dtb/uart/atags
V1.21	Joseph Chen	2019-01-21	Added dtbo/amp/dvfs wide temperature range/fdt command information
V1.22	Hisping Lin	2019-03-05	Added descriptions of optee client
V1.23	Joseph Chen Jason Zhu	2019-03-25	Added descriptions of kernel cmdline
V1.30	Joseph Chen	2019-03-25	reorganized and improved the documents, adjust contents to some chapters
V1.31	Jason Zhu	2019-04-23	Added hardware description of CRYPTO
V1.32	Jason Zhu	2019-05-14	Complement kernel cmdline descriptions
V1.33	Jason Zhu	2019-05-29	Added MMC command section, AVB and A/B system description , terminology descriptions
V1.40	Joseph Chen	2019-06-20	Added/updated: memblk/system/bi dram/statcktrace/hotkey/ fdt param/run_command/distro/led/reset/ env/wdt/spl/amp/crypto/ efuse/Android compatible/io-domain/bootflow/pack image
V1.41	Jason Zhu	2019-08-21	Added secure otp description
V1.42	Jason Zhu	2019-08-27	Added storage equipment/MTD description

Version	Author	Date	Change Description
V1.43	Jason Zhu	2019-10-08	Added BCB description
V1.44	Jason Zhu	2019-10-15	Added SPL driver and function support description
V1.45	Jason Zhu	2019-11-15	Added instructions of SPL pinctrl
V2.0.0	Joseph Chen	2020-05-02	Version upgrade, reorganized formatting, contents, layouts etc.
V2.1.0	Joseph Chen	2020-05-29	Added FIT solution
V2.1.1	Jon Lin	2020-06-07	Added open source framework storage support note
V2.1.2	Tao Huang	2020-07-08	Adjusted format
V2.2.0	David Wu	2020-07-09	Added Ethernet network support description
V2.3.0	Jeff Chen	2020-07-13	Added TPL support note
V2.4.0	Joseph Chen	2020-09-23	Updated chapters of FIT and compiling & programming
V2.5.0	Jason Zhu	2020-12-28	Updated FIT chapter
V2.6.0	Jason Zhu	2020-12-30	Added quick power-on chapter description
V2.7.0	Shawn Lin	2021-01-25	Added PCIe support description
V2.8.0	Joseph Chen	2021-03-12	Added description of U-Boot firmware format, storage capacity, AMP and RK 3568 support
V2.9.0	Joseph Chen	2021-04-13	Updated chapters of FIT and USB upgrade
V2.10.0	Jason Zhu	2021-05-06	Add step-by-step safe operation
V2.11.0	Joseph Chen	2021-05-13	FIT Chapter: added recovery.img packaging and signature、pss signature parameters
V2.12.0	Jason Zhu	2021-06-23	Updated efuse/OTP open region
V2.13.0	Qing Zhang	2021-07-21	Driver module chapter: Added booted CPU support SCMI interface

Version	Author	Date	Change Description
V2.14.0	Frank Wang	2021-10-19	Added USB support description
V2.15.0	Joseph Chen	2021-10-19	Updated AMP chapter
V2.16.0	Joseph Chen	2021-10-20	Added chapters of RNG、 Thermal and FS
V2.17.0	Nico Cheng	2021-11-01	Added DFU support description
V2.18.0	Joseph Chen	2021-12-23	Chip support list: Add rk3588
V2.19.0	Joseph Chen	2022-03-10	Added ENVF support description
V2.20.0	Jason Zhu	2022-08-29	Added RV1106 OTP safe region
V2.21.0	Joseph Chen	2023-01-15	Updated and simplified "chip feature support" in the first page. Updated and organized the differences of platforms to the chapter of "platform definition"
V2.22.0	Joseph Chen	2023-02-21	Updated chapters of clock/otp Added RK3562
V2.23.0	Joseph Chen	2023-03-21	Adjusted the sorting of Chapter 2, added storage type differentiation and GPIO compatible interface description
V2.24.0	Jon Lin	2023-04-03	Updated the chapter of PCIe
V2.25.0	Jon Lin	2023-08-17	Updated the chapter of SPI
V2.26.0	Jon Lin	2023-09-13	Updated the chapter of PCIe
V2.27.0	Joseph Chen	2024-01-18	Updated description of ENVF suitability and FIT firmware replacement
V2.28.0	Jon Lin	2024-01-26	Added SPI rate description
V2.29.0	Xuhui Lin	2024-04-22	Chip support list: Added rk3576
V2.30.0	Damon Ding	2024-08-27	Updated the chapter of Display
V2.31.0	Xuhui Lin	2024-09-23	Chip support list: Added rv1103b、rv1106b、rk3506

Contents

U-Boot v2017(next-dev) Developer Guide

1. Chapter-1 Basic Introduction
 - 1.1 Feature
 - 1.2 Version
 - 1.3 DM
 - 1.4 Security
 - 1.5 Boot-order
 - 1.6 Driver-probe
 - 1.7 Shell
 - 1.8 Boot-command
 - 1.9 TPL/SPL/U-Boot Proper
 - 1.10 Build-output
 - 1.11 Environment-variables
 - 1.12 U-Boot DTS
 - 1.13 Relocation
2. Chapter-2 RK Architecture
 - 2.1 Preface
 - 2.2 Platform Documentation
 - 2.3 Platform Configuration
 - 2.4 Boot Process
 - 2.5 Memory Layout
 - 2.6 Storage Layout
 - 2.7 Aliases
 - 2.8 AMP
 - 2.9 Atags
 - 2.10 Bidram/Sysmem
 - 2.11 Fuse/OTP
 - 2.12 Hotkey
 - 2.13 Image Decompress
 - 2.14 Image Kernel
 - 2.15 Image U-Boot
 - 2.16 Interrupt
 - 2.17 Kernel-DTB
 - 2.18 MMU Cache
 - 2.19 Make.sh
 - 2.20 HW-ID DTB
 - 2.21 Partition Table
 - 2.22 Relocation
 - 2.23 Reset
 - 2.24 Sd/Udisk
 - 2.25 Stacktrace
 - 2.26 TimeCost
 - 2.27 TimeStamp
 - 2.28 Vendor Storage
3. Chapter-3 Compile and Download
 - 3.1 Preparations
 - 3.2 Firmware Compiling
 - 3.3 Firmware Downloading
 - 3.4 Firmware Size
 - 3.5 Special Packaging
4. Chapter-4 System Module
 - 4.1 AArch32
 - 4.2 ANDROID AB
 - 4.2.1 Configuration Item
 - 4.2.2 Partition Table

- 4.2.3 Notes
- 4.3 ANDROID BCB
- 4.4 AVB Secure Boot
 - 4.4.1 Feature
 - 4.4.2 Configuration
 - 4.4.3 Reference
- 4.5 Cmdline
 - 4.5.1 Data Sources
 - 4.5.2 Data Meaning
- 4.6 DFU Update Firmware
- 4.7 DTBO/DTO
 - 4.7.1 Principle Introduction
 - 4.7.2 Enable DTO
 - 4.7.3 DTO Result
- 4.8 ENV
 - 4.8.1 Framework Support
 - 4.8.2 Relevant Interface
 - 4.8.3 Advanced Interface
 - 4.8.4 Storage Location
 - 4.8.5 General Options
 - 4.8.6 Fw_printenv Tool
 - 4.8.7 ENVF
- 4.9 Fastboot
 - 4.9.1 Configuration Options
 - 4.9.2 Trigger Method
 - 4.9.3 Command Support
 - 4.9.4 Command Details
- 4.10 FileSystem
 - 4.10.1 Framework Support
 - 4.10.2 Relevant Interface
 - 4.10.3 Example of Command
- 4.11 HW-ID DTB
 - 4.11.1 Design Principle
 - 4.11.2 Hardware Reference
 - 4.11.3 DTB Naming
 - 4.11.4 DTB Packaging
 - 4.11.5 Feature Enablement
 - 4.11.6 Load Results
- 4.12 SD and USB Flash Drives
 - 4.12.1 Mechanisms and Principles
 - 4.12.2 Firmware Creation
 - 4.12.3 SD Configuration
 - 4.12.4 USB Configuration
 - 4.12.5 Functions Taking Effect
 - 4.12.6 Notes
- 5. Chapter-5 Driver Module
 - 5.1 AMP
 - 5.1.1 Ideas for Implementation
 - 5.1.2 Framework Support
 - 5.1.3 Feature Enablement
 - 5.2 Charge
 - 5.2.1 Framework Support
 - 5.2.2 Packaging Pictures
 - 5.2.3 DTS Configuration
 - 5.2.4 System Hibernation
 - 5.2.5 Replacement of Pictures
 - 5.2.6 Charging Indicator
 - 5.3 Clock

- 5.3.1 Framework Support
 - 5.3.2 Relevant Interface
 - 5.3.3 Clock Initialization
 - 5.3.4 CPU Frequency Boost
 - 5.3.5 Clock Tree
- 5.4 Crypto
 - 5.4.1 Framework Support
 - 5.4.2 Relevant Interface
 - 5.4.3 DTS Configuration
- 5.5 Display
 - 5.5.1 Framework Support
 - 5.5.2 Relevant Interface
 - 5.5.3 DTS Configuration
 - 5.5.4 Defconfig
 - 5.5.5 LOGO Partition
 - 5.5.6 Analysis of Common Problems
- 5.6 Dvfs
 - 5.6.1 Wide Temperature Strategy
 - 5.6.2 Framework Support
 - 5.6.3 Relevant Interface
 - 5.6.4 Enable Wide Temperature
 - 5.6.5 Wide Temperature Results
- 5.7 Efuse/Otp
 - 5.7.1 Framework Support
 - 5.7.2 Relevant Interface
 - 5.7.3 DTS Configuration
 - 5.7.4 Recall Example
 - 5.7.5 Open Area
- 5.8 Ethernet
 - 5.8.1 Framework Support
 - 5.8.2 Relevant Interface
 - 5.8.3 DTS Configuration
 - 5.8.4 Usage Example
 - 5.8.5 Network Troubleshooting
- 5.9 Gpio
 - 5.9.1 Framework Support
 - 5.9.2 DM Interface
 - 5.9.3 Legacy Interface
- 5.10 Interrupt
 - 5.10.1 Framework Support
 - 5.10.2 Related Interface
- 5.11 I2C
 - 5.11.1 Framework Support
 - 5.11.2 Relevant Interface
- 5.12 IO-Domain
 - 5.12.1 Framework Support
 - 5.12.2 Relevant Interface
- 5.13 Key
 - 5.13.1 Framework Support
 - 5.13.2 Relevant Interface
- 5.14 Led
 - 5.14.1 Framework Support
 - 5.14.2 Relevant Interface
 - 5.14.3 DTS Node
- 5.15 Mtd
 - 5.15.1 Framework Support
 - 5.15.2 Relevant Interface
 - 5.15.3 Usage Example

- 5.16 Mtd_blk
 - 5.16.1 Framework Support
 - 5.16.2 Relevant Interface
- 5.17 Optee Client
 - 5.17.1 Framework Support
 - 5.17.2 Firmware Description
 - 5.17.3 Interface Description
 - 5.17.3.1 Suitability
 - 5.17.3.2 Return Value
 - 5.17.3.3 trusty_read_vbootkey_hash
 - 5.17.3.4 trusty_write_vbootkey_hash
 - 5.17.3.5 trusty_read_vbootkey_enable_flag
 - 5.17.3.6 trusty_write_oem_otp_key
 - 5.17.3.7 trusty_oem_otp_key_is_written
 - 5.17.3.8 trusty_set_oem_hr_otp_read_lock
 - 5.17.3.9 trusty_oem_otp_key_cipher
 - 5.17.4 Shared Memory
 - 5.17.5 Test Command
 - 5.17.6 Common Misprints
- 5.18 PCIe
 - 5.18.1 Development Notes
 - 5.18.2 Framework Support
 - 5.18.3 DTS Configuration
 - 5.18.4 Usage Example
 - 5.18.4.1 PCIe CMD
 - 5.18.4.2 NVMe
 - 5.18.4.3 RK3588 RC dma
 - 5.18.4.4 RK3568 RC dma
 - 5.18.5 Analysis of Common Problems
- 5.19 Pinctrl
 - 5.19.1 Framework Support
 - 5.19.2 Relevant Interface
- 5.20 Pmic/Regulator
 - 5.20.1 Framework Support
 - 5.20.2 Relevant Interface
 - 5.20.3 Init Voltage
 - 5.20.4 Skip Initialization
- 5.21 Reset
 - 5.21.1 Framework Support
 - 5.21.2 Relervant Interface
 - 5.21.3 DTS Configuration
- 5.22 Rng
 - 5.22.1 Framework Support
 - 5.22.2 Relevant Interface
 - 5.22.3 DTS Configuration
- 5.23 Spi
 - 5.23.1 Framework Support
 - 5.23.2 Relevant Interface
 - 5.23.3 DTS Configuration
 - 5.23.4 Recall Example
 - 5.23.5 Test Command
 - 5.23.6 Analysis of Common Problems
- 5.24 Storage
 - 5.24.1 Framework Support
 - 5.24.2 Relevant Interface
 - 5.24.3 Boot Storage Type Differentiation
 - 5.24.4 DTS Configuration
 - 5.24.5 Dual Storage Expansion

- 5.24.6 Analysis of Common Problems
- 5.25 Thermal
 - 5.25.1 Framework Support
 - 5.25.2 Relevant Interface
 - 5.25.3 DTS Configuration
- 5.26 Uart
 - 5.26.1 Individual Replacement
 - 5.26.2 Global Replacement
 - 5.26.3 Turn off Printing
 - 5.26.4 Relevant Interface
- 5.27 USB
 - 5.27.1 Framework Support
 - 5.27.2 Board Configuration
 - 5.27.3 DTS Configuration
 - 5.27.4 Related Commands
- 5.28 Vendor Storage
 - 5.28.1 Principle Overview
 - 5.28.2 Framework Support
 - 5.28.3 Relevant Interface
 - 5.28.4 Functionality Self-test
- 5.29 Watchdog
 - 5.29.1 Framework Support
 - 5.29.2 Relevant Interface
- 6. Chapter-6 Advanced Principle
 - 6.1 Kernel-DTB
 - 6.1.1 Design Background
 - 6.1.2 Live Device Tree
 - 6.1.3 Mechanisms to Achieve
 - 6.1.4 U-Boot
 - 6.2 Kernel Pass Parameter
 - 6.2.1 Cmdline
 - 6.2.2 Memory Capacity
 - 6.2.3 Other Ways
 - 6.3 AB System
 - 6.3.1 AB Data Format
 - 6.3.2 AB Activation Mode
 - 6.3.2.1 Successful-boot
 - 6.3.2.2 Reset-retry
 - 6.3.2.3 Mode Comparison
 - 6.3.3 Boot Process
 - 6.3.4 Upgrade and Exceptions
 - 6.3.5 Validation Methods
 - 6.3.5.1 Successful-boot
 - 6.3.5.2 Reset-retry
 - 6.3.6 References
 - 6.4 AVB Secure Boot
 - 6.4.1 References
 - 6.4.2 Terminology
 - 6.4.3 Brief Introduction
 - 6.4.4 Encryption Example
 - 6.4.5 AVB
 - 6.4.5.1 AVB Characteristics
 - 6.4.5.2 Key+signature+certificate
 - 6.4.5.3 AVB Lock
 - 6.4.5.4 AVB Unlock
 - 6.4.5.5 Kernel Configuration
 - 6.4.5.6 Android SDK
 - 6.4.5.7 Cmdline New Content

- 6.4.6 Partition Reference
- 6.4.7 Fastboot Command
 - 6.4.7.1 Quick Overview of Commands
 - 6.4.7.2 Command Usage
- 6.4.8 Firmware Downloading
- 6.4.9 Pre-loader Verified
- 6.4.10 U-boot Verified
- 6.4.11 System Verification Boot
- 6.4.12 Linux AVB
 - 6.4.12.1 Operating Workflow
 - 6.4.12.2 Verification Process
- 6.5 SD Boot and Upgrade
 - 6.5.1 Brief Introduction
 - 6.5.2 SD Card Category
 - 6.5.2.1 Regular SD Card
 - 6.5.2.2 SD Upgrade Card
 - 6.5.2.3 SD Boot Card
 - 6.5.2.4 SD Repair Card
 - 6.5.3 Firmware Logo
 - 6.5.4 Boot Process
 - 6.5.4.1 Pre-loader Boot
 - 6.5.4.2 U-Boot Boot
 - 6.5.4.3 Recovery and PCBA
 - 6.5.5 Notes
- 7. Chapter-7 Configuration Trimming
- 8. Chapter-8 Debugging Tools
 - 8.1 DEBUG
 - 8.2 Initcall
 - 8.3 IO Command
 - 8.4 IOMEM Command
 - 8.5 I2C Command
 - 8.6 GPIO Command
 - 8.7 FDT Command
 - 8.8 MMC Command
 - 8.9 TimeStamp
 - 8.10 DM Tree
 - 8.11 DM Uclass
 - 8.12 Stacktrace.sh
 - 8.13 System Crash
 - 8.14 CRC Check
 - 8.15 HASH Check
 - 8.16 Modify DDR Capacity
 - 8.17 Jump Information
 - 8.18 Boot Information
 - 8.18.1 RK Firmware
 - 8.18.2 Distro Firmware
 - 8.18.3 No Valid Firmware
- 9. Chapter-9 Test Case
- 10. Chapter-10 SPL
 - 10.1 Firmware Boot
 - 10.1.1 FIT Firmware
 - 10.1.2 RKFW Firmware
 - 10.1.3 Storage Priority
 - 10.2 Compilation and Packaging
 - 10.2.1 Code Compilation
 - 10.2.2 Firmware Packaging
 - 10.3 System Module
 - 10.3.1 GPT

- 10.3.2 A/B System
 - 10.3.3 Boot Priority
 - 10.3.4 ATAGS
 - 10.3.5 Kernel Boot
 - 10.3.6 Pinctrl
 - 10.3.7 Secure Boot
- 10.4 Driver Module
 - 10.4.1 MMC
 - 10.4.2 MTD Block
 - 10.4.3 OTP
 - 10.4.4 Crypto
 - 10.4.5 Uart
- 11. Chapter-11 TPL
 - 11.1 Compiling and Packaging
 - 11.1.1 Configuration
 - 11.1.2 Compiling
 - 11.1.3 Packaging
- 12. Chapter-12 FIT
 - 12.1 Preface
 - 12.2 Brief Introduction
 - 12.2.1 Basic Introduction
 - 12.2.2 Example Introduction
 - 12.2.3 ITB Structure
 - 12.3 Platform Configuration
 - 12.3.1 Chip Support
 - 12.3.2 Code Configuration
 - 12.3.3 Mirror File
 - 12.3.4 ITS File
 - 12.3.5 Related Tools
 - 12.4 Non-secure Boot
 - 12.4.1 uboot.img
 - 12.4.2 boot.img
 - 12.5 Secure Boot
 - 12.5.1 Principle
 - 12.5.1.1 Checking Process
 - 12.5.1.2 Key Storage
 - 12.5.1.3 Key Usage
 - 12.5.1.4 Signature Storage
 - 12.5.1.5 Anti-rollback
 - 12.5.2 Preliminary Preparation
 - 12.5.2.1 Key
 - 12.5.2.2 Configuration
 - 12.5.2.3 Firmware
 - 12.5.3 Compiling and Packaging
 - 12.5.4 Checking Principles
 - 12.5.5 Booting Information
 - 12.6 Remote Signature
 - 12.6.1 Implementation Idea
 - 12.6.2 Signed Data
 - 12.6.3 Detailed Steps
 - 12.6.4 Other Solutions
 - 12.7 Firmware Unpacking
 - 12.8 Firmware Replacement
 - 12.9 Safety Checking Step-by-Step
- 13. Chapter-13 Fast Boot
 - 13.1 Chip Support
 - 13.2 Storage Support
 - 13.3 bootrom Support

- 13.4 U-Boot SPL Support
- 13.5 MCU Configuration
- 13.6 Kernel Support
- 13.7 Fast Boot Process
- 14. Chapter-14 Platform Definition
 - 14.1 ATF/OPTEE
 - 14.2 Clock
 - 14.3 Defconfig
 - 14.4 DFU
 - 14.5 Optee
- 15. Chapter-15 Remarks
 - 15.1 SDK Compatibility
 - 15.1.1 androidboot.mode Compatibility
 - 15.1.2 MISC Compatibility
- 16. Chapter-16 Tools
 - 16.1 trust_merger
 - 16.2 boot_merger
 - 16.3 loaderimage
 - 16.4 resource_tool
 - 16.5 mkimage
 - 16.6 stacktrace.sh
 - 16.7 mkbooting
 - 16.8 unpack_booting
 - 16.9 repack-booting
 - 16.10 pack_resource.sh
 - 16.11 buildman
 - 16.12 patman
- 17. Chapter-17 Appendix
 - 17.1 Download address
 - 17.1.1 RKBIN
 - 17.1.2 GCC
 - 17.2 Terminology

1. Chapter-1 Basic Introduction

1.1 Feature

v2017(next-dev) is the version developed by RK from the official v2017.09 version of U-Boot, and it supports all the mainstream chips sold by RK. The main features supported are:

- Supports RK Android firmware booting;
- Supports Android AOSP firmware booting;
- Supports Linux Distro firmware booting;
- Supports both Rockchip miniloader and SPL/TPL pre-loader boot;
- Supports LVDS, EDP, MIPI, HDMI, CVBS, RGB and other display devices.
- Support eMMC, Nand Flash, SPI Nand flash, SPI NOR flash, SD card, USB flash disk and other storage devices;
- Supports FAT, EXT2, and EXT4 file systems;
- Supports GPT, RK parameter partition tables;
- Supports power-on LOGO, charging animation, low power management, power management;
- Supports I2C, PMIC, CHARGE, FUEL GUAGE, USB, GPIO, PWM, GMAC, eMMC, NAND, Interrupt, etc;
- Supports vendor storage saving user data and configuration.
- Supports RockUSB and Google Fastboot USB gadget to write eMMC;
- Supports mass storage、ethernet、HID and other USB devices;
- Supports dynamic selection of kernel DTB by hardware state;

1.2 Version

There are two versions of RK's U-Boot including v2014 and v2017, internally named rkdevelop and next-dev, respectively. Two methods are available for the user to confirm whether the current U-Boot is the v2017.

Method 1: Check whether or not the Makefile version number is 2017.

```
#
## Chapter-1 SPDX-License-Identifier:      GPL-2.0+
#

VERSION = 2017
PATCHLEVEL = 09
SUBLEVEL =
EXTRAVERSION =
NAME =
.....
```

Method 2: Check whether or not the first official line of the boot print is U-Boot 2017.09.

```
U-Boot 2017.09-01818-g11818ff-dirty (Nov 14 2019 - 11:11:47 +0800)
.....
```

Project open source: v2017 has been open source and regularly updated to Github: <https://github.com/rockchip-linux/u-boot>

kernel version: v2017 requires RK kernel version ≥ 4.4

1.3 DM

DM (Driver Model) is U-Boot's standard device-driver development model, which is very similar to the kernel's device-driver model. v2017 also follows the DM framework to develop various functional modules. Hence, it is recommended that readers read the DM documentation first to understand the principles and implementation of the DM architecture.

README:

```
./doc/driver-model/README.txt
```

Terminology

Uclass - a group of devices which operate in the same way. A uclass provides a way of accessing individual devices within the group, but always using the same interface. For example a GPIO uclass provides operations for get/set value. An I2C uclass may have 10 I2C ports, 4 with one driver, and 6 with another.

Driver - some code which talks to a peripheral and presents a higher-level interface to it.

Device - an instance of a driver, tied to a particular port or peripheral.

Brief summary:

- uclass : Device driver model
- driver
- device

Core code:

```
./drivers/core/
```

1.4 Security

U-Boot belongs to Non-Secure World in ARM TrustZone security system, it can't directly access any secure resources (e.g. secure memory, secure otp, efuse), and needs to use trust to access them indirectly. U-Boot operates in the following mode on RK platforms.

```
32-bit platform: Non-Secure PL1
64-bit platform: EL2 (Always be Non-Secure)
```

1.5 Boot-order

The RK platform currently has two sets of startup methods, depending on whether the front-level Loader code is open source or not:

```
// Front loader closed source
BOOTROM => ddr bin => Miniloader => TRUST => U-BOOT => KERNEL
// Front loader open source
BOOTROM => TPL => SPL => TRUST => U-BOOT => KERNEL
```

TPL is equivalent to ddr bin, SPL is equivalent to miniloader. the combination of TPL+SPL realizes the same function as RK closed source ddr.bin+miniloader, and can be replaced by each other.

1.6 Driver-probe

Although U-Boot introduces the device-driver development model, it will not automatically initiate the probe of the registered device-driver as kernel does during the initialization phase. The probe of the driver must be initiated with the user's active call. The interface is as follows:

```
int uclass_get_device(enum uclass_id id, int index, struct udevice **devp);
int uclass_get_device_by_name(enum uclass_id id, const char *name,
                              struct udevice **devp);
int uclass_get_device_by_seq(enum uclass_id id, int seq, struct udevice **devp);
int uclass_get_device_by_of_offset(enum uclass_id id, int node, struct udevice
**devp);
int uclass_get_device_by_ofnode(enum uclass_id id, ofnode node, struct udevice
**devp);
int uclass_get_device_by_phandle_id(enum uclass_id id,
                                    int phandle_id, struct udevice **devp);
int uclass_get_device_by_phandle(enum uclass_id id,
                                 struct udevice *parent, struct udevice **devp);
int uclass_get_device_by_driver(enum uclass_id id,
                                const struct driver *drv, struct udevice **devp);
int uclass_get_device_tail(struct udevice *dev, int ret, struct udevice **devp);
.....
```

Core calls to the above interfaces:

```
int device_probe(struct udevice *dev); // Users are recommended to understand
the internal implementation!
```

1.7 Shell

U-Boot's Shell is called CLI(Command Line Interface), users can customize CMD according to their needs.。 In addition to through the Shell, CMD can be called as code through run_command() and run_command_list()`.

```
int run_command(const char *cmd, int flag)
int run_command_list(const char *cmd, int len, int flag)
```


1.8 Boot-command

U-Boot eventually boots the kernel with the boot command defined by `CONFIG_BOOTCOMMAND`. The `CONFIG_PREBOOT` pre-boot command is also executed before the execution of `CONFIG_BOOTCMD`, which is usually defined as empty.

1.9 TPL/SPL/U-Boot Proper

By using **different compilation conditions**, U-Boot can, with the same set of code, get three different functional Loaders, TPL/SPL/U-Boot-proper.

TPL (Tiny Program Loader) and SPL (Secondary Program Loader) are loaders at an earlier stage than U-Boot:

- TPL: Running in sram, responsible for completing ddr initialization;
- SPL: Running in ddr, responsible for completing the lowlevel initialization of the system, and loading the later firmware (trust.img and uboot.img);
- U-Boot proper: Running in the ddr, we usually call it “U-Boot”, responsible for booting the kernel;

Note: The term U-Boot proper is used to distinguish it from SPL. For the sake of convention, all references to U-Boot proper in subsequent chapters will be abbreviated to U-Boot.

Booting process:

```
BOOTROM => TPL(ddr bin) => SPL(miniloader) => TRUST => U-BOOT => KERNEL
```

For more, please refer to `doc/README.TPL` and `doc/README.SPL`

1.10 Build-output

U-Boot will generate some important files in the root directory after successful compilation of U-Boot(TPL/SPL generated files are only available when TPL/SPL compilation is supported):

```
// U-Boot phase
./u-boot.map           // MAP table file
./u-boot.sym           // SYMBOL table file
./u-boot               // ELF files, kernel-like vmlinux (important!)
./u-boot.dtb           // u-boot's own dtb file
./u-boot.bin           // Executable binary file that will be packaged as
uboot.img for          programming

// SPL phase
./spl/u-boot-spl.map   // MAP table file
./spl/u-boot-spl.sym   // SYMBOL table file
./spl/u-boot-spl       // ELF files, kernel-like vmlinux (important!)
./spl/u-boot-spl.dtb   // spl's own dtb file
./spl/u-boot-spl.bin   // Executable binary file that will be packaged into a
loader for             programming

// TPL phase
./tpl/u-boot-tpl.map   // MAP table file
./tpl/u-boot-tpl.sym   // SYMBOL table file
```

```
./tpl/u-boot-tpl          // ELF files, kernel-like vmlinux (important!)
./tpl/u-boot-tpl.dtb      // tpl's own dtb file
./tpl/u-boot-tpl.bin      // Executable binary file that will be packaged into a
loader for                programming
```

1.11 Environment-variables

ENV (Environment-Variables) is a global data management and delivery method supported by U-Boot, the principle is to build a HASH mapping table, and manage user data as “key-data” table entries.

ENV is usually used to define platform configuration parameters such as firmware load address, network configuration (ipaddr, serverip), bootcmd, bootargs, which can be printed out by the user using the `printenv` command at the command line.

- Users can choose whether to save ENV data to local storage
- ENV data is restricted to U-Boot only and cannot be passed directly to the kernel or parsed by the kernel.
- The user layer can access ENV data through the `fw_printenv` tool provided by U-Boot

The storage address and size of ENV data on the RK platform are defined as follows (unit: byte):

```
if ARCH_ROCKCHIP
config ENV_OFFSET
    hex
    depends on !ENV_IS_IN_UBI
    depends on !ENV_IS_NOWHERE
    default 0x3f8000
    help
        Offset from the start of the device (or partition)

config ENV_SIZE
    hex
    default 0x8000
    help
        Size of the environment storage area
endif
```

1.12 U-Boot DTS

U-Boot has its own DTS file, and the corresponding DTB file is automatically generated when compiling, and then being added at the end of u-boot.bin. File directory:

```
arch/arm/dts/
```

Which DTS file to use for each platform is specified by `CONFIG_DEFAULT_DEVICE_TREE` in `defconfig`.

1.13 Relocation

Usually, during the boot phase, U-Boot is loaded into the low DRAM address by the previous bootloader, and after completing the board_f.c process, U-Boot will relocate itself to a reserved address at the end of the memory (called as relocation, the location depends on the memory layout of the U-Boot). After completing the relocation, the board_r.c process continues. This can be recognized by the boot message:

```
U-Boot 2017.09-gabfd1c5e3d-210202-dirty #cjh (Mar 08 2021 - 16:57:31 +0800)

Model: Rockchip RK3568 Evaluation Board
PreSerial: 2, raw, 0xfe660000
DRAM: 2 GiB
Sysmem: init
// relocate to ddr where first address offset 0x7d304000. If the offset is 0, no
relocation is executed.

Relocation Offset: 7d304000, fdt: 7b9f8ed8
Using default environment
.....
```

2. Chapter-2 RK Architecture

This chapter introduces users to some important basics, features, etc. on the RK platform.

2.1 Preface

All references to enable/disable CONFIG_ configuration item throughout the text refer to enable or disable it by means of `make menuconfig`.

Except for some special CONFIG_ configuration items that are defined directly in the .h file.

Do not enable/disable the CONFIG_ configuration item directly in defconfig to avoid .config not taking effect due to configuration dependencies defined in Kconfig.

Please use `make savedefconfig` when updating defconfig.

2.2 Platform Documentation

Platform catalog:

```
./arch/arm/include/asm/arch-rockchip/  
./arch/arm/mach-rockchip/  
./board/rockchip/  
./include/configs/
```

defconfig catalog:

```
./configs/
```

Core public board-level documentation!

```
./arch/arm/mach-rockchip/board.c
```

2.3 Platform Configuration

configuration file

Configuration items, parameters for each platforms are typically located in the following locations:

./include/configs/rk3399_common.h:

```
.....
#ifndef CONFIG_SPL_BUILD
#define ENV_MEM_LAYOUT_SETTINGS \           // Firmware loading address
    "scriptaddr=0x00500000\0" \
    "pxefile_addr_r=0x00600000\0" \
    "fdt_addr_r=0x01f00000\0" \
    "kernel_addr_r=0x02080000\0" \
    "ramdisk_addr_r=0x0a200000\0"

#include <config_distro_bootcmd.h>
#define CONFIG_EXTRA_ENV_SETTINGS \
    ENV_MEM_LAYOUT_SETTINGS \
    "partitions=" PARTS_DEFAULT \         // Default GPT partition table
    ROCKCHIP_DEVICE_SETTINGS \
    RKIMG_DET_BOOTDEV \
    BOOTENV                               // Booting device detection command when
booting                                  linux
#endif

#define CONFIG_PREBOOT                    // Pre-boot commands that are executed
before                                  CONFIG_BOOTCOMMAND
.....
```

./include/configs/evb_rk3399.h:

```
.....
#ifndef CONFIG_SPL_BUILD
#undef CONFIG_BOOTCOMMAND
#define CONFIG_BOOTCOMMAND RKIMG_BOOTCOMMAND // Define boot command (set to
                                              RKIMG_BOOTCOMMAND)

#endif
.....
#define ROCKCHIP_DEVICE_SETTINGS \         // Enable display module
    "stdout=serial,vidconsole\0" \
    "stderr=serial,vidconsole\0"
.....
```

2.4 Boot Process

The U-Boot boot process for the RK platform is as follows, only some of the important steps are listed

```
start.s
    // assembly environment
    => IRQ/FIQ/lowlevel/vbar/errata/cp15/gic // ARM architecture related
lowlevel                                     initialization
    => _main
    => stack                                // Prepare the stack needed for
the C                                       environment
    // 【Phase 1】Initialization of the C environment, initiating a series of
function calls
    => board_init_f: init_sequence_f[]
        initf_malloc
```

```

arch_cpu_init // 【Lowlevel initialization of
SoCs】
serial_init // Serial port initialization
dram_init // 【Getting ddr capacity
information】
reserve_mmu // Reserve memory from the end of
ddr to a lower address.
reserve_video
reserve_uboot
reserve_malloc
reserve_global_data
reserve_fdt
reserve_stacks
dram_init_banksize
systemem_init
setup_reloc //Determine the address of the U-
Boot itself to be relocated

// Compilation environment
=> relocate_code // Compilation of U-Boot code to
implement relocation
// 【Phase 2】C environment initialization, initiating a series of
function calls
=> board_init_r: init_sequence_r[]
initr_caches // Enable MMU and I/Dcache
initr_malloc
bidram_initr
systemem_initr
initr_of_live // Initialize of_live
initr_dm // Initializing the dm framework
board_init // 【Platform initialization, the
core part】
board_debug_uart_init // Serial port iomux, clk
configuration
init_kernel_dtb // 【Switch to kernel dtb】!
clks_probe // Initialize system frequency
regulators_enable_boot_on // Initialize system power
io_domain_init // io-domain initialization
set_armclk_rate // __weak, ARM boost (implemented
on demand by the platform)
dvfs_init // wide-temperature chip frequency
modulation and voltage control
rk_board_init // __weak, implemented by each
specific platform
console_init_r
board_late_init // 【Platform late
initialization】
rockchip_set_ethaddr // Setting the mac address
rockchip_set_serialno // Setting serialno
setup_boot_mode // Parsing the "reboot xxx"
command,
// Recognizes key and loader
modes, recovery
charge_display // U-Boot charge
rockchip_show_logo // Display boot logo
soc_clk_dump // print clk tree
rk_board_late_init // __weak, implemented by each
specific platform

```

```
run_main_loop // 【Enter command line mode, or  
execute the boot command】
```

2.5 Memory Layout

The U-Boot is loaded by the predecessor loader to the `CONFIG_SYS_TEXT_BASE` address, and initializes by probing the total memory capacity of the current system, which is assumed to be a maximum of 4GB available on 32-bit platforms (but doesn't affect the kernel's recognition of the capacity), and all of the memory is assumed to be available on 64-bit platforms. Then, through a series of `reserve_xxx()` interfaces, it reserves the memory it needs from the end of the memory forward, and finally relocates itself to a certain reserved space. The overall memory usage layout is as follows, using ARM64 as an example (the regular case):

Name	Start Addr Offset	Size	Usage	Secure
ATF	0x00000000	1M	ARM Trusted Firmware	Yes
SHM	0x00100000	1M	SHM, Pstore	No
OP-TEE	0x08400000	2M~30M	Refer to the TEE Development Manual	Yes
FDT	fdt_addr_r	-	kernel dtb	No
KERNEL	kernel_addr_r	-	kernel image	No
RAMDISK	ramdisk_addr_r	-	ramdisk image	No
.....	-	-	-	-
FASTBOOT	-	-	Fastboot buffer	No
.....	-	-	-	-
SP	-	-	stack	No
FDT	-	sizeof(dtb)	U-Boot dtb	No
GD	-	sizeof(gd)	-	No
Board	-	sizeof(bd_t)	-	No
MALLOC	-	CONFIG_SYS_MALLOC_LEN	System heap space	No
U-Boot	-	sizeof(mon)	u-boot image	No
Video FB	-	fb size	32M	No
TLB Table	RAM_TOP-64K	32K	MMU Page Table	No

The `Start Addr Offset` column in the above table indicates the address offset based on the DDR base;

Fastboot address and size are determined by configuration: `CONFIG_FASTBOOT_BUF_ADDR`, `CONFIG_FASTBOOT_BUF_SIZE`.

- Video FB/U-Boot/Malloc/Board/Gd/Fdt/Sp is allocated from top to bottom based on actual requirement size;;
- 64-bit platforms: ATF is required for ARMv8, OP-TEE is optional; 32-bit platforms: only OP-TEE available
- kernel fdt/kernel/ramdisk is the address of the firmware that U-Boot needs to load, defined by `ENV_MEM_LAYOUT_SETTINGS`;
- The address and size of the buffer needed for Fastboot functionality is defined in defconfig;
- The space occupied by OP-TEE needs to be based on the actual demand, the maximum is 30M; where OP-TEE on RK1808/RK3308 is placed at the low address, not at 0x8400000;

2.6 Storage Layout

The storage layout of the RK linux program is as follows, and the Android program is basically the same except that the definition of boot/rootfs is different from that of the linux platform, which can be used for reference.

Partition	Start Sector		Number of Sectors		Partition Size		Requirements
MBR	0	00000000	1	00000001	512	0.5KB	
Primary GPT	1	00000001	63	0000003F	32256	31.5KB	
loader1	64	00000040	7104	00001bc0	4096000	2.5MB	preloader (miniloader or U-Boot SPL)
Vendor Storage	7168	00001c00	512	00000200	262144	256KB	SN, MAC and etc.
Reserved Space	7680	00001e00	384	00000180	196608	192KB	Not used
reserved1	8064	00001f80	128	00000080	65536	64KB	legacy DRM key
U-Boot ENV	8128	00001fc0	64	00000040	32768	32KB	
reserved2	8192	00002000	8192	00002000	4194304	4MB	legacy parameter
loader2	16384	00004000	8192	00002000	4194304	4MB	U-Boot or UEFI
trust	24576	00006000	8192	00002000	4194304	4MB	trusted-os like ATF, OP-TEE
boot (bootable must be set)	32768	00008000	229376	00038000	117440512	112MB	kernel, dtb, extlinux.conf, ramdisk
rootfs	262144	00040000	-	-	-	-MB	Linux system
Secondary GPT	16777183	00FFFFDF	33	00000021	16896	16.5KB	

Picture reference: http://opensource.rock-chips.com/wiki_Partitions

2.7 Aliases

There are some special aliases in U-Boot that differ from those defined in the kernel DTS.

eMMC/SD are collectively referred to as mmc devices in U-Boot, using numbers 0 and 1 for differentiation; SD has a higher boot priority than eMMC.

```
mmc1: indicates sd
mmc0: indicates emmc
```

2.8 AMP

U-Boot for RK platform supports AMP (Asymmetric Multi-Processing) firmware boot.

For more references please check Driver Modules section.

2.9 Atags

The booting process of the RK platform:

```
BOOTROM => ddr-bin => Miniloader => TRUST => U-BOOT => KERNEL
```

Some configuration information can be passed between the various levels of firmware on the RK platform via the ATAGS mechanism.

- Scope of application: ddr-bin, miniloader, trust, U-Boot, excluding Kernel
- Passed content: serial port configuration, storage type, memory occupied by ATF and OP-TEE, ddr capacity, etc.


Code implementation:

```
./arch/arm/include/asm/arch-rockchip/rk_atags.h  
./arch/arm/mach-rockchip/rk_atags.c
```

2.10 Bidram/Sysmem

U-Boot can use all the memory of the system, and reserve the memory needed by the system from the high address to the low address, after reserving the memory, there is usually still a large memory space left. U-Boot does not have a mechanism to manage this space, so the RK platform introduces the mechanism of bidram, sysmem memory block to manage this block of memory.

Thus, together with U-Boot's existing malloc management mechanism, the RK platform manages all system memory through sysmem + bidram + malloc, preventing problems such as memory conflicts.



- bidram: Manage memory blocks that are unavailable at u-boot and kernel stage and need to be eliminated, e.g. space occupied by ATF and OP-TEE.
- sysmem: Manages blocks of memory visible and available to the kernel. For example, the space occupied by fdt, ramdisk, kernel, and fastboot.

Related Code:

```
./lib/sysmem.c  
./lib/bidram.c  
./include/memblk.h  
./arch/arm/mach-rockchip/memblk.c
```

The following table shows the memory management information for bidram and sysmem, which is dumped when a block is initialized or allocated abnormally. The following is a brief description.

bidram memory information table:

```

bidram_dump_all:
-----
// <1> Here shows the total capacity information of the ddr that U-Boot got
from the previous loader, which is 2GB in total
memory.rgn[0].addr      = 0x00000000 - 0x80000000 (size: 0x80000000)

memory.total            = 0x80000000 (2048 MiB. 0 KiB)
-----
// <2> This shows information about the memory that has been set aside for
each firmware, which is invisible to the kernel.
reserved.rgn[0].name    = "ATF"
                      .addr = 0x00000000 - 0x00100000 (size: 0x00100000)
reserved.rgn[1].name    = "SHM"
                      .addr = 0x00100000 - 0x00200000 (size: 0x00100000)
reserved.rgn[2].name    = "OP-TEE"
                      .addr = 0x08400000 - 0x0a200000 (size: 0x01e00000)

reserved.total          = 0x02000000 (32 MiB. 0 KiB)
-----
// <3> Here is how the core algorithm organizes the reserved information for
<2> above, e.g., it will merge adjacent blocks
LMB.reserved[0].addr    = 0x00000000 - 0x00200000 (size: 0x00200000)
LMB.reserved[1].addr    = 0x08400000 - 0x0a200000 (size: 0x01e00000)

reserved.core.total     = 0x02000000 (32 MiB. 0 KiB)
-----

```

systemem memory information table::

```

systemem_dump_all:
-----
// <1> Here is the total amount of memory that systemem can manage, i.e., the
amount of available ddr, excluding bidram <3>, visible to the kernel.
memory.rgn[0].addr      = 0x00200000 - 0x08400000 (size: 0x08200000)
memory.rgn[1].addr      = 0x0a200000 - 0x80000000 (size: 0x75e00000)

memory.total            = 0x7e000000 (2016 MiB. 0 KiB)
-----
// <2> This shows information about the memory blocks allocated away by each
firmware
allocated.rgn[0].name    = "U-Boot"
                      .addr = 0x71dd6140 - 0x80000000 (size: 0x0e229ec0)
allocated.rgn[1].name    = "STACK"      <Overflow!> // Indicates stack overflow
                      .addr = 0x71bd6140 - 0x71dd6140 (size: 0x00200000)
allocated.rgn[2].name    = "FDT"
                      .addr = 0x08300000 - 0x08316204 (size: 0x00016204)
allocated.rgn[3].name    = "KERNEL"     <Overflow!> // Indicates a memory block
overflow
                      .addr = 0x00280000 - 0x014ce204 (size: 0x0124e204)
allocated.rgn[4].name    = "RAMDISK"
                      .addr = 0x0a200000 - 0x0a3e6804 (size: 0x001e6804)
// <3> size of malloc_r/f
malloc_r: 192 MiB, malloc_f: 16 KiB

allocated.total          = 0x0f874acc (248 MiB. 466 KiB)
-----

```

```
// <4> Here's the information that the core algorithm organizes for the above
<2>, showing information about occupied memory blocks
LMB.reserved[0].addr    = 0x00280000 - 0x014ce204 (size: 0x0124e204)
LMB.reserved[1].addr    = 0x08300000 - 0x08316204 (size: 0x00016204)
LMB.reserved[2].addr    = 0x0a200000 - 0x0a3e6804 (size: 0x001e6804)
LMB.reserved[3].addr    = 0x71bd6140 - 0x80000000 (size: 0x0e429ec0)

reserved.core.total     = 0x0f874acc (248 MiB. 466 KiB)
-----
```

The following are some common error printouts. When these exceptions occur, analyze them in conjunction with the bidram and system dump memory information above.

```
//The memory expected to be requested is already occupied by other firmware and
there is memory overlap. This indicates that the current system's memory block
usage is not planned properly
System Error: "KERNEL" (0x00200000 - 0x02200000) alloc is overlap with existence
"RAMDISK" (0x00100000 - 0x01200000)

// Memory expected to be requested could not be requested for some specific
reason (analyze system and bidram messages)
System Error: Failed to alloc "KERNEL" expect at 0x00200000 - 0x02200000 but at
0x00400000 - 0x0420000

// system manages space starting at 0x200000, so it simply can't claim space
starting at 0x100000
System Error: Failed to alloc "KERNEL" at 0x00100000 - 0x02200000

// Duplicate request for "RAMDISK" memory block.
System Error: Failed to double alloc for existence "RAMDISK"
```

2.11 Fuse/OTP

The RK platform enables secure-boot mode (without the need of downloading efuse/otp) by signing the firmware for easy debugging of secure-boot. Miniloader will append a cmdline to the kernel via U-Boot to indicate whether the current efuse/otp enabling has been downloaded or not:

- "fuse.programmed=1" : Secure-boot is enabled, efuse/otp is already downloaded.
- "fuse.programmed=0" : Secure-boot is enabled and efuse/otp has not been downloaded.
- No fuse.programmed in cmdline: secure-boot is not enabled (Miniloader doesn't pass), or Miniloader is too old to support passing.

U-Boot needs to include the following commits:

```
83c9bd4 board: rockchip: pass fuse programmed state to kernel
```

2.12 Hotkey

RK platform provides serial port key combination to trigger some events for debugging and downloading (if you can't trigger it, please try again; invalid when secure-boot is enabled). **when booting, long pressing :**

- ctrl+c: Enter U-Boot command line mode;

- ctrl+d: Enter loader mode;
- ctrl+b: Enter maskrom mode
- ctrl+f: Enter fastboot mode;
- ctrl+m: Print bidram/system information
- ctrl+i: Enabling kernel initcall_debug
- ctrl+p: Print cmdline information
- ctrl+s: “Starting kernel...” After that, enter U-Boot command line;

2.13 Image Decompress

- 64-bit machines usually download Image, which is loaded by U-Boot to the target running address. U-Boot for RK platforms can also support decompression of 64-bit LZ4 compressed kernels. However, to achieve that, the user must enable:

```
CONFIG_LZ4=y
```

The pre and post decompression addresses of the 64-bit LZ4 compression kernel must be defined in the `rkxxx_common.h` file for each platform:

```
#define ENV_MEM_LAYOUT_SETTINGS \
    "scriptaddr=0x00500000\0" \
    "pxefile_addr_r=0x00600000\0" \
    "fdt_addr_r=0x01f00000\0" \
    "kernel_addr_no_b132_r=0x00280000\0" \
    "kernel_addr_r=0x00680000\0" \           // Address of the LZ4 decompression
kernel
    "kernel_addr_c=0x02480000\0" \           // Address of the LZ4 compression
kernel
    "ramdisk_addr_r=0x04000000\0"
```

- 32-bit machines usually download zImage, which is loaded by U-Boot to the `kernel_addr_r` address, and then self-decompressed by the kernel. U-Boot for RK platforms can also support Image format, which is loaded by U-Boot to the target runtime address.

Currently the `rkxxx_common.h` file for each platform only defines the `kernel_addr_r` but not the `kernel_addr_c` address. Users don't need to change the configuration, cause U-Boot will determine whether it is currently zImage or Image, and process these 2 addresses dynamically. But user must disable:

```
CONFIG_SKIP_RELOCATE_UBOOT
```

32-bit kernel loading address definition.

```
#define ENV_MEM_LAYOUT_SETTINGS \
    "scriptaddr=0x60000000\0" \
    "pxefile_addr_r=0x60100000\0" \
    "fdt_addr_r=0x68300000\0" \
    "kernel_addr_r=0x62008000\0" \           // zImage compressed kernel address
    "ramdisk_addr_r=0x6a200000\0"
```

2.14 Image Kernel

U-Boot for the RK platform supports three formats of kernel firmware boot:

- RK format

The magic of the image file is “KRNL”:

```
00000000  4B 52 4E 4C  42 97 0F 00  1F 8B 08 00  00 00 00 00
KRNL..y.....
00000010  00 03 A4 BC  0B 78 53 55  D6 37 BE 4F  4E D2 A4 69
.....xSU.7.ON...i
```

kernel.img = kernel;

resource.img = dtb + logo.bmp + logo_kernel.bmp;

boot.img = ramdisk;

recovery.img = ramdisk(for recovery) ;

- Android format

The magic of the image file is “ANDROID!”:

```
00000000  41 4E 44 52  4F 49 44 21  24 10 74 00  00 80 40 60
ANDROID!$.t...@`
00000010  F9 31 CD 00  00 00 00 62  00 00 00 00  00 00 F0 60
.1.....b.....`
```

boot.img = kernel + ramdisk+ resource + <dtb>;

recovery.img = kernel + ramdisk(for recovery) + resource + <recovery_dtbo> + <dtb>;

Notes: recovery_dtbo: images added only since Android-9.0; dtb: images added only since Android-10.0;

- Distro format

One common firmware packaging format for open source Linux is to package ramdisk, dtb, and kernel into an image. This image usually exists in a certain file system format, such as ext2, ext4, fat, etc. U-Boot needs to access its contents through the file system. For more information, please refer to:

```
./doc/README.distro
./include/config_distro_defaults.h
./include/config_distro_bootcmd.h
```

- Boot priority: android > rk > distro, each type of firmware has a corresponding boot command, and the three commands will be executed one by one in order of priority until the firmware is booted up. If all commands fail, it stays in U-Boot command line mode.

Boot Priority Definition:

```
#define RKIMG_BOOTCOMMAND \
    "boot_android ${devtype} ${devnum};" \
    "bootrkp;" \
    "run distro_bootcmd;"
```

2.15 Image U-Boot

There are two firmware formats for U-Boot and trust for RK platforms: the RK and FIT formats are booted by Miniloader and SPL respectively. The current SDK released by Rockchip takes RV1126 as the separating point, platforms after RV1126 use FIT format, and platforms before RV1126 use RK format.

- RK format

Rockchip's customized firmware formats, U-Boot and trust are packaged as uboot.img and trust.img respectively. as follows:

The uboot.img and 32-bit trust.img images have the magic “LOADER”.

```
00000000  4c 4f 41 44 45 52 20 20 00 00 00 00 00 00 00 00 | LOADER
.....|
00000010  00 00 20 00 78 d0 0f 00 06 99 c2 a8 20 00 00 00 | ... .x.....
...|
00000020  09 8a b0 e1 89 7a c2 89 0d e8 da ef 86 3e f2 24
| .....z.....>.$|
```

The 64-bit trust.img image file has the magic “BL3X”.

```
00000000  42 4c 33 58 00 01 00 00 23 00 00 00 f8 00 04 00
| BL3X....#.....|
00000010  00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
| .....|
```

- FIT format

The U-Boot mainline supports an extremely flexible firmware format, with U-Boot, trust and mcu firmware packaged together as uboot.img.

The image file of uboot.img has the magic “d0 0d fe ed”, with the command fdt dump uboot.img you can view the firmware header.

```
00000000  d0 0d fe ed 00 00 06 00 00 00 00 58 00 00 04 c4
| .....X....|
00000010  00 00 00 28 00 00 00 11 00 00 00 10 00 00 00 00 | ...
(| .....|
```

For more references: please check FIT section.

- Backup Packaging

Usually, uboot.img and trust.img are packaged with multiple backups in order to cope with the possibility of firmware corruption due to power failure during the OTA upgrade process and so on.

Firmware	Size per copy	Number of copies
RK uboot.img	1MB	4
RK 32-bit trust.img	1MB	4
RK 64-bit trust.img	2MB	2
FIT uboot.img	2MB	2

As you can see from the table above, both uboot.img and trust.img are 4MB in size by default.

Methods for modifying the size for per copy and number of copies

- RK format: add parameters to the compiling command. For example: `-sz-uboot 2048 1` and `-sz-trust 4096 1`, means uboot.img single copy size is 2M, with 1 copy packaged; trust.img single copy size is 4M, with 1 copy packaged.
- FIT Format: change the configuration parameters: `CONFIG_SPL_FIT_IMAGE_KB` and `CONFIG_SPL_FIT_IMAGE_MULTIPLE`, which indicate the single copy size (in KB) and the number of packaged copies, respectively.

2.16 Interrupt

U-Boot's native code does not have full support for interrupts, and the RK platform improves this feature to support GIC-V2 and GIC-V3.

Please refer to Driver Modules section for more.

2.17 Kernel-DTB

Native U-Boot only supports the use of U-Boot's own DTB, RK platform adds support for kernel DTB mechanism, i.e., using kernel DTB to initialize peripherals. The main purpose is to be compatible with peripheral board-level differences, such as: power, clock, display and so on.

Role of the two:

- U-Boot DTB: Responsible for initializing devices such as devices for storing and printing serial ports;
- Kernel DTB: Responsible for initializing devices other than devices for storing and printing serial ports;

When U-Boot initializes, it first uses the U-Boot DTB to complete the storage and print serial port initialization, and then loads the Kernel DTB from the storage and turns to this DTB to continue to initialize the rest of the peripherals. The code for the Kernel DTB is implemented in the function: `init_kernel_dtb()`.

Developers generally do not need to modify the U-Boot DTB (unless the print serial port is replaced), the defconfig used in the SDKs released for each platform has the kernel DTB mechanism enabled. So usually for peripheral DTS modification, user should modify kernel DTB.

About U-Boot DTB:

DTS directory:

```
./arch/arm/dts/
```

After enabling the kernel DTB mechanism: the compilation phase will filter out the nodes with `u-boot,dm-pre-reloc` and `u-boot,dm-spl` attributes from the U-Boot DTS, and on top of that, it will exclude the property specified by the `CONFIG_OF_SPL_REMOVE_PROPS` from defconfig, and finally generate the u-boot.dtb file and append it to the end of the u-boot.bin.

Users can check the DTB content by `fdtdump` command after compiling U-Boot:

```
fdtdump ./u-boot.dtb | less
```

For more references: please check Advanced Principles section

2.18 MMU Cache

RK platform enables MMU, Dcache and Icache by default, MMU adopts 1:1 linear mapping, and Dcache adopts write-back policy. Related interfaces:

```
// Icache interface:
void icache_enable (void);
void icache_disable (void);
void invalidate_icache_all(void);

// Dcache interface:
void dcache_disable (void);
void dcache_enable(void);
void flush_dcache_range(unsigned long start, unsigned long stop);
void flush_cache(unsigned long start, unsigned long size);
void flush_dcache_all(void);
void invalidate_dcache_range(unsigned long start, unsigned long stop);
void invalidate_dcache_all(void);
// Remap the Dcache attributes of a block of memory intervals
void mmu_set_region_dcache_behaviour(phys_addr_t start, size_t size,
                                     enum dcache_option option)
```

2.19 Make.sh

make.sh is both a compilation script and a packaging and debugging tool, can be used to disassemble and package firmware.

```
// help command
./make.sh --help

// Functions of packaging firmware
./make.sh trust           // packaging trust
./make.sh loader          // packaging loader
./make.sh trust <ini-file> // Specify ini file when packaging trust
./make.sh loader <ini-file> // Specify ini file when packaging loader
./make.sh spl             // Replace ddr and miniloader with tpl+spl, and
packaged as loader
./make.sh spl-s           // Replace miniloader with spl, packaged as loader
./make.sh itb             // Packaging u-boot.itb (64-bit platforms only
support packaging ATF and U-Boot, OP-TEE does not)
./make.sh env             // Generate fw_printenv tool

// Disassembly Functions
./make.sh elf-[x] [type]  // Disassembly: Use the -[x] parameter, [type] to
select whether to disassemble SPL or TPL.
./make.sh elf            // Disassemble the u-boot file, using the -D
parameter by default.
./make.sh elf-S          // Disassemble the u-boot file, using the -S
parameter
./make.sh elf-d          // Disassemble the u-boot file, using the -d
parameter
./make.sh elf spl        // Disassemble the tpl/u-boot-tpl file, using the -D
parameter by default.
```

```

./make.sh elf tpl           // Disassemble the spl/u-boot-tpl file, use the -D
parameter by default
./make.sh <addr>           // Requires the function name and code location
corresponding to addr
./make.sh map              // open u-boot.map
./make.sh sym              // open u-boot.sym

```

2.20 HW-ID DTB

The U-Boot of the RK platform can filter the DTBs that match the hardware state from multiple DTB files to be loaded based on the hardware state of the GPIOs or ADCs.

For more reference: please check the System Modules section.

2.21 Partition Table

U-Boot for RK platform supports two kinds of partition table: RK parameter format (old) and standard GPT format (new), when there are two kinds of partition table on the machine, the GPT partition table is preferred. No matter it is GPT format or RK parameter format, when making downloading, the partition table file used is called parameter.txt, users can confirm whether it is GPT or not through the “TYPE: GPT” attribute.

```

FIRMWARE_VER:8.1
MACHINE_MODEL:RK3399
MACHINE_ID:007
MANUFACTURER: RK3399
MAGIC: 0x5041524B
ATAG: 0x00200800
MACHINE: 3399
CHECK_MASK: 0x80
PWR_HLD: 0,0,A,0,1
TYPE: GPT           // Partition table in GPT format is under using,
otherwise it is RK paramter format
CMDLINE:mtdparts=rk29xxnand:0x00002000@0x00004000 (uboot),0x00002000@0x00006000 (tr
ust),0
x00002000@0x00008000 (misc),0x00008000@0x0000a000 (resource),0x00010000@0x00012000 (
kernel
),0x00010000@0x00022000 (boot),0x00020000@0x00032000 (recovery),0x00038000@0x000520
00 (bac
kup),0x00002000@0x0008a000 (security),0x00100000@0x0008c000 (cache),0x00500000@0x00
18c000
(system),0x00008000@0x0068c000 (metadata),0x00100000@0x00694000 (vendor),0x00100000
@0x007
96000 (oem),0x00000400@0x00896000 (frp),-@0x00896400 (userdata:grow)

```

2.22 Relocation

U-Boot will relocate itself to an address at the end of memory after completing the board_f.c process, depending on the U-Boot memory layout. RK's U-Boot default:

- 32-bit platforms: `CONFIG_SKIP_RELOCATE_UBOOT=y` does not have relocation, otherwise it does.
- 64-bit platforms have relocation.

2.23 Reset

- U-Boot reset, like kernel, eventually needs to be done in trust.
- U-Boot command line mode can support the same reboot xxx commands as the kernel (depending on the definition in the kernel dts)

2.24 Sd/Udisk

U-Boot for RK platform supports firmware booting or upgrading from SD/U disk. Among them:

- SD booting/upgrading is supported from the bootrom level onwards
- USB flash drive booting/upgrading is supported from the U-Boot level onwards

For more reference: please check System Modules section.

2.25 Stacktrace

Native U-Boot does not support call stack traceback mechanism, however, RK platform added the function. Currently there are a total of 3 ways to trigger call stack printing:

- Automatically triggered when the system crashes;
- User-initiated call to `dump_stack()`;
- Enable `CONFIG_ROCKCHIP_DEBUGGER`;

For example, system abort:

```
"Synchronous Abort" handler, esr 0x96000010

// abort reason, pc, lr, sp
* Reason:      Exception from a Data abort, from current exception level
* PC           = 000000000028f430
* LR           = 00000000002608d0
* SP           = 00000000f3dceb30

...

// Highlighting PC and LR
Call trace:
PC:    [< 0028f430 >]
LR:    [< 002608d0 >]

// Function call relationships
Stack:
    [< 0028f430 >]
    [< 0028da24 >]
    [< 00211600 >]
    [< 002117b0 >]
    [< 00202910 >]
    [< 00202aa8 >]
    [< 0027698c >]
    [< 002151ec >]
    [< 00201b2c >]
```

```
// Instructs the user to convert the above call stack information
Copy info from "Call trace..." to a file(eg. dump.txt), and run
command in your U-Boot project: ./scripts/stacktrace.sh dump.txt
```

According to the above instructions, the user copies the call stack information to any txt file (such as dump.txt) and executes the following command:

```
cjh@Ubuntu:~/u-boot$ ./scripts/stacktrace.sh dump.txt

// Symbol Table Sources
SYMBOL File: ./u-boot.sym

// Highlight the code locations corresponding to PC and LR
Call trace:
PC:    [< 0028f430 >] strncpy+0xc/0x20      ./lib/string.c:98
LR:    [< 002608d0 >] on_serialno+0x10/0x1c ./drivers/usb/gadget/g_dnl.c:217

// Converted to get the real function name
Stack:
    [< 0028f430 >] strncpy+0xc/0x20
    [< 0028da24 >] hdelete_r+0xcc/0xf0
    [< 00211600 >] _do_env_set.isra.0+0x70/0x1b8
    [< 002117b0 >] env_set+0x3c/0x58
    [< 00202910 >] rockchip_set_serialno+0x54/0x140
    [< 00202aa8 >] board_late_init+0x5c/0xa0
    [< 0027698c >] initcall_run_list+0x58/0x94
    [< 002151ec >] board_init_r+0x20/0x24
    [< 00201b2c >] relocation_return+0x4/0x0
```

Notes:

- There are three types of conversion commands, please follow the instructions after the call stack printout to determine which one to use

```
./scripts/stacktrace.sh ./dump.txt      // Parsing Call Stack Information
from U-Boot
./scripts/stacktrace.sh ./dump.txt tpl   // Parsing call stack information
from tpl
./scripts/stacktrace.sh ./dump.txt spl   // Parsing call stack information
from spl
```

When executing this command, **the firmware on the current machine must match the current code environment to be meaningful!** Otherwise you will get an incorrect conversion.

2.26 TimeCost

The end of U-Boot initialization prints the total elapsed time for this phase by default:

```

### Booting Android Image at 0x02007800 ...
Kernel load addr 0x02008000 size 8062 KiB
### Flattened Device Tree blob at 08300000
   Booting using the fdt blob at 0x8300000
   XIP Kernel Image ... OK
   'reserved-memory' dma-unusable@fe000000: addr=fe000000 size=1000000
   'reserved-memory' ramoops@00000000: addr=8000000 size=f0000
   Using Device Tree in place at 08300000, end 08316ed1
Adding bank: 0x00000000 - 0x08400000 (size: 0x08400000)
Adding bank: 0x09200000 - 0x80000000 (size: 0x76e00000)
Total: 812.613 ms    //Total elapsed time for the U-Boot phase

Starting kernel ...

```

The user can open `debug()` and `DEBUG` in `lib/initcall.c` to get the following process timings, the function addresses can be obtained with the help of `./make.sh` for disassembly.

```

U-Boot 2017.09-00019-g9b55ed0-dirty (Dec 26 2019 - 14:45:33 +0800)

                                     #    5212 us # 137.868 ms
initcall: 0020delf
                                     #          1 us # 142.636 ms
initcall: 0020e015
Model: Evb-RK3288
                                     #    1646 us # 149. 48 ms
initcall: 0020dd61
PreSerial: 2
                                     #    1213 us # 155. 28 ms
initcall: 0020ddcd
DRAM:
                                     #     606 us # 160.401 ms
initcall: 00203719
           // The following 187 us is the time consumed by initcall: 00203719
call
           // The following 165.355 ms is the U-Boot boot time until initcall:
00203719
                                     #    187 us # 165.355 ms
initcall: 0020de81
                                     #          2 us # 169.938 ms
initcall: 0020dc29
                                     #          1 us # 174.703 ms
initcall: 0020dc3d
                                     #          1 us # 179.469 ms
initcall: 0020ddad
                                     #          2 us # 184.237 ms
initcall: 0020de27
                                     #          1 us # 189.  2 ms
.....

```

2.27 TimeStamp

Kernel's print message has a timestamp by default, which is convenient for users to pay attention to the time. U-Boot's print message doesn't have a timestamp by default, users can enable the configuration

`CONFIG_BOOTSTAGE_PRINTF_TIMESTAMP` if necessary.

```
[ 0.324987] U-Boot 2017.09-00019-g9b55ed0-dirty (Dec 26 2019 - 14:31:44 +0800)

[ 0.327215] Model: Evb-RK3288
[ 0.330039] PreSerial: 2
[ 0.332526] DRAM: 2 GiB
[ 0.336454] Relocation Offset: 00000000, fdt: 7be22c38
[ 0.346981] Using default environment

[ 0.351075] dwmmc@ff0c0000: 1, dwmmc@ff0f0000: 0
[ 0.394136] Bootdev(atags): mmc 0
[ 0.394272] MMC0: High Speed, 52Mhz
[ 0.395276] PartType: EFI
[ 0.400347] Android 9.0, Build 2019.6
[ 0.402070] boot mode: None
[ 0.405213] Found DTB in boot part
[ 0.407833] DTB: rk-kernel.dtb
[ 0.418211] ANDROID: fdt overlay OK
[ 0.432128] I2c0 speed: 400000Hz
[ 0.435916] PMIC: RK808
[ 0.439113] vdd_arm 1100000 uV
[ 0.444148] vdd_gpu 1100000 uV
.....

[ 1.005018] ## Booting Android Image at 0x02007800 ...
[ 1.009917] Kernel load addr 0x02008000 size 8062 KiB
[ 1.014981] ## Flattened Device Tree blob at 08300000
[ 1.019970] Booting using the fdt blob at 0x8300000
[ 1.025185] XIP Kernel Image ... OK
[ 1.035469] 'reserved-memory' dma-unusable@fe000000: addr=fe000000
size=1000000
[ 1.037448] 'reserved-memory' ramoops@00000000: addr=8000000 size=f0000
[ 1.044412] Using Device Tree in place at 08300000, end 08316ed1
[ 1.064363] Adding bank: 0x00000000 - 0x08400000 (size: 0x08400000)
[ 1.064976] Adding bank: 0x09200000 - 0x80000000 (size: 0x76e00000)
[ 1.075259] Total: 812.613 ms

[ 1.075279] Starting kernel ...
.....:
```

Notes: The timestamp prints relative time, not absolute time.

2.28 Vendor Storage

The U-Boot of RK platform provides a Vendor storage area for users to save SN, MAC and other information. The storage offset is as follows (see vendor.c for details):

```
#define EMMC_VENDOR_PART_OFFSET      (1024 * 7)
/* --- Spi Nand/SLC/MLC large capacity case define --- */
#define NAND_VENDOR_PART_OFFSET      0
/* --- Spi/Spi Nand/SLC/MLC small capacity case define --- */
#define FLASH_VENDOR_PART_OFFSET      8
.....
```

Users generally do not need to concern themselves with and modify storage offsets, only with the read and write interfaces:

```
int vendor_storage_read(u16 id, void *pbuf, u16 size)
int vendor_storage_write(u16 id, void *pbuf, u16 size)
```

3. Chapter-3 Compile and Download

3.1 Preparations

- Download rkbin

Rkbin is a toolkit repository for RK's non-open-source bin, script, and packaging tools. U-Boot compiles from this repository and indexes the relevant files to package the loader, trust, and uboot firmware. Rkbin and the U-Boot project must be kept in the same directory-level.

rkbin downloading: please refer to the Appendix.

- Download GCC

The GCC compiler uses gcc-linaro-6.3.1 and is placed in the prebuilts directory. The prebuilts and U-Boot shall maintain a sibling directory relationship.

```
// 32-bit:
prebuilts/gcc/linux-x86/arm/gcc-linaro-6.3.1-2017.05-x86_64_arm-linux-
gnueabihf
// 64-bit:
prebuilts/gcc/linux-x86/aarch64/gcc-linaro-6.3.1-2017.05-x86_64_aarch64-
linux-gnu/
```

GCC downloading: please refer to the Appendix section

- select defconfig: **Please refer to the Platform Definition section.**
- config fragment introduction

Due to the differentiated needs of products on a single platform, a defconfig can no longer satisfy. So from RV1126 onwards, we support config fragment, i.e. overlaying the defconfig.

For example, if `CONFIG_BASE_DEFCONFIG="rv1126_defconfig"` is specified in `rv1126-emmc-tb.config`, when the `./make.sh rv1126-emmc-tb` command is executed, it will first generate the `.config` with `rv1126_defconfig`, and then overlay the `.config` with the configuration in `rv1126-emmc-tb.config`. This command is equivalent to:

```
make rv1126_defconfig rv1126-emmc-tb.config && make
```

To make updates to the config fragment file, simply resort to `./scripts/sync-fragment.sh`.

Example:

```
./scripts/sync-fragment.sh configs/rv1126-emmc-tb.config
```

Command effect: diff the configuration difference entries of the current `.config` and `rv1126_defconfig` into the `rv1126-emmc-tb.config` file.

3.2 Firmware Compiling

Compiling command:

```
./make.sh [board] // [board]: configs/[board]_defconfig file.
```

First- time compilation: Regardless of 32-bit or 64-bit platforms, the first time you specify defconfig or want to re-specify defconfig, the compiling command must specify [board]. Example:

```
./make.sh rk3399 // build for rk3399_defconfig
./make.sh evb-rk3399 // build for evb-rk3399_defconfig
./make.sh firefly-rk3288 // build for firefly-rk3288_defconfig
```

Secondary compilation: Regardless of 32-bit or 64-bit platforms, if you want to compile based on the current “.config”, you don't need to specify [board] in the compiling command.:

```
./make.sh
```

Note: If the compilation fails due to strange problems during compilation, try `make distclean` and recompile.

Firmware generation: When the compilation is complete, the following information is generated in the U-Boot root directory: trust, uboot, loader.:

```
// compile...
....

// uboot packaging process
load addr is 0x60000000!
pack input u-boot.bin
pack file size: 478737
crc = 0x840f163c
uboot version: v2017.12 Dec 11 2017
pack uboot.img success!
pack uboot okay! Input: u-boot.bin

// loader packaging process and the referenced ini file
out:rk3126_loader_v2.09.247.bin
fix opt:rk3126_loader_v2.09.247.bin
merge success(rk3126_loader_v2.09.247.bin)
pack loader okay! Input: /home/cjh/rkbin/RKBOOT/RK3126MINIALL.ini

// trust packaging process and the referenced ini file
load addr is 0x68400000!
pack file size: 602104
crc = 0x9c178803
trustos version: Trust os
pack ./trust.img success!
trust.img with ta is ready
pack trust okay! Input: /home/cjh/rkbin/RKTRUST/RK3126TOS.ini

// Prompts for a successful compilation. Note: This is prompted even if the above
trust and loader packaging fails, indicating that at least uboot.img was
generated
```

```
Platform RK3126 is build OK, with new .config(make rk3126_defconfig)
```

Eventually, downloadable firmware is generated in the root directory:

```
./uboot.img  
./trust.img    // Note: If the firmware is in fit format, there is no trust.img.  
the trust binary is packed in uboot.img.  
./rk3126_loader_v2.09.247.bin
```

Firmware packaging tool: Please refer to the Tools section.

3.3 Firmware Downloading

Downloading tool**:

The firmware downloading tool for Windows/Linux is recommended to use the tool version released by the SDK or the latest version.

Downloading mode:

The RK platform has a total of two downloading modes: Maskrom mode and Loader mode (U-Boot).

(1) How to enter Loader mode:

- When powering on, long press Volume + button
- When powering on, the host computer long presses ctrl+d at the same time
- U-Boot command line input: download or rockusb 0 \$devtype \$devnum

(2) How to enter Maskrom mode:

- When powering on, the host computer long presses ctrl+b at the same time.
- U-Boot command line input: rbrom

Notes:

- Currently U-Boot supports two types of partition tables: RK parameter (old) and GPT (new). If you want to replace the current partition table with another partition table type, the Nand machine must be rewritten/redownloaded with the whole firmware; eMMC machine can support replacing the partition table individually.
- If both partition tables exist on the machine, the GPT partition table is recognized first. This can be confirmed by a boot message:

```
...  
PartType: EFI // Currently it is the GPT partitioned table, otherwise print  
"PartType: RKPARM".  
...
```

3.4 Firmware Size

Please refer to section: RK Architecture => U-Boot Firmware.

3.5 Special Packaging

In addition to compiling code, `./make.sh` integrates firmware packaging function with providing some additional standalone packaging commands for developers to use. However, the prerequisite for that is the U-Boot has already been compiled once.

Non-FIT format:

```
./make.sh trust           // package trust
./make.sh loader          // package loader
./make.sh trust <ini-file> // Specify the ini file when packaging trust,
otherwise use the default ini file
./make.sh loader <ini-file> // Specify the ini file when packing the loader.
Otherwise, use the default ini file
```

FIT format:

```
// old script:
./make.sh spl           // Replace ddr and miniloader with tpl+spl and
package them into loader
./make.sh spl-s         // Replace the miniloader with spl and package it
into loader

// new script:
./make.sh --spl         // Replace the miniloader with spl and package it
into loader
./make.sh --tpl         // Replace ddr with tpl and package it into loader
./make.sh --tpl --spl   // Replace ddr and miniloader with tpl and spl and
package them into loader
./make.sh --spl-new     // ./make.sh--spl command do packages but not
compile. This command recompiles and repackages.
```

How to identify old and new scripts? If the new command is in effect, `make.sh` is the new script.

4. Chapter-4 System Module

4.1 AArch32

ARMv8's 64-bit chips support degradation from AArch64 to AArch32 mode (compatible with ARMv7), the code must be compiled in 32-bit.

Users can use this macro to confirm whether the current mode is AArch32 of ARMv8:

```
CONFIG_ARM64_BOOT_AARCH32=y
```

4.2 ANDROID AB

The so-called A/B System divides the system firmware into two parts, called slot-a and slot-b respectively. The system can be booted from any slot, and when one slot fails, it can also be booted from the other slot. Also, when upgrading, it can be directly copied to the other slot without entering the system upgrade mode. Please refer to the Advanced Principles section for detailed principles and procedures.

The current RK platform's pre-loader and U-Boot can support A/B systems.

4.2.1 Configuration Item

The A/B System depends on LIBAVB as follows

```
// A/B dependent libraries
CONFIG_AVB_LIBAVB=y
CONFIG_AVB_LIBAVB_AB=y
CONFIG_AVB_LIBAVB_ATX=y
CONFIG_AVB_LIBAVB_USER=y
CONFIG_RK_AVB_LIBAVB_USER=y
// Enable A/B function
CONFIG_ANDROID_AB=y
```

4.2.2 Partition Table

The A/B System has requirements for the partition table: partitions that need to support A/B must have the suffixes `_a` and `_b` added. Parameter.txt is referenced below:

```

FIRMWARE_VER:8.1
MACHINE_MODEL:RK3326
MACHINE_ID:007
MANUFACTURER: RK3326
MAGIC: 0x5041524B
ATAG: 0x00200800
MACHINE: 3326
CHECK_MASK: 0x80
PWR_HLD: 0,0,A,0,1
TYPE: GPT
CMDLINE:
mtdparts=rk29xxnand:0x00002000@0x00004000(uboot_a),0x00002000@0x00006000(uboot_b)
,0x00002000@0x00008000(trust_a),0x00002000@0x0000a000(trust_b),0x00001000@0x0000c
000(misc),0x00001000@0x0000d000(vbmeta_a),0x00001000@0x0000e000(vbmeta_b),0x00020
000@0x0000e000(boot_a),0x00020000@0x0002e000(boot_b),0x00100000@0x0004e000(system
_a),0x00300000@0x0032e000(system_b),0x00100000@0x0062e000(vendor_a),0x00100000@0x
0072e000(vendor_b),0x00002000@0x0082e000(oem_a),0x00002000@0x00830000(oem_b),0x00
100000@0x00832000(factory),0x00008000@0x842000(factory_bootloader),0x00080000@0x00
8ca000(oem),-@0x0094a000(userdata)

```

4.2.3 Notes

With the old U-Boot enabled A/B system, if the user accesses a partition with a/b, the partition name passed to `part_get_info_by_name()` must have a slot suffix, e.g. `"boot_a"` or `"boot_b"`. This adds a lot of redundant code: the user must first get the current system's slot, then do string splicing to get the partition name.

The new code optimizes this issue. If the user's version of the code is after the commit point below, the partition a/b can be accessed with or without a slot suffix, and the framework layer automatically detects which slot is currently used by the system. e.g. `"boot"` can be used directly in the above case.

```

commit c6666740ee3b51c3e102bfbaf1ab95b78df29246
Author: Joseph Chen <chenjh@rock-chips.com>
Date: Thu Oct 24 15:48:46 2019 +0800

    common: android/rkim: remove/clean android a/b (slot) code

    - the partition disk layer takes over the responsibility of slot suffix
      appending, we remove relative code to make file clean;
    - put android a/b code together and name them to be easy understood,
      this makes file easy to read.

Change-Id: Id8c838da682ce6098bd7192d7d7c64269f4e86ba
Signed-off-by: Joseph Chen <chenjh@rock-chips.com>

```

4.3 ANDROID BCB

BCB (Bootloader Control Block) is a mechanism designed for Android to control the boot process and to interact with the bootloader. The data structure is defined in the misc partition offset 16KB or 0 position.

data structure:

```

struct android_bootloader_message {

```

```

char command[32];
char status[32];
char recovery[768];

/* The 'recovery' field used to be 1024 bytes. It has only ever
 * been used to store the recovery command line, so 768 bytes
 * should be plenty. We carve off the last 256 bytes to store the
 * stage string (for multistage packages) and possible future
 * expansion. */
char stage[32];

/* The 'reserved' field used to be 224 bytes when it was initially
 * carved off from the 1024-byte recovery field. Bump it up to
 * 1184-byte so that the entire bootloader_message struct rounds up
 * to 2048-byte. */
char reserved[1184];
};

```

command: boot command, currently supports the following three:

Parameters	Functionality
bootonce-bootloader	Boot to entry U-Boot fastboot
boot-recovery	Boot to entry recovery
boot-fastboot	Boot to entry recovery fastboot (fastbootd)

recovery: the incidental command to enter recovery mode, it starts with “recovery\n” and can be followed by multiple parameters, starting with “--” and ending with “\n”, for example, “recovery\n--wipe_ab\n--wipe_package_size=345\n--reason=wipePackage\n”:

Parameters	Functionality
update_package	OTA upgrade
retry_count	the number of times to enter recovery upgrade, such as accidental power down during upgrade, based on this value to re-enter recovery upgrade.
wipe_data	erase user data (and cache), then reboot
wipe_cache	wipe cache (but not user data), then reboot
show_text	show the recovery text menu, used by some bootloader
sideload	
sideload_auto_reboot	an option only available in user-debug build, reboot the device without waiting
just_exit	do nothing, exit and reboot
locale	save the locale to cache, then recovery will load locale from cache when reboot
shutdown_after	return shutdown
wipe_all	Erase the entire userdata partition
wipe_ab	wipe the current A/B device, with a secure wipe of all the partitions in RECOVERY_WIPE
wipe_package_size	wipe package size
prompt_and_wipe_data	prompt the user that data is corrupt, with their consent erase user data (and cache), then reboot
fw_update	SD Card Firmware Upgrade
factory_mode	Factory mode, mainly used to do some device testing, such as PCBA testing
pcba_test	Access to PCBA Testing
resize_partition	Resizing partitions, dynamic partitioning support in android Q
rk_fwupdate	Specify rk SD/USB firmware upgrade, applicable scope limited to U-Boot

Generally, during U-Boot phase, it is no need to use and care about the above parameters, only for reference for users .

4.4 AVB Secure Boot

Android Verified Boot(AVB), a set of firmware verification process designed by Google, mainly used to verify the boot system and other firmware. Rockchip Secure Boot achieve a complete set of Secure Boot verification program with reference to verification method and AVB in communication .

4.4.1 Feature

- safety check
- integrity check
- anti-rollback protection
- persistent partition support
- chained partitions support, can be consistent with boot, system signing private key, or oem can save private key by itself, but must be signed by PRK.

4.4.2 Configuration

Enabling AVB requires trust support:

```
CONFIG_OPTEE_CLIENT=y
CONFIG_OPTEE_V1=y
CONFIG_OPTEE_ALWAYS_USE_SECURITY_PARTITION=y //Security data is stored in the
security partition
```

- `CONFIG_OPTEE_V1` : suitable for platforms with 312x,322x,3288,3228H,3368,3399。
- `CONFIG_OPTEE_V2` : suitable for platforms with 3326,3308。
- `CONFIG_OPTEE_ALWAYS_USE_SECURITY_PARTITION` : This macro is only enabled when eMMC's rpmb is not working, it is not enabled by default.

Enables AVB-related configuration:

```
CONFIG_AVB_LIBAVB=y
CONFIG_AVB_LIBAVB_AB=y
CONFIG_AVB_LIBAVB_ATX=y
CONFIG_AVB_LIBAVB_USER=y
CONFIG_RK_AVB_LIBAVB_USER=y
// The above options are mandatory, the following options support AVB and A/B
features, the two features can be used separately.
CONFIG_ANDROID_AB=y //This supports A/B
CONFIG_ANDROID_AVB=y //This supports A/B
// The following macros are for efuse-only platforms
CONFIG_ROCKCHIP_PRELOADER_PUB_KEY=y
// The following macros need to be turned on for strict unlock checksums
CONFIG_RK_AVB_LIBAVB_ENABLE_ATH_UNLOCK=y
// Enable Security check
CONFIG_AVB_VBMETA_PUBLIC_KEY_VALIDATE=y
// If you need the cpuid as a challenge number, enable the following macro
CONFIG_MISC=y
CONFIG_ROCKCHIP_EFUSE=y
CONFIG_ROCKCHIP_OTP=y
```

4.4.3 Reference

Because AVB involves more content, please refer to the Advanced Principles sector for the rest of the principles and configurations.

4.5 Cmdline

The cmdline is an important means for U-Boot to pass parameters to the kernel, such as boot storage, device status, etc. Currently, there are several sources of cmdlines, which are spliced by U-Boot and filtered for duplicates before being passed to the kernel. cmdlines from the U-Boot phase are stored in the `bootargs` environment variable.

U-Boot ultimately implements cmdline passing via `/chosen/bootargs` in the modified kernel DTB.

4.5.1 Data Sources

- `parameter.txt`

If the partition table is in RK format, you can store the cmdline information in `parameter.txt`, for example:

```
CMDLINE: console=ttyFIQ0 androidboot.baseband=N/A
androidboot.selinux=permissive androidboot.hardware=rk30board
androidboot.console=ttyFIQ0 init=/init
mtdparts=rk29xxnand:0x00002000@0x00002000 (uboot),0x00002000@0x00004000 (trust)
,
```

If the partition table is in GPT format, it is not valid to store cmdline information in `parameter.txt`.

- `/chosen/bootargs` of kernel dts , e.g.

```
chosen {
    bootargs = "earlyprintk=uart8250,mmio32,0xff30000 swiotlb=1
console=ttyFIQ0
                androidboot.baseband=N/A androidboot.veritymode=enforcing
                androidboot.hardware=rk30board androidboot.console=ttyFIQ0
                init=/init kpti=0";
};
```

- U-Boot: Depending on the current running state, U-Boot will dynamically append something to the cmdline. for example:

```
storagemedia=emmc androidboot.mode=emmc .....
```

- The ones in the `boot/recovery.img` firmware header usually have the cmdline field information as well.

4.5.2 Data Meaning

The following is a list of cmdline parameters that are commonly used on the RK platform. For more information, please refer to the kernel documentation: `Documentation/admin-guide/kernel-parameters.txt`.

- `sdfwupdate`: sd upgrade card logo, required by the recovery program ;
- `root=PARTUUID`: Specify the UUID of the rootfs(system) partition, supported only by the GPT table
- `skip_initramfs`: kernel uses the ramdisk in rootfs(system) but not the ramdisk loaded by uboot,
- `storagemedia`: Storage boot type;
- `console`: kernel print port configuration information

- earlycon: Specify the serial port and its configuration before the serial node is created
- loop.max_part: max_part is used to set the number of partitions that can be supported by each loop's device.
- rootwait: \ Used in cases where the file system is not immediately available, for example, emmc initialization is not complete, if you do not set root_wait at this time, mount rootfs failed, but if you add this parameter, you can wait for the driver to finish loading, then copy the rootfs from the storage device and mount it again, then it will not prompt the Failed
- ro/rw: Load rootfs attributes, read-only/read-write
- firmware_calss.path: Specify driver location, e.g. wifi, bt, gpu, etc.
- dm="lroot none 0, 0 4096 linear 98:3 0, 4096 4096 linear 98:32" root=/dev/dm-0: Will boot to a rw dm-linear target of 8192 sectors split across two block devices identified by their major:minor numbers. After boot, udev will rename this target to /dev/mapper/lroot (depending on the rules). No uuid was assigned. please refer to <https://android.googlesource.com/kernel/common/+android-3.18/Documentation/device-mapper/boot.txt>>
- androidboot.slot_suffix: Specify a slot for the kernel to boot from during AB System.
- androidboot.serialno: Provide serial numbers for the kernel and upper layers, e.g. adb's serial number, etc.
- androidboot.verifiedbootstate: Android requirements, which provide the upper layers with the state of the uboot verification firmware, it has three states, as follows
 1. green: If in LOCKED state and the key used for verification was not set by the end user
 2. yellow: If in LOCKED state and the key used for verification was set by the end user
 3. orange: If in the UNLOCKED state
- androidboot.hardware: boot the device, e.g. rk30board
- androidboot.verifymode: Specify the true mode/state of the verification partition (i.e., verify the integrity of the firmware)
- androidboot.selinux: SELinux is a mandatory access control (MAC) security system based on the domain-type model There are three models:
 1. enforcing: enforcing mode, meaning that SELinux is running and has started restricting the domain/type correctly.
 2. permissive: Tolerant Mode: This means that SELinux is running, but only warning messages will be displayed without actually restricting access to the domain/type. This mode can be used for debugging SELinux.
 3. disabled: Shutdown, SELinux does not actually work!
- androidboot.mode: Android boot method: normal and charger.
 1. normal: Normal boot up
 2. charger: After powering off and on, androidboot.mode is set to charger, which is set to the bootargs environment variable by uboot after detecting power charging.
- androidboot.wificountrycode: Set wifi country code, e.g. US, CN
- androidboot.baseband: Configure baseband, RK does not have this feature, set to N/A
- androidboot.console: android message output port configuration
- androidboot.vbmeta.device=PARTUUID: Specify the location of vbmeta in the storage
- androidboot.vbmeta.hash_alg: Set the vbmeta hash algorithm, e.g. sha512
- androidboot.vbmeta.size: Specify the size of the vbmeta
- androidboot.vbmeta.digest: Upload a digest of the vbmeta to the kernel, the kernel loads the vbmeta, calculates the digest, and compares it to this digest
- androidboot.vbmeta.device_state: avb2.0 specifying system lock and unlock

4.6 DFU Update Firmware

DFU is Device Firmware Update, which is used to update the firmware of the device. For the platforms that supporting DFU **Please refer to the Platform Definition section.**

To enable the DFU feature, the macros that need to be enabled include:

```
CONFIG_CMD_DFU=y
CONFIG_USB_FUNCTION_DFU=y
```

Depending on the storage media used, you can choose to turn on the following switches

```
CONFIG_DFU_MMC
CONFIG_DFU_MTD
CONFIG_DFU_NAND
CONFIG_DFU_RAM
CONFIG_DFU_SF
```


Platforms that support DFU usually provide a separate config file, for example, compiling the RV1126 firmware with DFU support can be done by executing the following compile command

```
./make.sh rv1126-dfu
```

Download the firmware into the development board and connect the OTG connector to the PC, execute the following in the U-Boot command line

```
dfu 0 $devtype $devnum
```

where devtype can be mmc or mtd, at this point you will find a USB download gadget device on your PC, use Zadig to replace the device driver, the screenshot after successful replacement is as follows



Execute the followings from the Windows command line using the host computer software

```
./dfu-util.exe -l
```

At this point the device will upload the partition table, which is defined in

```
include/configs/evb_rv1126.h.
```

```
F:\Prj\20210901-Hisense-AB\dfu-util-0.9-win64>dfu-util.exe -l
dfu-util 0.9

Copyright 2005-2009 Weston Schmidt, Harald Welte and OpenMoko Inc.
Copyright 2010-2016 Tormod Volden and Stefan Schmidt
This program is Free Software and has ABSOLUTELY NO WARRANTY
Please report bugs to http://sourceforge.net/p/dfu-util/tickets/

Found DFU: [2207:0107] ver=0223, devnum=16, cfg=1, intf=0, path="1-12", alt=5,
name="userdata", serial="UNKNOWN"
Found DFU: [2207:0107] ver=0223, devnum=16, cfg=1, intf=0, path="1-12", alt=4,
name="rootfs", serial="UNKNOWN"
Found DFU: [2207:0107] ver=0223, devnum=16, cfg=1, intf=0, path="1-12", alt=3,
name="boot", serial="UNKNOWN"
Found DFU: [2207:0107] ver=0223, devnum=16, cfg=1, intf=0, path="1-12", alt=2,
name="uboot", serial="UNKNOWN"
Found DFU: [2207:0107] ver=0223, devnum=16, cfg=1, intf=0, path="1-12", alt=1,
name="loader", serial="UNKNOWN"
Found DFU: [2207:0107] ver=0223, devnum=16, cfg=1, intf=0, path="1-12", alt=0,
name="gpt", serial="UNKNOWN"
```

The Windows command line executes the following command to transfer files to the development board in the command line format

dfu-util.exe VID:PID -a (partition name) -D (file name) -R (reboot option)

```
F:\Prj\20210901-Hisense-AB\dfu-util-0.9-win64>dfu-util.exe -d 2207:0107 -a
system_b -D rootfs.img -R
```

The log of a successful download is as follows

```
dfu-util 0.9

Copyright 2005-2009 Weston Schmidt, Harald Welte and OpenMoko Inc.
Copyright 2010-2016 Tormod Volden and Stefan Schmidt
This program is Free Software and has ABSOLUTELY NO WARRANTY
Please report bugs to http://sourceforge.net/p/dfu-util/tickets/

Invalid DFU suffix signature
A valid DFU suffix will be required in a future dfu-util release!!!
Opening DFU capable USB device...
ID 2207:0107
Run-time device DFU version 0110
Claiming USB DFU Interface...
Setting Alternate Setting #8 ...
Determining device status: state = dfuIDLE, status = 0
dfuIDLE, continuing
DFU mode device DFU version 0110
Device returned transfer size 4096
Copying data from PC to DFU device
Download      [=====] 100%      49938432 bytes
Download done.
state(7) = dfuMANIFEST, status(0) = No error condition is present
state(2) = dfuIDLE, status(0) = No error condition is present
Done!
can't detach
```

If you need to download other partitions, you only need to replace the partition name after the `-a` option of the download command and the file name after the `-D` option; the `-R` parameter appended to the download command indicates that the board will be rebooted after the download is completed.

4.7 DTBO/DTO

In order to facilitate the user's understanding of the contents of this chapter, here we recommend you first read the Appendix Section to recognize the terminology: DTB, DTBO, DTC, DTO, DTS, FDT.

The relationship between them can be described as:

- DTS is the file used to describe the FDT;
- DTS is compiled by DTC, can generate DTB/DTBO;
- DTB and DTBO can be combined into a new DTB through a DTO operation;

Usually, many users are used to replace the action meaning of the word “DTO” with “DTBO”. In the following, to avoid this mixing concepts, we make it clear that DTO is a verb concept, which stands for operation; while DTBO is a noun concept, which refers to the number of dtb, indicating aggregation.

More knowledge of this chapter can be found at : <https://source.android.google.cn/devices/architecture/dto>。

4.7.1 Principle Introduction

DTO (Devicie Tree Overlay) is a mandatory feature introduced with Android P that allows a secondary device tree Blob (DTBO) to be overlayed on top of an existing primary device tree Blob. DTO maintains the system-on-chip SoC device tree and dynamically overlays device-specific device trees to add nodes to the tree and make changes to properties in the existing tree.

The Primary Device Tree Blob (*.dtb) is usually provided by the Vendor, while the Secondary Device Tree Blob (*.dtbo) can be provided by ODM/OEM, etc., and finally merged by the bootloader before passing to the kernel. as shown in the figure below:




Image from: <https://source.android.google.cn/devices/architecture/dto>

Note: The compilation of DTB and DTBO for DTO operations is different from the normal DTB compilation, and there is a special syntax difference:

When compiling .dts with dtc, you must add the option `-@` to add the `_symbols_` node to the resulting .dtbo. The `_symbols_` node contains a list of all nodes with labels that the DTO library can use the list as a reference. The following is an example:

1. Sample commands for compiling the main .dts:

```
dtc -@ -O dtb -o my_main_dt.dtb my_main_dt.dts
```

2. Sample commands for compiling the overlay DT .dts:

```
dtc -@ -O dtb -o my_overlay_dt.dtbo my_overlay_dt.dts
```

4.7.2 Enable DTO

1. Configuration Enable::

```
CONFIG_CMD_DTIMG=y
CONFIG_OF_LIBFDT_OVERLAY=y
```

2. Implementation of the `board_select_fdt_index()` function. This is a `__weak` function that can be reimplemented by the user. The function is to get the DTBO used to perform DTO operation among multiple DTBOs (return index index, the smallest starts from 0), the default weak function returns index 0.

```
/*
 * Default return index 0.
 */
__weak int board_select_fdt_index(ulong dt_table_hdr)
{
    /*
     * User can use "dt_for_each_entry(entry, hdr, idx)" to iterate
     * over all dt entry of DT image and pick up which they want.
     *
     * Example:
     * struct dt_table_entry *entry;
     * int index;
     *
     * dt_for_each_entry(entry, dt_table_hdr, index) {
     *     .... (use entry)
     * }
     *
     * return index;
     */
    return 0;
}
```

4.7.3 DTO Result

1. After DTO execution is complete, you can see the result in the boot message of U-Boot:

```
// The printout when it succeed
ANDROID: fdt overlay OK

// The printout when it failed
ANDROID: fdt overlay failed, ret=-19
```

Often the cause of failure is generally due to incompatibility between the contents of the primary/secondary device book blob, so the user needs to be clear about their generation syntax and compatibility.

2. The following message is appended to the cmdline of the kernel after successful DTO execution, indicating which DTBO is being used for the DTO operation:

```
androidboot.dtbo_idx=1 // The idx starts from 0. Here it means that the DTBO
with idx=1 is selected for DTO operation.
```

3. After the DTO is successfully executed you can use the `fdt` command at the U-Boot command line to view the contents of the DTB to confirm that the changes have taken effect.

4.8 ENV

4.8.1 Framework Support

ENV is a very important data management method in U-Boot framework, which constructs “key value” and “data” through hash table for mapping management, and supports “add/delete/modify/check” operations. Usually, we call the keys and data it manages as environment variables. U-Boot supports saving ENV data in various storage media: NOWHERE/eMMC/FLASH/EEPROM/NAND/SPI_FLASH/UBI ...

configurations:

```
// Default configuration: ENV saved in memory
CONFIG_ENV_IS_NOWHERE

// ENV saved on various storage media
CONFIG_ENV_IS_IN_MMC
CONFIG_ENV_IS_IN_NAND
CONFIG_ENV_IS_IN_EEPROM
CONFIG_ENV_IS_IN_FAT
CONFIG_ENV_IS_IN_FLASH
CONFIG_ENV_IS_IN_NVRAM
CONFIG_ENV_IS_IN_ONENAND
CONFIG_ENV_IS_IN_REMOTE
CONFIG_ENV_IS_IN_SPI_FLASH
CONFIG_ENV_IS_IN_UBI

// Any storage media (except mmc) that has been accessed to the BLK framework
layer is recommended by the RK platform !
CONFIG_ENV_IS_IN_BLK_DEV
```

Framework code:

```
./env/nowhere.c
./env/env_blk.c
./env/mmc.c
./env/nand.c
./env/eeprom.c
./env/embedded.c
./env/ext4.c
./env/fat.c
./env/flash.c
.....
```

4.8.2 Relevant Interface

```
// Getting Environment Variables
char *env_get(const char *varname);
ulong env_get_ulong(const char *name, int base, ulong default_val);
```

```

ulong env_get_hex(const char *varname, ulong default_val);

// Modify or create environment variables, value NULL is equivalent to deletion.
int env_set(const char *varname, const char *value);
int env_set_ulong(const char *varname, ulong value);
int env_set_hex(const char *varname, ulong value);

// Load all the ENV information saved on the storage media
int env_load(void);

// Save all current ENV information to a storage medium
int env_save(void);

```

- `env_load()`: The user does not need to call it, the U-Boot framework will call it in the appropriate boot process;
- `env_save()`: User-initiated invocation at the moment of need will save all ENV information to the storage medium specified by `CONFIG_ENV_IS_NOWHERE_XXX`;

4.8.3 Advanced Interface

RK provides two high-level interfaces that unify the handling of ENVs with create, append, and replace functionality. This is primarily for handling `bootargs` environment variables, but is equally applicable to other environment variable operations.

```

/**
 * env_update() - update sub value of an environment variable
 *
 * This add/append/replace the sub value of an environment variable.
 *
 * @varname: Variable to adjust
 * @valude: Value to add/append/replace
 * @return 0 if OK, 1 on error
 */
int env_update(const char *varname, const char *varvalue);

/**
 * env_update_filter() - update sub value of an environment variable but
 * ignore some key word
 *
 * This add/append/replace/ignore the sub value of an environment variable.
 *
 * @varname: Variable to adjust
 * @valude: Value to add/append/replace
 * @ignore: Value to be ignored that in varvalue
 * @return 0 if OK, 1 on error
 */
int env_update_filter(const char *varname, const char *varvalue, const char
*ignore);

```

1 Rules for using `env_update()`:

- Create: creates varname and varvalue if varname does not exist;
- Append: append varvalue if varname already exists and varvalue does not;

- Replace: If varname already exists and varvalue already exists, replace the original with the current varvalue. For example: the original is “storagemedia=emmc”, the current input varvalue is “storagemedia=rknand”, then the final update will be “storagemedia=rknand”. rknand”.

2 env_update_filter() is an extended version of env_update(): it strips out a keyword from varvalue while updating env;

3 Special note: env_update() and env_update_filter() both use space and “=” as separator to split ENV content, so the unit of operation is: single word, “key=value” combination word:

- single word: sdfwupdate、.....
- "key=value"combination word: storagemedia=emmc、init=/init、androidboot.console=ttyFIQ0、.....
- The above two interfaces cannot handle long string units. For example, it is not possible to operate “console=ttyFIQ0 androidboot.baseband=N/A androidboot.selinux=permissive” as a whole unit.

4.8.4 Storage Location

env_save() saves the ENV to the storage medium. The storage location and size of the ENV for the RK platform are defined below:

```
if ARCH_ROCKCHIP
config ENV_OFFSET
    hex
    depends on !ENV_IS_IN_UBI
    depends on !ENV_IS_NOWHERE
    default 0x3f8000
    help
        Offset from the start of the device (or partition)

config ENV_SIZE
    hex
    default 0x8000
    help
        Size of the environment storage area
endif
```

- Normally, neither ENV_OFFSET nor ENV_SIZE are recommended for modification.

4.8.5 General Options

Currently, the commonly used storage media are: eMMC/sdmmc/Nandflash/Norflash, etc. However, U-Boot's native Nand and Nor ENV drivers all follow the MTD framework, while all the supported storage media in RK follow the BLK framework, so these ENV drivers cannot be used.

Hence, RK provides the CONFIG_ENV_IS_IN_BLK_DEV configuration option for storage accessing the BLK framework

- For the eMMC/sdmmc case, select CONFIG_ENV_IS_IN_MMC ;
- For Nand、Nor case, select CONFIG_ENV_IS_IN_BLK_DEV;

Users please first read the definition CONFIG_ENV_IS_IN_BLK_DEV of Kconfig

```
// It is already specified by default and does not need to be changed.
CONFIG_ENV_OFFSET
CONFIG_ENV_SIZE

// It won't be used usually.
CONFIG_ENV_OFFSET_REDUND (optional)
CONFIG_ENV_SIZE_REDUND (optional)
CONFIG_SYS_MMC_ENV_PART (optional)
```

Note: Whichever CONFIG_ENV_IS_IN_XXX configuration you choose, read the definition description in Kconfig first, which contains subconfiguration descriptions.

4.8.6 Fw_printenv Tool

fw_printenv is an env tool provided by U-Boot for linux. With this tool, users can access and modify the contents of env on linux. Using this tool requires that the env region be located on a kernel-visible partition (separate partitions are recommended), essentially accessing the env region through the storage node under the kernel sys.

Tool Acquisition Methods:

```
./make.sh env
```

after executing the command, you will obtained :

```
./tools/env/fw_printenv      // env read/write tool
./tools/env/fw_env.config    // env configuration file
./tools/env/README           // env read/write tool documentation
```

Please refer to the README documentation for usage.

4.8.7 ENVF

This feature currently only applies to SDK firmware existed with env.img (mainly IPC-type products). If it does not exist, please ignore this section.

U-Boot's native ENV function is to save all environment variables to a specified storage area, which can be modified at will externally. If system-related variables are modified incorrectly, the system fail to boot normally, or be maliciously attacked. For example, the boot command `bootcmd` can be erased or pointed to a malicious boot process. Therefore, we have added the ENV Fragment function to separate U-Boot system environment variables from external user environment variables. Users have to define an env fragment for storing customized environment variables and set up a whitelist in U-Boot, U-Boot only allows importing/exporting/modifying whitelisted environment variables from the env fragment.

ENVF process:

The user creates env.txt on demand and specifies the contents, then uses mkenvimage to generate and download env.img to storage 0 address. Loader and U-Boot load and parse the content of env.img at boot time, and import legal environment variables according to the CONFIG_ENVF_LIST whitelist. Where: for different storage types, different sizes of env.img need to be made.

Configuration:

```

CONFIG_ENVF
CONFIG_SPL_ENVF
CONFIG_ENVF_LIST="blkdevparts mtdparts sys_bootargs app reserved"

// eMMC:
// Specifies the storage address of Primary env.img. Unit: bytes.
CONFIG_ENV_OFFSET=0x0
// Specifies the storage address of Backup env.img, which is the same as
CONFIG_ENV_OFFSET when there is no backup. Unit: bytes.
CONFIG_ENV_OFFSET_REDUND=0x0
// Size of Primary and Backup env.img. Unit: bytes.
CONFIG_ENV_SIZE=0x8000

// spi-nor: the same usage as above.
CONFIG_ENV_NOR_OFFSET=0x0
CONFIG_ENV_NOR_OFFSET_REDUND=0x0
CONFIG_ENV_NOR_SIZE=0x10000

// spi-nand/slc-nand: the same usage as above.
CONFIG_ENV_NAND_OFFSET=0x0
CONFIG_ENV_NAND_OFFSET_REDUND=0x0
CONFIG_ENV_NAND_SIZE=0x40000

```

Code:

```
./env/envf.c
```

Tools:

```

// By default, it participates in U-Boot compilation and generates
tools/mkenvimage, which is used to package env.img.
./tools/mkenvimage.c

```

PC development process (example)

1. Creat env.txt:

```

// The system partition table must be defined or it will not boot properly.
Example:
blkdevparts=mmcblk0:4M@8M(uboot),4M(trust),32M(boot),32M(recovery),32M(backup),-
(rootfs)
sys_bootargs=rootwait earlycon=uart8250,mmio32,0xff570000 console=ttyFIQ0
.....

```

- Formatting requirements:
 - (1) Use “key=value” key-value pairs.
 - (2) “=” in key-value pairs: no spaces in left or right, no single/double quotes
 - (3) Use newlines to indicate the end of a key-value pair
- `sys_bootargs`: The effect is equivalent to bootargs in kernel dts. if this field is specified, U-Boot will use sys_bootargs to overlay the bootargs in kernel dts, and sys_bootargs will have a higher priority when there are the same entries.
- Partition table: Support kernel-standard mtdparts and blkdevparts partition table format, please choose according to your needs (choose one). The partition formats for different storage are listed below:

```
// eMMC:
blkdevparts=mmcblk0:32K(env),512K@32K(idblock),256K(uboot),32M(boot),2G(rootfs),1
G(oem),2G(userdata),-(media)

// spi-nor:
mtdparts=sfc_nor:64K(env),128K@64K(idblock),128K(uboot),2M(boot),4M(rootfs),6M(oe
m),-(userdata)

// spi-nand/slc-nand:
mtdparts=rk-
nand:256K(env),256K@256K(idblock),256K(uboot),8M(boot),64M(rootfs),32M(userdata),
-(media)
```

2. Generate env.img:

```
## Chapter-4 eMMC:
./tools/mkenvimage -s 0x8000 -p 0x0 -o env.img env.txt

## Chapter-4 spi-nor:
./tools/mkenvimage -s 0x10000 -p 0x0 -o env.img env.txt

#spi-nand/slc-nand:
./tools/mkenvimage -s 0x40000 -p 0x0 -o env.img env.txt
```

3. env.img is downloaded to memory 0 address.

U-Boot-side development process (example):

1. Enable and configure env.img on demand

```
// enable ENVF
CONFIG_ENVF=y
CONFIG_SPL_ENVF=y
CONFIG_ENVF_LIST="blkdevparts mtdparts sys_bootargs app reserved"

// eMMC:
CONFIG_ENV_SIZE=0x8000
CONFIG_ENV_OFFSET=0x0
CONFIG_ENV_OFFSET_REDUND=0x0

// spi nor:
CONFIG_ENV_NOR_OFFSET=0x0
CONFIG_ENV_NOR_OFFSET_REDUND=0x0
CONFIG_ENV_NOR_SIZE=0x10000

// spi nand/slc nand:
CONFIG_ENV_NAND_OFFSET=0x0
CONFIG_ENV_NAND_OFFSET_REDUND=0x0
CONFIG_ENV_NAND_SIZE=0x40000
```

2. Recompile and download uboot.img.

3. Power-on message display

```

.....
dwmmc@ffc50000: 0, dwmmc@ffc60000: 1
Bootdev(atags): mmc 0
MMC0: HS200, 200Mhz
// printout as follows:
ENVF: Primary 0x00000000 - 0x00008000
ENVF: OK
PartType: ENV
DM: v1
boot mode: normal
FIT: no signed, no conf required
DTB: rk-kernel.dtb
.....

```

4. The user can save env from the U-Boot command line with the following command, or use code

```
env_save()
```

```

=> env save
Saving Environment to env... // Exporting and saving whitelisted environment
variables

```

4.9 Fastboot

Fastboot is a way provided by Android to interact with U-Boot via USB, which is generally used for getting device information, downloading firmware, etc.

4.9.1 Configuration Options

```

// Enabled Configuration
CONFIG_FASTBOOT
CONFIG_FASTBOOT_FLASH
CONFIG_USB_FUNCTION_FASTBOO

// Parameter Configuration
CONFIG_FASTBOOT_BUF_ADDR
CONFIG_FASTBOOT_BUF_SIZE
CONFIG_FASTBOOT_FLASH_MMC_DEV
CONFIG_FASTBOOT_USB_DEV

```

4.9.2 Trigger Method

Fastboot uses Google adb's VID/PID by default, with the following trigger methods:

- Command line execution of the kernel: reboot fastboot
- Command line execution of U-Boot: fastboot usb 0
- Power on and long press combination-key : ctrl+f

4.9.3 Command Support

```
fastboot flash < partition > [ < filename > ]
fastboot erase < partition >
fastboot getvar < variable > | all
fastboot set_active < slot >
fastboot reboot
fastboot reboot-bootloader
fastboot flashing unlock
fastboot flashing lock
fastboot stage [ < filename > ]
fastboot get_staged [ < filename > ]
fastboot oem fuse at-perm-attr-data
fastboot oem fuse at-perm-attr
fastboot oem at-get-ca-request
fastboot oem at-set-ca-response
fastboot oem at-lock-vboot
fastboot oem at-unlock-vboot
fastboot oem at-disable-unlock-vboot
fastboot oem fuse at-bootloader-vboot-key
fastboot oem format
fastboot oem at-get-vboot-unlock-challenge
fastboot oem at-reset-rollback-index
```

4.9.4 Command Details

- fastboot flash < partition > [< filename >]

Function: Partition download

Example: fastboot flash boot boot.img

- fastboot erase < partition >

Function: Erase Partition

Example: fastboot erase boot

- fastboot getvar < variable >

Function: Get device information

Example: fastboot getvar version-bootloader

< variable > parameters:

```
version                               /* fastboot version */
version-bootloader                     /* uboot version */
version-baseband
product                               /* Product Information */
serialno                              /* serial number */
secure                                /* security checking enabled or not*/
max-download-size                     /* the maximum number of bytes
supported by fastboot in a single transfer */
logical-block-size                    /* Number of logical blocks */
erase-block-size                      /* Number of erased blocks */
partition-type : < partition >        /* Partition type*/
partition-size : < partition >        /* Partition size */
unlocked                              /* Device lock status */
```

```

off-mode-charge
battery-voltage
variant
battery-soc-ok
slot-count /* Number of slots*/
has-slot: < partition > /* Check if the partition name is in
the slot */
current-slot /* Currently booted slots*/
slot-suffixes /* The current slot of the device,
print its name. */
slot-successful: < _a | _b > /* See if the partition is properly
verified and booted*/
slot-unbootable: < _a | _b > /* Check if the partition is set to
unbootable */
slot-retry-count: < _a | _b > /* Check the number of retry-counts for
a partition */
at-attest-dh
at-attest-uuid
at-vboot-state

```

- fastboot getvar all

Function: Get all device information

- fastboot set_active < slot >

Function: Set the slot for reboot

Example: fastboot set_active _a

- fastboot reboot

Function: Reboot the device for normal startup

Example: fastboot reboot

- fastboot reboot-bootloader

Function: Reboot the device to enter fastboot mode.

Example: fastboot reboot-bootloader

- fastboot flashing unlock

Function: Unlock the device and allow firmware downloading

Example: fastboot flashing unlock

- fastboot flashing lock

Function: Lock the device, prohibit downloading

Example: fastboot flashing lock

- fastboot stage [< filename >]

Function: Download data to device-side memory, the memory start address is CONFIG_FASTBOOT_BUF_ADDR.

Example: fastboot stage permanent_attributes.bin

- fastboot get_staged [< filename >]

Function: Getting data from the device side

Example: fastboot get_staged raw_unlock_challenge.bin

- fastboot oem fuse at-perm-attr

Function: Download permanent_attributes.bin and hash.

Example:

```
fastboot stage permanent_attributes.bin
```

```
fastboot oem fuse at-perm-attr
```

- fastboot oem fuse at-perm-attr-data

Function: Download only permanent_attributes.bin to the secure storage area (RPMB)

Example:

```
fastboot stage permanent_attributes.bin
```

```
fastboot oem fuse at-perm-attr-data
```

- fastboot oem at-get-ca-request
- fastboot oem at-set-ca-response
- fastboot oem at-lock-vboot

Function: Lock device

Example: fastboot oem at-lock-vboot

- fastboot oem at-unlock-vboot

Function: Unlock the device, now support authenticated unlock

Example:

```
fastboot oem at-get-vboot-unlock-challenge
```

```
fastboot get_staged raw_unlock_challenge.bin
```

```
./make_unlock.sh (See make_unlock.sh for reference)
```

```
fastboot stage unlock_credential.bin
```

```
fastboot oem at-unlock-vboot
```

You can refer to “how-to-generate-keys-about-avb.md”.

- fastboot oem fuse at-bootloader-vboot-key

Function: Download bootloader key hash

Example:

```
fastboot stage bootloader-pub-key.bin
```

```
fastboot oem fuse at-bootloader-vboot-key
```

- fastboot oem format

Function: reformat partitions, partition information depends on \$partitions

Example: fastboot oem format

- fastboot oem at-get-vboot-unlock-challenge

Function: authenticated unlock, need to get unlock challenge data

Example: please refer to 16. fastboot oem at-unlock-vboot

- fastboot oem at-reset-rollback-index

Function: Reset the rollback data of the device

Example: fastboot oem at-reset-rollback-index

- fastboot oem at-disable-unlock-vboot

Function: Disables the fastboot oem at-unlock-vboot command.

Example: fastboot oem at-disable-unlock-vboot

4.10 FileSystem

4.10.1 Framework Support

FAT and EXT2/4 are commonly used file system formats. Among them, FAT uses DOS (MBR) partition table, and the common devices are: SD card, USB flash drive.

These two file systems are generally accessed more often in U-Boot today.

FAT configuration:

```
CONFIG_DOS_PARTITION=y
CONFIG_FS_FAT=y
CONFIG_FAT_WRITE=y
CONFIG_FS_FAT_MAX_CLUSTSIZE=65536
CONFIG_CMD_FAT=y
CONFIG_CMD_FS_GENERIC=y
```

FAT command:

```
fatinfo fatload fatls fatsize fatwrite
```

EXT2/4 configuration:

```
CONFIG_CMD_EXT2=y
CONFIG_CMD_EXT4=y
CONFIG_CMD_FS_GENERIC=y
```

EXT2/4 command:

```
ext2load ext2ls ext4load ext4ls ext4size
```

4.10.2 Relevant Interface

FAT function header file ./include/fat.h:

```
int file_fat_detectfs(void);
int fat_exists(const char *filename);
int fat_size(const char *filename, loff_t *size);
int file_fat_read_at(const char *filename, loff_t pos, void *buffer,
                    loff_t maxsize, loff_t *actread);
int file_fat_read(const char *filename, void *buffer, int maxsize);
int fat_set_blk_dev(struct blk_desc *rbdd, disk_partition_t *info);
int fat_register_device(struct blk_desc *dev_desc, int part_no);

int file_fat_write(const char *filename, void *buf, loff_t offset, loff_t len,
                 loff_t *actwrite);
int fat_read_file(const char *filename, void *buf, loff_t offset, loff_t len,
                 loff_t *actread);
int fat_opendir(const char *filename, struct fs_dir_stream **dirsp);
int fat_readdir(struct fs_dir_stream *dirs, struct fs_dirent **dentp);
```

```
void fat_closedir(struct fs_dir_stream *dirs);
void fat_close(void);
```

EXT2/4 function header file include/ext4fs.h:

```
struct ext_filesystem *get_fs(void);
int ext4fs_open(const char *filename, loff_t *len);
int ext4fs_read(char *buf, loff_t offset, loff_t len, loff_t *actread);
int ext4fs_mount(unsigned part_length);
void ext4fs_close(void);
void ext4fs_reinit_global(void);
int ext4fs_ls(const char *dirname);
int ext4fs_exists(const char *filename);
int ext4fs_size(const char *filename, loff_t *size);
void ext4fs_free_node(struct ext2fs_node *node, struct ext2fs_node *currroot);
int ext4fs_devread(lbaint_t sector, int byte_offset, int byte_len, char *buf);
void ext4fs_set_blk_dev(struct blk_desc *rbdd, disk_partition_t *info);
long int read_allocated_block(struct ext2_inode *inode, int fileblock);
int ext4fs_probe(struct blk_desc *fs_dev_desc,
                 disk_partition_t *fs_partition);
int ext4_read_file(const char *filename, void *buf, loff_t offset, loff_t len,
                  loff_t *actread);
int ext4_read_superblock(char *buffer);
int ext4fs_uuid(char *uuid_str);
```

4.10.3 Example of Command

```
// Confirm that the SD card is recognizable(if it is a USB flash drive then use
the usb command for recognition, the device number is usually: usb 0)
=> mmc dev 1
switch to partitions #0, OK
mmc1 is current device

// View Information
=> fatinfo mmc 1
Interface: MMC
Device 1: Vendor: Man 000003 Snr e81ec501 Rev: 1.9 Prod: SC16G
Type: Removable Hard Disk
Capacity: 15193.5 MB = 14.8 GB (31116288 x 512)
Filesystem: FAT32 "NO NAME"

// View File
=> fatls mmc 1
                System Volume Information/
                23  hello.txt
                23  linux.txt

2 file(s), 1 dir(s)

// Read the size of the hello.txt file (the result is saved to the variable
filesize by default)
=> fatsize mmc 1 hello.txt
=> echo $filesize
0x17
```

```
// Read hello.txt file to address 0x2000000
=> fatload mmc 1 0x2000000 hello.txt
reading hello.txt
23 bytes read in 2 ms (10.7 KiB/s)
// Viewing the contents of read hello.txt
=> md.l 0x2000000
02000000: 6c6c6568 65682d6f 2d6f6c6c 6c6c6568    hello-hello-hell
02000010: 65682d6f ff6f6c6c ffffffff ffffffff    o-hello.....

// Create a new file: hello-copy.txt. Write the contents of addresses
0x2000000~0x2000017 to hello-copy.txt.
=> fatwrite mmc 1 0x2000000 hello-copy.txt 0x17
writing hello-copy.txt
23 bytes written
// See new file: hello-copy.txt
=> fatls mmc 1
                System Volume Information/
    23    hello.txt
    23    linux.txt
    23    hello-copy.txt

3 file(s), 1 dir(s)
```

Note: The ext2/4 and fat commands are used in a similar way, so no specific instructions are given.

4.11 HW-ID DTB

The U-Boot of RK platform supports detecting the GPIO or ADC status on the hardware to dynamically load different Kernel DTBs, which is tentatively called HW-ID DTB (Hardware id DTB) function.

4.11.1 Design Principle

Usually the hardware design is frequently updated with newer versions and components, such as screen, wifi module, etc. If each hardware version has to correspond to a set of software, it will be troublesome to maintain it. So we need the HW_ID function to realize that a set of software can be adapted to different versions of hardware.

For different hardware versions, the software needs to provide the corresponding dtb file, as well as the ADC/GPIO hardware unique values to characterize the current hardware version (e.g., a fixed adc value, a fixed GPIO level).


The user packages all these dtb files corresponding to the hardware version into a same resource.img. When U-Boot boots the kernel, it checks for hardware uniqueness and finds the dtb that matches the current hardware version from the resource.img and passes it to the kernel.

4.11.2 Hardware Reference

Both ADC and GPIO are currently supported to determine the hardware version.


ADC reference design

The RK3326-EVB/PX30-EVB motherboard has reserved voltage divider resistors, different resistor divider has different ADC value, so that you can determine the different hardware versions:.



The MIPI panel is equipped with an additional pull-down resistor.

LCD/TP Adapter Board



Different mipi screens will be configured with different resistance values, and a unique ADC parameter value will be determined in conjunction with the EVB motherboard.

ADC calculation method for current V1 version: the maximum value of the ADC parameter is 1024, which corresponds to the ADC_IN0 pin being pulled up directly to the supply voltage of 1.8V, and there is a 10K pull-down resistor on the MIPI screen, after successful connecting to the EVB board, the $ADC = 1024 * 10K / (10K + 51K) = 167.8$.

GPIO reference design

There is currently no hardware reference design for GPIOs, which can be customized by the user.

4.11.3 DTB Naming

Users need to reflect the hardware unique value information of ADC/GPIO in the dtb file name. The naming convention is as follows:

ADC as HW_ID DTB:

- The file name ends with “.dtb”;
- HW_ID format: #[controller]_ch[channel]=[adcval], called a complete unit
[controller]: The node name of the ADC controller inside dts.
[channel]: ADC channel.
[adcval]: The center value of the ADC, the actual valid range is: adcval+-30.
- Each complete unit must be in lowercase letters with no internal spaces;
- Multiple units are separated by #, up to 10 units are supported.;

Example:

```
rk3326-evb-lp3-v10#saradc_ch2=111#saradc_ch1=810.dtb
rk3326-evb-lp3-v10#_saradc_ch2=569.dtb
```

GPIO as HW_ID DTB:

- The file name ends with “.dtb”;
- HW_ID format: #gpio[pin]=[level], called a complete unit
[pin]: GPIO pin, e.g. 0a2 for gpio0a2
[level]: GPIO Pin Levels.
- Each complete unit must be in lowercase letters with no internal spaces;
- Multiple units are separated by #, up to 10 units are supported.;

Example:

```
rk3326-evb-lp3-v10#gpio0a2=0#gpio0c3=1.dtb
```

4.11.4 DTB Packaging

kernel repository: scripts/mkmultidtb.py. This script can be used to package multiple dtbs into the same resource.img.

The user needs to open the script file to write the dtb file to be packed into the DTBS dictionary and fill in the corresponding ADC/GPIO configuration information.

```
...
DTBS = {}
DTBS['PX30-EVB'] = OrderedDict([('rk3326-evb-lp3-v10', '#_saradc_ch0=166'),
                                ('px30-evb-ddr3-lvds-v10', '#_saradc_ch0=512')])
...
```

In the above example, executing scripts/mkmultidtb.py PX30-EVB generates resource.img with 3 copies of the dtb:

- rk-kernel.dtb: rk's default dtb, not reflected in the above dictionary. It is used by default when all dtb's are not matched successfully. The packaging script will use the first dtb of the DTBS as the default dtb;
- rk3326-evb-lp3-v10#_saradc_ch0=166.dtb: The rk3326 dtb file containing ADC information;;
- px30-evb-ddr3-lvds-v10#_saradc_ch0=512.dtb: The px30 dtb file containing ADC information;;

4.11.5 Feature Enablement

Configuration options:

```
CONFIG_ROCKCHIP_HWID_DTB=y
```

Driver code:

```
./arch/arm/mach-rockchip/resource_img.c // Specific realization:
rockchip_read_hwid_dtb()
```

DTS configuration:

If GPIOs are used as hardware identification, the corresponding pinctrl and gpio nodes must be reserved in rkxx-u-boot.dtsi; ADCs are enabled by default.

For example, gpio0 and gpio1 are used as identification:

```
...

&pinctrl {
    u-boot,dm-spl; // Append this attribute to allow the node to be retained in
the U-Boot DTB. Same below.
};

&gpio0 {
    u-boot,dm-spl;
};

&gpio1 {
    u-boot,dm-spl;
};

...
```

4.11.6 Load Results

```
.....
mmc0(part 0) is current device
boot mode: None
DTB: rk3326-evb-lp3-v10#_saradc_ch0=166.dtb // Prints the matching DTB, otherwise
defaults to "rk-kernel.dtb".
Using kernel dtb
.....
```

4.12 SD and USB Flash Drives

This chapter focuses on firmware booting and upgrading of SD and USB flash drives on the RK platform.

4.12.1 Mechanisms and Principles

After the boot card and upgrade card are created, a fixed tag is placed in the firmware header at a fixed storage offset location to mark whether it is a boot card or an upgrade card. U-Boot recognizes this tag and proceeds with the corresponding boot or upgrade process. where:

- **Boot Card:** There is only one complete firmware in the card, U-Boot uses this complete firmware to directly boot the system normally;
- **Upgrade card:** The card contains two copies of firmware. When creating an upgrade card, the PC tool will write two copies of firmware: one of which containing only the partition image necessary to enter recovery mode (denoted as firmware A), and the other on containing with the complete update.img firmware (denoted as firmware B). U-Boot uses firmware A to boot the system into recovery mode, and then the recovery program uses firmware B to complete the upgrade work.


Special Notes:

- SD card boot/upgrade is supported from the bootrom level;
- USB disk boot/upgrade is only supported from the U-Boot level, which means that the user should at least make sure that U-Boot is working properly!

4.12.2 Firmware Creation

The process of creating SD and USB disk boot cards and upgrade cards on the RK platform is identical and requires only two steps:

- Use the `RKTools/linux/Linux_Pack_Firmware/rockdev/` tool in the SDK directory to generate update.img.
- Use SDDiskTool to download update.img to SD or USB disk. As shown in the picture:
 - Select removable disks
 - Select `Firmware Upgrade` or `SD Boot`.
 - Click `Start Creating`



4.12.3 SD Configuration

SD Boot/Upgrade: U-Boot released by SDK of each platform has enabled this function by default, users do not need to configure it additionally.

4.12.4 USB Configuration

USB Boot/Upgrade: U-Boot released by each platform SDK is not enabled by default. Because U-Boot's native USB scanning command is time-consuming, it's better for users enabling it themselves on demand:

- Step 1: download the upgrade firmware to local storage (eMMC/Nand/...etc.), make sure the firmware is available.
- Step 2: Plug in the USB flash drive and boot into U-Boot command line mode. Execute `usb start` and `usb info` commands to make sure the USB flash drive is recognized normally, otherwise, please adjust the USB flash drive recognition first.
- Step 3: Make a copy of the kernel DTB that aligned with step 1 and name it kern.dtb and put it in U-Boot's `. /dts/` directory of U-Boot. This kern.dtb will be automatically packed into uboot.img when compiling U-Boot.

kern.dtb Purpose: U-Boot uses kern.dtb to ensure that the USB is initialized properly when the kernel dtb of the local storage partition is corrupted.

- Step 4: U-Boot enable boot/upgrade configuration of USB

```
CONFIG_ROCKCHIP_USB_BOOT=y
```

Recompile and download uboot.img.

If the process prompts that uboot's firmware is too large to be packaged and resulted from the addition of kern.dtb in step 3, please cut out some unused U-Boot configurations first.

4.12.5 Functions Taking Effect

How to confirm that the SD, USB disk boot or upgrade function is in effect.

Users can erase key partitions such as kernel, resource, boot, recovery on local storage (eMMC, Nand...) to make sure you can enter kernel after inserting SD/U disk.

4.12.6 Notes

- The `usb start` command is called when the USB flash drive is initialized, and the whole process is relatively time-consuming;
- If the boot/upgrade card needs to support GPT partition tables, the version of the SDDiskTool tool requires $\geq v1.59$;
- If the boot/upgrade card needs to support AB systems, the version of the SDDiskTool tool requires $\geq v1.61$
- Because the USB disk boot/upgrade feature is a feature added in 2019.11, the relevant repository needs to meet the following conditions

1. U-Boot repository shall be **updated** to the following commit points (recommended)

```
commit 369e944c844f783508b7839ae86a3418e2f63bc7
Author: Joseph Chen <chenjh@rock-chips.com>
Date: Thu Dec 12 18:07:07 2019 +0800

    fdt/Makefile: make u-boot-dtb.bin 8-byte aligned

    The dts/kern.dtb is appended after u-boot-dtb.bin for U-disk boot.

    Make sure u-boot-dtb.bin is 8-byte aligned to avoid data-abort on
    calling: fdt_check_header(gd->fdt_blob_kern).

    Signed-off-by: Joseph Chen <chenjh@rock-chips.com>
    Change-Id: Id5f2daf0c5446e7ea828cb970d3d4879e3acda86
```

Or add the following patch changes individually (presumably more difficult):

```
369e944 fdt/Makefile: make u-boot-dtb.bin 8-byte aligned
b3b57ac rockchip: board: fix always entering recovery on normal boot U-disk
e0cee41 rockchip: resource: add sha1/256 verify for kernel dtb
5e817a0 tools: rockchip: resource_tool: add sha1 for file entry
fc474da lib: sha256: add sha256_csum()
0ed06f1 rockchip: support boot from U-disk
01f0422 common: bootm: skip usb_stop() if usb is boot device
5704c89 fdtdec: support pack "kern.dtb" to the end of u-boot.bin
3bdef7e gpt: return 1 directly when test the mbr sector
```

1. The rkbin repository should contain this commit:

```
commit f9c0b0b72673a65865b00a8824908ca6f12ecc32
```

```
Author: Joseph Chen <chenjh@rock-chips.com>
```

```
Date: Thu Nov 7 09:21:36 2019 +0800
```

```
tools: resource: add sha1 for file entry
```

```
Base on U-Boot next-dev branch:
```

```
(5e817a0 tools: rockchip: resource_tool: add sha1 for file entry)
```

```
Change-Id: Ife061cabacab488dbecf2a3245d58cc660091dbd
```

```
Signed-off-by: Joseph Chen <chenjh@rock-chips.com>
```

1. The kernel repository should contain this commit:

```
commit 078785057478c789bb033ba06925fa3a07e3130a
```

```
Author: Tao Huang <huangtao@rock-chips.com>
```

```
Date: Thu Nov 7 17:53:38 2019 +0800
```

```
rk: scripts/resource_tool: add sha1 for file entry
```

```
From u-boot 5e817a0ea427 ("tools: rockchip: resource_tool: add sha1 for  
file entry").
```

```
Merge all C files to one resource_tool.c
```

```
Change-Id: If63ba77d1f5a3660bd6ef87769bb456fa086ae71
```

```
Signed-off-by: Tao Huang <huangtao@rock-chips.com>
```

- If the SDK owned by the user is relatively old, in addition to adding the above patches individually, it is recommended to check with the engineer in charge of recovery to see if recovery has the relevant patches.

5. Chapter-5 Driver Module

5.1 AMP

5.1.1 Ideas for Implementation

The U-Boot framework does not have AMP (Asymmetric Multi-Processing) support by default, however, RK implements a set of AMP mechanism by itself: different CPUs run different firmware.

Implementation Ideas:

(1) Firmware Packaging

All AMP firmware (excluding Linux) specifies the CPU running state, describes the firmware information through its file, and finally packages it into a FIT-formatted `amp.img` to be downloaded to the `amp` partition.

During booting, U-Boot is responsible for loading the `amp.img` firmware and performing sha256 integrity checks, and then trust specifies the running state of each CPU and dispatches it to the corresponding entry address.

(2) Boot order

The CPU running U-Boot is called the master core, which finally operates on itself after completing state switching and firmware jumps of other cores.

(3) Resource management

U-Boot is not responsible for the coordination of resources (including the division of memory, interrupts, etc.) between firmwares under the AMP scheme, so developers please make sure for it.

(4) Trust support

The AMP feature requires trust support. If the user-specified CPU running state is the default state, then the SDK's trust is already supported; if it is not the default state, then trust requires additional support (but some platforms' SDKs already support it by default).

The above CPU default state refers to:

32-bit chip default state: `arch = "arm", thumb = <0>, hyp = 0;`

64-bit chip default state: `arch = "arm64", thumb = <0>, hyp = 1;`

(5) Linux+AMP combination

1. Considering the compatibility, the Linux-related firmware under the combination scheme is consistent with the traditional SMP firmware, i.e. Linux-related firmware + `amp.img`.
2. Developers can specify the state of the CPU running Linux by adding a “linux” node to `amp`'s its (without it, it's the default state).
3. If the main core is running Linux or no firmware is specified, the main core will boot Linux from U-Boot in the traditional SMP boot fashion after booting other AMP firmware.
4. If the non-main core is running Linux, boot Linux first, then other AMP firmware. Note: If you want to boot on a core other than CPU0, you need special trust support.
5. The load address of the Linux firmware is determined by the U-Boot configuration only, e.g. `rk3568_common.h`.

5.1.2 Framework Support

Configurations:

```
CONFIG_AMP
CONFIG_ROCKCHIP_AMP
```

Framework Code:

```
./drivers/cpu/rockchip_amp.c
```

its templates:

```
./drivers/cpu/amp.its
```

Packing Tools:

```
./tools/mkimage // wil be generated automatically after a full U-Boot
compilation
```

Code commit point at least includes:

```
commit c51cf04095dde2df2dd047e70d2c7fb0866ea916
Author: Joseph Chen <chenjh@rock-chips.com>
Date: Tue Oct 19 03:16:35 2021 +0000

    cpu: amp.its: update amps "arm64" => "arm"

Signed-off-by: Joseph Chen <chenjh@rock-chips.com>
Change-Id: I99de02c5b6c62ffdd9b25565acd172801d6e983c
```

5.1.3 Feature Enablement

1. To create amp.img you need an its file, please modify it based on `drivers/cpu/amp.its`:

The following its: CPU1/2/3 runs AMP, CPU0 runs Linux, and the main core is CPU3. The boot order is: CPU0 => CPU1/2 => CPU3.

```
/dts-v1/;
/ {
    description = "FIT source file for rockchip AMP";
    #address-cells = <1>;

    // All AMP firmware (excluding Linux) should be specified under the images
node;
    images {
        amp1 {
            description = "bare-mental-core1";           // Required: Description
info
            data        = /incbin("./amp1.bin");        // Required: amp1 firmware
            type        = "firmware";                   // Required: No change
            compression = "none";                       // Required: No change
```

```

        arch          = "arm";           // Required: "arm64": 64-bit, "arm": 32-
bit
        cpu           = <0x100>;         // Required: cpu hardware id (mpidr)
        thumb         = <0>;             // Required: 0: arm or thumb2; 1: pure
thumb
        hyp           = <0>;             // Required: 0: el1/svc; 1: el2/hyp
        load          = <0x01800000>;    // Required: Firmware load and run
address
        udelay        = <1000000>;      // Optional: delay after booting the
current CPU and then start the next CPU.
        hash {
            algo = "sha256";
        };
    };

    amp2 {
        description = "bare-mental-core2";
        data        = /incbin/("./amp2.bin");
        type        = "firmware";
        compression = "none";
        arch        = "arm";
        cpu         = <0x200>;
        thumb       = <0>;
        hyp         = <0>;
        load        = <0x03800000>;
        udelay      = <1000000>;
        hash {
            algo = "sha256";
        };
    };

    amp3 {
        description = "bare-mental-core3";
        data        = /incbin/("./amp3.bin");
        type        = "firmware";
        compression = "none";
        arch        = "arm";
        cpu         = <0x300>;
        thumb       = <0>;
        hyp         = <0>;
        load        = <0x05800000>;
        udelay      = <1000000>;
        hash {
            algo = "sha256";
        };
    };
};

configurations {
    default = "conf";
    conf {
        description = "Rockchip AMP images";
        rollback-index = <0x0>;
        // Specifies the firmware to be loaded and the order in which it
should be loaded and booted, but the master core is not subject to this order.
        loadables = "amp1", "amp2", "amp3";

        signature {

```

```

        algo = "sha256,rsa2048";
        padding = "pss";
        key-name-hint = "dev";
        sign-images = "loadables";
    };

    // Linux CPU runtime state designation:
    // (1) Only the udelay attribute is optional;
    // (2) The boot address is not assignable and is determined by U-
    Boot's platform configuration file, e.g.: rk3568_common.h;
    linux {
        description = "linux-os";
        arch = "arm64";
        cpu = <0x000>; // CPU0 runs linux
        thumb = <0>;
        hyp = <0>;
        udelay = <1000000>;
    };
};

};
};
};

```

Notes:

- **description:** Description information.
- **type:** The default is “firmware”.
- **compression:** The default is “none”.
- **data:** Firmware path. The path is a relative path based on amp.its.
- **arch:** CPU 32/64 mode: ARMv7 can only be specified as “arm”; ARMv8 can be specified as “arm64” or “arm”, which means AArch64 or AArch32 respectively.
- **cpu:** CPU hardware ID, i.e. mpidr (Multiprocessor Affinity Register), take the lower 32 bits. For example:

```

cpus {
    #address-cells = <2>;
    #size-cells = <0>;

    cpu0: cpu@0 {
        device_type = "cpu";
        compatible = "arm,cortex-a55";
        reg = <0x0 0x0>; // mpidr
        .....
    };

    cpul: cpu@100 {
        device_type = "cpu";
        compatible = "arm,cortex-a55";
        reg = <0x0 0x100>; // mpidr
        .....
    };
    .....
};

```

- **thumb:** CPU instruction mode. Specify 1 if pure THUMB, 0 otherwise.
- **hyp:** CPU VM mode.
- **load:** Firmware load and run address

- **udelay:** Delay after completion of boot (optional), in us. After booting the current CPU, do the corresponding delay before booting the next CPU.
- **loadables:** The AMP firmware to be loaded and the order in which it is loaded and booted. The main CPU must be the last to be booted and is not subject to the order here.
- **linux node:** For Linux + AMP combination programs. Please refer to the “Ideas for Implementation” in this section.

2. Firmware packing:

```
// 0xe00 is the firmware header size and is not recommended to be changed
./tools/mkimage -f ./drivers/cpu/amp.its -E -p 0xe00 amp.img
```

A full compilation of U-Boot is required to automatically generate the mkimage tool.

3. Add amp partition to partition table

Add the “amp” partition to the parameter.txt partition table file and then download amp.img.

U-Boot is to directly load the contents of the entire amp partition into memory, so it is recommended that the amp partition size is configured according to actual needs

4. Bring up

The U-Boot framework will automatically initiate the bring up of all AMPs at the right time. The following is the boot information of CPU3 running AMP firmware as the main core and CPU0/1/2 running Linux firmware:

```
.....
// the master core loading firmware amp3 firmware
### Loading loadables from FIT Image at 7bdbcf80 ...
  Trying 'amp3' loadables subimage
    Description:  rtthread
    Type:         Firmware
    Compression:  uncompressed
    Data Start:   0x7bdbdd80
    Data Size:    311296 Bytes = 304 KiB
    Architecture: ARM
    Load Address: 0x01800000
    Hash algo:    sha256
    Hash value:
d08db937e4d7bd4125056239154bb30d44a2fcca9e70aa8dea448fabda4838d5
  Verifying Hash Integrity ... sha256+ OK
  Loading loadables from 0x7bdbdd80 to 0x01800000
### Booting FIT Image FIT: No fit blob
FIT: No FIT image
ANDROID: reboot reason: "(none)"
optee api revision: 2.0
TEEC: Waring: Could not find security partition
Not AVB images, AVB skip
ANDROID: Hash OK

// the master core loading Linux firmware
Booting IMAGE kernel at 0x03880000 with fdt at 0x0a100000...

Fdt Ramdisk skip relocation
### Booting Android Image at 0x0387f800 ...
Kernel load addr 0x03880000 size 21655 KiB
### Flattened Device Tree blob at 0x0a100000
  Booting using the fdt blob at 0x0a100000
```

```

XIP Kernel Image from 0x03880000 to 0x03880000 ... OK
'reserved-memory' ramoops@110000: addr=110000 size=f0000
Using Device Tree in place at 000000000a100000, end 000000000a12322a
vp1 adjust cursor plane from 0 to 1
vp0, plane_mask:0x2a, primary-id:5, curser-id:1
vp1 adjust cursor plane from 1 to 0
vp1, plane_mask:0x15, primary-id:4, curser-id:0
vp2, plane_mask:0x0, primary-id:0, curser-id:-1
Adding bank(fixed): 0x03880000 - 0x80000000 (size: 0x7c780000)

// At this point, all the firmware is loaded, and it starts to boot each CPU
according to the program's prioritization rules,as follows

// The main core boots CPU0 to run Linux (CPU1/2 subsequently boots via Linux)
AMP: Brought up cpu[0] with state 0x12, entry 0x03880000 ...OK
// The main core boots itself (CPU3) to run the AMP firmware
AMP: Brought up cpu[300, self] with state 0x10, entry 0x01800000 ...OK

// Linux runs on CPU0:
[ 0.000000] Booting Linux on physical CPU 0x0000000000 [0x412fd050]
[ 0.000000] Linux version 4.19.193 (stevenliu@stevenliu) (gcc version 6.3.1
20170404 (Linaro GCC 6.3-2017.05), GNU ld (Linaro_Binutils-2017.05)
2.27.0.20161019) #5 SMP Mon Sep 13 16:22:51 CST 2021
[ 0.000000] Machine model: Rockchip RK3568 EVB1 DDR4 V10 Board
.....

```

The above print information may vary depending on the user's its configuration and is subject to actual conditions.

5.2 Charge

5.2.1 Framework Support

The U-Boot native code doesn't support charging, however, RK implemented a set of its own.

Charging involves many modules including Display, PMIC, power meter, charging animation, pwrkey, led, CPU low-power hibernation, Timer and so on.

Power meter support:

```
RK809/RK816/RK817/RK818/cw201x.
```

Configurations:

```

// Framework
CONFIG_DM_CHARGE_DISPLAY
CONFIG_CHARGE_ANIMATION
CONFIG_DM_FUEL_GAUGE
// Driver
CONFIG_POWER_FG_CW201X
CONFIG_POWER_FG_RK818
CONFIG_POWER_FG_RK817
CONFIG_POWER_FG_RK816

```


Charging frame:

```
./drivers/power/charge-display-uclass.c
```

Charging animation driver:

```
// Responsible for managing the entire charging process, it will get the power
level, charging type, button events, initiate low-power hibernation, and more.
./drivers/power/charge_animation.c
```

E Power meter framework::

```
./drivers/power/fuel_gauge/fuel_gauge_uclass.c
```

Power meter driver:

```
./drivers/power/fuel_gauge/fg_rk818.c
./drivers/power/fuel_gauge/fg_rk817.c    // rk809 re-use
./drivers/power/fuel_gauge/fg_rk816.c
.....
```

Logical process:

```
charge-display-uclass.c
  => charge_animation.c
    => fuel_gauge_uclass.c
      => fg_rkxx.c
```

5.2.2 Packaging Pictures

Charging images are located in the `./tools/images/` directory and need to be packaged into `resource.img` to be displayed by the charging frame.

The `resource.img` compiled by the kernel is not packed with charging images by default, and needs to be packed separately in U-Boot.

```
$ ls tools/images/
battery_0.bmp  battery_1.bmp  battery_2.bmp  battery_3.bmp  battery_4.bmp
battery_bmp   battery_fail.bmp
```

Packaging command:

```
./pack_resource.sh <input resource.img> or
./scripts/pack_resource.sh <input resource.img>
```

Packaging information:

```

./pack_resource.sh /home/cjh/3399/kernel/resource.img

Pack ./tools/images/ & /home/guest/3399/kernel/resource.img to resource.img ...
Unpacking old image(/home/guest/3399/kernel/resource.img):
rk-kernel.dtb logo.bmp logo_kernel.bmp
Pack to resource.img succeeded!
Packed resources:
rk-kernel.dtb battery_1.bmp battery_2.bmp battery_3.bmp battery_4.bmp battery_bmp
battery_fail.bmp logo.bmp logo_kernel.bmp battery_0.bmp

resource.img is packed ready

```

After success, a resource.img containing the image will be generated in the U-Boot root directory, and the contents will be confirmed by the hd command:

```

hd resource.img | less

00000000  52 53 43 45 00 00 00 00  01 01 01 00 0a 00 00 00  |RSCE.....|
00000010  00 00 00 00 00 00 00 00  00 00 00 00 00 00 00 00  |.....|
*
.....
*
00000400  45 4e 54 52 62 61 74 74  65 72 79 5f 31 2e 62 6d  |ENTRbattery_1.bm| //
picture1
00000410  70 00 00 00 00 00 00 00  00 00 00 00 00 00 00 00  |p.....|
00000420  00 00 00 00 00 00 00 00  00 00 00 00 00 00 00 00  |.....|
*
00000500  00 00 00 00 4d 00 00 00  9c 18 00 00 00 00 00 00  |...M.....|
00000510  00 00 00 00 00 00 00 00  00 00 00 00 00 00 00 00  |.....|
*
00000600  45 4e 54 52 62 61 74 74  65 72 79 5f 32 2e 62 6d  |ENTRbattery_2.bm| //
picture 2
00000610  70 00 00 00 00 00 00 00  00 00 00 00 00 00 00 00  |p.....|
00000620  00 00 00 00 00 00 00 00  00 00 00 00 00 00 00 00  |.....|
.....

```

5.2.3 DTS Configuration

DTS Charging Node:

```

charge-animation {
    compatible = "rockchip,uboot-charge";
    status = "okay";

    rockchip,uboot-charge-on = <0>;           // Whether to enable U-Boot
charging
    rockchip,android-charge-on = <1>;         // Whether to enable Android
charging

    rockchip,uboot-exit-charge-level = <5>;    // Minimum power allowed to power
on while U-Boot is charging.
    rockchip,uboot-exit-charge-voltage = <3650>; // Minimum voltage allowed to
power on when U-Boot is charging.

```

```

    rockchip,screen-on-voltage = <3400>;          // Minimum voltage allowed to
light up the screen while U-Boot is charging.

    rockchip,uboot-low-power-voltage = <3350>;    // Minimum voltage for forcing U-
Boot to entry into charging mode unconditionally.

    rockchip,system-suspend = <1>;                // Whether to enter trust low-
power standby when the screen goes off ( need to be supported by ATF)
    rockchip,auto-off-screen-interval = <20>;     // Timeout for automatic screen
going off, in seconds, default 15s
    rockchip,auto-wakeup-interval = <10>;         // Automatic wake-up time from
hibernation in seconds. If the value is 0 or no such attribute,
                                                    // hibernation automatic wake-up
is disabled,
                                                    // generally used for stress
test.
    rockchip,auto-wakeup-screen-invert = <1>;     // Whether or not to light up the
screen when automatic wake-up from hibernation.
};

```

5.2.4 System Hibernation

Pwrkey pressing:

- Press pwrkey briefly to turn on/off the screen, when the screen is off, the system will enter the low power mode;
- Press and hold pwrkey to boot into the system.

There are 2 low power modes, selected by `rockchip,system-suspend = <VAL>`:

- VAL is 0: cpu wfi mode. At this time, no peripherals are processed, only the cpu enters the low-power mode;
- VAL is 1: system suspend mode, requires ATF/OPTEE support to be effective. Kernel-like system go deep standby, the whole SoC goes into standby.

Minimum version number for ATF/OPTEE to support U-Boot low-power standby: **Please refer to the Platform Definition section.**

5.2.5 Replacement of Pictures

1. Replace the images in the `./tools/images/` directory (using 8bit or 24bit bmp), use the command `ls | sort` to make sure the images are sorted from low power to high power, and use the `pack_resource.sh` script to package the images into `resource.img`;
2. Modify `./drivers/power/charge_animation.c` in the image and charge relationship;

```

/*
 * IF you want to use your own charge images, please:
 *
 * 1. Update the following 'image[]' to point to your own images;
 * 2. You must set the failed image as last one and soc = -1 !!!
 */
static const struct charge_image image[] = {
    { .name = "battery_0.bmp", .soc = 5, .period = 600 },
    { .name = "battery_1.bmp", .soc = 20, .period = 600 },

```

```

{ .name = "battery_2.bmp", .soc = 40, .period = 600 },
{ .name = "battery_3.bmp", .soc = 60, .period = 600 },
{ .name = "battery_4.bmp", .soc = 80, .period = 600 },
{ .name = "battery_bmp", .soc = 100, .period = 600 },
{ .name = "battery_fail.bmp", .soc = -1, .period = 1000 },
};

// @name: Name of the picture;
// @soc: Amount of electricity corresponding to the picture;
// @period: Image refresh time (unit: ms);
// Note: The last image must be a fail image and "soc=-1" cannot be changed.  !!

```

5.2.6 Charging Indicator

In actual products, users have different control requirements for led, so the charging frame only supports 2 leds. Charging indicator, Fully-Charged indicator:

- Charging Indicator: The led will be flipped when there is a change in power level while charging;
- Fully-Charged Indicator: The led will only light up when the battery is 100% full;

The above two Led configuration only serves as a demo , users need to modify the code according to your own needs.

Configuration options:

```

CONFIG_LED_CHARGING_NAME
CONFIG_LED_CHARGING_FULL_NAME

```

These two configuration options are used to specify the label attribute of the led, please refer to the Led section.

5.3 Clock

5.3.1 Framework Support

The clock driver uses the clk-uclass framework and standard interfaces.

Configuration:

```

CONFIG_CLK

```

Framework code:

```

./drivers/clk/clk-uclass.c

```

Platform Driver Code:

```

./drivers/clk/rockchip/...

```

5.3.2 Relevant Interface

```
// Apply Clock
int clk_get_by_index(struct udevice *dev, int index, struct clk *clk);
int clk_get_by_name(struct udevice *dev, const char *name, struct clk *clk);

// Enable/Disable Clock
int clk_enable(struct clk *clk);
int clk_disable(struct clk *clk);

// Configure/acquire frequency
ulong (*get_rate)(struct clk *clk);
ulong (*set_rate)(struct clk *clk, ulong rate);

// Configure/get phase
int (*get_phase)(struct clk *clk);
int (*set_phase)(struct clk *clk, int degrees);
```

5.3.3 Clock Initialization

There are a total of three categories of interfaces involved in clock initialization, for the sake of subsequent introduction, here first list cru node information

```
cru: clock-controller@ff2b0000 {
    compatible = "rockchip,px30-cru";
    .....
    assigned-clocks =
        <&pmucru PLL_GPLL>, <&pmucru PCLK_PMU_PRE>,
        <&pmucru SCLK_WIFI_PMU>, <&cru ARMCLK>,
        <&cru ACLK_BUS_PRE>, <&cru ACLK_PERI_PRE>,
        <&cru HCLK_BUS_PRE>, <&cru HCLK_PERI_PRE>,
        <&cru PCLK_BUS_PRE>, <&cru SCLK_GPU>;
    assigned-clock-rates =
        <1200000000>, <1000000000>,
        <260000000>, <600000000>,
        <200000000>, <200000000>,
        <150000000>, <150000000>,
        <100000000>, <200000000>;
    .....
}
```

Category I, default initialization of the platform base clock: `rkclk_init()` **:

Each platform cru driver probe will call `rkclk_init()` to complete the pll/cpu/bus frequency initialization, which is defined in `cru_rkxxx.h`. For example, RK3399:

```
#define APLL_HZ          (600 * MHz)
#define GPLL_HZ          (800 * MHz)
#define CPLL_HZ          (384 * MHz)
#define NPLL_HZ          (600 * MHz)
#define PPLL_HZ          (676 * MHz)
#define PMU_PCLK_HZ      ( 48 * MHz)
#define ACLKM_CORE_HZ    (300 * MHz)
```

```
#define ATCLK_CORE_HZ      (300 * MHz)
#define PCLK_DBG_HZ       (100 * MHz)
#define PERIHP_ACLK_HZ    (150 * MHz)
#define PERIHP_HCLK_HZ    ( 75 * MHz)
#define PERIHP_PCLK_HZ    (37500 * KHz)
#define PERILP0_ACLK_HZ   (300 * MHz)
#define PERILP0_HCLK_HZ   (100 * MHz)
#define PERILP0_PCLK_HZ   ( 50 * MHz)
#define PERILP1_HCLK_HZ   (100 * MHz)
#define PERILP1_PCLK_HZ   ( 50 * MHz)
.....
```

Category II, secondary initialization of platform base clock : `clk_set_defaults()`

Each platform cru driver probe may call `clk_set_defaults()` to parse and configure the frequencies (i.e., reconfigure the frequencies) specified by `assigned-clocks/assigned-clock-parents/assigned-clock-rates` within the cru node, but not the arm frequencies. The arm frequency is only reconfigured if `set_armclk_rate()` is implemented, see CPU frequency boosting below.

In addition to cru, peripherals that require it can actively call `clk_set_defaults()` in their own probes, e.g. vop, gmac.

Category III, clock initialization for each module: `clk_set_rate()`

Most peripheral modules call `clk_set_rate()` to configure their frequency

5.3.4 CPU Frequency Boost

For the current CPU frequency boost support in U-Boot for each platform: **Please refer to the Platform Definition section**. It is divided into the following three categories according to the different implementation mechanisms:

Category I: CPU using APLL

cpu boot frequency boost implementation process:

- Step 1: Specify the arm target frequency in the `assigned-clocks` of the cru node.;
- Step 2: cru drives the probe with a call to `clk_set_defaults()` to get (but not configure) the arm target frequency from step 1;
- Step 3: Implement `set_armclk_rate()`, set the arm target frequency obtained from step 2. Some platforms that need it are already implemented by default, other platforms can refer to the existing implementation to add it as needed, e.g.: `arch/arm/mach-rockchip/px30/px30.c`;

```
int set_armclk_rate(void)
{
    struct px30_clk_priv *priv;
    struct clk clk;
    int ret;

    ret = rockchip_get_clk(&clk.dev);
    if (ret) {
        printf("Failed to get clk dev\n");
        return ret;
    }
    clk.id = ARMCLK;
    priv = dev_get_priv(clk.dev);
```

```

    ret = clk_set_rate(&clk, priv->armclk_hz);
    if (ret < 0) {
        printf("Failed to set armclk %lu\n", priv->armclk_hz);
        return ret;
    }
    priv->set_armclk_rate = true;

    return 0;
}

```

- Step 4: Refer to the cpu opp-table (frequency and voltage table), add `regulator-init-microvolt = <...>` to the regulator node of the arm to specify the init voltage, ensure the target frequency and voltage can match.

Category II: CPU using SCMI CLK

For example, for RK356X, boot-up boost requires the use of the scmi interface to set CPU clock related parameters.

The implementation process of cpu boot boost:

- Step 1: Specify the arm target frequency in `rockchip,clk-init` of the scmi node;
- Step 2: Verify that UBOOT has the SCMI, `CONFIG_CLK_SCMI` macro turned on;
- Step 3: Implement `set_armclk_rate()`, set the arm target frequency from the dts node of scmi. Some platforms that require it have already implemented it by default, other platforms can refer to the existing implementation to add it as needed, for example: `arch/arm/mach-rockchip/rk3568/rk3568.c`;

```

#ifdef CONFIG_CLK_SCMI
#include <dm.h>
/*
 * armclk: 1104M:
 *   rockchip,clk-init = <1104000000>,
 *   vdd_cpu : regulator-init-microvolt = <825000>;
 * armclk: 1416M(by default):
 *   rockchip,clk-init = <1416000000>,
 *   vdd_cpu : regulator-init-microvolt = <900000>;
 * armclk: 1608M:
 *   rockchip,clk-init = <1608000000>,
 *   vdd_cpu : regulator-init-microvolt = <975000>;
 */

int set_armclk_rate(void)
{
    struct clk clk;
    u32 *rates = NULL;
    int ret, size, num_rates;

    ret = rockchip_get_scmi_clk(&clk.dev);
    if (ret) {
        printf("Failed to get scmi clk dev\n");
        return ret;
    }

    size = dev_read_size(clk.dev, "rockchip,clk-init");
    if (size < 0)
        return 0;
}

```

```

num_rates = size / sizeof(u32);
rates = calloc(num_rates, sizeof(u32));
if (!rates)
    return -ENOMEM;

ret = dev_read_u32_array(clk.dev, "rockchip,clk-init",
                        rates, num_rates);
if (ret) {
    printf("Cannot get rockchip,clk-init reg\n");
    return -EINVAL;
}
clk.id = 0;
ret = clk_set_rate(&clk, rates[clk.id]);
if (ret < 0) {
    printf("Failed to set armclk\n");
    return ret;
}
return 0;
}
#endif

```

- Step 4: Refer to the cpu opp-table (frequency and voltage table), and add `regulator-init-microvolt = <...>` to the regulator node of arm to specify ini voltage, ensure the target frequency and voltage can match.

SCMI: Please refer to section CH17-Appendix.

Category III: CPU using SCMI CLK

The difference with the Category II is that you only need to perform step 4. the cpu frequency will be automatically increased according to the voltage.。

5.3.5 Clock Tree

The U-Boot framework does not provide clock tree management, and platforms have added `soc_clk_dump()` for simple printing of clock information. Example:

```

CLK: (sync kernel. arm: enter 1200000 KHz, init 1200000 KHz, kernel 800000 KHz)
apll 800000 KHz
dpll 392000 KHz
cp1l 1000000 KHz
gp1l 1188000 KHz
np1l 24000 KHz
pp1l 100000 KHz
hsc1k_bus 297000 KHz
msc1k_bus 198000 KHz
lsc1k_bus 99000 KHz
msc1k_peri 198000 KHz
lsc1k_peri 99000 KHz

```

The meaning of the first printed line:

- `sync kernel`: The cru driver is configured with `clk_set_defaults()` for each of the bus frequencies specified within the kernel cru node (except for the ARM frequency); otherwise it is shown as sync uboot;

- `enter 1200000 KHz`: The arm frequency at which the previous Loader enters U-Boot;
- `init 1200000 KHz`: U-Boot's arm initialization frequency as defined by `APLL_HZ`;
- `kernel 800000 KHz`: Implemented `set_armclk_rate()` and set the arm frequency specified by `assigned-clocks` in the kernel cru node; otherwise displays: “kernel 0N/A”;

5.4 Crypto

The Crypto module is primarily used to implement hardware-level encryption and hashing algorithms and is currently available in v1 and v2 IP versions

5.4.1 Framework Support

U-Boot doesn't have crypto framework support by default, RK has implemented a set by itself.

Configuration:

```
CONFIG_DM_CRYPTO
// choose either one of the below two options, the defconfig of each platform has
// enabled the corresponding configuration by default.
CONFIG_ROCKCHIP_CRYPTOV1
CONFIG_ROCKCHIP_CRYPTOV2
```

Framework Code:

```
./drivers/crypto/crypto-uclass.c
./cmd/crypto.c
```

Driver Code:

```
// crypto v1:
./drivers/crypto/rockchip/crypto_v1.c

// crypto v2:
./drivers/crypto/rockchip/crypto_v2.c
./drivers/crypto/rockchip/crypto_v2_pka.c
./drivers/crypto/rockchip/crypto_v2_util.c
```

5.4.2 Relevant Interface

```
// Get crypto:
struct udevice *crypto_get_device(u32 capability);
// SHA interface:
int crypto_sha_init(struct udevice *dev, sha_context *ctx);
int crypto_sha_update(struct udevice *dev, u32 *input, u32 len);
int crypto_sha_final(struct udevice *dev, sha_context *ctx, u8 *output);
int crypto_sha_csum(struct udevice *dev, sha_context *ctx,
    char *input, u32 input_len, u8 *output);
// RSA interface:
int crypto_rsa_verify(struct udevice *dev, rsa_key *ctx, u8 *sign, u8 *output);
```

- For interface usage, please refer to: `./cmd/crypto.c`;
- Difference on SHA usage between v1 and v2: v1 requires `crypto_sha_init()` to first assign the total length of the data to be computed to `ctx->length`, while v2 does not;

5.4.3 DTS Configuration

crypto nodes must be defined in U-Boot dts, the main reason:

- The kernel dts of the old SDKs for each platform do not have crypto nodes, so you need to consider compatibility with the old SDKs.
- The secure boot of U-Boot will use crypto, so it is safer and more reasonable for U-Boot to control the crypto itself;

1. crypto v1 configuration (RK3399 as an example):

```
crypto: crypto@ff8b0000 {
    u-boot,dm-pre-reloc;

    compatible = "rockchip,rk3399-crypto";
    reg = <0x0 0xff8b0000 0x0 0x10000>;
    clock-names = "sclk_crypto0", "sclk_crypto1";
    clocks = <&cru SCLK_CRYPT0>, <&cru SCLK_CRYPT1>; // No need to specify
frequency, default 100M
    status = "disabled";
};
```

2. crypto v2 configuration (px30 for example):

```
crypto: crypto@ff0b0000 {
    u-boot,dm-pre-reloc;

    compatible = "rockchip,px30-crypto";
    reg = <0x0 0xff0b0000 0x0 0x4000>;
    clock-names = "sclk_crypto", "apbclk_crypto";
    clocks = <&cru SCLK_CRYPT0>, <&cru SCLK_CRYPT0_APK>;
    clock-frequency = <200000000>, <300000000>; // Generally need to specify the
frequency
    status = "disabled";
};
```

- The difference between crypto v1 and v2 dts configurations lies in the clk frequency specification.

5.5 Display

5.5.1 Framework Support

RK U-Boot currently supports the following display interfaces: RGB, LVDS, EDP, MIPI, HDMI, CVBS, DP, etc. The logo images displayed by U-Boot are taken from the kernel root directory, `logo.bmp` and `logo_kernel.bmp`, which are packaged in `resource.img`.

:Requirements for images.

- BI_RGB 8bpp/16bpp/24bpp/32bpp and BI_RLE4/BI_RLE8 format BMP images;
- RK312X/PX30/RK3308/RV1126/RV1106 and other chips based on VOP LITE architecture do not support the mirror function in design. If the displayed logo has a mirror problem in the X/Y direction, please use photoshop or ffmpeg and other tools to process the BMP image in advance to the expected effect.

Configuration:

```
CONFIG_DM_VIDEO
CONFIG_DISPLAY
CONFIG_DRM_ROCKCHIP
CONFIG_DRM_ROCKCHIP_PANEL
CONFIG_DRM_ROCKCHIP_DW_HDMI
CONFIG_DRM_ROCKCHIP_DW_HDMI_QP
CONFIG_DRM_ROCKCHIP_INNO_HDMI
CONFIG_ROCKCHIP_INNO_HDMI_PHY
CONFIG_DRM_ROCKCHIP_INNO_MIPI_PHY
CONFIG_DRM_ROCKCHIP_INNO_VIDEO_PHY
CONFIG_DRM_ROCKCHIP_INNO_VIDEO_COMBO_PHY
CONFIG_DRM_ROCKCHIP_DW_MIPI_DSI
CONFIG_DRM_ROCKCHIP_DW_MIPI_DSI2
CONFIG_DRM_ROCKCHIP_DW_DP
CONFIG_DRM_ROCKCHIP_ANALOGIX_DP
CONFIG_DRM_ROCKCHIP_LVDS
CONFIG_DRM_ROCKCHIP_RGB
CONFIG_DRM_ROCKCHIP_RK618
CONFIG_DRM_ROCKCHIP_RK628
CONFIG_DRM_ROCKCHIP_SAMSUNG_MIPI_DCPHY
CONFIG_PHY_ROCKCHIP_SAMSUNG_HDPTX_HDMI
CONFIG_ROCKCHIP_DRM_TVE
CONFIG_SII902X
```

Framework Code:

```
drivers/video/drm/rockchip_display.c
drivers/video/drm/rockchip_display.h
drivers/video/drm/rockchip_crtc.c
drivers/video/drm/rockchip_crtc.h
drivers/video/drm/rockchip_connector.c
drivers/video/drm/rockchip_connector.h
drivers/video/drm/rockchip_bridge.c
drivers/video/drm/rockchip_bridge.h
drivers/video/drm/rockchip_panel.c
drivers/video/drm/rockchip_panel.h
drivers/video/drm/rockchip_phy.c
drivers/video/drm/rockchip_phy.h
```

Driver file:

```
vop:
drivers/video/drm/rockchip_vop.c
drivers/video/drm/rockchip_vop.h
drivers/video/drm/rockchip_vop_reg.c
drivers/video/drm/rockchip_vop_reg.h
drivers/video/drm/rockchip_vop2.c

rgb:
```

```

drivers/video/drm/rockchip_rgb.c
drivers/video/drm/rockchip_rgb.h

lvds:
drivers/video/drm/rockchip_lvds.c
drivers/video/drm/rockchip_lvds.h

mipi:
drivers/video/drm/drm_mipi_dsi.c
drivers/video/drm/dw_mipi_dsi.c
drivers/video/drm/dw_mipi_dsi2.c

edp:
drivers/video/drm/rockchip_analogix_dp.c
drivers/video/drm/rockchip_analogix_dp.h
drivers/video/drm/rockchip_analogix_dp_reg.c
drivers/video/drm/rockchip_analogix_dp_reg.h

hdmi:
drivers/video/drm/dw_hdmi.c
drivers/video/drm/dw_hdmi.h
drivers/video/drm/rockchip_dw_hdmi.c
drivers/video/drm/rockchip_dw_hdmi.h
drivers/video/drm/dw_hdmi_qp.c
drivers/video/drm/dw_hdmi_qp.h
drivers/video/drm/rockchip_dw_hdmi_qp.c
drivers/video/drm/rockchip_dw_hdmi_qp.h

cvbs:
drivers/video/drm/rockchip_tve.c
drivers/video/drm/rockchip_tve.h

dp:
drivers/video/drm/dw-dp.c

bridge:
drivers/video/drm/rk618.c
drivers/video/drm/rk618.h
drivers/video/drm/rk618_lvds.c
drivers/video/drm/rk618_lvds.c
drivers/video/drm/rk628/
drivers/video/drm/sii902x.c

```

5.5.2 Relevant Interface

```

// Display U-Boot logo and kernel logo:
void rockchip_show_logo(void);

// Display bmp images, currently mainly used for charging image display:
void rockchip_show_bmp(const char *bmp);

// Passes some variables from U-Boot to the kernel via dtb.
// Including kernel logo size, address, format, bcsh/csc configuration, crtc
output scan timing and overscan configuration, etc.
void rockchip_display_fixup(void *blob);

```

5.5.3 DTS Configuration

```
reserved-memory {
    #address-cells = <2>;
    #size-cells = <2>;
    ranges;

    drm_logo: drm-logo@000000000 {
        compatible = "rockchip,drm-logo";
        // Reserve buffer for kernel logo storage, the exact address and size
        // will be modified in U-Boot
        reg = <0x0 0x0 0x0 0x0>;
    };
};

&route-edp {
    status = "okay"; // Enable U-Boot logo display function
    logo,uboot = "logo.bmp"; // Specify the image to display for the
    // U-Boot logo
    logo,kernel = "logo_kernel.bmp"; // Specify the image to display for the
    // kernel logo
    logo,mode = "center"; // center: center display, fullscreen:
    // fullscreen display
    logo,rotate = <90>; // Rotation angle: 90/180/270
    charge_logo,mode = "center"; // center: center display, fullscreen:
    // fullscreen display
    connect = <&vopb_out_edp>; // Determine the display path, vopb-
    // >edp->panelDetermine the display path, vopb->edp->panel
};

&edp {
    status = "okay"; // enable edp
};

&vopb {
    status = "okay"; // enable vopb
};

&panel {
    "simple-panel";
    ...
    status = "okay";

    disp_timings: display-timings {
        native-mode = <&timing0>;
        timing0: timing0 {
            ...
        };
    };
};
```

5.5.4 Defconfig

Currently, except for some platforms that have requirements for boot speed or small memory, U-Boot's defconfig already supports display by default, as long as the relevant information is configured in dts.

RK3308/RV1103/RV1106 and other platforms do not support display by default due to some reasons such as boot speed, and the following modifications need to be added to defconfig:

```
--- a/configs/evb-rk3308_defconfig
+++ b/configs/evb-rk3308_defconfig
@@ -4,7 +4,6 @@ CONFIG_SYS_MALLOC_F_LEN=0x2000
CONFIG_ROCKCHIP_RK3308=y
CONFIG_ROCKCHIP_SPL_RESERVE_IRAM=0x0
CONFIG_RKIMG_BOOTLOADER=y
-# CONFIG_USING_KERNEL_DTB is not set
CONFIG_TARGET_EVB_RK3308=y
CONFIG_DEFAULT_DEVICE_TREE="rk3308-evb"
CONFIG_DEBUG_UART=y
@@ -55,6 +54,11 @@ CONFIG_USB_GADGET_DOWNLOAD=y
CONFIG_G_DNL_MANUFACTURER="Rockchip"
CONFIG_G_DNL_VENDOR_NUM=0x2207
CONFIG_G_DNL_PRODUCT_NUM=0x330d
+CONFIG_DM_VIDEO=y
+CONFIG_DISPLAY=y
+CONFIG_DRM_ROCKCHIP=y
+CONFIG_DRM_ROCKCHIP_RGB=y
+CONFIG_LCD=y
CONFIG_USE_TINY_PRINTF=y
CONFIG_SPL_TINY_MEMSET=y
CONFIG_ERRNO_STR=y
```

Or enable the corresponding .config configuration:

```
// rk3308
make rk3308_defconfig rk3308-display.config
// rv1103/rv1106
make rv1106_defconfig rv1106-display.config
```

Note on the upstream defconfig configuration

upstream maintains a set of Rockchip U-Boot display drivers, currently supporting the RK3288 and RK3399 platforms.:

```
./drivers/video/rockchip/
```

To use this driver, you can turn on CONFIG_VIDEO_ROCKCHIP and turn off CONFIG_DRM_ROCKCHIP, which has some advantages over the display driver we currently use for the SDK:

- Supported platforms and display interfaces are more comprehensive;
- HDMI, DP and other display interfaces can output the specified resolution, overscan effect, display effect, adjustment effect and so on according to the user's settings;
- The U-Boot logo can be smoothly transitioned to the kernel logo until the system boots.

5.5.5 LOGO Partition

Users who have a need to dynamically update the power-up LOGO (usually initiating the update at the application layer) can do so through a separate LOGO partition.

Operational Steps:

- Add a separate LOGO partition to the partition table
- Users can dynamically update the images in the logo partition in a certain way according to their needs.
When updating, users can directly update the original image to the logo partition without any packaging.
When the image in the logo partition is invalid, the default image in the resource file is still used.

LOGO Partition Support:

If the code only contains the following commit, the logo partition only supports 1 image and can only replace the default logo.bmp:

```
1d30bcc rockchip: resource: support parse "logo" partition picture
```

If the code contains the following commit, the logo partition supports 2 images: image 1 is used to replace logo.bmp, and the image 2 is used to replace logo_kernel.bmp. The two images are placed next to each other, with 512-byte alignment between the images, and the order is not replaceable

```
commit 07f987d8d495380787203e2bc2accd44100e6051
Author: Joseph Chen <chenjh@rock-chips.com>
Date: Sun Dec 8 18:00:37 2019 +0800

    rockchip: resource: support parse logo_kernel.bmp from logo partition

    "logo" partition layout, not change order:

    |-----| 0x00
    | raw logo.bmp          |
    |-----| N*512-byte aligned
    | raw logo_kernel.bmp  |
    |-----|

    N: the sector count of logo.bmp

    Signed-off-by: Joseph Chen <chenjh@rock-chips.com>
    Change-Id: I2deba013d3963c99664c5bfd69693835a46ba48f
```

Assuming the images are logo.bmp and logo_kernel.bmp. logo.img package command:

```
cat logo.bmp > logo.img && truncate -s 512 logo.img && cat logo_kernel.bmp >>
logo.img
```

Just download the generated logo.img to the logo partition and you will see “LOGO:” printed after booting:

```
U-Boot 2017.09-g042c01531e-210512-dirty #cjh (May 14 2021 - 11:25:03 +0800)

Model: Rockchip RK3568 Evaluation Board
PreSerial: 2, raw, 0xfe660000
DRAM: 2 GiB
System: init
```

```

Relocation Offset: 7d34f000, fdt: 7b9f8758
Using default environment

dwmmc@fe2b0000: 1, dwmmc@fe2c0000: 2, sdhci@fe310000: 0
Bootdev(atags): mmc 0
MMC0: HS200, 200Mhz
PartType: EFI
boot mode: normal
FIT: No fdt blob
Android 11.0, Build 2021.4, v2
Found DTB in boot part
// The following printout indicates that the image in the logo.img partition was
recognized correctly.
LOGO: logo.bmp
LOGO: logo_kernel.bmp
DTB: rk-kernel.dtb
HASH(c): OK
.....

```

5.5.6 Analysis of Common Problems

Q1: If you want the default mirror display in the X/Y direction, is there any way?

A1: The default mirror display in the Y direction is not supported. The default mirror display in the X direction is not supported for the VOP LITE architecture platform, but for the VOP2 architecture platforms such as RK3568 and RK3588, you can ensure that the X direction is mirrored from U-Boot through the following configuration:

```

&vp1 {
    xmirror-enable;
};

```

Q2: Can it support BMP logo images with 4K resolution?

A2: Yes, it can, but the defconfig of each platform cannot support the normal display of 4K logo images. The following modifications need to be added (taking the rk3576 platform as an example):

```

diff --git a/drivers/video/drm/rockchip_display.c
b/drivers/video/drm/rockchip_display.c
index b1773ba6942..d1606db1ba5 100644
--- a/drivers/video/drm/rockchip_display.c
+++ b/drivers/video/drm/rockchip_display.c
@@ -52,7 +52,7 @@
#define RK_BLK_SIZE 512
#define BMP_PROCESSED_FLAG 8399
#define BYTES_PER_PIXEL sizeof(uint32_t)
-#define MAX_IMAGE_BYTES (8 * 1024 * 1024)
+#define MAX_IMAGE_BYTES (32 * 1024 * 1024)

DECLARE_GLOBAL_DATA_PTR;
static LIST_HEAD(rockchip_display_list);
diff --git a/include/configs/rk3576_common.h b/include/configs/rk3576_common.h
index 16abba314c5..b4a8ec3b898 100644
--- a/include/configs/rk3576_common.h
+++ b/include/configs/rk3576_common.h
@@ -22,7 +22,7 @@

```



```

#endif
#define CONFIG_SPL_LOAD_FIT_ADDRESS    0x42000000

-#define CONFIG_SYS_MALLOC_LEN        (32 << 20)
+#define CONFIG_SYS_MALLOC_LEN        (32 << 21)
#define CONFIG_SYS_CBSIZE              1024

#ifdef CONFIG_SUPPORT_USBPLUG

```

And you need to change the configuration item `CONFIG_DRM_MEM_RESERVED_SIZE_MBYTES` to 64 MB.

- Due to memory usage and default parameter partition table configuration, it is not recommended to use too large BMP logo images, so `MAX_IMAGE_BYTES` is limited to 8 MB. If the size exceeds this, it is recommended to use BI_RLE4/BI_RLE8 format BMP images.
- The common 4K BI_RGB 24bpp BMP image size is about 24 MB. The default malloc heap size of each platform is usually 32 MB, which will cause the BMP decode related functions to fail to apply for memory.
- In order to ensure smooth switching from U-Boot to Kernel logo display, the two logo images are usually of the same resolution and format, so the size of the memory area reserved for the logo display function (determined by `CONFIG_DRM_MEM_RESERVED_SIZE_MBYTES`, 32 MB by default) is not enough.

5.6 Dvfs

The DVFS in this chapter is different from the kernel, which is a dynamic frequency and voltage regulation mechanism specialized for wide temperature chips.

5.6.1 Wide Temperature Strategy

The U-Boot framework doesn't support DVFS, in order to support the wide temperature function for some chips, RK has implemented a set of DVFS wide temperature drivers to adjust the cpu/dmc frequency-voltage according to the chip temperature. However, unlike the kernel DVFS driver, this wide-temperature driver perform control only when the max/low temperature thresholds are triggered.

Wide temperature strategy:

1. The wide temperature driver is used to adjust the frequency-voltage of cpu/dmc, the control strategy can be effective for both cpu and dmc, or only one of them, determined by the dts configuration; the control strategy is the same for both cpu and dmc
2. The wide-temperature driver parses the “trip-point-0” of the opp table, regulator, clock, and thermal zone of the cpu/dmc node to get information about the frequency-voltage range, max/low temperature thresholds, and the maximum voltage allowed;
3. If `rockchip,low-temp = <...>` or `rockchip,high-temp = <...>` is specified in the opp table of the cpu/dmc, the cpu/dmc will not be able to use it. `>` or `rockchip,high-temp = <...>`, or cpu/dmc references a trip node in the thermal zone, then the cpu/dmc wide-temperature control policy will take effect;
4. Key attributes:
 - `rockchip,low-temp`: Minimum temperature threshold, referred to as `TEMP_min` below;;
 - `rockchip,high-temp` 和 `thermal zone`: The maximum temperature threshold, referred to as `TEMP_max` below (if both are valid, they will be compared with the current temperature, strategically);
 - `rockchip,max-volt`: The maximum permissible setting voltage is indicated by `V_max` below;
5. Threshold-triggered processing:
 - If the temperature is higher than `TEMP_max`, reduce both frequency and voltage to the lowest gear;

- If the temperature is below TEMP_min, the default boost is 50mv. If boosting the voltage by 50mv causes the voltage to exceed V_max, the voltage is set to V_max while lower the frequency by 2 gears;

6. The current wide temperature strategy is applied at 2 points:

- After the regulator and clk frameworks are initialized, the wide-temperature driver is initialized and the wide-temperature policy is executed once, which is called in board_init() in the board.c file;
- During the preboot phase (i.e. before loading the firmware), the wide-temperature policy will be executed once more: if attribute such as “repeat” has been specified in the dts node (see below), and the chip temperature is still not within the temperature threshold after executing the current wide-temperature policy, the system will stop booting and the wide-temperature policy will be executed continuously until the chip temperature is back within the temperature threshold before continuing to boot the system. If there is no attribute such as “repeat”, then the system will boot up directly after the current wide-temperature policy is executed, generally, the repeat attribute is not needed at present.

5.6.2 Framework Support

Framework Code:

```
./drivers/power/dvfs/dvfs-uclass.c
./include/dvfs.h
./cmd/dvfs.c
```

Driver Code:

```
./drivers/power/dvfs/rockchip_wtemp_dvfs.c
```

5.6.3 Relevant Interface

```
// Execute the dvfs policy once
int dvfs_apply(struct udevice *dev);

// If the repeat attribute is specified, the dvfs policy will be executed
repeated when the temperature is not within the threshold range
int dvfs_repeat_apply(struct udevice *dev);
```

5.6.4 Enable Wide Temperature

1. Configuration Enable:

```
CONFIG_DM_DVFS=y
CONFIG_ROCKCHIP_WTEMP_DVFS=y

CONFIG_DM_THERMAL=y
CONFIG_ROCKCHIP_THERMAL=y
CONFIG_USING_KERNEL_DTB=y
```

2. Specify CONFIG_PREBOOT:

```

#ifdef CONFIG_DM_DVFS
#define CONFIG_PREBOOT "dvfs repeat"
#else
#define CONFIG_PREBOOT
#endif

```

3. kernel dts configure wide-temperature nodes:

```

uboot-wide-temperature {
    compatible = "rockchip,uboot-wide-temperature";

    // Optional. Indicates whether to have the wide temperature driver stop
    booting the system when the maximum/low temperature threshold of the cpu is
    triggered during the U-Boot phase,
    // and to keep executing the wide temperature processing strategy until the
    chip temperature returns to within the threshold range before continuing to boot
    the system
    cpu,low-temp-repeat;
    cpu,high-temp-repeat;

    // Optional. Indicates whether to stop the wide temperature driver from
    booting the system when the U-Boot stage triggers the dmc's maximum/low
    temperature threshold,
    // and to keep enforcing the wide temperature processing strategy until the
    chip temperature returns to within the threshold range before continuing to boot
    the system.
    dmc,low-temp-repeat;
    dmc,high-temp-repeat;

    status = "okay";
};

```

In general, the repeat-related attributes described above do not need to be configured.

5.6.5 Wide Temperature Results

The following will be printed when cpu temperature control is enabled:

```

// <NULL> indicates that no low temperature threshold is specified
DVFS: cpu: low=<NULL>'c, high=95'c, Vmax=1350000uV, tz_temp=88.0'c, h_repeat=0,
l_repeat=0

```

There will be an adjustment message when the cpu temperature control triggers the high temperature threshold:

```

DVFS: 90.352'c
DVFS: cpu(high): 600000000->408000000 Hz, 1050000->950000 uV

```

There will be an adjustment message when the cpu temperature control triggers the low temperature threshold:

```

DVFS: 10.352'c
DVFS: cpu(low): 600000000->600000000 Hz, 1050000->1100000 uV

```

Similarly, when dmc triggers the high and low temperature thresholds, the above message will be printed with the prefix “dmc”:

```
DVFS: dmc: .....  
DVFS: dmc(high): .....  
DVFS: dmc(low): .....
```

5.7 Efuse/Otp

5.7.1 Framework Support

The efuse/otp driver uses the misc-uclass.c framework and standard interfaces. Genrally, efuse/otp is divided into secure and non-secure, with U-Boot providing access to non-secure and U-Boot SPL providing access to certain areas of secure otp.

non-secure configuration:

```
CONFIG_MISC  
// choose either one of the below two options, the defconfig of each platform has  
enabled the corresponding configuration by default.  
CONFIG_ROCKCHIP_EFUSE  
CONFIG_ROCKCHIP_OTP
```

secure configuration:

```
CONFIG_SPL_MISC=y  
CONFIG_SPL_ROCKCHIP_SECURE_OTP=y
```

framework code:

```
./drivers/misc/misc-uclass.c
```

driver code:

```
// non-secure:  
./drivers/misc/rockchip-efuse.c  
./drivers/misc/rockchip-otp.c  
// secure:  
./drivers/misc/rockchip-secure-otp.S
```

5.7.2 Relevant Interface

```
// non-secure:  
int misc_read(struct udevice *dev, int offset, void *buf, int size)  
// secure:  
int misc_read(struct udevice *dev, int offset, void *buf, int size)  
int misc_write(struct udevice *dev, int offset, void *buf, int size)
```

5.7.3 DTS Configuration

Take rk3308 as an example:

non-secure:

```
otp: otp@ff210000 {
    compatible = "rockchip,rk3308-otp";
    reg = <0x0 0xff210000 0x0 0x4000>;
};
```

secure:

```
secure_otp: secure_otp@0xff2a8000 {
    compatible = "rockchip,rk3308-secure-otp";
    reg = <0x0 0xff2a8000 0x0 0x4000>;
    secure_conf = <0xff2b0004>;
    mask_addr = <0xff540000>;
};
```

5.7.4 Recall Example

take non-secure as an example:

```
char data[10] = {0};
struct udevice *dev;

/* retrieve the device */
ret = uclass_get_device_by_driver(UCLASS_MISC,
                                  DM_GET_DRIVER(rockchip_otp), &dev);
if (ret) {
    printf("no misc-device found\n");
    return 0;
}

misc_read(dev, 0x10, &data, 10);
```

secure example:

```
char data[10] = {0};
struct udevice *dev;
int i;

dev = misc_otp_get_device(OTP_S);
if (!dev)
    return -ENODEV;

for (i = 0; i < 10; i++)
    data[i] = i;

misc_otp_write(dev, 0x10, &data, 10);
memset(data, 0, 10);
misc_otp_read(dev, 0x10, &data, 10);
```

5.7.5 Open Area

Secure-OTP only opens part of the region to read and write, please refer to the document: “Rockchip OTP Development Guide”.

5.8 Ethernet

5.8.1 Framework Support

Framework code:

```
./net/*  
./drivers/net/*  
./drivers/net/phy/*
```

Driver code:

```
./drivers/net/designware.c  
./drivers/net/dwc_eth_qos.c  
./drivers/net/gmac_rockchip.c
```

menuconfig configuration:

- Driver configuration

There are two sets of Rockchip Ethernet drivers, if in doubt about the driver selection, please refer to our corresponding sdk config.

```
// designware:  
CONFIG_DM_ETH=y  
CONFIG_ETH_DESIGNWARE=y  
CONFIG_GMAC_ROCKCHIP=y
```

```
// dwc_eth_qos:  
CONFIG_DM_ETH=y  
CONFIG_DM_ETH_PHY=y  
CONFIG_DWC_ETH_QOS=y  
CONFIG_GMAC_ROCKCHIP=y
```

另外 dwc_eth_qos 驱动需要配置 nocache memory, 参考 RV1126:

In addition the dwc_eth_qos driver needs to be configured with nocache memory, refer to RV1126:.

```
diff --git a/include/configs/rv1126_common.h b/include/configs/rv1126_common.h
index 933917f3f0..9d70795fb8 100644
--- a/include/configs/rv1126_common.h
+++ b/include/configs/rv1126_common.h
@@ -50,6 +50,7 @@
#define CONFIG_SYS_SDRAM_BASE            0
#define SDRAM_MAX_SIZE                   0xfd000000

+#define CONFIG_SYS_NONCACHED_MEMORY     (1 << 20)        /* 1 MiB */
#ifndef CONFIG_SPL_BUILD
```

- cmd configuration

Manually configure the required features .

Command line interface ---> Network commands --->

```
[*] bootp, tftpboot
[ ] tftp put
[ ] tftp download and bootm
[ ] tftp download and flash
[ ] tftpsrv
[ ] rarpboot
-- dhcp
-- pxe
[ ] nfs
-- mii
-- ping
[ ] cdp
[ ] sntp
[ ] dns
[ ] linklocal
[ ] ethsw
```

5.8.2 Relevant Interface

- Data Structure Initialization Interface

```
void net_init(void);
int eth_register(struct eth_device *dev);
int phy_init(void);
```

- Device Registration Interface

```
int eth_register(struct eth_device *dev);
int phy_register(struct phy_driver *drv);
```

- Network data read/write and phy read/write

U-Boot's data sending and receiving needs to be called actively, no interrupt or polling method is used, the specific implementation can refer to NetLoop().

```

int eth_send(void *packet, int length);
int eth_rx(void);

int phy_read(struct phy_device *phydev, int devad, int regnum);
int phy_write(struct phy_device *phydev, int devad, int regnum, u16 val);

```

5.8.3 DTS Configuration

DTS nodes, like kernels, need to be concerned with the configuration of the following board-related attributes:

- phy interface configuration (phy-mode)
- phy reset pin and reset time (snps,reset-gpio) (snps,reset-delays-us)
- Clock output direction for mcu (clock_in_out)
- Clock source selection and frequency setting (assigned-clock-parents) (assigned-clock-rates)
- RGMII Delayline, RGMII interface requirement (tx_delay) (rx_delay)

```

&gmac {
    phy-mode = "rgmii";
    clock_in_out = "input";

    snps,reset-gpio = <&gpio3 RK_PA0 GPIO_ACTIVE_LOW>;
    snps,reset-active-low;
    /* Reset time is 20ms, 100ms for rtl8211f */
    snps,reset-delays-us = <0 20000 100000>;

    assigned-clocks = <&cru CLK_GMAC_SRC>, <&cru CLK_GMAC_TX_RX>, <&cru
CLK_GMAC_ETHERNET_OUT>;
    assigned-clock-parents = <&cru CLK_GMAC_SRC_M1>, <&cru RGMII_MODE_CLK>;
    assigned-clock-rates = <125000000>, <0>, <250000000>;

    pinctrl-names = "default";
    pinctrl-0 = <&rgmiim1_pins &clk_out_ethernetm1_pins>;

    tx_delay = <0x2a>;
    rx_delay = <0x1a>;

    phy-handle = <&phy>;
    status = "okay";
};

```

5.8.4 Usage Example

Commonly used network commands:

- DHCP

```

Usage:
dhcp [loadAddress] [[hostIPAddr:]bootfilename]

```

With this command, there is no need to set serverip, ipaddr, and gateway.

When dhcp successfully gets the ip address from the dhcp server, it will obtain the file by tftp from the hostIPAddr address.

[illegible]

```
=> ping 192.168.0.1
ethernet@fffc40000 Waiting for PHY auto negotiation to complete. done
Using ethernet@fffc40000 device
host 192.168.0.1 is alive
```

000M environment:

You can also set your own IP address:

[illegible]

- Is the firewall on the computer not turned off?
- If it is cross-network segments, confirm whether the gateway is set or not;
- Is the TFTP server configured correctly;
- Whether the TFTP function is disabled on some routers.

2. Code issues, in general, are traced in 3 main aspects:

- Check the pinctrl configuration is correct or not. Check if the iomux and drive strength of the relevant pins is correct or not, you can also dump the relevant registers and compare them with the kernel to see if they are the consistent. In most cases, we adjust the kernel's network first before adjusting U-Boot.
- Check the clock configuration is correct or not. The clock configuration check is relatively more troublesome, mainly checking the division ratio, clock source, and clock direction, most of the registers in the CRU, there are also some chips whose registers in the GRF. You can also dump the relevant registers to compare with the kernel to see if they are consistent.
- PHY reset pin. It mainly detects whether the reset pin is configured correctly and whether the reset waveform meets the PHY requirements.

5.9 Gpio

5.9.1 Framework Support

GPIO driver using gpio-uclass framework and standard interfaces

Configurations:

```
CONFIG_DM_GPIO
CONFIG_ROCKCHIP_GPIO
```

Framework Code:

```
./drivers/gpio/gpio-uclass.c
```

Driver Code:

```
./drivers/gpio/rk_gpio.c
```

5.9.2 DM Interface

DM standard interface. To access gpio, the user must pass `struct gpio_desc`, the recommended type.

```
// Request/Release GPIO
int gpio_request_by_name(struct udevice *dev, const char *list_name,
                        int index, struct gpio_desc *desc, int flags);
int gpio_request_by_name_nodev(ofnode node, const char *list_name, int index,
                              struct gpio_desc *desc, int flags);
int gpio_request_list_by_name(struct udevice *dev, const char *list_name,
                              struct gpio_desc *desc_list, int max_count, int
                              flags);
int gpio_request_list_by_name_nodev(ofnode node, const char *list_name,
                                    struct gpio_desc *desc_list, int max_count,
                                    int flags);
int dm_gpio_free(struct udevice *dev, struct gpio_desc *desc)

// Configure GPIO direction. @flags: GPIOD_IS_OUT (output) 和 GPIOD_IS_IN (input)
int dm_gpio_set_dir_flags(struct gpio_desc *desc, ulong flags);

// Set/Get GPIO level
int dm_gpio_get_value(const struct gpio_desc *desc)
int dm_gpio_set_value(const struct gpio_desc *desc, int value)
```

Notes:

The return value of `dm_gpio_get_value()` indicates the active state, not a high or low level. Example:

- `gpios = <&gpio2 RK_PD0 GPIO_ACTIVE_LOW>`, the return value is 1 for a low level and 0 for a high level.
- `gpios = <&gpio2 RK_PD0 GPIO_ACTIVE_HIGH>`, the return value is 0 for a low level and 1 for a high level.

The same is true for the `dm_gpio_set_value()` parameter `value1: atcive, 0: inactive`.

5.9.3 Legacy Interface

Compatible interface type. This interface type is mainly compatible with the old U-Boot API, the internal implementation of the function is still essentially going through the DM framework, but externally shield with `struct gpio_desc`. The function is available, but from the point of view of DM code standardization, it is not recommended.

```
int gpio_request(unsigned gpio, const char *label)
int gpio_free(unsigned gpio)
int gpio_direction_input(unsigned gpio)
int gpio_direction_output(unsigned gpio, int value)
int gpio_get_value(unsigned gpio)
int gpio_set_value(unsigned gpio, int value)
```

The `@gpio` is calculated based on the rule that each group of GPIOs has 32 pins and each bank has 8 pins.
Example:

```
gpio0_a7 = (0 * 32) + (0 * 8) + 7 = 7
gpio1_b6 = (1 * 32) + (1 * 8) + 6 = 46
gpio3_c2 = (3 * 32) + (2 * 8) + 2 = 114
```

`@value`: The function is consistent with the interface of type `dm_gpio_` above.

5.10 Interrupt

5.10.1 Framework Support

U-Boot native code does not have an interrupt framework, RK has implemented a set of interrupts framework to support GICv2/v3, which are enabled by default.

Scenarios currently need interrupt framework:

- Pwrkey: When U-Boot is charging, the CPU will enter low-power hibernation, and you need to wake up the CPU through Pwrkey interrupt;
- Timer: Timer interrupts are used in U-Boot charging and test cases;
- Debug: Enable CONFIG_ROCKCHIP_DEBUGGER debugging;

Configuration:

```
CONFIG_IRQ
CONFIG_GICV2
CONFIG_GICV3
```

Framework code:

```
./drivers/irq/irq-gpio-switch.c
./drivers/irq/irq-gpio.c
./drivers/irq/irq-generic.c
./drivers/irq/irq-gic.c
./drivers/irq/virq.c
./include/irq-generic.h
```

5.10.2 Related Interface

```
// CPU local interrupt switch
void enable_interrupts(void);
int disable_interrupts(void);

// GPIO converted to Interrupt Number
int gpio_to_irq(struct gpio_desc *gpio);
int phandle_gpio_to_irq(u32 gpio_phandle, u32 pin);
int hard_gpio_to_irq(unsigned gpio);

// Registering/Releasing Interrupt Callbacks
void irq_install_handler(int irq, interrupt_handler_t *handler, void *data);
void irq_free_handler(int irq);

// Enable/disable interrupt
int irq_handler_enable(int irq);
int irq_handler_disable(int irq);

// Interrupt trigger type
int irq_set_irq_type(int irq, unsigned int type);
```

IRQ Request

- Peripherals with separate hardware interrupt numbers do not require additional conversions, e.g. pwm, timer, etc.
- The pin of the GPIO does not have a separate hardware interrupt number and requires an additional conversion request.

There are three ways to request the interrupt number of the pin of the GPIO:

(1) Input `struct gpio_desc` structure

```
// This method can dynamically parse the dts configuration, which is more
flexible and commonly used.
int gpio_to_irq(struct gpio_desc *gpio);
```

Example:

```
battery {
    compatible = "battery,rk817";
    .....
    dc_det_gpio = <&gpio2 7 GPIO_ACTIVE_LOW>;
    .....
};
```

```

struct gpio_desc dc_det;
int ret, irq;

ret = gpio_request_by_name_nodem(dev_ofnode(dev), "dc_det_gpio", 0,
                                &dc_det, GPIOD_IS_IN);
// For the sake of simplicity of the example, the return value judgment is
omitted.
if (!ret) {
    irq = gpio_to_irq(&dc_det);
    irq_install_handler(irq, ...);
    irq_set_irq_type(irq, IRQ_TYPE_EDGE_FALLING);
    irq_handler_enable(irq);
}

```

(2) Input gpio 's phandle and pin

```

// This method can dynamically parse the dts configuration, which is more
flexible and commonly used.
int phandle_gpio_to_irq(u32 gpio_phandle, u32 pin);

```

Example (rk817 interrupt pin is GPIO0_A7)

```

rk817: pmic@20 {
    compatible = "rockchip,rk817";
    reg = <0x20>;
    .....
    interrupt-parent = <&gpio0>;           // "&gpio0": the phandle pointing to
the gpio0 node;;
    interrupts = <7 IRQ_TYPE_LEVEL_LOW>;   // "7": pin;
    .....
};

```

```

u32 interrupt[2], phandle;
int irq, ret;

phandle = dev_read_u32_default(dev->parent, "interrupt-parent", -1);
if (phandle < 0) {
    printf("failed get 'interrupt-parent', ret=%d\n", phandle);
    return phandle;
}

ret = dev_read_u32_array(dev->parent, "interrupts", interrupt, 2);
if (ret) {
    printf("failed get 'interrupt', ret=%d\n", ret);
    return ret;
}

// For the sake of simplicity of the example, the return value judgment is
omitted.
irq = phandle_gpio_to_irq(phandle, interrupt[0]);
irq_install_handler(irq, pwrkey_irq_handler, dev);
irq_set_irq_type(irq, IRQ_TYPE_EDGE_FALLING);
irq_handler_enable(irq);

```

(3) force to specify gpio

```
// This method forces the gpio to be specified directly, and the incoming gpio
must be declared by a special macro, which is not flexible enough and is not
recommended.
int hard_gpio_to_irq(unsigned gpio);
```

Example (GPIO0_A0 request is interrupted)

```
int gpio0_a0, irq;

// For the sake of simplicity of the example, the return value judgment is
omitted.
gpio0_a0 = RK_IRQ_GPIO(RK_GPIO0, RK_PA0);
irq = hard_gpio_to_irq(gpio0_a0);
irq_install_handler(irq, ...);
irq_handler_enable(irq);
```

5.11 I2C

5.11.1 Framework Support

The i2c driver uses the i2c-uclass framework and standard interfaces.

Configuration:

```
CONFIG_DM_I2C
CONFIG_SYS_I2C_ROCKCHIP
```

Framework code:

```
./drivers/i2c/i2c-uclass.c
```

Driver code:

```
./drivers/i2c/rk_i2c.c
./drivers/i2c/i2c-gpio.c    // gpio emulates i2c communication, which is not used
at the moment
```

5.11.2 Relevant Interface

```
// i2c read/write
int dm_i2c_read(struct udevice *dev, uint offset, uint8_t *buffer, int len)
int dm_i2c_write(struct udevice *dev, uint offset, const uint8_t *buffer, int
len)

// encapsulation of the above interface
int dm_i2c_reg_read(struct udevice *dev, uint offset)
int dm_i2c_reg_write(struct udevice *dev, uint offset, unsigned int val);
```

5.12 IO-Domain

5.12.1 Framework Support

The U-Boot framework does not have io-domain support by default, but RK implements a set by itself.

Configuration:

```
CONFIG_IO_DOMAIN
CONFIG_ROCKCHIP_IO_DOMAIN
```

Framework code:

```
./drivers/power/io-domain/io-domain-uclass.c
```

Driver code:

```
./drivers/power/io-domain/rockchip-io-domain.c
```

5.12.2 Relevant Interface

```
void io_domain_init(void)
```

Users don't need to actively call `io_domain_init()`, just enable the above configuration and the U-Boot framework will automatically initialize the

5.13 Key

5.13.1 Framework Support

The U-Boot framework does not support keystrokes by default, RK implements a set of keystrokes by itself.

Realization rules::

- All keys are specified through the kernel and U-Boot's DTS. U-Boot does not use hard code to define any keys;
- U-Boot prioritizes the search for the keys in the kernel dts, and then looks for keys in the U-Boot dts if it can't find them.
- Only the downloading keys are defined in the U-Boot dts.
- If the user wants to update the downloading key definitions, it is needed to update both the kernel and U-Boot dts.

Configuration:


```
CONFIG_DM_KEY
CONFIG_RK8XX_PWRKEY
CONFIG_ADC_KEY
CONFIG_GPIO_KEY
CONFIG_RK_KEY
```

Framework code:

```
./include/dt-bindings/input/linux-event-codes.h
./drivers/input/key-uclass.c
./include/key.h
```

Driver code:

```
./drivers/input/rk8xx_pwrkey.c    // Support PMIC pwrkey(RK805/RK809/RK816/RK817)
./drivers/input/rk_key.c          // Support compatible = "rockchip,key"
./drivers/input/gpio_key.c        // Support compatible = "gpio-keys"
./drivers/input/adc_key.c         // Support compatible = "adc-keys"
```

pwrkey is recognized only in interrupt mode, the rest of the gpio keys are recognized in polling mode.

5.13.2 Relevant Interface

Interface:

```
int key_read(int code)
```

code definition:

```
/include/dt-bindings/input/linux-event-codes.h
```

Returned value:

```
enum key_state {
    KEY_PRESS_NONE,          // Non-complete short press (no key release) or non-
    complete long press (not pressed long enough);
    KEY_PRESS_DOWN,          // One complete short press (press => release);
    KEY_PRESS_LONG_DOWN,     // One full long press (can be unreleased);
    KEY_NOT_EXIST,           // key does not exist
};
```

KEY_PRESS_LONG_DOWN Default duration 2000ms, currently only used for U-Boot charging pwrkey long press event.

```
#define KEY_LONG_DOWN_MS    2000
```

Example:

```
int ret;

ret = key_read(KEY_VOLUMEUP);
...
```

5.14 Led

5.14.1 Framework Support

The Led driver uses the led-uclass.c framework and standard interfaces.

Configuration:

```
CONFIG_LED_GPIO
```

Framework code:

```
drivers/led/led-uclass // Default Compilation
```

Driver code:

```
drivers/led/led_gpio.c // Support compatible = "gpio-leds"
```

5.14.2 Relevant Interface

```
// obtain led device
int led_get_by_label(const char *label, struct udevice **devp);
// set/obtain led status
int led_set_state(struct udevice *dev, enum led_state_t state);
enum led_state_t led_get_state(struct udevice *dev);
// Please ignore this, no underlying driver implementation done currently
int led_set_period(struct udevice *dev, int period_ms);
```

5.14.3 DTS Node

U-Boot's led_gpio.c is relatively simple, parsing only 3 attributes under the led node:

- gpios: led control pins and active states;
- label: led label;
- default-state: default states, set when the probe is driven;

```
leds {
    compatible = "gpio-leds";
    status = "okay";

    blue-led {
        gpios = <&gpio2 RK_PA1 GPIO_ACTIVE_LOW>;
        label = "battery_full";
    }
}
```

```

        default-state = "off";
    };

    green-led {
        gpios = <&gpio2 RK_PA0 GPIO_ACTIVE_LOW>;
        label = "greenled";
        default-state = "off";
    };

    .....
};

```

5.15 Mtd

MTD (Memory Technology Device) i.e. Memory Technology Device, supports parallel port nand, spi nand, spi nor

5.15.1 Framework Support

```

CONFIG_MTD=y
CONFIG_CMD_MTD=y

```

5.15.2 Relevant Interface

Common interfaces are listed below:

```

struct mtd_info *get_mtd_device_nm(const char *name);
int mtd_read(struct mtd_info *mtd, loff_t from, size_t len, size_t *retlen,
u_char *buf);
int mtd_write(struct mtd_info *mtd, loff_t to, size_t len, size_t *retlen, const
u_char *buf);
int mtd_erase(struct mtd_info *mtd, struct erase_info *instr);
int mtd_block_isbad(struct mtd_info *mtd, loff_t ofs);
int mtd_block_markbad(struct mtd_info *mtd, loff_t ofs);

```

5.15.3 Usage Example

spi nor loading firmware example

Take flash offset 0x400000 byte, 0x800 bytes data to memory address 0x4000000 as an example:

```

#include <mtd.h>

#define MTD_SPINOR_NAME    "nor0"

static int mtd_demo(void)
{
    char *mtd_name = MTD_SPINOR_NAME;
    struct mtd_info *mtd;

```

```

size_t retlen, off, size;
u_char *des_buf;
int ret;

mtd = get_mtd_device_nm(mtd_name);
if (IS_ERR_OR_NULL(mtd)) {
    printf("MTD device %s not found, ret %ld\n",
           mtd_name, PTR_ERR(mtd));
    return CMD_RET_FAILURE;
}

des_buf = (u_char *)0x4000000;

off = 0x4000000;
size = 0x800;

ret = mtd_read(mtd, off, size, &retlen, des_buf);
if (ret || size != retlen) {
    pr_err("mtd read fail, ret=%d retlen=%ld size=%ld\n", ret, retlen, size);
}

return ret;
}

```

Nand Example

Recommendations:

- Refer to drivers/mtd/nand/nand_util.c, use the read/write/erase interface with bad block identification.
- For a complete write with a small amount of data (usually less than 2KB per power-up), consider using the MTD_BLK related interface, as frequent calls to this interface will affect the flash lifetime.

5.16 Mtd_blk

RK has designed MTD block layer based on MTD interface, which supports parallel port nand, spi nand, spi nor, and registers the corresponding MTD block device to support the corresponding block interface.

Features:

- The unit is sector, i.e. 512B
- No matter how much data is written in a single write request, the flash block corresponding to the data will be erased, so calling this interface for piecemeal and frequent writes will affect the lifetime of the flash.

5.16.1 Framework Support

U-Boot Configuration:

```
// MTD driver
CONFIG_MTD=y
CONFIG_CMD_MTDPARTS=y
CONFIG_MTD_DEVICE=y

// MTD block device driver
CONFIG_CMD_MTD_BLK=y
CONFIG_MTD_BLK=y

// Other nand device drivers config
.....
```

SPL configuration:

```
CONFIG_MTD=y
CONFIG_CMD_MTDPARTS=y
CONFIG_MTD_DEVICE=y
CONFIG_SPL_MTD_SUPPORT=y

// Other nand device drivers config
.....
```

Framework Code:

```
drivers/mtd/mtd-uclass.c
drivers/mtd/mtdcore.c
drivers/mtd/mtd_uboot.c
drivers/mtd/mtd_blk.c
```

The drivers are individual controller drivers that hook up interfaces such as read/write to the MTD layer.

5.16.2 Relevant Interface

```
unsigned long blk_dread(struct blk_desc *block_dev, lbaint_t start,
                      lbaint_t blkcnt, void *buffer)
unsigned long blk_dwrite(struct blk_desc *block_dev, lbaint_t start,
                      lbaint_t blkcnt, const void *buffer)
```

5.17 Optee Client

U-Boot belongs to Non-Secure World in ARM TrustZone and requires OPTEE Client to access secure resources.

5.17.1 Framework Support

The U-Boot framework does not support the OPTEE Client feature by default, However, RK implements a set by itself.

Configuration:

```
// Enabled all the time
CONFIG_OPTEE_CLIENT

// Used on older platforms, such as RK312x、RK322x、RK3288、RK3228H、RK3368、RK3399
CONFIG_OPTEE_V1
// Used on new platforms, , 如 RK3326、RK3308
CONFIG_OPTEE_V2
// 当 eMMC 的 RPMB 不能用时必须开启此配置，即启用security分区This configuration must be
enabled when RPMB for eMMC is not available, i.e., enable security partitioning!
CONFIG_OPTEE_ALWAYS_USE_SECURITY_PARTITION
```

Frameworks and drivers:

```
lib/optee_clientApi/
```

5.17.2 Firmware Description

The trust.img used must have TA enabled or it will not be able to interact with the OPTEE Client.

5.17.3 Interface Description

The Optee client driver is in the lib/optee_client directory, for the Optee Client Api, please refer to 《TEE_Client_API_Specification-V1.0_c.pdf》。

The download address is: <https://globalplatform.org/specs-library/tee-client-api-specification/>

Based on Optee's built-in TA functionality, RK encapsulates an interface to use the built-in TA functionality in the Optee client. The source code of the interface can be found

in lib\optee_clientApi\OpteeClientInterface.c, when using it, please include the header file include\optee_include\OpteeClientInterface.h`。

Please see the following explanations for APIs .

5.17.3.1 Suitability

The following interfaces are available on each platform: **Please refer to the Platform Definition section.**

```
trusty_read_vbootkey_hash()
trusty_write_vbootkey_hash()
trusty_read_vbootkey_enable_flag()
trusty_write_oem_otp_key()
trusty_oem_otp_key_is_written()
trusty_set_oem_hr_otp_read_lock()
trusty_oem_otp_key_cipher()
```

5.17.3.2 Return Value

If not otherwise noted, the return values for the following APIs are shown in the [Return Codes](#) section of the above document [TEE_Client_API_Specification-V1.0_c.pdf](#).

5.17.3.3 trusty_read_vbootkey_hash

```
uint32_t trusty_read_vbootkey_hash(uint32_t *buf, uint32_t length);
```

Functions

Retrieves the hash of the secure boot public key from OTP or eFuse.

Related explanations on Secure boot, please refer

to [Rockchip_Developer_Guide_Secure_Boot_Application_Note_EN](#).

**** Parameters****

- [out] buf - The hash buffer to be read
- [in] length - Hash length, the specific length of the supported hash algorithms to secure boot documents, the length unit is in word (32bits).

5.17.3.4 trusty_write_vbootkey_hash

```
uint32_t trusty_write_vbootkey_hash(uint32_t *buf, uint32_t length);
```

Function

Write the hash value of the secure boot public key in OTP or eFuse, **enable the secure boot flag, turn on secure boot.**

Secure boot related description, please refer

to [Rockchip_Developer_Guide_Secure_Boot_Application_Note_EN](#) file.

Parameter

- [in] buf - The hash buffer to be written
- [in] length - hash length, the length of the supported hash algorithms is based on the secure boot documentation, the length unit is in word (32bits).

5.17.3.5 trusty_read_vbootkey_enable_flag

```
uint32_t trusty_read_vbootkey_enable_flag(uint8_t *flag);
```

Function

read the flag indicating secure boot is on or not.

Secure boot related explanation please

see [Rockchip_Developer_Guide_Secure_Boot_Application_Note_EN](#) file.

Parameters

- [in] flag - 1 Byte, 1 means secure boot is on, 0 means off.

5.17.3.6 trusty_write_oem_otp_key

```
uint32_t trusty_write_oem_otp_key(enum RK_OEM_OTP_KEYID key_id,
                                  uint8_t *byte_buf,
                                  uint32_t byte_len);
```

Function

Write the plaintext key to the specified OEM OTP area.

For a description of the relevant features of the OEM OTP, see the [Rockchip_Developer_Guide_OTP_CN](#) document.

Parameter

- [in] key_id - the key_id that will be written, default support `RK_OEM_OTP_KEY0 - 3` total 4 keys, for rv1126/rv1109, additional support for key_id is `RK_OEM_OTP_KEY_FW` key.
`RK_OEM_OTP_KEY_FW`: the key used by Boot ROM to decrypt the loader, the `trusty_oem_otp_key_cipher` interface supports to use this key to do the business data encryption and decryption or decrypt the kernel image.
- [in] byte_buf - plaintext key
- [in] byte_len - Plaintext key length, for `RK_OEM_OTP_KEY_FW`, byte_len supports 16 only, for other keys, byte_len supports 16, 24, 32.

5.17.3.7 trusty_oem_otp_key_is_written

```
uint32_t trusty_oem_otp_key_is_written(enum RK_OEM_OTP_KEYID key_id, uint8_t *value);
```

Function

Determines whether the key has been written to the specified OEM OTP area.

For a description of the relevant features of the OEM OTP, see the [Rockchip_Developer_Guide_OTP_CN](#) document.

Parameter

- [in] key_id - index of the key area to be written, default support `RK_OEM_OTP_KEY0 - 3` total 4 keys, for rv1126/rv1109, additionally support key with key_id `RK_OEM_OTP_KEY_FW`
- [out] value - Determines whether the secret key has been written, 1 means it has been written, 0 means it has not been written.

Return value

The return value is meaningful when the value is `#define TEEC_SUCCESS 0x00000000`

The RK3588 platform will also determine whether the key_id is locked or not, if the corresponding key_id is locked then it will return `#define TEEC_ERROR_ACCESS_DENIED 0xFFFF0001` error.

5.17.3.8 trusty_set_oem_hr_otp_read_lock

```
uint32_t trusty_set_oem_hr_otp_read_lock(enum RK_OEM_OTP_KEYID key_id);
```

Function

Set the read lock flag of the specified OEM OTP region, after successful setting, the region is prohibited to write data, and the existing data in the region is not readable by the CPU software, and the key can be used through the `trusty_oem_otp_key_cipher` interface.

For a description of the relevant features of the OEM OTP, see the `Rockchip_Developer_Guide_OTP_CN` document.

Note: When the `key_id` is set to `RK_OEM_OTP_KEY0` or `RK_OEM_OTP_KEY1` or `RK_OEM_OTP_KEY2`, it will affect the attributes of the other OTP areas after the successful setup, e.g., some of the OTP areas become unwritable, see `Rockchip_Developer_Guide_OTP_CN` documentation

Parameter

- [in] `key_id` - `key_id` to be set, Support `RK_OEM_OTP_KEY0 - 3`

5.17.3.9 `trusty_oem_otp_key_cipher`

```
uint32_t trusty_oem_otp_key_cipher(enum RK_OEM_OTP_KEYID key_id,
                                   rk_cipher_config *config,
                                   uint32_t src_phys_addr,
                                   uint32_t dst_phys_addr,
                                   uint32_t len);
```

Function

Select the key for the OEM OTP region to perform a cipher single calculation.

Parameter

- [in] `key_id` - the `key_id` to be used, `RK_OEM_OTP_KEY0 - 3` are supported by default, for rv1126/rv1109, `RK_OEM_OTP_KEY_FW` is additionally supported.
- [in] `config` - Algorithms, patterns, keys, iv, etc.

Support AES, SM4 algorithms

Support ECB/CBC/CTS/CTR/CFB/OFB modes

The key length supports 16, 24, 32 Bytes, if it is rv1109/rv1126 platform, the key length only supports 16, 32, when the `key_id` is `RK_OEM_OTP_KEY_FW` the key length only supports 16.

- [in] `src_phys_addr` - The buffer address of the data to be computed, which supports the same as `dst_phys_addr`, i.e. supports in-place encryption and decryption
- [out] `dst_phys_addr` - The buffer address of the result of the calculation, which supports the same as `src_phys_addr`
- [in] `len` - Byte length of the input and output data buffer, required to be aligned with the block of the algorithm used

5.17.4 Shared Memory.

When U-Boot communicates with Optee, the data should be put in shared memory. Users can request shared memory through `TEEC_AllocateSharedMemory()`, but it is recommended not to exceed 1M, if it exceeds 1M, it is recommended to split the data for multiple passes, and call `TEEC_ReleaseSharedMemory()` to release the shared memory after use.

5.17.5 Test Command

Purpose: To test the secure storage feature. the U-Boot command line:

```
=> mmc testsecurestorage
```

This test case will cycle through the secure storage read and write functions, testing both rpmb and security partition secure storage when the hardware is using emmc, and only security partition secure storage when the hardware is using nand.

5.17.6 Common Misprints

- No emmc or nand device was found. Check if the U-Boot is missing configuration or if the hardware is damaged.

```
"TEEC: Could not find device"
```

- No security partition found. When no RPMB is available, you need to define the security partition in parameter.txt.

```
"TEEC: Could not find security partition"
```

- This printout appears the first time a security partition is used for secure storage or if the security partition data has been illegally tampered with.

```
"TEEC: verify [%d] fail, cleaning ...."
```

- There is not enough space in the secure storage. Please check if the stored data is too large, or if a large amount of data was previously stored but not deleted.

```
"TEEC: Not enough space available in secure storage !"
```

5.18 PCIe

5.18.1 Development Notes

Confirm at which stage of u-boot boot the PCIe is applied and configure the dts accordingly:

1. The NVME, as a boot device, needs to be initialized as early as possible, and all subsequent firmware is in this NVME, so the PCIe can only be configured using the dts of the u-boot
2. Devices that are not used as boot devices, such as those that support network cards, are allowed to initialize later, and since the u-boot framework supports the use of the kernel dtb, use the configuration in the kernel dtb in the boot.img
3. In u-boot phase, PCIe RC only registers mem 32bits range, not applicable to mem 64bits-pref space

5.18.2 Framework Support

Framework code:

```
./drivers/pci/*  
./drivers/phy/*
```

Driver code:

```
drivers/pci/pcie_dw_rockchip.c  
drivers/phy/phy-rockchip-snps-pcie3.c
```

menuconfig configuration:

- Driver configuration

For the currently supported platforms of the Rockchip PCIe driver, please check the compatible attribute in the pcie_dw_rockchip.c file, and if you are in doubt about the driver selection, please refer to our corresponding sdk config.

```
CONFIG_DM_REGULATOR_GPIO=y  
CONFIG_DM_REGULATOR_FIXED=y  
CONFIG_PCI=y  
CONFIG_DM_PCI=y  
CONFIG_DM_PCI_COMPAT=y  
CONFIG_PCI_PNP=y  
CONFIG_PCIE_DW_ROCKCHIP=y  
CONFIG_PHY_ROCKCHIP_SNPS_PCIE3=y  
CONFIG_PHY_ROCKCHIP_NANENG_COMBOPHY=y  
CONFIG_PHY=y  
CONFIG_CMD_PCI=y  
//Add NVMe support  
CONFIG_NVME=y  
CONFIG_CMD_NVME=y  
// Add PCIe to USB support  
CONFIG_USB_XHCI_PCI=y  
//Add Embedded DTB support, the image size will be bigger after adding Embedded DTB support.  
CONFIG_EMBED_KERNEL_DTB_ALWAYS=y  
CONFIG_SPL_FIT_IMAGE_KB=2560
```

5.18.3 DTS Configuration

Loading Program Selection Recommendations:

- flash + PCIe NVMe dual storage solution: use PCIe before loading kernel dtb
- Using PCIe support in AMP scenarios: using PCIe after loading Embedded dtb
- Common practice: load the kernel dtb and then use PCIe.

Use PCIe before loading kernel dtb

It is recommended to refer to the kernel DTB node configuration to set up the uboot dtsi related nodes and add the u-boot,dm-pre-reloc attribute:

- phy power supply, can be left off if already enabled by default
- vcc 3v3 power supply
- phy nodes
- controller node

Take the RK3588 PCIe3x4 as an example:

```
diff --git a/arch/arm/dts/rk3588-u-boot.dtsi b/arch/arm/dts/rk3588-u-boot.dtsi
index 3fe8054aac..a8e2defbad 100644
--- a/arch/arm/dts/rk3588-u-boot.dtsi
+++ b/arch/arm/dts/rk3588-u-boot.dtsi
@@ -22,6 +22,28 @@
+
+       compatible = "rockchip,rk3588-secure-otp";
+       reg = <0x0 0xfe3a0000 0x0 0x4000>;
+
+   };
+
+   +
+   +       vcc12v_dcin: vcc12v-dcin {
+   +           u-boot,dm-pre-reloc;
+   +           compatible = "regulator-fixed";
+   +           regulator-name = "vcc12v_dcin";
+   +           regulator-always-on;
+   +           regulator-boot-on;
+   +           regulator-min-microvolt = <12000000>;
+   +           regulator-max-microvolt = <12000000>;
+   +       };
+   +
+   +       vcc3v3_pcie30: vcc3v3-pcie30 {
+   +           u-boot,dm-pre-reloc;
+   +           compatible = "regulator-fixed";
+   +           regulator-name = "vcc3v3_pcie30";
+   +           regulator-min-microvolt = <3300000>;
+   +           regulator-max-microvolt = <3300000>;
+   +           enable-active-high;
+   +           gpio = <&gpio3 RK_PC3 GPIO_ACTIVE_HIGH>;
+   +           startup-delay-us = <5000>;
+   +           vin-supply = <&vcc12v_dcin>;
+   +       };
+   };
+
+   &firmware {
+@@ -117,6 +139,19 @@
+       status = "okay";
+   };
+
+   +&pcie30phy {
+   +       u-boot,dm-pre-reloc;
+   +       rockchip,pcie30-phy-mode = <PHY_MODE_PCIE_AGGREGATION>;
+   +       status = "okay";
+   +   };
+   +
+   +   +&pcie3x4 {
+   +       u-boot,dm-pre-reloc;
+   +       reset-gpios = <&gpio4 RK_PB6 GPIO_ACTIVE_HIGH>;
+   +       vpcie3v3-supply = <&vcc3v3_pcie30>;
+   +       status = "okay";
+   +   };
+   +
```

```
uart2_{
    u-boot,dm-spl;
    status = "okay";
}
```

Take RK3566 as an example:

```
From b58a47956bbd03de0fcef572fa06cdeea974e2a9 Mon Sep 17 00:00:00 2001
From: Jon Lin <jon.lin@rock-chips.com>
Date: Thu, 9 Mar 2023 15:29:37 +0800
Subject: [PATCH] TEST: u-boot: rk3566_evb2_v11: nvme

Change-Id: I87b3786a433691f3c385460fa8636291bce8ed9a
Signed-off-by: Jon Lin <jon.lin@rock-chips.com>
---
 arch/arm/dts/rk3568-u-boot.dtsi | 43 +++++
 configs/rk3568_defconfig         | 13 +++++
 2 files changed, 56 insertions(+)

diff --git a/arch/arm/dts/rk3568-u-boot.dtsi b/arch/arm/dts/rk3568-u-boot.dtsi
index a0678e35db..1ab8ea4436 100644
--- a/arch/arm/dts/rk3568-u-boot.dtsi
+++ b/arch/arm/dts/rk3568-u-boot.dtsi
@@ -26,6 +26,27 @@
     cru_rst_addr = <0xfdd20470>;
     u-boot,dm-spl;
 }

+
+ dc_12v: dc-12v {
+     compatible = "regulator-fixed";
+     regulator-name = "dc_12v";
+     regulator-always-on;
+     regulator-boot-on;
+     regulator-min-microvolt = <12000000>;
+     regulator-max-microvolt = <12000000>;
+ };
+
+
+ vcc3v3_pcie: gpio-regulator {
+     u-boot,dm-pre-reloc;
+     compatible = "regulator-fixed";
+     regulator-name = "vcc3v3_pcie";
+     regulator-min-microvolt = <3300000>;
+     regulator-max-microvolt = <3300000>;
+     enable-active-high;
+     gpio = <&gpio0 RK_PC2 GPIO_ACTIVE_HIGH>;
+     startup-delay-us = <5000>;
+     vin-supply = <&dc_12v>;
+ };
+
+};

&psci {
@@ -386,6 +407,28 @@
     status = "okay";
 }

+&pipegrf {
+    u-boot,dm-pre-reloc;
+    status = "okay";
+};
```

```

+};
+
+&pipe_phy_grf2 {
+    u-boot,dm-pre-reloc;
+    status = "okay";
+};
+
+&combphy2_psq {
+    u-boot,dm-pre-reloc;
+    status = "okay";
+};
+
+&pcie2x1 {
+    u-boot,dm-pre-reloc;
+    reset-gpios = <&gpio1 RK_PB2 GPIO_ACTIVE_HIGH>;
+    vpcie3v3-supply = <&vcc3v3_pcie>;
+    status = "okay";
+};
+
+&pinctrl {
+    u-boot,dm-pre-reloc;
+    status = "okay";

```

Using PCIe after loading Embedded dtb

The u-boot project supports the Embedded dtb scheme, which avoids the impact from kernel dtb changes, including product schemes without kernel support. Usually, the Embedded dtb source is the kernel standard dtb file, and the main steps are as follows:

- Compile kernel firmware, generate target dtb file
- U-Boot Enabling Embedded dtb Configuration

```

CONFIG_EMBED_KERNEL_DTB=y
CONFIG_EMBED_KERNEL_DTB_ALWAYS=y
CONFIG_EMBED_KERNEL_DTB_PATH="./dts/rkTarget Chip-Target Device.dtb" # for
example, CONFIG_EMBED_KERNEL_DTB_PATH="dts/rk3588-evb1.dtb"

```

- Compile and generate u-boot image

Recommendation:

- For some AMP scenarios, where there is no PCIe early init requirement and no kernel, and in order to complete PCIe enumeration before AMP is loaded, the following patch can be used to enumerate PCIe during the boot process

```

diff --git a/arch/arm/mach-rockchip/board.c b/arch/arm/mach-rockchip/board.c
index 979598ff7b..87d131e118 100644
--- a/arch/arm/mach-rockchip/board.c
+++ b/arch/arm/mach-rockchip/board.c
@@ -537,6 +537,11 @@ int board_init(void)
     io_domain_init();
 #endif
     set_armclk_rate();
+
+ #ifdef CONFIG_PCI
+     pci_init();
+ #endif

```

```

+
#ifdef CONFIG_DM_DVFS
    dvfs_init(true);
#endif

```

Using PCIe after loading the kernel dtb

You can consider reusing the kernel DTB directly by placing the relevant call in the “RK u-boot using kernel DTB phase”, please refer to the Kernel PCIe Configuration for related explanation.

5.18.4 Usage Example

Common Command:

5.18.4.1 PCIe CMD

```

## Chapter-5 PCI enumeration, where CFG maps to memory address 0x00000000f0000000
=> pci enum
pcie@fe150000: PCIe Linking... LTSSM is 0x1
pcie@fe150000: PCIe Linking... LTSSM is 0x6
pcie@fe150000: PCIe Linking... LTSSM is 0x4
pcie@fe150000: PCIe Linking... LTSSM is 0x210023
pcie@fe150000: PCIe Link up, LTSSM is 0x230011
pcie@fe150000: PCIe-0: Link up (Gen3-x2, Bus0)
pcie@fe150000: invalid flags type!
pcie@fe150000: Config space: [0x00000000f0000000 - 0x00000000f0100000, size
0x100000].

```

Chapter-5 Scanning all devices

```

=> pci

```

BusDevFun	VendorId	DeviceId	Device Class	Sub-Class
00.00.00	0x1d87	0x3588	Bridge device	0x04
01.00.00	0x144d	0xa809	Mass storage controller	0x08

Chapter-5 Display bus 01 device details

```

=> pci 01 long

```

Scanning PCI devices on bus 1

Found PCI device 01.00.00:

```

vendor ID = 0x144d
device ID = 0xa809
command register ID = 0x0006
status register = 0x0010
revision ID = 0x00
class code = 0x01 (Mass storage controller)
sub class code = 0x08
programming interface = 0x02
cache line = 0x08
latency time = 0x00
header type = 0x00
BIST = 0x00
base address 0 = 0xf0300004
base address 1 = 0x00000000

```

```

base address 2 = 0x00000000
base address 3 = 0x00000000
base address 4 = 0x00000000
base address 5 = 0x00000000
cardBus CIS pointer = 0x00000000
sub system vendor ID = 0x144d
sub system ID = 0xa801
expansion ROM base address = 0x00000000
interrupt line = 0xff
interrupt pin = 0x01
min Grant = 0x00
max Latency = 0x00

## Chapter-5 display bdf 01.00.00 device bar mapping address, sample code shows
bar0 mapping memory address 0xf0300000, size 0x4000.
=> pci bar 01.00.00
ID      Base              Size              Width  Type
-----
0      0x00000000f0300000  0x00000000000004000  64      MEM

## Chapter-5 Read bdf 01.00.00 device CFG space information
=> pci d.w 01.00.00 0
00000000: 144d a809 0006 0010 0200 0108 0008 0000
00000010: 0004 f030 0000 0000 0000 0000 0000 0000
00000020: 0000 0000 0000 0000 0000 0000 144d a801
00000030: 0000 0000 0040 0000 0000 0000 01ff 0000

```

5.18.4.2 NVMe

```

## Chapter-5 Initiate nvme scan
=> nvme scan

## Chapter-5 List nvme equipment details
=> nvme details

Blk device 0: Optional Admin Command Support:
Namespace Management/Attachment: no
Firmware Commit/Image download: yes
Format NVM: yes
Security Send/Receive: no
Blk device 0: Optional NVM Command Support:
Reservation: yes
Save/Select field in the Set/Get features: yes
Write Zeroes: yes
Dataset Management: yes
Write Uncorrectable: yes
Blk device 0: Format NVM Attributes:
Support Cryptographic Erase: No
Support erase a particular namespace: Yes
Support format a particular namespace: Yes
Blk device 0: LBA Format Support:
Blk device 0: End-to-End DataProtect Capabilities:
As last eight bytes: No
As first eight bytes: No
Support Type3: No
Support Type2: No

```



```

Support Type1: No
Blk device 0: Metadata capabilities:
As part of a separate buffer: No
As part of an extended data LBA: No

## Chapter-5 Seeing a 256GB NVMe, if you cannot see the capacity, you need to
unplug the device to make sure it's completely powered down and start over.
=> nvme info
Device 0: Vendor: 0x144d Rev: EXD7201Q Prod: S444NA0M384608
Type: Hard Disk
Capacity: 244198.3 MB = 238.4 GB (500118192 x 512)

## Chapter-5 Select the nvme device with ID 0
=> nvme device 0

Device 0: Vendor: 0x144d Rev: EXD7201Q Prod: S444NA0M384608
Type: Hard Disk
Capacity: 244198.3 MB = 238.4 GB (500118192 x 512)
... is now current device

## Chapter-5 Set 0x40000000 memory to bit 0x55aa55aa
=> md.l 0x40000000 1
40000000: d08ec033 3...
=> mw.l 0x40000000 0x55aa55aa
=> md.l 0x40000000 1
40000000: 55aa55aa .U.U

## Chapter-5 Take 1 block of data starting at 0x40000000 memory and write it to
the NVME LBA 0 address
=> nvme write 0x40000000 0x0 0x1

nvme write: device 0 block # 0, count 1 ... 1 blocks written: OK

## Chapter-5 Check the 0x44000000 memory to confirm the raw data
=> md.l 0x44000000 1
44000000: ffffffff ....

## Chapter-5 Read 1 block of data from NVMe's LBA 0 address and write to memory
0x44000000
=> nvme read 0x44000000 0x0 0x1

nvme read: device 0 block # 0, count 1 ... 1 blocks read: OK

## Chapter-5 Confirm that 0x44000000 memory data is read back from NVMe
=> md.l 0x44000000 1
44000000: 55aa55aa

```

5.18.4.3 RK3588 RC dma

```

=> pci
BusDevFun VendorId DeviceId Device Class Sub-Class
=====
00.00.00 0x1d87 0x3588 Bridge device 0x04
01.00.00 0x1d87 0x356a ??? 0x00
=> pci 1 long

```

Scanning PCI devices on bus 1

Found PCI device 01.00.00:

<u>vendor ID =</u>	<u>0x1d87</u>
<u>device ID =</u>	<u>0x356a</u>
<u>command register ID =</u>	<u>0x0006</u>
<u>status register =</u>	<u>0x0010</u>
<u>revision ID =</u>	<u>0x01</u>
<u>class code =</u>	<u>0x12 (???)</u>
<u>sub class code =</u>	<u>0x00</u>
<u>programming interface =</u>	<u>0x00</u>
<u>cache line =</u>	<u>0x08</u>
<u>latency time =</u>	<u>0x00</u>
<u>header type =</u>	<u>0x00</u>
<u>BIST =</u>	<u>0x00</u>
<u>base address 0 =</u>	<u>0xf0400000 # CPU address mapped by BAR0. Since</u>

RK PCIe uses CPU-BUS one-to-one mapping, the bus addr is the same value.

<u>base address 1 =</u>	<u>0x00000000</u>
<u>base address 2 =</u>	<u>0x0400000c</u>
<u>base address 3 =</u>	<u>0x00000000</u>
<u>base address 4 =</u>	<u>0xf0800000</u>
<u>base address 5 =</u>	<u>0x00000000</u>
<u>cardBus CIS pointer =</u>	<u>0x00000000</u>
<u>sub system vendor ID =</u>	<u>0x0000</u>
<u>sub system ID =</u>	<u>0x0000</u>
<u>expansion ROM base address =</u>	<u>0x00000000</u>
<u>interrupt line =</u>	<u>0xff</u>
<u>interrupt pin =</u>	<u>0x01</u>
<u>min Grant =</u>	<u>0x00</u>
<u>max Latency =</u>	<u>0x00</u>

=>

Chapter-5 BAR CPU Access, PIO Access

md.l 0xf0400000 0x40

Chapter-5 DMA read

mw.l 0x3c000000 0xffffffff
dcache flush 0x3c000000 0x100 # flush
mw.l 0xf538002c 0x1
mw.l 0xf5380300 0x4000008
mw.l 0xf5380304 0x0
mw.l 0xf5380308 0x100
mw.l 0xf538030c 0xf0400000
mw.l 0xf5380310 0x0
mw.l 0xf5380314 0x3c000000
mw.l 0xf5380318 0x0
mw.l 0xf5380030 0x0
dcache invalidate 0x3c000000 0x100 # invalidate
md.l 0x3c000000

Chapter-5 DMA write

mw.l 0x3c000000 0xffffffff
dcache flush 0x3c000000 0x100 # flush
mw.l 0xf538000c 0x1
mw.l 0xf5380200 0x4000008
mw.l 0xf5380204 0x0
mw.l 0xf5380208 0x100
mw.l 0xf538020c 0x3c000000

```
mw.1 0xf5380210 0x0
mw.1 0xf5380214 0xf0400000
mw.1 0xf5380218 0x0
mw.1 0xf5380010 0x0
md.1 0x3c000000 0x40
```

Notes:

- The dcache flush/clean macro switch, CONFIG_CMD_CACHE, requires the following support patches to be added

```
commit b46a81a12dd4a1514a6522e33a1d16194f242d62
Author: Joseph Chen <chenjh@rock-chips.com>
Date: Wed Sep 28 01:36:45 2022 +0000

cmd: cache: Add flush/invalidate dcache range support

Signed-off-by: Joseph Chen <chenjh@rock-chips.com>
Change-Id: Id0e0cd9019072e8c557ebd2987b439057cb4ae3b
```

5.18.4.4 RK3568 RC dma

```
=> pci
BusDevFun  VendorId  DeviceId  Device Class      Sub-Class
-----
00.00.00   0x1d87   0x356a   Bridge device     0x04
01.00.00   0x1d87   0x356a   ???               0x00
=> pci 1 long
Scanning PCI devices on bus 1

Found PCI device 01.00.00:
 vendor ID = 0x1d87
 device ID = 0x356a
 command register ID = 0x0006
 status register = 0x0010
 revision ID = 0x01
 class code = 0x12 (???)
 sub class code = 0x00
 programming interface = 0x00
 cache line = 0x08
 latency time = 0x00
 header type = 0x00
 BIST = 0x00
 base address 0 = 0xf0400000 # CPU address mapped by BAR0. Since
RK PCIe uses CPU-BUS one-to-one mapping, the bus addr is the same value.
 base address 1 = 0x00000000
 base address 2 = 0x0400000c
 base address 3 = 0x00000000
 base address 4 = 0xf0800000
 base address 5 = 0x00000000
 cardBus CIS pointer = 0x00000000
 sub system vendor ID = 0x0000
 sub system ID = 0x0000
 expansion ROM base address = 0x00000000
 interrupt line = 0xff
```

```

interrupt_pin = 0x01
min Grant = 0x00
max Latency = 0x00
=>

## Chapter-5 BAR CPU access, PIO access
md.l 0xf0400000 0x40

## Chapter-5 DMA read
mw.l 0x3c000000 0xffffffff
dcache flush 0x3c000000 0x100 # flush
mw.l 0xf638002c 0x1
mw.l 0xf6380300 0x40000008
mw.l 0xf6380304 0x0
mw.l 0xf6380308 0x100
mw.l 0xf638030c 0xf0400000
mw.l 0xf6380310 0x0
mw.l 0xf6380314 0x3c000000
mw.l 0xf6380318 0x0
mw.l 0xf6380030 0x0
dcache invalidate 0x3c000000 0x100 # invalidate
md.l 0x3c000000

## Chapter-5 DMA write
mw.l 0x3c000000 0xffffffff
dcache flush 0x3c000000 0x100 # flush
mw.l 0xf638000c 0x1
mw.l 0xf6380200 0x40000008
mw.l 0xf6380204 0x0
mw.l 0xf6380208 0x100
mw.l 0xf638020c 0x3c000000
mw.l 0xf6380210 0x0
mw.l 0xf6380214 0xf0400000
mw.l 0xf6380218 0x0
mw.l 0xf6380010 0x0
md.l 0x3c000000 0x40

```

Notes:

- The dcache flush/clean macro switch, CONFIG_CMD_CACHE, requires the following support patch to be added:

```

commit b46a81a12dd4a1514a6522e33a1d16194f242d62
Author: Joseph Chen <chenjh@rock-chips.com>
Date:   Wed Sep 28 01:36:45 2022 +0000

    cmd: cache: Add flush/invalidate dcache range support

Signed-off-by: Joseph Chen <chenjh@rock-chips.com>
Change-Id: Id0e0cd9019072e8c557ebd2987b439057cb4ae3b

```

5.18.5 Analysis of Common Problems

RK3568 Linux 5.10 uboot shutdown PCIE ASPM power saving

The default controller has ASPM support turned off, to confirm that the command mode under the PCIe3x2 uboot shell please refer to:

```
pci_display.l 20.00.00 0x80 1
```

Where BITS[1:0] PCIE_CAP_ACTIVE_STATE_LINK_PM_CONTROL:

```
Values:
0x0 (DISABLED): Disabled
0x1 (LOS_ENTRY_EN): L0s Entry Enabled
0x2 (L1_ENTRY_EN): L1 Entry Enabled
0x3 (LOS_L1_ENTRY_EN): L0s and L1 Entry Enabled
```

RC DMA access to FPGA limits

BAR access for FPGAs and most peripherals behaves differently:

- Some devices support memory read/write TLP packets of different lengths
- Some devices only support 4Bytes memory read/write TLP packets

So only 4Bytes memory read/write TLP is supported resulting in a

- CPU access to BAR space is normal
- RC DMA initiates requests that exceed the 4B address transfer length will bring up different errors, such as ca abort

```
## Chapter-5 RK3568 DMA read ca abort info
=> md.l 0xf63800b8 1
f63800b8: 00000100      ....
```

Other notes:

- To catch this kind of problem, the PCIe protocol analyzer should use a TLP trigger, not a memory trigger, otherwise there is no cpl to trigger after an error.
- It is suspected that PCIe access to the bus is limited after the peripheral receives a tlp request that exceeds 4B length, resulting in a ca abort, but the specific requirements need to be analyzed with the assistance of the peripheral's original manufacturer

5.19 Pinctrl

5.19.1 Framework Support

The pinctrl driver uses the pinctrl-uclass framework and standard interfaces.

Configuration:

```
CONFIG_PINCTRL_GENERIC
CONFIG_PINCTRL_ROCKCHIP
```

Framework code:

```
./drivers/pinctrl/pinctrl-uclass.c
```

Driver code:

```
./drivers/pinctrl/pinctrl-rockchip.c
```

5.19.2 Relevant Interface

```
int pinctrl_select_state(struct udevice *dev, const char *statename) // set
status
int pinctrl_get_gpio_mux(struct udevice *dev, int banknum, int index) // Get
Status
```

The pinctrl framework will automatically set the “default” state for each driver when it probes, and users generally do not need to call the pinctrl interface.

5.20 Pmic/Regulator

5.20.1 Framework Support

The PMIC/Regulator driver uses the pmic-uclass, regulator-uclass framework and standard interfaces.

PMIC support:

```
rk805/rk808/rk809/rk816/rk817/rk818
```

Regulator support:

```
rk805/rk808/rk809/rk816/rk817/rk818/syr82x/tcs452x/fan53555/pwm/gpio/fixed
```

Configuration:

```
CONFIG_DM_PMIC
CONFIG_PMIC_CHILDREN
CONFIG_PMIC_RK8XX // Suitable for all current RK8XX series chips
CONFIG_DM_REGULATOR
CONFIG_REGULATOR_PWM
CONFIG_REGULATOR_RK8XX // Suitable for all current RK8XX series chips
CONFIG_REGULATOR_FAN53555
```

Framework Code:

```
./drivers/power/pmic/pmic-uclass.c
./drivers/power/regulator/regulator-uclass.c
```

Driver file:

```

./drivers/power/pmic/rk8xx.c
./drivers/power/regulator/rk8xx.c
./drivers/power/regulator/fixed.c
./drivers/power/regulator/gpio-regulator.c
./drivers/power/regulator/pwm_regulator.c
./drivers/power/regulator/fan53555_regulator.c

```

5.20.2 Relevant Interface

```

// get regulator. @platname: name specified by "regulator-name", e.g: vdd_arm,
vdd_logic;
int regulator_get_by_platname(const char *platname, struct udevice **devp);

// Enable/Disable
int regulator_get_enable(struct udevice *dev);
int regulator_set_enable(struct udevice *dev, bool enable);
int regulator_set_suspend_enable(struct udevice *dev, bool enable);
int regulator_get_suspend_enable(struct udevice *dev);

// Configure/Get Voltage
int regulator_get_value(struct udevice *dev);
int regulator_set_value(struct udevice *dev, int uV);
int regulator_set_suspend_value(struct udevice *dev, int uV);
int regulator_get_suspend_value(struct udevice *dev);

```

5.20.3 Init Voltage

There are currently two ways to set the initialization voltage output for a particular regulator, provided that `regulator-boot-on` is configured:

- Configure `regulator-min-microvolt` and `regulator-max-microvolt` to the same value;
- Configure `regulator-init-microvolt = <...>`

```

vdd_arm: DCDC_REG1 {
    regulator-name = "vdd_arm";
    regulator-boot-on; // Must be configured
    regulator-min-microvolt = <712500>;
    regulator-max-microvolt = <1450000>;
    regulator-init-microvolt = <1100000>; // Set initialization voltage to 1.1v
    .....
};

```

5.20.4 Skip Initialization

Add `regulator-loader-ignore` if you want to skip the initialization of a certain way regulator.

```
vdd_arm: DCDC_REG1 {
    regulator-name = "vdd_arm";
    regulator-loader-ignore; // Only valid for regulator initialization in U-Boot
    phase, not for kernel.
    .....
};
```

5.21 Reset

5.21.1 Framework Support

The reset driver uses the reset-uclass.c framework and standard interfaces. reset on the RK platform is essentially a soft reset of the CRU.

Configuration:

```
CONFIG_DM_RESET
CONFIG_RESET_ROCKCHIP
```

Framework code:

```
./drivers/reset/reset-uclass.c
```

Driver code:

```
./drivers/reset/reset-rockchip.c
```

5.21.2 Relervant Interface

```
// Get reset handle
int reset_get_by_index(struct udevice *dev, int index, struct reset_ctl
*reset_ctl);
int reset_get_by_name(struct udevice *dev, const char *name,
                      struct reset_ctl *reset_ctl);
// release reset
int reset_free(struct reset_ctl *reset_ctl);
// request reset
int reset_request(struct reset_ctl *reset_ctl);
// trigger reset, release reset
int reset_assert(struct reset_ctl *reset_ctl);
int reset_deassert(struct reset_ctl *reset_ctl);
```

Example:

```
struct reset_ctl reset_ctl;

ret = reset_get_by_name(dev, "mac-phy", &reset_ctl);
if (ret) {
    debug("reset_get_by_name(.) failed: %d\n", ret);
}
```



```

    return ret;
}

ret = reset_request(&reset_ctl);
if (ret)
    return ret;

ret = reset_assert(&reset_ctl);
if (ret)
    return ret;

.....

ret = reset_deassert(&reset_ctl);
if (ret)
    return ret;

.....

ret = reset_free(&reset_ctl);
if (ret)
    return ret;

```

5.21.3 DTS Configuration

U-Boot enables reset function by default, users only need to specify the reset object to be operated in the peripheral node:

```

// format:
reset-names = <name-string-list>
resets = <cru-phandle-list>

```

Take gmac2phy as an example:

```

gmac2phy: ethernet@ff550000 {
    compatible = "rockchip,rk3328-gmac";
    .....

    // specify reset attribute
    reset-names = "stmmaceth", "mac-phy";
    resets = <&cru SRST_GMAC2PHY_A>, <&cru SRST_MACPHY>;
};

```

5.22 Rng

5.22.1 Framework Support

RNG is used to implement the hardware random number function.

Framework code:

```
./drivers/rng/rng-uclass.c
```

Driver code:

```
./drivers/rng/rockchip_rng.c
```

Configuration:

```
CONFIG_DM_RNG=y  
CONFIG_RNG_ROCKCHIP=y
```

5.22.2 Relevant Interface

```
// @buffer: Save random number output  
// @size: Random number length, Unit: byte  
int dm_rng_read(struct udevice *dev, void *buffer, size_t size)
```

5.22.3 DTS Configuration

Because RNG is one of the features of the Crypto hardware module, RNG nodes have V1/2 just like Crypto nodes. there are two types of compatible fields for RNG nodes:

```
compatible = "rockchip,cryptov1-rng";  
compatible = "rockchip,cryptov2-rng";
```

For complete node configuration, please refer to the rv1126.dtsi, rk3568.dtsi, rk3399.dtsi files.

5.23 Spi

5.23.1 Framework Support

Framework code:

```
./drivers/spi/spi-uclass.c
```

Driver code:

```
./drivers/spi/rk_spi.c
```

menuconfig :

```
CONFIG_ROCKCHIP_SPI=y  
CONFIG_CMD_SPI=y
```

5.23.2 Relevant Interface

[./include/spi.h](#)

```
// Initialize the corresponding SPI bus
struct spi_slave *spi_setup_slave(unsigned int bus, unsigned int cs, unsigned int
max_hz, unsigned int mode);

// Get/Release Bus
int spi_claim_bus(struct spi_slave *slave);
void spi_release_bus(struct spi_slave *slave);

// Common Read/Write Interfaces
int spi_xfer(struct spi_slave *slave, unsigned int bitlen, const void *dout,
             void *din, unsigned long flags);
int spi_write_then_read(struct spi_slave *slave, const u8 *opcode,
                        size_t n_opcode, const u8 *txbuf, u8 *rxbuf,
                        size_t n_buf);
```

5.23.3 DTS Configuration

```
&spi0 {
    u-boot,dm-pre-reloc;
    status = "okay";
};
```

5.23.4 Recall Example

We recommend that you refer to [drivers/power/power_spi.c](#).

For simple reference you can check this [demo](#):

```
static u32 spi_bus_test(int bus, int cs)
{
    struct spi_slave *spi_slave;
    u32 tx_data, rx_data;
    int ret;

#ifdef CONFIG_DM_SPI
    struct udevice *dev;
    char name[30], *str;

    snprintf(name, sizeof(name), "generic_%d:%d", bus, cs);
    str = strdup(name);
    if (!str)
        return -ENOMEM;
    ret = spi_get_bus_and_cs(bus, cs, 50000000, SPI_MODE_0, "spi_generic_drv",
str, &dev, &spi_slave);
    if (ret)
        return ret;
#else
    spi_slave = spi_setup_slave(bus, cs, 50000000, SPI_MODE_0);
```

```

    if (!spi_slave) {
        /*
         * Invalid bus 1 (err=-19) means that spi1 is disabled in dts
         * Invalid chip select 1:0 (err=-19) means that there is no dev under
         spi1 bus in dts
         * check it in uboot dtb or kernel dtb(if is enabled)
         */
        /* btw, spi_get_bus_and_cs support no sub dev operation but
         spi_setup_slave can't
         */
        return -ENODEV;
    }
#endif

    if (spi_claim_bus(spi_slave))
        return -ENODEV;

    tx_data = 0x12345678;
    ret = spi_xfer(spi_slave, 32, &tx_data, &rx_data, SPI_XFER_BEGIN |
SPI_XFER_END);

    spi_release_bus(spi_slave);

    pr_err("%s succuss\n", __func__);

    return ret;
}

```

Notes:

- The spi peripheral supports specifying the rate via the spi-max-frequency attribute of the dts device child node, as well as transmitting the setup rate during spi_get_bus_and_cs/spi_setup_slave

5.23.5 Test Command

Use the cmd_spi related commands:

```

sspi 3:0.0 24 AAA # bus3:cs0:mode0 Transmission length is 24bits
Transmission data is "AAA"

```

5.23.6 Analysis of Common Problems

Q1: No signal?

A1: Please make sure the corresponding iomux and clock are configured properly.

Q2: RK3399 cmd_spi exception?

A2: The cmd stage uses kernel dtb by default, please make sure whether the corresponding spi is specified in kernel rk3399.dtsi aliases.

Q3: Why SPI failed to call spi_setup_slave?

A3: SPI bus node has to go with the device before spi_setup_slave can work properly, but u-boot has a standard dev with driver spi_generic_drv for the bus, the device name is generic_1:0, which shall be declared in the call of spi_setup_slave.

Q4: How to confirm the frequency of spi in uboot stage?

Q4: Turn on the debug switch

```
→ u-boot-release git:(next-dev) X_gd drivers/spi/rk_spi.c
diff --git a/drivers/spi/rk_spi.c b/drivers/spi/rk_spi.c
index 836b94a24ec..8aaa51b9e84 100644
--- a/drivers/spi/rk_spi.c
+++ b/drivers/spi/rk_spi.c
@@ -24,6 +24,8 @@
DECLARE_GLOBAL_DATA_PTR;

+#undef _DEBUG
+#define _DEBUG 1
/* Change to 1 to output registers at the start of each transaction */
#define DEBUG_RK_SPI 0
```

以 cmd/spi.c 测试威力, 关键 debug log 说明Testing power with cmd/spi.c, key debug log description:

```
=> sspi 0:0.0 24 AAA
rockchip_spi_ofdata_to_platdata: base=ff500000, max-frequency=50000000,
deactivate_delay=0 rsd=0
rockchip_spi_probe: probe
rockchip_spi_probe: rate = 200000000 #控制器工作时钟Controller Operating
Clock
spi speed 50000000, div 4 #io 时钟, io 时钟由控制器工作时钟 4 分频输
出io clock, io clock is output from the controller's operating clock in 4
divisions
rockchip_spi_xfer: dout=07fd640c, din=07fd63ec, len=3, flags=3
activate cs0
deactivate cs0
000000
```

5.24 Storage

: The storage driver uses the standard storage framework, and the access interface is interfaced to the BLK layer for file system support. Currently, the supported storage devices are: eMMC, Nand flash, SPI Nand flash, SPI Nor flash, of which the flash related framework is as follows:

Acronyms	Main supported particle types	Host Control Driver	flash Framework	Registered Device Type	Main supported file systems
rk NAND solution	MLC TLC Nand	drivers/rkand	drivers/rkand	block device	FAT、EXT、SquashFS
rkflash solution	SLC Nand、SPI Nand	drivers/rkflash	drivers/rkflash	block device	FAT、EXT、SquashFS
rkflash solution (SPI Nor support)	SPI Nor	drivers/rkflash	drivers/rkflash	block or mtd device	SquashFS、JFFS2
SLC Nand open source solution	SLC Nand	drivers/mtd/nand/raw	drivers/mtd/nand/raw	mtd device	UBI
SPI Nand open source solution	SPI Nand	drivers/spi/rockchip_sfc.c	drivers/mtd/nand/raw	mtd device	UBI
SPI Nor open source solution	SPI Nor	drivers/spi/rockchip_sfc.c	drivers/mtd/spi	mtd or mtd block device	SquashFS、JFFS2

Notes:

1. rkflash 与 开源方案中关于 Nand flash 的支持主要区别在于：rkflash 集成 rk ftl (Flash Transfer Layer) 在存储驱动中，而开源方案 ftl 部分则依赖于文件系统自身的 flash 的管理，例如 UBI 文件系统支持坏块管理、磨损均衡等适合 Nand flash 的文件系统特性。The main difference between rkflash and open source solutions for Nand flash support is that rkflash integrates rk ftl (Flash Transfer Layer) in the storage driver, while open source ftl partially relies on the file system's own flash management, for example, the UBI file system supports bad block management, wear leveling, etc., which is suitable for Nand flash file system characteristics. For example, the UBI file system supports bad block management, wear leveling, and other file system features suitable for Nand flash.

5.24.1 Framework Support

rk NAND

rk NAND is a storage driver designed for high-capacity Nand flash devices, which communicates with Nand flash devices through Nandc host. Refer to “RKNandFlashSupportList” for the selection of applicable particles, and the following particles are applicable:

- SLC、MLC、TLC Nand flash

Configuration:

```
CONFIG_RKNAND
```

Driver file:

```
./drivers/rk NAND/
```

rkflash

rkflash is a storage driver designed for devices that use small capacity storage. Nand flash support is accomplished through communication between the Nandc host and the Nand flash device, and SPI flash support is accomplished through communication between the SFC host and the SPI flash devices, and the specific selection of the applicable particles can be found in the “RK SpiNor and SLC Nand SupportList”. applicable to the following particles

- 128MB, 256MB and 512MB SLC Nand flash
- Partial SPI Nand flash
- Partial SPI Nor flash particles

Configuration:

```
CONFIG_RKFLASH
```

```
CONFIG_RKNANDC_NAND /* Small-capacity parallel port Nand flash */  
CONFIG_RKSFC_NOR /* SPI Nor flash */  
CONFIG_RKSFC_NAND /* SPI Nand flash */
```

Driver file:

```
./drivers/rkflash/
```

Notes:

1. SFC (serial flash controller) is a specialized module designed by Rockchip for easy support of spi flash
 2. Since the rkflash driver is not compatible with the ftl of the rkflash driver's Nand code, hence
- CONFIG_RKNAND and CONFIG_RKNANDC_NAND cannot be configured at the same time.
 - CONFIG_RKNAND and CONFIG_RKSFC_NAND cannot be configured at the same time.

MMC & SD

MMC is multimedia card, such as eMMC; SD is a new generation of memory device based on semiconductor flash memory. On the rockchip platform, they share a common dw_mmc controller (except rk3399, rk3399pro).

Configuration:

```
CONFIG_MMC_DW=y  
CONFIG_MMC_DW_ROCKCHIP=y  
CONFIG_CMD_MMC=y
```

Driver file:

```
./drivers/mmc/
```

SLC Nand & SPI Nand & SPI Nor open-source program

Due to the continuous improvement of the open source community and the feasibility of the UBI file system, RK has also improved the flash combined with more open source code programs, and the open source program default pre loader for the SPL startup program, so most of the configurations are completed by combining with the SPL related configuration.

Configuration:

```
// MTD driver support  
CONFIG_MTD=y
```

```

CONFIG_CMD_MTD_BLK=y
CONFIG_SPL_MTD_SUPPORT=y
CONFIG_MTD_BLK=y
CONFIG_MTD_DEVICE=y

// spi nand driver support
CONFIG_MTD_SPI_NAND=y
CONFIG_ROCKCHIP_SFC=y
CONFIG_SPL_SPI_FLASH_SUPPORT=y
CONFIG_SPL_SPI_SUPPORT=y

// nand driver support
CONFIG_NAND=y
CONFIG_CMD_NAND=y
CONFIG_NAND_ROCKCHIP=y /* NandC v6 can be confirmed basing on the register TRM
NANDC->NANDC_NANDC_VER,0x00000801 */
//CONFIG_NAND_ROCKCHIP_V9=y /* NandC v9 can be confirmed basing on the register
TRM NANDC->NANDC_NANDC_VER, 0x56393030, For example: the version for RK3326/PX30
*/
CONFIG_SPL_NAND_SUPPORT=y
CONFIG_SYS_NAND_U_BOOT_LOCATIONS=y
// The nand page size needs to be defined according to the real size, if you use
NAND with capacity greater than or equal to 512MB, you generally need to
configure it as 4096.
#define CONFIG_SYS_NAND_PAGE_SIZE 2048

// spi nor driver support
CONFIG_CMD_SF=y
CONFIG_CMD_SPI=y
CONFIG_SPI_FLASH=y
CONFIG_SF_DEFAULT_MODE=0x1
CONFIG_SF_DEFAULT_SPEED=50000000
CONFIG_SPI_FLASH_GIGADEVICE=y
CONFIG_SPI_FLASH_MACRONIX=y
CONFIG_SPI_FLASH_WINBOND=y
CONFIG_SPI_FLASH_MTD=y
CONFIG_ROCKCHIP_SFC=y
CONFIG_SPL_SPI_SUPPORT=y
CONFIG_SPL_MTD_SUPPORT=y
CONFIG_SPL_SPI_FLASH_SUPPORT=y

```

Removing the rkflash/rknand macro configuration:

```

CONFIG_RKFLASH=n
CONFIG_RKNAND=n

```

Driver file:

```

./drivers/mtd/nand/raw           //SLC Nand Master Driver and Protocol Layer
./drivers/mtd/nand/spi           //SPI Nand Protocol Layer
./drivers/spi/rockchip_sfc.c     //SPI Flash Master Driver
./drivers/mtd/spi                //SPI Nor Protocol Layer

```


5.24.2 Relevant Interface

The storage driver's access interfaces are all pegged to the BLK layer, so whatever storage is accessed is accessed through the following interfaces

```
// Getting a Storage Handle
struct blk_desc *rockchip_get_bootdev(void)

// Access interface
unsigned long blk_dread(struct blk_desc *block_dev, lbaint_t start,
                        lbaint_t blkcnt, void *buffer)
unsigned long blk_dwrite(struct blk_desc *block_dev, lbaint_t start,
                        lbaint_t blkcnt, const void *buffer)
unsigned long blk_derase(struct blk_desc *block_dev, lbaint_t start,
                        lbaint_t blkcnt)
```

5.24.3 Boot Storage Type Differentiation

U-Boot's current boot storage type is differentiated in two ways:

- Via the string corresponding to environment variables. `devtype` and `devnum` .
- via the `if_type` and `devnum` member variables within the current struct `blk_desc` structure (handle).

devtype	if_type	devnum	storage type	Remarks
mmc	IF_TYPE_MMC	0	eMMC	-
mmc	IF_TYPE_MMC	1	SD card	-
mtdev	IF_TYPE_MTD	0	Nand	mtdev open-source program
mtdev	IF_TYPE_MTD	1	SPI Nand	mtdev open-source program
mtdev	IF_TYPE_MTD	2	SPI Nor	mtdev open-source program
rkdev	IF_TYPE_RKNAND	0	Nand	rkflash program
spinand	IF_TYPE_SPINAND	0	SPI Nand	rkflash program
spinor	IF_TYPE_SPINOR	1	SPI Nor	rkflash program
nvme	IF_TYPE_NVME	0	SSD	-
scsi	IF_TYPE_SCSI	0	SATA	-

5.24.4 DTS Configuration

eMMC configuration:

```
// rkxxxx.dtsi configuration
emmc: dwmmc@ff390000 {
    compatible = "rockchip,px30-dw-mshc", "rockchip,rk3288-dw-mshc";
```

```

reg = <0x0 0xff390000 0x0 0x4000>; // Controller register base address
and length
max-frequency = <150000000>; // eMMCThe eMMC normal mode clock is
50MHz, when configured as eMMC
// HS200 mode, this max-frequency is
in effect
clocks = <&cru HCLK_EMMC>, <&cru SCLK_EMMC>,
<&cru SCLK_EMMC_DRV>, <&cru SCLK_EMMC_SAMPLE>; // Controller Clock
Number Corresponding to the controller
clock-names = "biu", "ciu", "ciu-drv", "ciu-sample"; // Controller Clock
Name
fifo-depth = <0x100>; // fifo depth, default
configuration
interrupts = <GIC_SPI 53 IRQ_TYPE_LEVEL_HIGH>; // Interrupt
Configuration
status = "disabled";
};

// rkxxxx-u-boot.dtsi
&emmc {
u-boot,dm-pre-reloc;
status = "okay";
};

// rkxxxx.dts
&emmc {
bus-width = <8>; // Device Bus Bit Width
cap-mmc-hspspeed; // Identifies this card slot as supporting
highspeed mmc
mmc-hs200-1_8v; // Support for HS200
supports-emmc; // Identifies this slot as eMMC capable,
must be added or peripheral cannot be initialized
disable-wp; // For no physical WP pins, you need to
configure
non-removable; // This item indicates that the slot is a
non-removable device. This item is mandatory
num-slots = <1>; // Marked as Slot No.
status = "okay";
};

```

Nandc configuration:

```

&nandc0 {
u-boot,dm-pre-reloc;
status = "okay";
#address-cells = <1>;
#size-cells = <0>;

nand@0 {
u-boot,dm-pre-reloc;
reg = <0>;
nand-ecc-mode = "hw_syndrome";
nand-ecc-strength = <16>;
nand-ecc-step-size = <1024>;
};
};

```

SFC configuration:

```
&sfc {  
    u-boot,dm-pre-reloc;  
    status = "okay";  
    spi_nand: flash@0 {  
        u-boot,dm-spl;  
        compatible = "spi-nand";  
        reg = <0>;  
        spi-tx-bus-width = <1>;  
        spi-rx-bus-width = <4>;  
        spi-max-frequency = <96000000>;  
    };  
    spi_nor: flash@1 {  
        u-boot,dm-spl;  
        compatible = "jedec,spi-nor";  
        reg = <0>;  
        spi-tx-bus-width = <1>;  
        spi-rx-bus-width = <4>;  
        spi-max-frequency = <96000000>;  
    };  
};
```

Notes:

1. Considering the software compatibility, only one line SPI flash transfer with spi-tx-bus-width = <1> is supported under u-boot.

5.24.5 Dual Storage Expansion

Refer to the Rockchip_Developer_Guide_Dual_Storage_CN.pdf document for details

5.24.6 Analysis of Common Problems

Q1: How to adjust and confirm the clock frequency of the open source solution FSPI/SFC controller output?

A1: Set the value of the spi-max-frequency attribute for the device subnodes under the sfc node in rkxxx-u-boot.dtsi and turn off invalid subdevices, then turn on debug messages within the driver:

```
diff --git a/drivers/spi/rockchip_sfc.c b/drivers/spi/rockchip_sfc.c  
index 939b48e377c..62a425a29f4 100644  
--- a/drivers/spi/rockchip_sfc.c  
+++ b/drivers/spi/rockchip_sfc.c  
@@ -790,7 +790,7 @@ static int rockchip_sfc_set_speed(struct udevice *bus, uint  
speed)  
{  
    sfc->cur_speed = speed;  
    sfc->cur_real_speed = clk_get_rate(&sfc->clk);  
  
-    dev_dbg(sfc->dev, "set_freq=%dHz real_freq=%dHz\n",  
+    dev_err(sfc->dev, "set_freq=%dHz real_freq=%dHz\n",  
            sfc->cur_speed, sfc->cur_real_speed);  
#else  
    dev_dbg(sfc->dev, "sfc failed, CLK not support\n");
```

5.25 Thermal

5.25.1 Framework Support

Thermal module is used to get the temperature of the chip collected by tsadc, the default is CPU temperature.

Framework code:

```
./drivers/thermal/thermal-uclass.c
```

Driver code:

```
./drivers/thermal/rockchip_thermal.c
```

Configuration:

```
CONFIG_DM_THERMAL=y  
CONFIG_ROCKCHIP_THERMAL=y
```

5.25.2 Relevant Interface

```
// @temp: Save the acquired temperature  
int thermal_get_temp(struct udevice *dev, int *temp)
```

5.25.3 DTS Configuration

The kernel's dts are generally fully configured and enabled by default.

5.26 Uart

serial uses the serial-uclass.c framework and standard interfaces, and is currently used mainly by the UART debug.

Configuration:

```
// Enable configuration  
CONFIG_DEBUG_UART  
CONFIG_SYS_NS16550  
  
// Parameter configuration  
CONFIG_DEBUG_UART_BASE  
CONFIG_DEBUG_UART_CLOCK  
CONFIG_BAUDRATE
```

Framework code:

```
./drivers/serial/serial-uclass.c
```

Driver code:

```
./drivers/serial/ns16550.c
```

5.26.1 Individual Replacement

The process for individual replacement of UART debug in U-Boot phase is as follows (take uart2 as an example):

- CONFIG_ROCKCHIP_PRELOADER_SERIAL disabled;
- Configure uart iomux in board_debug_uart_init(). (note: some platforms have m0, m1... modes to configure).
- Configure the uart clock in board_debug_uart_init(). to ensure that the clock source is 24Mhz;
- defconfig updates CONFIG_BAUDRATE;
- defconfig updates CONFIG_DEBUG_UART_BASE;
- Add 2 required attributes to the U-Boot uart node and enable them.

```
&uart2 {  
    u-boot,dm-pre-reloc;  
    clock-frequency = <24000000>;  
    status = "okay";  
};
```

- Specify the stdout-path in the U-Boot chosen node:

```
chosen {  
    stdout-path = &uart2;  
};
```

5.26.2 Global Replacement

Pre-loader serial is a mechanism to realize the sharing of UART debug configuration among the previous firmware, including: ddr, miniloader, bl31, op-tee, U-Boot. Its principle: the UART debug is configured by the earliest ddr bin and is passed down through the ATAGS parameter passing mechanism, and all levels of firmware get the UART debug configuration and use it (excluding the kernel).

Users can realize the global replacement of UART debug by modifying the serial port configuration in the ddr bin, processes are as follows:

DDR bin configuration

The rkbin repository provides tools for the user to configure different parameters, including serial port replacement:

```
tools/ddrbin_tool  
tools/ddrbin_param.txt  
tools/ddrbin_tool_user_guide.txt
```

U-Boot configuration

1 enable configuration:

```
CONFIG_ROCKCHIP_PRELOADER_SERIAL // Already enabled by default
```

2 rkxx-u-boot.dtsi adds the attribute “u-boot,dm-pre-reloc” to the uart nodes to be used.:

3 aliases establish serial aliases, since U-Boot finds the target node and initializes it through aliases.

For example: ./arch/arm/dts/rk1808-u-boot.dtsi creates aliases for all uarts for convenience;

```
aliases {
    mmc0 = &emmc;
    mmc1 = &sdmmc;

    // Alias must be created
    serial0 = &uart0;
    serial1 = &uart1;
    serial2 = &uart2;
    serial3 = &uart3;
    serial4 = &uart4;
    serial5 = &uart5;
    serial6 = &uart6;
    serial7 = &uart7;
};

.....

// Must add u-boot,dm-pre-reloc attribute
&uart0 {
    u-boot,dm-pre-reloc;
};
&uart1 {
    u-boot,dm-pre-reloc;
};
&uart2 {
    u-boot,dm-pre-reloc;
    clock-frequency = <24000000>;
    status = "okay";
};
&uart3 {
    u-boot,dm-pre-reloc;
};
&uart4 {
    u-boot,dm-pre-reloc;
};
```

5.26.3 Turn off Printing

```
CONFIG_DISABLE_CONSOLE=y
```

5.26.4 Relevant Interface

```
// UART debug interface
void putc(const char c);
void puts(const char *s);
int printf(const char *fmt, ...);
void flushc(void);

// General UART interface for communication with peripherals
int serial_dev_getc(struct udevice *dev);
int serial_dev_tstc(struct udevice *dev);
void serial_dev_putc(struct udevice *dev, char ch);
void serial_dev_puts(struct udevice *dev, const char *str);
void serial_dev_setbrg(struct udevice *dev, int baudrate);
void serial_dev_clear(struct udevice *dev);
```

5.27 USB

U-Boot USB mainly includes Devcie, Host, PHY and USB peripheral driver, which will be detailed in this section with their framework configuration, board-level configuration and the use of related commands

5.27.1 Framework Support

Device

Device is based on Gadget framework (without DM_USB), generally configured as rockusb or fastboot mode for firmware upgrade, firmware verification, etc. The rockusb protocol is based on the UMS protocol, and its state machine is embedded in the UMS framework in the form of HOOK, which can be referenced in the implementation of the rockusb driver.

Currently, there are two kinds of USB Device controllers, DWC2 and DWC3, usually a chip will only integrate one of the OTG controllers, so you only need to enable one kind of controller related configurations in the CONFIG, for which controller you need to configure please refer to the chip's TRM or Rockchip USB development guide.

Configuration:

```
CONFIG_USB=y

// gadget configuration
CONFIG_USB_GADGET=y
CONFIG_USB_GADGET_MANUFACTURER="Rockchip"
CONFIG_USB_GADGET_VENDOR_NUM=0x2207
CONFIG_USB_GADGET_PRODUCT_NUM=0x330a // Configured based on chip ID
CONFIG_USB_GADGET_VBUS_DRAW=2
CONFIG_USB_GADGET_DUALSPEED=y

// rockusb configuration
#define CONFIG_USB_FUNCTION_MASS_STORAGE // placed in
include/configs/rkxxx_common.h
CONFIG_USB_GADGET_DOWNLOAD=y
CONFIG_CMD_ROCKUSB=y
```

```
// DWC3 Controller Configuration
CONFIG_USB_DWC3=y.
CONFIG_USB_DWC3_GADGET=y.

// DWC2 Controller Configuration
CONFIG_USB_GADGET_DWC2_OTG=y.
```

Framework code:

```
// gadget framework
drivers/usb/gadget/g_dnl.c
drivers/usb/gadget/g_dnl.c
drivers/usb/gadget/config.c
drivers/usb/gadget/epautoconf.c
drivers/usb/gadget/usbstring.c
drivers/usb/gadget/f_mass_storage.c
```

Driver code:

```
// rockusb
cmd/rockusb.c
drivers/usb/gadget/f_rockusb.c

// controller
drivers/usb/gadget/dwc2_udc_otg* // dwc2 OTG controller
drivers/usb/dwc3 // dwc3 OTG controller
```

Host

Host controllers include OHCI, EHCI and xHCI, of which xHCI can support USB3 devices, but not all chips have integrated xHCI controllers, the specific integration situation needs to be referred to the chip TRM or Rockchip USB development guide. Host development is mainly about the adaptation of the controller to the DTS.

Configuration:

```
CONFIG_USB=y.
CONFIG_DM_USB=y.

// xHCI
CONFIG_USB_HOST=y.
CONFIG_USB_XHCI_HCD=y.
CONFIG_USB_XHCI_DWC3=y.
CONFIG_USB_DWC3_GENERIC=y.

// EHCI
CONFIG_USB_EHCI_HCD=y.
CONFIG_USB_EHCI_GENERIC=y.

// OHCI
#define CONFIG_USB_OHCI_NEW // 位于include/configs/rkxxx_common.h中
#define CONFIG_SYS_USB_OHCI_MAX_ROOT_PORTS 1
CONFIG_USB_OHCI_HCD=y.
CONFIG_USB_OHCI_GENERIC=y.
```

Framwork code:


```
// Framework code
cmd/usb.c
drivers/usb/host/usb-uclass.c

// EHCI
drivers/usb/host/ehci-generic.c
drivers/usb/host/ehci-hcd.c

// OHCI
drivers/usb/host/ohci-generic.c
drivers/usb/host/ohci-hcd.c

// xHCI
drivers/usb/host/xhci.c
drivers/usb/host/xhci-dwc3.c
drivers/usb/host/xhci-mem.c
drivers/usb/host/xhci-ring.c
```

PHY

U-Boot USB PHY mainly consists of USB2 and USB3 PHY drivers, using DM_USB configuration and is compatible with the Linux kernel DTB. For specific PHY IP integration, you need to refer to the Chip TRM or Rockchip USB PHY Development Guide.

Configuration:

```
CONFIG_PHY=y

// INNO USB2
CONFIG_PHY_ROCKCHIP_INNO_USB2=y
// INNO USB3
CONFIG_PHY_ROCKCHIP_INNO_USB3=y
// NANENG USB2
CONFIG_PHY_ROCKCHIP_NANENG_USB2=y
// NANENG COMBOPHY
CONFIG_PHY_ROCKCHIP_NANENG_COMBOPHY=y
// RK3399 USBDP PHY
CONFIG_PHY_ROCKCHIP_TYPEC=y
```

Framework code:

```
drivers/phy/phy-uclass.c
```

Driver code:

```
// INNO USB2
drivers/phy/phy-rockchip-inno-usb2.c
// INNO USB3
drivers/phy/phy-rockchip-inno-usb3.c
// NANENG USB2
drivers/phy/phy-rockchip-naneng-usb2.c
// NANENG COMBOPHY
drivers/phy/phy-rockchip-naneng-combphy.c
// RK3399 USBDP PHY
drivers/phy/phy-rockchip-typec.c
```

**** Other Peripherals****

U-Boot USB peripheral support is primarily about USB HUBs, USB keyboards and UMS devices.

Configuration:

```
// USB Keyboard
CONFIG_USB_KEYBOARD=y
CONFIG_USB_KEYBOARD_FN_KEYS=y // Support F1-F12, INS, HOME and other shortcuts.

// USB storage device
CONFIG_USB_STORAGE=y
```

Framework code:

```
// Framework code
common/usb.c
drivers/usb/host/usb-uhci.c

// USB keyboard
drivers/input/usb_kbd.c
drivers/input/keyboard-uhci.c

// USB storage device
common/usb/usb_storage.c
```

5.27.2 Board Configuration

Device

Since the USB Device does not use the DM_USB method, you need to configure the Properties of the corresponding controller in the Board file, such as the address of the USB controller, the size of the TX FIFO, and so on.

```
// DWC3 Controller Configuration
// board/rockchip/evb_rk3399/evb_rk3399.c
#ifdef CONFIG_USB_DWC3
static struct dwc3_device dwc3_device_data = {
    .maximum_speed = USB_SPEED_HIGH,
    .base = 0xfe800000, // Modified according to different chip USB OTG
    .controller_base_address,
    .dr_mode = USB_DR_MODE_PERIPHERAL,
    .index = 0,
    .dis_u2_susphy_quirk = 1,
    .usb2_phyif_utmi_width = 16,
};

int usb_gadget_handle_interrupts(void)
{
    dwc3_uboot_handle_interrupt(0);
    return 0;
}

int board_usb_init(int index, enum usb_init_type init)
{
    }
```

```

        return dwc3_uboot_init(&dwc3_device_data);
    }.
#endif

// The DWC2 controller configuration is implemented in the rockchip_generic
// board.c file and generally does not need to be modified
// arch/arm/mach-rockchip/board.c

```

USB keyboard

If you use USB keyboard as U-Boot standard input device, you need to add usbkbd to the stdin environment variable, the reference code is as follows.

```

// Environment variable configuration is located in each board header file
// include/configs/evb_rk3568.h

#define ROCKCHIP_DEVICE_SETTINGS \
    "stdin=serial,usbkbd\0" \

```

5.27.3 DTS Configuration

As mentioned earlier, USB Device does not use the DM_USB method, so it does not need the configuration of the relevant DT node; USB Host and USB PHY drivers are compatible with the Linux kernel DTB, so you can directly use the Linux kernel DTB, and if you want to configure the use of U-Boot DTB you can refer to the implementation of the relevant node in the Linux kernel.

5.27.4 Related Commands

rockusb

```

rockusb - Use the rockusb Protocol

Usage:
rockusb <USB_controller> <devtype> <dev[:part]> e.g. rockusb 0 mmc 0

```

There are three ways to enter the U-Boot loader upgrade mode as follows:

- Accessed by reset + recovery keystrokes
- Enter the U-Boot command line and execute the above command to turn on rockusb and enter upgrade mode;
- After entering the system, execute “reboot loader” on the command line to soft reboot into upgrade mode.

usb

```

usb - USB sub-system

Usage:
usb start - start (scan) USB controller
usb reset - reset (rescan) USB controller
usb stop [f] - stop USB [f]=force stop
usb tree - show USB device tree
usb info [dev] - show available USB devices

```

```

usb test [dev] [port] [mode] - set USB 2.0 test mode
    (specify port 0 to indicate the device's upstream port)
    Available modes: J, K, S[E0_NAK], P[acket], F[orce_Enable].
usb storage - show details of USB storage devices
usb dev [dev] - show or set current USB storage device
usb part [dev] - print partition table of one or all USB storage devices
usb read addr blk# cnt - read `cnt' blocks starting at block `blk#'
    to memory address `addr'
usb write addr blk# cnt - write `cnt' blocks starting at block `blk#'
    from memory address `addr'

```

U-Boot USB does not support hot plugging and unplugging of devices, so it is necessary to execute USB commands to enumerate and disconnect devices.

- Parse the controller node and scan the devices conneted to all ports with the “usb start” or “usb reset” command.
- Disconnect all devices and deconstruct the controller device with the “usb stop” command.
- View controller information and information about currently connected devices with the “usb info” and “usb tree” commands.
- The “usb storage” and its following commands are used for UMS function, please refer to the command description for details.

fastboot

Refer to section CH04-System Module, chapter Fastboot for fastboot configuration and use.

5.28 Vendor Storage

Vendor Storage is used to store small data such as SN, MAC, etc. that does not require encryption. Data is stored in a reserved partition of NVM (eMMC, NAND, etc.) with multiple backups, so that when updating data, the data is kept with a high reliability and won't be lost.

Refer to the document “appnote rk vendor storage” for details.

5.28.1 Principle Overview

The vendor block is divided into 4 partitions, vendor0, vendor1, vendor2, and vendor3, and each vendorX (X=0, 1, 2, 3) has a monotonically incrementing version field in its hdr to indicate the point of time when the vendorX was updated. Each read operation reads only the newest vendorX (i.e., the largest version), while a write operation updates the version and moves all existing and new information to the vendorX+1 partition. For example, if you read from vendor2, modify it and then write it back, you will write to vendor3. This is just a simple security measure.

5.28.2 Framework Support

The U-Boot framework does not support Vendor Storage functionality, Rockchip has implemented its own set of Vendor Storage drivers.

configure:

```
CONFIG_ROCKCHIP_VENDOR_PARTITION
```

driver file:

```
./arch/arm/mach-rockchip/vendor.c  
./arch/arm/include/asm/arch-rockchip/vendor.h
```

5.28.3 Relevant Interface

```
int vendor_storage_read(u16 id, void *pbuf, u16 size)  
int vendor_storage_write(u16 id, void *pbuf, u16 size)
```

For the definition and use of ids, see apnote rk vendor storage.

5.28.4 Functionality Self-test

The Vendor Storage function can be self-tested by using the “rktest vendor” command from the U-Boot serial command line.

5.29 Watchdog

5.29.1 Framework Support

The watchdog driver uses the wdt-uclass.c framework and standard interfaces.

Configure:

```
CONFIG_WDT  
CONFIG_ROCKCHIP_WATCHDOG
```

Framework Code:

```
./drivers/watchdog/wdt-uclass.c
```

Driver code

```
./drivers/watchdog/rockchip_wdt.c
```

5.29.2 Relevant Interface

```
// Set the timeout for feeding the dog and start wdt (@flags is 0 by default)  
int wdt_start(struct udevice *dev, u64 timeout_ms, ulong flags);  
// Close wdt  
int wdt_stop(struct udevice *dev);  
// feed the dog  
int wdt_reset(struct udevice *dev);  
// Ignore this please, no underlying driver implementation done at this time  
int wdt_expire_now(struct udevice *dev, ulong flags)
```

Currently, U-Boot does not enable or use the wdt function in the default process, users can enable it according to their own product requirements.

6. Chapter-6 Advanced Principle

6.1 Kernel-DTB

6.1.1 Design Background

The native architecture of U-Boot requires that one board must correspond to one U-Boot dts, and the dtb generated by U-Boot dts is packaged into U-Boot's own image. This results in N boards requiring N copies of the U-Boot image on each SoC platform.

It is not difficult to find out that the main difference between different boards of a SoC platform is the peripherals, and the core part of the SoC is the same. RK platform has added the kernel DTB mechanism in order to realize that a SoC platform only needs one U-Boot image. The essence is to cut to the kernel DTB at an earlier stage and initialize the peripherals with its configuration information.

So the RK platform can achieve compatibility with board differences such as display, pmic/regulator, pinctrl, clk, etc. by supporting kernel DTB.

kernel DTB enablement relies on OF_LIVE (live device tree, short: live-dt)

```
config USING_KERNEL_DTB  
bool "Using dtb from Kernel/resource for U-Boot"  
depends on RKIMG_BOOTLOADER && OF_LIVE  
default y  
help  
This enable support to read dtb from resource and use it for U-Boot,  
the uart and emmc will still using U-Boot dtb, but other devices like  
regulator/pmic, display, usb will use dts node from kernel.
```

6.1.2 Live Device Tree

Background and rationale:

After the introduction of the kernel DTB, there are two copies of the DTB in the U-Boot stage, where modules such as Storage, Serial, Crypto are related to the U-Boot DTB and the rest of the modules are related to the kernel DTB. Then in U-Boot stage, it may need to cross access to these two types of modules at different moments, and at the same time, modules may need to access their own DTB node information.

So, these two types of modules belong to different DTBs, and `gd->fdt_blob` can only point to one of them and it is not easy to switch between them, what should we do? Since the kernel dts will eventually be passed to the kernel, you can't just overlay some nodes from the U-Boot dts to the kernel dts to make a single copy.

Live dt can solve this problem. the principle of live dt is: during the initialization phase, U-Boot scans the entire DTB directly, converts all DTB nodes into struct device_node node list, and binds them to specific device-driver. In the future, when the device-driver wants to access the DTB nodes, it can directly access its own device_node, and does not need to access the original DTB again.

So, it is equivalent to that both U-Boot and kernel DTBs are bound to their respective device-driver groups, and there is no need to directly access to the DTB files.

This resolves the conflict caused by accessing two sets of DTBs.

More references:

```
./doc/driver-model/livetree.txt
```

fdt and live dt conversion:

The ofnode type (include/dm/ofnode.h) is an encapsulation format supported by both types of dt. device_node is used to access dt nodes when using live dt, and offset is used to access dt nodes when using fdt. When you need to support both types of drivers, please use the ofnode type.

ofnode structure:

```
/*
 * @np: Pointer to device node, used for live tree
 * @of_offset: Pointer into flat device tree, used for flat tree. Note that this
 *           is not a really a pointer to a node: it is an offset value. See above.
 */
typedef union ofnode_union {
    const struct device_node *np; /* will be used for future live tree */
    long of_offset;
} ofnode;
```

- Functions starting with “dev_”, “ofnode_” are functions that support both dt access methods;
- Functions starting with “of_” are interfaces that only support live dt;
- Functions starting with “fdtdec_”, “fdt_” are interfaces that only support fit;

6.1.3 Mechanisms to Achieve

The kernel dtb switch is implemented in . /arch/arm/mach-rockchip/board.c in init_kernel_dtb().
At this point, U-Boot's dts have been scanned and the mmc/nand/nor storage drivers are working properly.

At this point, read the kernel dtb from the firmware, then build live dt table and bind all device-drivers, and finally update the gd->fdt_blob pointer to point to the kernel dtb.

6.1.4 U-Boot

- After U-Boot is compiled it will generate two dtbs in the ./dts/ directory:
 - dt.dtb: Compiled from the dts specified by CONFIG_DEFAULT_DEVICE_TREE in defconfig;
 - dt-spl.dtb: get from dt.dtb by extracting all the nodes with u-boot,dm-pre-reloc properties, and then remove the properties specified by CONFIG_OF_SPL_REMOVE_PROPS in defconfig. Generally, only the nodes that must be relied on by drivers for serial ports, DDR, storage, etc. are included: DMC, UART, MMC, NAND, GRF, CRU, and so on.
- System uses dt.dtb when CONFIG_USING_KERNEL_DTB is not enabled; system uses dt-spl.dtb when CONFIG_USING_KERNEL_DTB is enabled.
- Both dt.dtb or dt-spl.dtb are named u-boot.dtb at the end of U-Boot compilation and then appended to the end of u-boot.bin. Users can check the content of u-boot.dtb by fdt dump command.

6.2 Kernel Pass Parameter

This chapter describes how U-Boot passes parameters to the kernel.

6.2.1 Cmdline

U-Boot reads `/chosen/bootargs` from the kernel DTB, modifies/appends it with the new content and then rewrites it back to the `/chosen/bootargs` node for the purpose of passing the cmdline.

6.2.2 Memory Capacity

U-Boot modifies the `/memory` node in the kernel DTB, and fill in the available memory capacity information. The boot information is printed:

```
.....
## Chapter-6 Booting Android Image at 0x0027f800 ...
Kernel load addr 0x00280000 size 23387 KiB
RAM disk load addr 0x0a200000 size 782 KiB
## Chapter-6 Flattened Device Tree blob at 08300000
  Booting using the fdt blob at 0x8300000
  XIP Kernel Image ... OK
  'reserved-memory' ramoops@110000: addr=110000 size=f0000
  Using Device Tree in place at 0000000008300000, end 0000000008314648

// Memory space available to the kernel
Adding bank: 0x00200000 - 0x08400000 (size: 0x08200000).
Adding bank: 0x0a200000 - 0x80000000 (size: 0x75e00000).
Total: 473.217 ms

Starting kernel ...
```

6.2.3 Other Ways

All other methods of passing parameters are essentially modifying the kernel DTB, as follows:

Nodes/attributes	Operation	Effects
/serial-number	Create	serial number
/memory	Modify	Kernel Visible Memory
/display-subsystem/route/route-edp/	Append	Show related parameters (edp for example)
/chosen/linux,initrd-start	Create	ramdisk starting address
/chosen/linux,initrd-end	Create	ramdisk ending address
/bootargs	Modify	cmdline visible to kernel
mac-address or local-mac-address within the GMAC node	Modify	mac address
arch/arm/mach-rockchip/board.c: board_fdt_fixup()	Modify	board fdt fixup

6.3 AB System

6.3.1 AB Data Format

The data structure for A/B is located 2KB offset from the misc partition.

```

/* Magic for the A/B struct when serialized. */
#define AVB_AB_MAGIC "\0AB0"
#define AVB_AB_MAGIC_LEN 4

/* Versioning for the on-disk A/B metadata - keep in sync with avbtool. */
#define AVB_AB_MAJOR_VERSION 1
#define AVB_AB_MINOR_VERSION 0

/* Size of AvbABData struct. */
#define AVB_AB_DATA_SIZE 32

/* Maximum values for slot data */
#define AVB_AB_MAX_PRIORITY 15
#define AVB_AB_MAX_TRIES_REMAINING 7

typedef struct AvbABSlotData {
    /* Slot priority. Valid values range from 0 to AVB_AB_MAX_PRIORITY,
     * both inclusive with 1 being the lowest and AVB_AB_MAX_PRIORITY
     * being the highest. The special value 0 is used to indicate the
     * slot is unbootable.
     */
    uint8_t priority;

    /* Number of times left attempting to boot this slot ranging from 0
     * to AVB_AB_MAX_TRIES_REMAINING.
     */
    uint8_t tries_remaining;

```

```

    /* Non-zero if this slot has booted successfully, 0 otherwise. */
    uint8_t successful_boot;

    /* Reserved for future use. */
    uint8_t reserved[1];
} AVB_ATTR_PACKED AvbABSlotData;

/* Struct used for recording A/B metadata.
 *
 * When serialized, data is stored in network byte-order.
 */
typedef struct AvbABData {
    /* Magic number used for identification - see AVB_AB_MAGIC. */
    uint8_t magic[AVB_AB_MAGIC_LEN];

    /* Version of on-disk struct - see AVB_AB_{MAJOR,MINOR}_VERSION. */
    uint8_t version_major;
    uint8_t version_minor;

    /* Padding to ensure |slots| field start eight bytes in. */
    uint8_t reserved1[2];

    /* Per-slot metadata. */
    AvbABSlotData slots[2];

    /* Reserved for future use. */
    uint8_t reserved2[12];

    /* CRC32 of all 28 bytes preceding this field. */
    uint32_t crc32;
} AVB_ATTR_PACKED AvbABData;

```

For small capacity storage that does not have a misc partition but does have a vendor partition, consider storing to the vendor.

Add lastboot to mark the last bootable firmware. It is mainly used in low power situation or factory production test when the retry count is used up and the boot_ctrl service has not yet been called by the system. The reference is as follows:

```

typedef struct AvbABData {
    /* Magic number used for identification - see AVB_AB_MAGIC. */
    uint8_t magic[AVB_AB_MAGIC_LEN];

    /* Version of on-disk struct - see AVB_AB_{MAJOR,MINOR}_VERSION. */
    uint8_t version_major;
    uint8_t version_minor;

    /* Padding to ensure |slots| field start eight bytes in. */
    uint8_t reserved1[2];

    /* Per-slot metadata. */
    AvbABSlotData slots[2];

    /* mark last boot slot */
    uint8_t last_boot;

    /* Reserved for future use. */
    uint8_t reserved2[11];
}

```

```

    /* CRC32 of all 28 bytes preceding this field. */
    uint32_t crc32;
} AVB_ATTR_PACKED AvbABData;

```

Also add the is_update flag bit to AvbABSlotData to flag the status of the system upgrade, changes as follows:

```

typedef struct AvbABSlotData {
    /* Slot priority. Valid values range from 0 to AVB_AB_MAX_PRIORITY,
     * both inclusive with 1 being the lowest and AVB_AB_MAX_PRIORITY
     * being the highest. The special value 0 is used to indicate the
     * slot is unbootable.
     */
    uint8_t priority;

    /* Number of times left attempting to boot this slot ranging from 0
     * to AVB_AB_MAX_TRIES_REMAINING.
     */
    uint8_t tries_remaining;

    /* Non-zero if this slot has booted successfully, 0 otherwise. */
    uint8_t successful_boot;

    /* Mark update state, mark 1 if the slot is in update state, 0 otherwise. */
    uint8_t is_update : 1;
    /* Reserved for future use. */
    uint8_t reserved : 7;
} AVB_ATTR_PACKED AvbABSlotData;

```

The table illustrates the meaning of each parameter:

AvbABData:

Parameter	Meaning
priority	Flag slot priority, 0 is not bootable, 15 is the top priority
tries_remaining	Number of attempts to start, set to 7
successful_boot	This parameter is configured after the system boots up successfully, 1: the slot boots up successfully, 0: the slot does not boot up successfully
is_update	Marks the upgrade status of the slot, 1: the slot is being upgraded, 0: the slot has not been upgraded or has been upgraded successfully.

AvbABSlotData:

Parameter	Meaning
magic	Structure header information:\0AB0
version_major	Major Version Information
version_minor	Minor version information
slots	slot boot information, see AvbABData
last_boot	Last successful boot slot, 0: slot A last boot succeeded, 1: slot B last boot succeeded
crc32	data validation

6.3.2 AB Activation Mode

Currently, system bootctrl is designed with two control modes, and the bootloader supports both modes.

6.3.2.1 Successful-boot

After entering the system normally, boot_ctrl is based on androidboot.slot_suffix to set the current slot variable:

```
successful_boot = 1;
priority = 15;
tries_remaining = 0;
is_update = 0;
last_boot = 0 or 1;_____ :refer to androidboot.slot_suffix
```

Upgrade the system with the boot_ctrl setting:

```
Upgraded slot settings:
successful_boot = 0;
priority = 14;
tries_remaining = 7;
is_update = 1;
lastboot = 0 or 1;_____ :refer to androidboot.slot_suffix

Current Slot Settings:
successful_boot = 1;
priority = 15;
tries_remaining = 0;
is_update = 0;
last_boot = 0 or 1;_____ :refer to androidboot.slot_suffix
```

System upgradation complete, boot_ctrl set:

```
Upgraded slot settings:  
successful_boot = 0;  
priority = 15;  
tries_remaining = 7;  
is_update = 0;  
lastboot = 0 or 1;_____ :refer to androidboot.slot_suffix  
  
Current Slot Settings:  
successful_boot = 1;  
priority = 14;  
tries_remaining = 0;  
is_update = 0;  
last_boot = 0 or 1;_____ :refer to androidboot.slot_suffix
```

6.3.2.2 **Reset-retry**

After entering the system normally, boot_ctrl is based on androidboot.slot_suffix to set the current slot variable:

```
successful_boot = 0;  
priority = 15;  
tries_remaining = 7;  
is_update = 0;  
last_boot = 0 or 1;_____ :refer to androidboot.slot_suffix
```

Upgrade the system with the boot_ctrl setting:

```
Upgraded slot settings:  
successful_boot = 0;  
priority = 14;  
tries_remaining = 7;  
is_update = 1;  
lastboot = 0 or 1;_____ :refer to androidboot.slot_suffix  
  
Current Slot Settings:  
successful_boot = 0;  
priority = 15;  
tries_remaining = 7;  
is_update = 0;  
last_boot = 0 or 1;_____ :refer to androidboot.slot_suffix
```

Upgrade system complete, boot_ctrl set:

```

Upgraded slot settings:
successful_boot = 0;
priority = 15;
tries_remaining = 7;
is_update = 0;
lastboot = 0 or 1; _____:refer to androidboot.slot_suffix


Current Slot Settings:
successful_boot = 0;
priority = 14;
tries_remaining = 7;
is_update = 0;
last_boot = 0 or 1; _____:refer to androidboot.slot_suffix


```


6.3.2.3 Mode Comparison

- successful_boot mode
 - Advantage: As long as the system is booted normally, it will not revert back to an older firmware version unless system bootctrl is configured
 - Disadvantage: After the device has been working for a long time, if it stores some particles abnormally, it will cause the system to reboot all the time
- reset retry mode
 - Advantage: always keep the retry mechanism, can cope with storage exception problems
 - Disadvantage: May falls back to an older firmware version


6.3.3 Boot Process









AB successful_boot mode data flow:





AB reset retry mode data flow:





6.3.4 Upgrade and Exceptions

- System Upgrade: Refer to the Rockchip Linux Upgrade Program Development Guide.
- Recovery upgrades: The AB system does not consider supporting recovery upgrades.

6.3.5 Validation Methods

6.3.5.1 Successful-boot

1. Write only slot A, the system boots from slot A. Setup to boot from slot B, system boots from slot A. Test completed, clear the misc partition.
2. Write slot A and slot B, boot the system, the current system is slot A. Set the system to boot from slot B, reboot the system, the current system is slot B. Test completed, clear the misc partition.
3. Write slot A and slot B and quickly resetting the system 14 times, the retry counter runs out and the system can still boot from the system specified by last_boot, i.e., it can boot from slot A normally. Test completed, clear the misc partition
4. Write slot A and slot B, boot the system, current system is slot A. Set the system to boot from slot B, reboot the system, current system is slot B. Set the system to boot from slot A, reboot the system, current system is slot A. Test completed, clear the misc partition.

6.3.5.2 Reset-retry

1. Write only slot A, the system boots from slot A. Setup to boot from slot B, system boots from slot A. Test completed, clear misc partition
2. Write slot A and slot B, boot the system, the current system is slot A. Set the system to boot from slot B, reboot the system, the current system is slot B. Test completed, clear the misc partition.
3. Writing slot A and slot B and quickly resetting the system 14 times, the retry counter runs out and the system can still boot from the system specified by last_boot, i.e., it can boot from slot A normally. Test completed, clear the misc partition
4. Write slot A and slot B, where the boot.img of slot B is corrupted, boot the system, the current system is slot A. Set the system to boot from slot B, reboot the system, the system will reboot 7 times, then boot the system from slot A normally. Test completed, clear the misc partition
5. Write slot A and slot B, boot the system, current system is slot A. Set the system to boot from slot B, reboot the system, current system is slot B. Set the system to boot from slot A, reboot the system, current system is slot A. Test completed, clear the misc partition.

6.3.6 References

Rockchip-Secure-Boot2.0.md

Rockchip-Secure-Boot-Application-Note.md

Android Verified Boot 2.0

6.4 AVB Secure Boot

6.4.1 References

Rockchip-Secure-Boot-Application-Note.md

Android Verified Boot 2.0

Rockchip_Developer_Guide_Linux4.4_SecureBoot_CN.pdf

6.4.2 Terminology

AVB : Android Verified Boot

OTP & efuse : One Time Programmable

Product RootKey (PRK): AVB's root key is verified by the signature loader, uboot & trust's root key.

ProductIntermediate Key (PIK): Intermediate key, intermediary role

ProductSigning Key (PSK): The key used to sign the firmware

ProductUnlock Key (PUK): For unlocking devices

Separation of various keys and clear responsibilities can reduce the risk of key leakage.。

6.4.3 Brief Introduction

This chapter describes the Rockchip security verification bootstrap process. The so-called security verification bootstrap process is divided into security verification and integrity verification. Security verification is the verification of the cryptographic public key, the process is to read the public key hash from the secure storage (OTP & efuse), compare it with the calculated public key hash to see if it is the same, and then the public key is used to decrypt the firmware hash. Integrity verification is to verify the integrity of the firmware, the process is to load the firmware from the storage, and then calculate the firmware's hash and decrypted hash to see if it is the same.

6.4.4 Encryption Example

The security verification initiation process of the device is similar to the data encryption verification process in communication, and the example can accelerate the understanding of the avb verification process. If Alice now transmits a digital message to Bob, in order to ensure the confidentiality, authenticity, integrity and non-repudiation of the message transmission, it is necessary to digitally encrypt and sign the transmitted message, and the transmission process is:

1. Alice prepares the digital information (plaintext) to be transmitted;
2. Alice performs a hash operation on a digital message to obtain a message digest;
3. Alice encrypts the message digest with her own private key to get Alice's digital signature and attaches it to the digital message;
4. Alice randomly generates an encryption key and uses this cipher to encrypt the message to be sent to form a ciphertext;
5. Alice uses Bob's public key to encrypt the randomly generated encryption key, and transmits the encrypted DES key along with the ciphertext to Bob;
6. Bob receives the ciphertext and encrypted DES key from Alice, and first decrypts the encrypted DES key with his own private key to get the encryption key randomly generated by Alice;
7. Bob then decrypts the received ciphertext with a random key to get the digital information in plaintext, and then discards the random key;
8. Bob decrypts Alice's digital signature with Alice's public key to get the message digest;
9. Bob uses the same hashing algorithm to hash the received plaintext again to get a new message digest
10. Bob compares the summary of the received message with the summary of the newly generated message, and if it agrees, the received message has not been modified.

The DES algorithm mentioned above can be replaced with other algorithms, such as AES encryption algorithm, and the public-private key algorithm can be replaced with RSA algorithm, the process is as follows:



6.4.5 AVB

AVB is short for Android Verified Boot, a set of firmware verification process designed by Google, mainly used to verify the boot system and other firmware. rockchip Secure Boot achieve a complete set of Secure Boot verification program with reference to AVB and the verification method used in communication.

6.4.5.1 AVB Characteristics

- safety check
- integrity check
- anti-rollback protection
- persistent partition support
- chained partitions support, can be consistent with boot, system signing private key, or oem can save private key by itself, but must be signed by PRK.

6.4.5.2 Key+signature+certificate

```
#!/bin/sh
touch temp.bin
openssl genpkey -algorithm RSA -pkeyopt rsa_keygen_bits:4096 -outform PEM -out
testkey_prk.pem
openssl genpkey -algorithm RSA -pkeyopt rsa_keygen_bits:4096 -outform PEM -out
testkey_psk.pem
openssl genpkey -algorithm RSA -pkeyopt rsa_keygen_bits:4096 -outform PEM -out
testkey_pik.pem
python avbtool make_atx_certificate --output=pik_certificate.bin --
subject=temp.bin --subject_key=testkey_pik.pem --
subject_is_intermediate_authority --subject_key_version 42 --
authority_key=testkey_prk.pem
python avbtool make_atx_certificate --output=psk_certificate.bin --
subject=product_id.bin --subject_key=testkey_psk.pem --subject_key_version 42 --
authority_key=testkey_pik.pem
python avbtool make_atx_metadata --output=metadata.bin --
intermediate_key_certificate=pik_certificate.bin --
product_key_certificate=psk_certificate.bin
```

permanent_attributes.bin generate:

```
python avbtool make_atx_permanent_attributes --output=permanent_attributes.bin --
product_id=product_id.bin --root_authority_key=testkey_prk.pem
```

Among them, product_id.bin needs to be defined by yourself, which occupies 16 bytes and can be used as the product ID definition.

boot.img signature example:

```
avbtool add_hash_footer --image boot.img --partition_size 33554432 --
partition_name boot --key testkey_psk.pem --algorithm SHA256_RSA4096
```

Note: The partition size should be at least 64K larger than the original firmware, the size should be 4K aligned, and not larger than the partition size defined in parameter.txt.

system.img signature example:


```
avbtool add_hashtree_footer --partition_size 536870912 --partition_name system --
image system.img --algorithm SHA256_RSA4096 --key testkey_psk.pem
```

Generate vbmeta which includes metadata.bin, command example is as follows:

```
python avbtool make_vbmeta_image --public_key_metadata metadata.bin --
include_descriptors_from_image boot.img --include_descriptors_from_image
system.img --generate_dm_verity_cmdline_from_hashtree system.img --algorithm
SHA256_RSA4096 --key testkey_psk.pem --output vbmeta.img
```

The resulting vbmeta.img is eventually written to the corresponding partition, e.g. the vbmeta partition.

Generate PrivateKey.pem and PublicKey.pem with SecureBootTool.



Sign permanent_attributes.bin:

```
openssl dgst -sha256 -out permanent_attributes_cer.bin -sign PrivateKey.pem
permanent_attributes.bin
```

permanent_attributes.bin is the secure authentication data for the whole system, it needs to write its hash to efuse or OTP, or its data is securely authenticated by the previous level (pre-load). Since there is insufficient efuse made by rockchip platform, the authentication of permanent_attributes.bin is authenticated by the public key of the preload plus the certificate of permanent_attributes.bin. For platforms with OTP with enough secure data space, the hash of permanent_attributes.bin will be written directly to the OTP.

efuse and OTP support by platform:**Please refer to the Driver Module section.**


efuse platform pub_key download:

```
fastboot stage permanent_attributes.bin
fastboot oem fuse at-perm-attr
fastboot stage permanent_attributes_cer.bin
fastboot oem fuse at-rsa-perm-attr
```

OTP platform pub_key download:

```
fastboot stage permanent_attributes.bin
fastboot oem fuse at-perm-attr
```

The entire signature process:



6.4.5.3 AVB Lock

```
fastboot oem at-lock-vboot
```

How to enter fastboot? please see the fastboot command support section.

6.4.5.4 AVB Unlock

Currently Rockchip uses strict security checksums, which need to be added to the corresponding defconfig.

```
CONFIG_RK_AVB_LIBAVB_ENABLE_ATH_UNLOCK=y
```

Otherwise you can just enter fastboot oem at-unlock-vboot to unlock the device, and boot vbmeta.img verification, and the device will be booted successfully even boot.img fails.

First, a PUK needs to be generated:

```
openssl genpkey -algorithm RSA -pkeyopt rsa_keygen_bits:4096 -outform PEM -out testkey_puk.pem
```

unlock_credential.bin is the certificate that needs to be downloaded to the device to be unlocked, and its generation process is as follows:

```
python avbtool make_atx_certificate --output=puk_certificate.bin --  
subject=product_id.bin --subject_key=testkey_puk.pem --  
usage=com.google.android.things.vboot.unlock --subject_key_version 42 --  
authority_key=testkey_pik.pem
```


Get unlock_credential.bin from the device, use the avb-challenge-verify.py script to get unlock_credential.bin, execute the following command to get unlock_credential.bin:

```
python avbtool make_atx_unlock_credential --output=unlock_credential.bin --  
intermediate_key_certificate=pik_certificate.bin --  
unlock_key_certificate=puk_certificate.bin --challenge=unlock_challenge.bin --  
unlock_key=testkey_puk.pem
```


Eventually you can download the certificate to the device and unlock the device with the fastboot command as follows:

```
fastboot stage unlock_credential.bin  
fastboot oem at-unlock-vboot
```

Final OTP device unlocking process:



Final efuse device unlocking process:



The final operating procedure is as follows:

1. The device enters fastboot mode, and on the computer side, enter

```
fastboot oem at-get-vboot-unlock-challenge
fastboot get_staged raw_unlock_challenge.bin
```

Get the data with version, Product Id and 16 bytes random number, take out the random number as unlock_challenge.bin.

1. Use avbtool to generate unlock_credential.bin, refer to make_unlock.sh.
2. Input the following from PC

```
fastboot stage unlock_credential.bin
fastboot oem at-unlock-vboot
```

Note: At this point, the device is always in fastboot mode for the first time, and cannot be powered off, shut down, or rebooted during this period. Because after step 1, the device stores the generated random number, if you power off or reboot, the random number will be lost, and the subsequent verification of challenge signature will fail because of the random number mismatch.

If enable:

```
CONFIG_MISC=y
CONFIG_ROCKCHIP_EFUSE=y
CONFIG_ROCKCHIP_OTP=y
```

It will use the CPUID as the challenge number, and the CPUID is matched with the machine, so the data will not be lost because of the shutdown, and the generated unlock_credential.bin can be reused. It saves the steps of generating unlock_challenge.bin and making unlock_credential.bin repeatedly. The steps to unlock again are changed to:

```
fastboot oem at-get-vboot-unlock-challenge
fastboot stage unlock_credential.bin
fastboot oem at-unlock-vboot
```

1. The device enters the unlocked state and begins to unlock.

make_unlock.sh refer to

```
#!/bin/sh
python avb-challenge-verify.py raw_unlock_challenge.bin product_id.bin
python avbtool make_unlock_credential --output=unlock_credential.bin --
intermediate_key_certificate=pik_certificate.bin --
unlock_key_certificate=puk_certificate.bin --challenge=unlock_challenge.bin --
unlock_key=testkey_puk.pem
```

avb-challenge-verify.py source code

```
#!/user/bin/env python
"This is a test module for getting unlock_challenge.bin"
import sys
import os
from hashlib import sha256

def challenge_verify():
    if (len(sys.argv) != 3) :
        print "Usage: rkpublickey.py [challenge_file] [product_id_file]"
        return
    if ((sys.argv[1] == "-h") or (sys.argv[1] == "--h")):
        print "Usage: rkpublickey.py [challenge_file] [product_id_file]"
        return
    try:
        challenge_file = open(sys.argv[1], 'rb')
        product_id_file = open(sys.argv[2], 'rb')
        challenge_random_file = open('unlock_challenge.bin', 'wb')
        challenge_data = challenge_file.read(52)
        product_id_data = product_id_file.read(16)
        product_id_hash = sha256(product_id_data).digest()
        print("The challenge version is %d" %ord(challenge_data[0]))
        if (product_id_hash != challenge_data[4:36]) :
            print("Product id verify error!")
            return
        challenge_random_file.write(challenge_data[36:52])
        print("Success!")
    finally:
        if challenge_file:
```

```

        challenge_file.close()
    if product_id_file:
        product_id_file.close()
    if challenge_random_file:
        challenge_random_file.close()

if __name__ == '__main__':
    challenge_verify()

```

4.5.5 Enable U-boot

Enabling avb requires trust support, which needs to be configured by U-Boot in the defconfig file:

```

CONFIG_OPTEE_CLIENT=y
CONFIG_OPTEE_V1=y
CONFIG_OPTEE_ALWAYS_USE_SECURITY_PARTITION=y // Security data is stored in the
security_partition

```

CONFIG_OPTEE_V1: suitable for platforms with 312x,322x,3288,3228H,3368,3399。

CONFIG_OPTEE_V2: suitable for platforms with 3326,3308。

CONFIG_OPTEE_ALWAYS_USE_SECURITY_PARTITION: This macro is turned on when rpmb for emmc is not available; it is not turned on by default.

The enablement of avb needs to be configured in the defconfig file:

```

CONFIG_AVB_LIBAVB=y
CONFIG_AVB_LIBAVB_AB=y
CONFIG_AVB_LIBAVB_ATX=y
CONFIG_AVB_LIBAVB_USER=y
CONFIG_RK_AVB_LIBAVB_USER=y
// The above options are mandatory, the following options support AVB and A/B
features, the two features can be used separately.
CONFIG_ANDROID_AB=y //This supports A/B
CONFIG_ANDROID_AVB=y //This supports A/B
// The following macros are for efuse-only platforms
CONFIG_ROCKCHIP_PRELOADER_PUB_KEY=y
// The following macros need to be turned on for strict unlock checksums
CONFIG_RK_AVB_LIBAVB_ENABLE_ATH_UNLOCK=y
// Enable security check
CONFIG_AVB_VBMETA_PUBLIC_KEY_VALIDATE=y
// If you need the cpuid as a challenge number, enable the following macro
CONFIG_MISC=y
CONFIG_ROCKCHIP_EFUSE=y
CONFIG_ROCKCHIP_OTP=y

```

6.4.5.5 Kernel Configuration

The checksums for system, vendor, oem, etc. are loaded by the kernel's dm-verify module, so you need to enable this module.

To enable AVB, you need to configure the parameter avb on the kernel dts as follows:

```

&firmware_android {
    compatible = "android,firmware";
    boot_devices = "fe330000.sdhci";
}

```

```

vbmeta {
    compatible = "android,vbmeta";
    parts = "vbmeta,boot,system,vendor,dtbo";
}
fstab {
    compatible = "android,fstab";
    vendor {
        compatible = "android,vendor";
        dev = "/dev/block/by-name/vendor";
        type = "ext4";
        mnt_flags = "ro,barrier=1,inode_readahead_blks=8";
        fsmgr_flags = "wait,avb";
    }
}
}

```

To enable the A/B system, you need to configure the slotselect parameter as follows:

```

firmware {
    android {
        compatible = "android,firmware";
        fstab {
            compatible = "android,fstab";
            system {
                compatible = "android,system";
                dev = "/dev/block/by-name/system";
                type = "ext4";
                mnt_flags = "ro,barrier=1,inode_readahead_blks=8";
                fsmgr_flags = "wait,verify,slotselect";
            }
            vendor {
                compatible = "android,vendor";
                dev = "/dev/block/by-name/vendor";
                type = "ext4";
                mnt_flags = "ro,barrier=1,inode_readahead_blks=8";
                fsmgr_flags = "wait,verify,slotselect";
            }
        }
    }
}

```

6.4.5.6 Android SDK

The following describes some of the configuration instructions on the Android SDK.

AVB Enable

Enable BOARD_AVB_ENABLE

A/B system

There are three main categories of these variables:

- Variables that must be defined by the A/B system
 - AB_OTA_UPDATER := true
 - AB_OTA_PARTITIONS := boot system vendor

- `BOARD_BUILD_SYSTEM_ROOT_IMAGE := true`
- `TARGET_NO_RECOVERY := true`
- `BOARD_USES_RECOVERY_AS_BOOT := true`
- `PRODUCT_PACKAGES += update_engine update_verifier`
- Variables that is optionally defined for A/B system
 - `PRODUCT_PACKAGES_DEBUG += update_engine_client`
- Variables that cannot be defined in the A/B system
 - `BOARD_RECOVERYIMAGE_PARTITION_SIZE`
 - `BOARD_CACHEIMAGE_PARTITION_SIZE`
 - `BOARD_CACHEIMAGE_FILE_SYSTEM_TYPE`

6.4.5.7 Cmdline New Content

```
Kernel command line: androidboot.verifiedbootstate=green
androidboot.slot_suffix=_a dm="1 vroot none ro 1,0 1031864 verity 1
PARTUUID=b2110000-0000-455a-8000-44780000706f PARTUUID=b2110000-0000-455a-8000-
44780000706f 4096 4096 128983 128983 sha1
90d1d406caac04b7e3fbf48b9a4dcd6992cc628e 4172683f0d6b6085c09f6ce165cf152fe3523c89
10 restart_on_corruption ignore_zero_blocks use_fec_from_device
PARTUUID=b2110000-0000-455a-8000-44780000706f fec_roots 2 fec_blocks 130000
fec_start 130000" root=/dev/dm-0 androidboot.vbmeta.device=PARTUUID=f24f0000-
0000-4e1b-8000-791700006a98 androidboot.vbmeta.avb_version=1.1
androidboot.vbmeta.device_state=unlocked androidboot.vbmeta.hash_alg=sha512
androidboot.vbmeta.size=6528
androidboot.vbmeta.digest=41991c02c82ea1191545c645e2ac9cc7ca08b3da0a2e3115aff479d
2df61feaccdd35b6360cfa936f6f4381e4557ef18e381f4b236000e6ecc9ada401eda4cae
androidboot.vbmeta.invalidate_on_error=yes androidboot.veritymode=enforcing
```

Notes on a few parameters:

1. Why pass the PARTUUID of the vbmeta? To ensure the legitimacy of the subsequent use of the vbmeta hash-tree, the kernel needs to verify the vbmeta again, with digest as androidboot.vbmeta.digest.
2. skip_initramfs: boot ramdisk is packed to boot.img or not, in A/B system, ramdisk is not packed to boot.img, cmdline need to pass this parameter.
3. root=/dev/dm-0 enables dm-verify, specifies system.
4. androidboot.vbmeta.device_state: android verify 状态 androidboot.vbmeta.device_state: android verify state
5. androidboot.verifiedbootstate: verification results.

green: If in LOCKED state and an the key used for verification was not set by the end user.

yellow: If in LOCKED state and an the key used for verification was set by the end user.

orange: If in the UNLOCKED state.

Special remarks on the dm="1 vroot none ro....." parameter is generated:

```
avbtool make_vbmeta_image --include_descriptors_from_image boot.img --
include_descriptors_from_image system.img --
generate_dm_verity_cmdline_from_hashtree system.img --
include_descriptors_from_image vendor.img --algorithm SHA512_RSA4096 --key
testkey_psk.pem --public_key_metadata metadata.bin --output vbmeta.img
```


When avbtool generates vbmeta, add --generate dm_verity_cmdline from hashtree to the system firmware. dm="l vroot none ro....." will be saved to vbmeta. This part is Android-specific, if the partition only checksums to boot.img, you don't need to add this parameter.

Enabling BOARD_AVB_ENABLE in the Android SDK will add this information to the vbmeta.

6.4.6 Partition Reference

Newly added vbmeta partition and security partition, vbmeta partition stores firmware verification information, security partition stores encrypted security data.

```
FIRMWARE_VER:8.0  
MACHINE_MODEL:RK3326  
MACHINE_ID:007  
MANUFACTURER: RK3326  
MAGIC: 0x5041524B  
ATAG: 0x00200800  
MACHINE: 3326  
CHECK_MASK: 0x80  
PWR_HLD: 0,0,A,0,1  
TYPE: GPT  
CMDLINE:mtddparts=rk29xxnand:0x00002000@0x00004000(uboot),0x00002000@0x00006000(trust),0x00002000@0x00008000(misc),0x00008000@0x0000a000(resource),0x00010000@0x00012000(kernel),0x00002000@0x00022000(dtbo),0x00002000@0x00024000(dtbo),0x00000800@0x00026000(vbmeta),0x00010000@0x00026800(boot),0x00020000@0x00036800(recovery),0x0038000@0x00056800(backup),0x00002000@0x0008e800(security),0x000c0000@0x00090800(cache),0x00514000@0x00150800(system),0x00008000@0x00664800(metadata),0x000c0000@0x0066c800(vendor),0x00040000@0x0072c800(oem),0x00000400@0x0076c800(frp),-@0x0076cc00(userdata:grow)  
uuid:system=af01642c-9b84-11e8-9b2a-234eb5e198a0
```

A/B System Partition Definition Reference:

```
FIRMWARE_VER:8.1  
MACHINE_MODEL:RK3326  
MACHINE_ID:007  
MANUFACTURER: RK3326  
MAGIC: 0x5041524B  
ATAG: 0x00200800  
MACHINE: 3326  
CHECK_MASK: 0x80  
PWR_HLD: 0,0,A,0,1  
TYPE: GPT  
CMDLINE:  
mtddparts=rk29xxnand:0x00002000@0x00004000(uboot_a),0x00002000@0x00006000(uboot_b),0x00002000@0x00008000(trust_a),0x00002000@0x0000a000(trust_b),0x00001000@0x0000c000(misc),0x00001000@0x0000d000(vbmeta_a),0x00001000@0x0000e000(vbmeta_b),0x00020000@0x0000e000(boot_a),0x00020000@0x0002e000(boot_b),0x00100000@0x0004e000(system_a),0x00300000@0x0032e000(system_b),0x00100000@0x0062e000(vendor_a),0x00100000@0x0072e000(vendor_b),0x00002000@0x0082e000(oem_a),0x00002000@0x00830000(oem_b),0x00100000@0x00832000(factory),0x00008000@0x842000(factory_bootloader),0x00080000@0x008ca000(oem),-@0x0094a000(userdata)
```

6.4.7 Fastboot Command

Under U-Boot, you can enter fastboot by entering the command:

```
fastboot usb 0
```

6.4.7.1 Quick Overview of Commands

```
fastboot flash < partition > [ < filename > ].  
fastboot erase < partition >  
fastboot getvar < variable > | all  
fastboot set_active < slot >  
fastboot reboot  
fastboot reboot-bootloader  
fastboot flashing_unlock  
fastboot flashing_lock  
fastboot stage [ < filename > ].  
fastboot get_staged [ < filename > ].  
fastboot oem fuse at-perm-attr-data  
fastboot oem fuse at-perm-attr  
fastboot oem fuse at-rsa-perm-attr  
fastboot oem at-get-ca-request  
fastboot oem at-set-ca-response  
fastboot oem at-lock-vboot  
fastboot oem at-unlock-vboot  
fastboot oem at-disable-unlock-vboot  
fastboot oem fuse at-bootloader-vboot-key.  
fastboot oem format  
fastboot oem at-get-vboot-unlock-challenge  
fastboot oem at-reset-rollback-index
```

6.4.7.2 Command Usage

1. fastboot flash < partition > [< filename >]

Function: Write Partition.

Example: fastboot flash boot boot.img

1. fastboot erase < partition >

Function: Erase the partition.

Example: fastboot erase boot

1. fastboot getvar < variable > | all

Function: Get device information

Example: fastboot getvar all (get all information about the device)

Parameters that can be brought with variable:

```
version /* fastboot version */  
version-bootloader /* U-Boot version */
```

```

version-baseband
product /* Product Information */
serialno /* Serial number*/
secure /* Whether to enable security checking */
max-download-size /* maximum number of bytes supported by
fastboot in a single transfer */
logical-block-size /* Number of logical blocks */
erase-block-size /* Number of erased blocks*/
partition-type : < partition > /* Partition type */
partition-size : < partition > /* Partition size*/
unlocked /* Device lock status */
off-mode-charge
battery-voltage
variant
battery-soc-ok
slot-count /* Number of slots*/
has-slot: < partition > /* Check if the partition name is in the
slot*/
current-slot /* Currently booted slots */
slot-suffixes /* The current slot of the device, print
its name. */
slot-successful: < _a | _b > /* Check if the partition is properly
verified and booted*/
slot-unbootable: < _a | _b > /* Check if the partition is set to
unbootable */
slot-retry-count: < _a | _b > /* Check the number of retry-counts for
partition */
at-attest-dh
at-attest-uuid
at-vboot-state

```

fastboot getvar all example:

```

PS E:\U-Boot-AVB\adb> .\fastboot.exe getvar all
(bootloader) version:0.4
(bootloader) version-bootloader:U-Boot 2017.09-gc277677
(bootloader) version-baseband:N/A
(bootloader) product:rk3229
(bootloader) serialno:7b2239270042f8b8
(bootloader) secure:yes
(bootloader) max-download-size:0x04000000
(bootloader) logical-block-size:0x512
(bootloader) erase-block-size:0x80000
(bootloader) partition-type:bootloader_a:U-Boot
(bootloader) partition-type:bootloader_b:U-Boot
(bootloader) partition-type:tos_a:U-Boot
(bootloader) partition-type:tos_b:U-Boot
(bootloader) partition-type:boot_a:U-Boot
(bootloader) partition-type:boot_b:U-Boot
(bootloader) partition-type:system_a:ext4
(bootloader) partition-type:system_b:ext4
(bootloader) partition-type:vbmata_a:U-Boot
(bootloader) partition-type:vbmata_b:U-Boot
(bootloader) partition-type:misc:U-Boot
(bootloader) partition-type:vendor_a:ext4

```

(bootloader) partition-type:vendor_b:ext4
(bootloader) partition-type:oem_bootloader_a:U-Boot
(bootloader) partition-type:oem_bootloader_b:U-Boot
(bootloader) partition-type:factory:U-Boot
(bootloader) partition-type:factory_bootloader:U-Boot
(bootloader) partition-type:oem_a:ext4
(bootloader) partition-type:oem_b:ext4
(bootloader) partition-type:userdata:ext4
(bootloader) partition-size:bootloader_a:0x400000
(bootloader) partition-size:bootloader_b:0x400000
(bootloader) partition-size:tos_a:0x400000
(bootloader) partition-size:tos_b:0x400000
(bootloader) partition-size:boot_a:0x2000000
(bootloader) partition-size:boot_b:0x2000000
(bootloader) partition-size:system_a:0x20000000
(bootloader) partition-size:system_b:0x20000000
(bootloader) partition-size:vbmeta_a:0x10000
(bootloader) partition-size:vbmeta_b:0x10000
(bootloader) partition-size:misc:0x100000
(bootloader) partition-size:vendor_a:0x4000000
(bootloader) partition-size:vendor_b:0x4000000
(bootloader) partition-size:oem_bootloader_a:0x400000
(bootloader) partition-size:oem_bootloader_b:0x400000
(bootloader) partition-size:factory:0x2000000
(bootloader) partition-size:factory_bootloader:0x1000000
(bootloader) partition-size:oem_a:0x10000000
(bootloader) partition-size:oem_b:0x10000000
(bootloader) partition-size:userdata:0x7ad80000
(bootloader) unlocked:no
(bootloader) off-mode-charge:0
(bootloader) battery-voltage:0mv
(bootloader) variant:rk3229_evb
(bootloader) battery-soc-ok:no
(bootloader) slot-count:2
(bootloader) has-slot:bootloader:yes
(bootloader) has-slot:tos:yes
(bootloader) has-slot:boot:yes
(bootloader) has-slot:system:yes
(bootloader) has-slot:vbmeta:yes
(bootloader) has-slot:misc:no
(bootloader) has-slot:vendor:yes
(bootloader) has-slot:oem_bootloader:yes
(bootloader) has-slot:factory:no
(bootloader) has-slot:factory_bootloader:no
(bootloader) has-slot:oem:yes
(bootloader) has-slot:userdata:no
(bootloader) current-slot:a
(bootloader) slot-suffixes:a,b
(bootloader) slot-successful:a:yes
(bootloader) slot-successful:b:no
(bootloader) slot-unbootable:a:no
(bootloader) slot-unbootable:b:yes
(bootloader) slot-retry-count:a:0
(bootloader) slot-retry-count:b:0
(bootloader) at-attest-dh:1:P256
(bootloader) at-attest-uuid:
all: Done!
finished. total time: 0.636s

1. fastboot set_active < slot >

Function: Set the slot for reboot.

Example: fastboot set_active_a

1. fastboot reboot

Function: Reboot the device for normal startup

Example: fastboot reboot

1. fastboot reboot-bootloader

Function: Reboot the device to enter fastboot mode.

Example: fastboot reboot-bootloader

1. fastboot flashing unlock

Function: Unlock the device and allow firmware downloading

Example: fastboot flashing unlock

1. fastboot flashing lock

Function: Lock the device, prohibit downloading

Example: fastboot flashing lock

1. fastboot stage [< filename >]

Function: Download data to device-side memory, the memory start address is CONFIG_FASTBOOT_BUF_ADDR.

Example: fastboot stage permanent_attributes.bin

1. fastboot get_staged [< filename >]

Function: Getting data from the device side

Example: fastboot get_staged raw_unlock_challenge.bin

1. fastboot oem fuse at-perm-attr

Function: write permanent_attributes.bin and hash

Example: fastboot stage permanent_attributes.bin

fastboot oem fuse at-perm-attr

1. fastboot oem fuse at-perm-attr-data

Function: Burn only permanent_attributes.bin to the secure storage area (RPMB).

Example: fastboot stage permanent_attributes.bin

fastboot oem fuse at-perm-attr-data

1. fastboot oem at-get-ca-request
2. fastboot oem at-set-ca-response
3. fastboot oem at-lock-vboot

Function: Lock device

Example: fastboot oem at-lock-vboot

1. fastboot oem at-unlock-vboot

Function: Unlock the device, now support authenticated unlock

Example: fastboot oem at-get-vboot-unlock-challenge

fastboot get_staged raw_unlock_challenge.bin

./make_unlock.sh (refer to make_unlock.sh)

fastboot stage unlock_credential.bin

fastboot oem at-unlock-vboot

1. fastboot oem fuse at-bootloader-vboot-key

Function: download bootloader key hash

Example: fastboot stage bootloader-pub-key.bin

fastboot oem fuse at-bootloader-vboot-key

1. fastboot oem format

Function: reformat partitions, partition information depends on \$partitions

Example: fastboot oem format

1. fastboot oem at-get-vboot-unlock-challenge

Function: authenticated unlock, need to get unlock challenge data

Example: please refer to 16. fastboot oem at-unlock-vboot

1. fastboot oem at-reset-rollback-index

Function: Reset the rollback data of the device

Example: fastboot oem at-reset-rollback-index


1. fastboot oem at-disable-unlock-vboot

Function: Disables the fastboot oem at-unlock-vboot command.


Example: fastboot oem at-disable-unlock-vboot

6.4.8 Firmware Downloading

The following is the windows firmware downloading tool




A/B System downloading




6.4.9 Pre-loader Verified


Please refer to 《Rockchip-Secure-Boot-Application-Note.md》




6.4.10 U-boot Verified


OTP Device Verification Process:






Efuse Device Verification Process:





6.4.11 System Verification Boot



he system boots to the kernel, which first parses the cmdline parameters passed by U-Boot to verify whether the system boots with dm-verify, then loads and enables the system fs_mgr service. fs_mgr verifies that the firmware is loaded based on the fsmgr_flags parameter. The firmware hash & hash tree is stored in vbmeta.img with the following parameters

avb: loads and verifies partition in avb mode

slotselect: The slotselect is for A/B, and will be loaded with the parameter “androidboot.slot_suffix=_a” in the cmdline.

6.4.12 Linux AVB

The following describes the AVB operation and verification process based on linux environment.

6.4.12.1 Operating Workflow

1. Generate complete firmware
2. Generate PrivateKey.pem and PublicKey.pem using SecureBootConsole with rk_sign_tool with the following commands

```
rk_sign_tool cc --chip 3399
rk_sign_tool kk --out .
```

3. load key

```
rk_sign_tool lk --key_privateKey.pem --pubkey_publicKey.pem
```

4. Signature loader

```
rk_sign_tool sl --loader loader.bin
```

5. Signature uboot.img & trust.img

```
rk_sign_tool si --img uboot.img
rk_sign_tool si --img trust.img
```

6. avb signature firmware preparations: Prepare empty temp.bin, 16-byte product_id.bin, boot.img to be signed, and run the following code

```
#!/bin/bash
touch temp.bin
openssl genpkey -algorithm RSA -pkeyopt rsa_keygen_bits:4096 -outform PEM -out
testkey_prk.pem
openssl genpkey -algorithm RSA -pkeyopt rsa_keygen_bits:4096 -outform PEM -out
testkey_psk.pem
openssl genpkey -algorithm RSA -pkeyopt rsa_keygen_bits:4096 -outform PEM -out
testkey_pik.pem
python avbtool make_atx_certificate --output=pik_certificate.bin --
subject=temp.bin --subject_key=testkey_pik.pem --
subject_is_intermediate_authority --subject_key_version 42 --
authority_key=testkey_prk.pem
python avbtool make_atx_certificate --output=psk_certificate.bin --
subject=product_id.bin --subject_key=testkey_psk.pem --subject_key_version 42 --
authority_key=testkey_pik.pem
python avbtool make_atx_metadata --output=metadata.bin --
intermediate_key_certificate=pik_certificate.bin --
product_key_certificate=psk_certificate.bin
python avbtool make_atx_permanent_attributes --output=permanent_attributes.bin --
product_id=product_id.bin --root_authority_key=testkey_prk.pem
python avbtool add_hash_footer --image boot.img --partition_size 33554432 --
partition_name boot --key testkey_psk.pem --algorithm SHA256_RSA4096
python avbtool make_vbmeta_image --public_key_metadata metadata.bin --
include_descriptors_from_image boot.img --algorithm SHA256_RSA4096 --key
testkey_psk.pem --output vbmeta.img
openssl dgst -sha256 -out permanent_attributes_cer.bin -sign PrivateKey.pem
permanent_attributes.bin
```

generate vbmeta.img, permanent_attributes_cer.bin, permanent_attributes.bin。

This step signs boot.img.....

7.Firmware downloading

```
rkdeveloptool db loader.bin  
rkdeveloptool ul loader.bin  
rkdeveloptool gpt parameter.txt  
rkdeveloptool wlx uboot uboot.img  
rkdeveloptool wlx trust trust.img  
rkdeveloptool wlx boot boot.img  
rkdeveloptool wlx system system.img
```

For rkdeveloptool, please refer to <https://github.com/rockchip-linux/rkdeveloptool>>

1. Download permanent_attributes_cer.bin, permanent_attributes.bin


OTP platform available:

```
fastboot stage permanent_attributes.bin  
fastboot oem fuse at-perm-attr
```

efuse platform available:

```
fastboot stage permanent_attributes.bin  
fastboot oem fuse at-perm-attr  
fastboot stage permanent_attributes_cer.bin  
fastboot oem fuse at-rsa-perm-attr
```

1. efuse downloading (efuse tool is only available in windows version at the moment), select a specific loader, select the corresponding device, and click start download.



1. OTP platform loader public key download

Please refer to Rockchip-Secure-Boot-Application-Note.md

6.4.12.2 Verification Process

[TODO]

6.5 SD Boot and Upgrade

6.5.1 Brief Introduction

Rockchip now categorizes SD cards into regular SD cards, SD upgrade cards, SD boot cards, and SD repair cards. You can download the update.img to the SD card through the Rockchip by creating upgrade-disk tool to create different card types

SD Card Category	Function
Regular SD card	Common storage devices
SD Upgrade Card	The device boots from the SD card to recovery, which is responsible for updating the firmware in the sd to the device memory.
SD Boot Card	Device boots directly from SD card
SD Repair Card	Copy the firmware from the SD card to the device memory, starting with the pre-loader.

6.5.2 SD Card Category

6.5.2.1 Regular SD Card

A regular SD card is used exactly the same as a PC, and can be used as normal storage space in U-Boot and Kernel systems without any tools to do anything with the SD card.

6.5.2.2 SD Upgrade Card

SD upgrade card is made by RK's tool to realize firmware upgrade from SD card to local storage (e.g. eMMC, nand flash). SD card upgrade is a firmware upgrade method which can be detached from PC or network. Specifically, the SD card boot code is written to the reserved area of the SD card, and then the firmware is copied to the visible partition of the SD card, when the master control boots from the SD card, the SD card boot code and upgrade code will download the firmware to the local master storage. At the same time, the SD upgrade card supports PCBA testing and copying of demo files. These functions of the SD upgrade card can make the firmware upgrade independent of the PC and improve the production efficiency. If you only need to update the firmware and demo files on the SD card, you can follow the steps below to complete the process:

1. Copy the firmware to the root directory of the SD card and rename it sdupdate.img
2. Copy the demo file to the demo directory in the root directory of the SD card.

SD bootable upgrade card format (not GPT)

Offset	Data segment
disk sector 0	MBR
disk sector 64-4M	IDBLOCK(Start flag set to 0)
4M-8M	Parameter
12M-16M	uboot
16M-20M	trust
.....	misc
.....	resource
.....	kernel
.....	recovery
Room left	Fat32 stores update.img

SD bootable upgrade card format (GPT).

Offset	Data segment
disk sector 0	MBR
disk sector 1-34	GPT partition
disk sector 64-4M	IDBLOCK(Start flag set to 0)
4M-8M	Parameter
.....	uboot
.....	trust
.....	misc
.....	resource
.....	kernel
.....	recovery
Room left	Fat32 stores update.img

6.5.2.3 SD Boot Card

The SD boot card is made by RK's tool to realize booting directly from the SD card, which greatly facilitates the user to update and boot new firmware without having to re- download the firmware into the device storage. The specific realization is to downlaod the firmware into the SD card and use the SD card as the main storage. When the master control starts from the SD card, the firmware and temporary files are stored on the SD card, and it can work normally with or without the local master storage. Currently, it is mainly used for device system booting from SD card, or for PCBA testing. Note: PCBA test is only a function under recovery, it can be used for SD upgrad card and SD boot card.

SD boot card format (not GPT)

Offset	Data segment
disk sector 0	MBR
disk sector 64-4M	IDBLOCK(Start flag set to 0)
4M-8M	Parameter
8M-12M	uboot
12M-16M	trust
.....	misc
.....	resource
.....	boot
.....	kernel
.....	recovery
.....	system
.....	user

SD Boot Card Format (GPT)

Offset	Data segment
disk sector 0	MBR
disk sector 1-34	GPT partition
disk sector 64-4M	IDBLOCK(Start flag set to 1)
.....	uboot
.....	Boot
.....	trust
.....	resource
.....	kernel
.....	recovery
.....	system
.....	vendor
.....	oem
.....	user
the last 33 disk sector	Backup GPT

6.5.2.4 SD Repair Card

The SD Repair Card is similar to the function of SD upgrade card, but the firmware upgrade is done by the miniloader. First the tool writes the boot code to the reserved area of the SD card, then it copies the firmware to the visible partitions of the SD card, and when the master is booted from the SD card, the SD card upgrade code upgrades the firmware to the local master storage. It is mainly used when the firmware of the device is damaged and the SD card can repair the device.

SD repair card format (not GPT).

Offset	Data segment
disk sector 0	MBR
disk sector 64-4M	IDBLOCK(Start flag set to 2)
4M-8M	Parameter
8M-12M	uboot
12M-16M	trust
.....	misc
.....	resource
.....	boot
.....	kernel
.....	recovery
.....	system
.....	user

SD Repaid Card Format(GPT).

Offset	Data segment
disk sector 0	MBR
disk sector 1-34	GPT Partition
disk sector 64-4M	IDBLOCK(Start flag set to 2)
.....	uboot
.....	Boot
.....	trust
.....	resource
.....	kernel
.....	recovery
.....	system
.....	vendor
.....	oem
.....	user
Last 33 sectors	Backup GPT

6.5.3 Firmware Logo


SD cards are used as a variety of different functions and will make some markings inside the sd card.

At sector 64 of the SD card, if the start flag (magic number) is 0xFCDC8C3B, then it is a special card that will read the firmware from the SD card and boot the device. If not, it will be treated as a normal SD card. At sector (64 + 616bytes), the various card logos are stored. There are currently three types:


Card logo	Card Category
0	SD upgrade card or PCBA test card
1	SD Boot Card
2	SD Repair Card

6.5.4 Boot Process

The boot process of SD card can be divided into pre-loader boot process and uboot boot process. Both processes need to load and detect the SD card and the Startup Flag in the IDB Block of the SD card, and will perform different functions according to these flags. The process is as follows:





6.5.4.1 Pre-loader Boot



maskrom first finds a copy of the available miniloader firmware (you can determine the boot storage media supported by Maskrom from the TRM and prioritize them, maskrom scans the available storage for firmware), then jumps to the miniloader. miniloader re-finds the storage device, and if it detects an SD card, it detects if the SD card contains IDB format firmware. If SD card is detected, check if SD card contains IDB format firmware. If yes, then determine the card flag. If the SD card is available and the flag bit is '0' or '1', then read the U-Boot firmware from the SD card and load and boot the U-Boot, if the flag is '2', then enter the process of repairing the card and update the firmware under the loader. The normal boot process is to scan for other storage and load and boot the next level loader.

6.5.4.2 U-Boot Boot





SD upgrade card: U-Boot re-search the storage device, if SD card is detected, check if SD card contains IDB format firmware. If yes, then determine if the card bias flag is 0, and add 'sdfwupdate' to the cmdline passed to the kernel. Finally, read the misc partition of the SD card, read the boot mode of the card, if it is recovery mode, load and start recovery.

SD boot card: U-Boot re-search the storage device, if it detects SD card, it will check whether SD card contains IDB format firmware, if yes, then determine whether the card flag is 1. Finally, read the misc partition of the SD card and read the boot mode of the card, if it is recovery, load the boot recovery, if it is normal mode, load the boot kernel.

6.5.4.3 Recovery and PCBA

For details, please refer to Rockchip Recovery User Operation Guide V1.03.pdf

6.5.5 Notes

- U-Boot needs to configure CONFIG_RKPARM_PARTITION when making non-GPT format firmware.
- When making SD upgrade card, update.img must contain MiniloaderAll.bin, parameter.txt, uboot.img, trust.img, misc.img, resource.img, recovery.img, or else the update.img will fail to write MBR.

7. Chapter-7 Configuration Trimming

TODO

8. Chapter-8 Debugging Tools

This section focuses on some of the common debugging tools used in the U-Boot stage, including the use of commands, scripts, configuration options, boot printing, and so on.

8.1 DEBUG

Function: Enables global `debug()` printing.

This can be enabled by adding a macro definition to `rkxxx_common.h` for each platform:

```
#define DEBUG
```

8.2 Initcall

Function: Prints the boot process.

U-Boot's boot is essentially a series of initcall calls, changing `debug()` to `printf()` within the `initcall_run_list()` function. Example:

```
U-Boot 2017.09-01725-g03b8d3b-dirty (Jul 06 2018 - 10:08:27 +0800)

initcall: 0000000000214388
initcall: 0000000000214724
Model: Rockchip RK3399 Evaluation Board
initcall: 0000000000214300
DRAM:  initcall: 0000000000203f68
initcall: 0000000000214410 // Combine with disassembly to find the function
corresponding to the address
initcall: 00000000002140dc
....
3.8 GiB
initcall: 00000000002143b8
....
Relocation Offset is: f5c03000
initcall: 00000000f5e176bc
initcall: 00000000002146a4 (relocated to 00000000f5e176a4)
initcall: 0000000000214668 (relocated to 00000000f5e17668)
...
```

8.3 IO Command

Function: Reads and writes memory.

```
// read
md - memory display
Usage: md [.b, .w, .l, .q] address [# of objects]

// write
mw - memory write (fill)
Usage: mw [.b, .w, .l, .q] address value [count].
```

Read operation. Example: Displays 0x10 consecutive data starting at address 0x76000000.

```
=> md.l 0x76000000 0x10
76000000: ffffffff ffffffff ffffffff ffffffff .....
76000010: ffffffff ffffffff ffffffff ffffffff .....
76000020: ffffffff ffffffff ffffffff ffffffff .....
76000030: ffffffff ffffffff ffffffff ffffffff .....
```

Write operation. Example: Assign 0x1234 to address 0x76000000;

```
=> mw.l 0x76000000 0xffff1234 // Higher 16 bits have mask
=> md.l 0x76000000 0x10 // readback
76000000: ffff1234 ffffffff ffffffff ffffffff .....
76000010: ffffffff ffffffff ffffffff ffffffff .....
76000020: ffffffff ffffffff ffffffff ffffffff .....
76000030: ffffffff ffffffff ffffffff ffffffff .....
```

8.4 IOMEM Command

Function: Read memory. More flexible than the md command, obtains base address information by automatically parsing DTS nodes.

```
=> iomem
iomem - Show iomem data by device compatible

Usage:
// @<compatible>: Keyword matching for the compatible part of the node
iomem <compatible> <start offset> <end offset>
eg: iomem -grf 0x0 0x200
```

Example: RK3228 reads the data from 0x00 to 0x20 in GRF:

```
// The keyword "-grf" is used here to distinguish it from "rockchip_rk3288-
pmugrf".
=> iomem -grf 0x0 0x20
rockchip_rk3228-grf:
11000000: 00000000 00000000 00004000 00002000
11000010: 00000000 00005028 0000a5a5 0000aaaa
11000020: 00009955
```

8.5 I2C Command

Function: read/write i2c device.

```
=> i2c
i2c - I2C sub-system

Usage:
i2c dev [dev] - show or set current I2C bus
i2c md chip address[.0, .1, .2] [# of objects] - read from I2C device
i2c mw chip address[.0, .1, .2] value [count] - write to I2C device (fill)
.....
```

Read operation. Example:

```
=> i2c dev 0 // Switch to i2c0 (just specify once)
Setting bus to 0

=> i2c md 0x1b 0x2e 0x20 // The i2c device address is 1b (7-bit address)
and reads 0x20 consecutive register values starting at 0x2e
002e: 11 0f 00 00 11 0f 00 00 01 00 00 00 09 00 00 0c .....
003e: 00 0a 0a 0c 0c 0c 00 07 07 0a 00 0c 0c 00 00 00 .....
```

Write operation. Example:

```
=> i2c dev 0 // Switch to i2c0 (just specify once)
Setting bus to 0

=> i2c mw 0x1b 0x2e 0x10 // The i2c device address is 1b (7-bit address),
and the 0x2e register is assigned the value 0x10
=> i2c md 0x1b 0x2e 0x20 // readback
002e: 10 0f 00 00 11 0f 00 00 01 00 00 00 09 00 00 0c .....
003e: 00 0a 0a 0c 0c 0c 00 07 07 0a 00 0c 0c 00 00 00 .....
```

8.6 GPIO Command

Function: read/write pin input/output

```
=> gpio
gpio - query and control gpio pins

Usage:
gpio <input|set|clear|toggle> <pin>
    - input/set/clear/toggle the specified pin
gpio status [-a] [<bank> | <pin>] - show [all/claimed] GPIOs
```

Check pin status: e.g. RV1126

```
=> gpio status -a
Bank A:
A0: input: 0 [_.]
```

```

A1: output: 1 [_].
A2: input: 1 [_].
...
A29: unused: 1 [_].
A30: unknown
A31: unused: 0 [_].
...
D6: input: 0 [_].
D7: output: 1 [x] vcc18-lcd-n.gpio
...
D31: input: 0 [_].

Bank E:
E0: input: 0 [_].
E1: input: 0 [_].

```

pin input:

```
=> gpio input A7
```

pin output INACTIVE:

```
=> gpio clear A7
```

pin output ACTIVE:

```
=> gpio set A7
```

Pin state switching: e.g. A7: input: 0 to A7: output: 1

```
=> gpio toggle A7
```

8.7 FDT Command

Function: Prints the contents of the DTB.

```

=> fdt
fdt - flattened device tree utility commands

Usage:
fdt addr [-c] <addr> [<length>] - Set the [control] fdt location to <addr>
fdt print <path> [<prop>] - Recursive print starting at <path>
fdt list <path> [<prop>] - Print one level starting at <path>
.....
NOTE: Dereference aliases by omitting the leading '/', e.g. fdt print ethernet0.

```

The following two commands together can dump the device-tree completely:

```

=> fdt addr $fdt_addr_r // Specify fdt address
=> fdt print // Print out the entire contents of the fdt

```

8.8 MMC Command

Function: MMC device read/write, switching.

MMC Device View:

```
=> mmc info
Device: dwmmc@ff0f0000           // device node
Manufacturer ID: 15
OEM: 100
Name: 8GME4
Timing Interface: High Speed     // Speed Mode
Tran Speed: 52000000             // current speed
Rd Block Len: 512
MMC version 5.1
High Capacity: Yes
Capacity: 7.3 GiB                // storage capacity
Bus Width: 8-bit                 // Bus width
Erase Group Size: 512 KiB
HC WP Group Size: 8 MiB
User Capacity: 7.3 GiB WRREL
Boot Capacity: 4 MiB ENH
RPMB Capacity: 512 KiB ENH
```

MMC device switching:

```
=> mmc dev 0                     // Switch to eMMC
=> mmc dev 1                     // Switch to sd card
```

MMC device reads and writes:

```
mmc read addr blk# cnt
mmc write addr blk# cnt
mmc erase blk# cnt
Example:
=> mmc read 0x70000000 0 1       // Read the first block of the MMC device, data
size - 1 sector, into memory 0x70000000
=> mmc write 0x70000000 0 1      // Write 1 sector of data from memory 0x70000000 to
the first block of memory
=> mmc erase 0 1                 // Erase 1 sector of data from the first block of
memory.
```

If the MMC device reads or writes abnormally, you can quickly locate it by following these simple steps:

Change debug() to printf() in drivers/mmc/dw_mmc.c and recompile and download. View the print information of the MMC device:

- If the last print is Sending CMD0, please check the hardware power supply, pin connection; check whether the software IOMUX is cut away by other IP;
- If the last print is Sending CMD8, in the Security Software section, configure the MMC device to allow access to secure storage;
- If all the initialization commands have passed and the last printout is Sending CMD18, please check the MMC hardware power supply, or check whether the capacitance of the power supply close to the MMC

side is sufficient (can replace to a larger capacitor), check the software (can reduce the clock frequency), or try to switch the speed mode of the MMC device.

8.9 TimeStamp

Function: Adds a timestamp (relative time) to the U-Boot print message.

```
CONFIG_BOOTSTAGE_PRINTF_TIMESTAMP
```

Example:

```
[ 0.259266] U-Boot 2017.09-01739-g856f373-dirty (Jul 10 2018 - 20:26:05 +0800)
[ 0.260596] Model: Rockchip RK3399 Evaluation Board
[ 0.261332] DRAM: 3.8 GiB
Relocation Offset is: f5bfd000
Using default environment

[ 0.354038] dwmmc@fe320000: 1, sdhci@fe330000: 0
[ 0.521125] Card did not respond to voltage select!
[ 0.521188] mmc_init: -95, time 9
[ 0.671451] switch to partitions #0, OK
[ 0.671500] mmc0(part 0) is current device
[ 0.675507] boot mode: None
[ 0.683738] DTB: rk-kernel.dtb
[ 0.706940] Using kernel dtb
.....
```

The timestamp only prints out the time of the current system timer, not do the timing from 0. So the timestamp prints only the relative time, not the absolute time.

8.10 DM Tree

Function: View the binding and probe status between all device-drivers.

```
=> dm tree
```

Class	Probed	Driver	Name
root	[+]	root_driver	root_driver
syscon	[]	rk322x_syscon	-- syscon@11000000
serial	[+]	ns16550_serial	-- serial@11030000 *
clk	[+]	clk_rk322x	-- clock-controller@110e0000
sysreset	[]	rockchip_sysreset	-- sysreset
reset	[]	rockchip_reset	-- reset
mmc	[+]	rockchip_rk3288_dw_mshc	-- dwmmc@30020000 *
blk	[+]	mmc_blk	-- dwmmc@30020000.blk *
ram	[]	rockchip_rk322x_dmc	-- dmc@11200000
serial	[+]	ns16550_serial	-- serial@11020000
i2c	[+]	i2c_rockchip	-- i2c@11050000
.....			

Print Meaning:

- List all the device-drivers that have completed the bind.
- List the affiliations between all uclass-device-driver
- [+] means the current driver has completed probe
- * Indicates that the current device-driver comes from the U-Boot DTB, otherwise it comes from the kernel DTB.

8.11 DM Uclass

Function: View all devices under a certain class uclass.

```
=> dm uclass

uclass 0: root
- * root_driver @ 7be54c88, seq 0, (req -1)

uclass 11: adc
- * saradc@ff100000 @ 7be56220, seq 0, (req -1)
.....
uclass 40: backlight
- * backlight @ 7be81178, seq 0, (req -1)

uclass 77: key
- rockchip-key @ 7be811f0
.....
```

8.12 Stacktrace.sh

Analyze the site of abort, dump_stack() using the call stack back mechanism. Please refer to the RK Architecture section.

8.13 System Crash

Function: Print the current CPU scene and call stack, suitable for use when the system is stuck. The serial port will dump similar information as abort every 5s.

```
CONFIG_ROCKCHIP_DEBUGGER
```

Get the call stack information and then use the stacktrace script to convert it. Please refer to the RK Architecture section.

8.14 CRC Check

Function: Checks the integrity of the firmware in RK format.

The image header of the RK format contains the CRC32 of the entire image, which can be used to verify the integrity of the firmware by opening the following macro

CONFIG_ROCKCHIP_CRC

Example:

```
=Booting Rockchip format image=
kernel image CRC32 verify... okay.      // kernel verifies success (or prints
"fail!" if it fails).
boot image CRC32 verify... okay.      // boot verifies success (prints "fail!"
if it fails).
kernel @ 0x02080000 (0x01249808)
ramdisk @ 0x0a200000 (0x001e6650)
## Chapter-8 Flattened Device Tree blob at 01f00000
   Booting using the fdt blob at 0x1f00000
   'reserved-memory' secure-memory@20000000: addr=20000000 size=10000000
   Loading Ramdisk to 08019000, end 081ff650 ... OK
   Loading Device Tree to 0000000008003000, end 0000000008018c97 ... OK
Adding bank: start=0x00200000, size=0x08200000
Adding bank: start=0x0a200000, size=0xede00000

Starting kernel ...
```

8.15 HASH Check

Function: Check the integrity of the firmware in Android format.

ANDROID_BOOT_IMAGE_HASH

When this configuration is enabled, the integrity of the firmware is verified when loading firmware in Android format.

For some historical reasons, if the above configuration does not verify the firmware correctly, please try turning on the following configuration at the same time:

HASH_ROCKCHIP_LEGACY

8.16 Modify DDR Capacity

The DDR initialization code during boot passes the DDR capacity to U-Boot, which will remove some safe memory before passing it to the kernel. The user can modify the DDR capacity to be passed to the kernel during the U-Boot stage.

Example of Passing:


```

.....
// The block of available memory passed to the kernel (with the safe memory block
removed).
Adding bank: 0x00200000 - 0x08400000 (size: 0x08200000).
Adding bank: 0x0a200000 - 0x40000000 (size: 0x35e00000).
Total: 895.411 ms

Starting kernel ...
[ 0.000000] Booting Linux on physical CPU 0x0

```

Code Location:

```
./arch/arm/mach-rockchip/param.c
```

Modify the location:

```

struct memblock *param_parse_ddr_mem(int *out_count)
{
    .....

    // Here is the capacity information that ddr passes to U-Boot.
    // Because of the possibility of discontinuous addresses, they are passed in
    blocks, specifying the starting address and size of each memory block separately.
    // PS: It's usually contiguous memory and won't need to be chunked.
    for (i = 0, n = 0; i < count; i++, n++){
        // For example, for a 2GB capacity (contiguous addresses): count = 1,
        base = 0, size = 0x80000000.
        // when debugging, users can modify here as needed.
        base = t->u.ldr_mem.bank[i];
        size = t->u.ldr_mem.bank[i + count];

        /* 0~4GB */
        if (base < SZ_4GB){
            mem[n].base = base;
            mem[n].size = ddr_mem_get_usable_size(base, size);
            if (base + size > SZ_4GB){
                n++;
                mem[n].base_u64 = SZ_4GB;
                mem[n].size_u64 = base + size - SZ_4GB;
            }
        } else {
            /* 4GB+ */
            mem[n].base_u64 = base;
            mem[n].size_u64 = size;
        }

        assert(n < count + MEM_RESV_COUNT);
    }
    .....
}

```

8.17 Jump Information

Function: Confirm the firmware version and process. In some cases, the boot information can also help users to locate some crash problems

1. Trust getting stuck after running

Possibility of trust getting stuck after running: There is a problem with the firmware packaging or downloading, causing the trust to jump to the wrong U-Boot boot address. In this case, you can check the U-Boot boot address printed on the trust.

64-bit platform U-Boot boot address is typically offset 0x200000 (DRAM starts at 0x0)

```
NOTICE: BL31: v1.3(debug):d98d16e
NOTICE: BL31: Built : 15:03:07, May 10 2018
NOTICE: BL31: Rockchip release version: v1.1
INFO: GICv3 with legacy support detected. ARM GICV3 driver initialized in EL3
INFO: Using opteed sec cpu_context!
INFO: boot cpu mask: 0
INFO: plat_rockchip_pmu_init(1151): pd status 3e
INFO: BL31: Initializing runtime services
INFO: BL31: Initializing BL32
INFO: BL31: Preparing for EL3 exit to normal world
INFO: Entry point address = 0x200000 // U-Boot address
INFO: SPSR = 0x3c9
```

The 32-bit platform U-Boot boot address is typically offset 0x0 (DRAM starts at 0x60000000):

```
INF [0x0] TEE-CORE:init_primary_helper:378: Release version: 1.9
INF [0x0] TEE-CORE:init_primary_helper:379: Next entry point address: 0x60000000
// U-Boot address
INF [0x0] TEE-CORE:init_tecore:83: teecore inits done
```

2. U-Boot version backtracking:

The U-Boot boot information can be used to trace back the build version. The following commit point corresponds to commit: b34f08b.

```
U-Boot 2017.09-01730-gb34f08b (Jul 06 2018 - 17:47:52 +0800)
```

The fact that “dirty” appears in the boot message means that there are local changes that were not committed to the repository during compilation, and the compilation point is not clean.

```
U-Boot 2017.09-01730-gb34f08b-dirty (Jul 06 2018 - 17:35:04 +0800)
```

8.18 Boot Information

Users can know the current U-Boot process and the status of each peripheral through the U-Boot boot information, which is convenient to quickly locate the abnormality.

Currently U-Boot supports three types of firmware boot: Android format > RK format > DISTRO format. the SDK released by RK is mainly for the first two firmware formats, and DISTRO is generally used by open source users.

Note: If the user's code is not new enough, some prints may not be visible, this does not affect the user's overall understanding of the U-Boot boot message.

17.1 Android firmware

```
// The first line of U-Boot prints, containing information such as commit
version, compiling time, etc.
// Note: This is only "relatively early" first regular line printout from U-
Boot, not the earliest printout that U-Boot can make.
// Open the debug message, you can see earlier debug prints
U-Boot 2017.09-03033-g81b79f7-dirty (Jul 04 2019 - 15:04:00 +0800)

// The content of the "model" field of the U-Boot dts, which tells us which U-
Boot dts we are using.
Model: Rockchip RK3399 Evaluation Board
// The preloader-serial function is enabled, i.e., it follows the serial port
configuration of the previous loader, and the print port currently used is UART2.
PreSerial: 2
// The total memory capacity of the board is 2GB
DRAM: 2 GiB
// The current version supports the system memory card management mechanism
System: init
// U-Boot will self-move its own code from the current ddr forward position to a
backward position (see the U-Boot development documentation for details on the
boot process).
// The starting address of the self-moved code is 0x7dbe2000, which may be useful
for disassembly and debugging.
Relocation Offset is: 7dbe2000
// ENV is saved in ddr by default. If you choose to save it in eMMC, Nand, etc.,
it will not be printed.
Using default environment

// The current storage medium is mmc0, i.e. eMMC (or mmc1 if it is a sd card)
dwmmc@fe320000: 1, sdhci@fe330000: 0
// The storage media type is informed to U-Boot via atags, passed as a parameters
by the previous miniloader
Bootdev(atags): mmc 0
// Current eMMC operates in HS400 mode with a clock frequency of 150M
MMC0: HS400, 150Mhz
// Currently using GPT partition table (if RK parameter partition table used,
print: RKPARM)
PartType: EFI
// It's currently in recovery mode
// The "reboot xxx" command executed in the kernel is ultimately represented by
this printout
boot mode: recovery
// The Kernel DTB comes from recovery.img, which is loaded normally
Load FDT from recovery_part
DTB: rk-kernel.dtb
HASH: OK(c)

// ==> Note: Since then, U-Boot has swithed to the kernel dtb and all subsequent
peripheral drivers use information from the kernel dtb!
```

```
// DTBO executed successfully
ANDROID: fdt overlay OK
// I2C speed, this is one of the influencing factors of U-Boot boot speed,
especially for PMICs with very many DCDCs and LDOs, if the I2C speed is slow,
// Then it will hinder the booting speed to some extent. If users care about boot
speed, they can pay attention to this information
I2c speed: 400000Hz
// Current PMIC is RK818
// The on value corresponds to the ON_SOURCE register and indicates the reason
for this current PMIC power-up
// The off value corresponds to the OFF_SOURCE register and indicates the reason
for the previous shutdown or power loss
// on and off information, which is valuable in the event of an abnormal reboot
or shutdown of the system
PMIC: RK818 (on=0x20 off=0x40)
// The current voltage value of each regulator, is generally DCDC and
corresponding to the RK platform arm, logic, center and other voltages.
// vdd_center 900000 uV- This is valuable information in the event of problems
such as abnormal system startups, erratic booting, etc.
vdd_cpu_l 900000 uV
vdd_log 900000 uV
// The content of the "model" field of the Kernel dts, which tells us which
Kernel dts we are using.
Model: Rockchip RK3399 Excavator Board edp avb (Android)
enter Recovery mode!
// Display driver related information
Rockchip UBOOT DRM driver version: v1.0.1
Using display timing_dts
Detailed mode clock 200000 kHz, flags[a]
  H: 1536 1548 1564 1612
  V: 2048 2056 2060 2068
bus_format: 100e
// clk-tree information, please refer to the CLK section of the U-Boot
development documentation for details.
CLK: (uboot. arml: enter 816000 KHz, init 816000 KHz, kernel ON/A)
CLK: (uboot. armb: enter 24000 KHz, init 24000 KHz, kernel ON/A)
_aplll 816000 KHz
_apllb 24000 KHz
_dpll 800000 KHz
_cppll 200000 KHz
_gppll 800000 KHz
_nppll 600000 KHz
_vppll 24000 KHz
_aclk_perihp 133333 KHz
_hclk_perihp 66666 KHz
_pclk_perihp 33333 KHz
_aclk_perilp0 266666 KHz
_hclk_perilp0 88888 KHz
_pclk_perilp0 44444 KHz
_hclk_perilp1 100000 KHz
_pclk_perilp1 50000 KHz
// GMAC driver enable
Net: eth0: ethernet@fe300000
// Boot and long_press ctrl+c to enter U-Boot command line mode after the
following printout
Hit key to stop autoboot('CTRL+C'): 0
// Once again, we know that we are currently in recovery mode.
```

```

ANDROID: reboot reason: "recovery"
// vboot=0 means secureboot is not enabled; it's currently AVB firmware, so it
will go through AVB's regular checking flow
Vboot=0, AVB images, AVB verify
// kWhether the device is unlocked
read_is_device_unlocked() ops returned that device is UNLOCKED
// Native U-Boot by default loads the entire boot.img/recovery.img, and then
ramdisk, fdt, kernel
// A single move (called relocation) to an address predetermined by the user,
which is time-consuming, especially if the ramdisk is very large.
// The RK platform was modified to move ramdisk, fdt, and kernel directly from
storage to the intended memory address all at once.
// A printout such as the following indicates that this one-time move is enabled,
saving you time
Fdt Ramdisk skip relocation

// Load the firmware in Android format, load kernel to 0x00280000, fdt to
0x8300000
// If it is an LZ4 compressed kernel, it may print here:
// Booting LZ4 kernel at 0x00680000(Uncompress to 0x00280000) with fdt at
0x8300000...
Booting IMAGE kernel at 0x00280000 with fdt at 0x8300000...

// Ignore, no need to concern.
### Booting Android Image at 0x0027f800 ...
// \kernel and ramdisk load address and size
Kernel load addr 0x00280000 size 19081 KiB
RAM disk load addr 0x0a200000 size 9627 KiB
// fdt load address
### Flattened Device Tree blob at 08300000
   Booting using the fdt blob at 0x8300000
// Ignore, no need to concern
   XIP Kernel Image ... OK
// This simply prints the reserved-memory specified by the kernel dts, which can
be used as a piece of information to analyze if the kernel has problems booting.
   'reserved-memory' secure-memory@20000000: addr=20000000 size=10000000
// Start and end address of fdt
   Using Device Tree in place at 0000000008300000, end 000000000831c6f7
// Passed to the kernel to inform the kernel of the range of memory space
available to the kernel (ATF, optee, etc. space has been removed)
Adding bank: 0x00200000 - 0x08400000 (size: 0x08200000)
Adding bank: 0x0a200000 - 0x80000000 (size: 0x75e00000)
// U-Boot phase boot time consuming
Total: 367.128 ms

// Printed by U-Boot, after this print, U-Boot will complete some ARM
architecture related (e.g., clearing cache, turning off interrupts,
// cpu state switching, etc.) and U-Boot's dm device logout and other clearing
work, the probability of problems is extremely low.
// Once the above work's done, it jump to the kernel, so it can also be
understood as that this printout means you've reached the kernel stage.
Starting kernel ...

// Printed information from the kernel phase
[ 0.000000] Booting Linux on physical CPU 0x0
[ 0.000000] Initializing cgroup subsys cpuset
[ 0.000000] Initializing cgroup subsys cpu
[ 0.000000] Initializing cgroup subsys cpuacct

```

```
[ 0.000000] Initializing cgroup subsys schedtune
[ 0.000000] Linux version 4.4.167 (hgc@ubuntu) (gcc version 6.3.1 20170404
(Linaro
GCC 6.3-2017.05)) #83 SMP PREEMPT Thu Mar 21 09:31:08 CST 2019
[ 0.000000] Boot CPU: AArch64 Processor [410fd034].
[ 0.000000] earlycon: Early serial console at MMIO32 0xff1a0000 (options '')
[ 0.000000] bootconsole [uart0] enabled
[ 0.000000] Reserved memory: failed to reserve memory for node 'stb-
devinfo@00000000': base 0x0000000000000000, size 0 MiB
[ 0.000000] cma: Reserved 16 MiB at 0x000000007f000000
.....
```

8.18.1 RK Firmware

```
U-Boot 2017.09-03352-gb1265b5 (Jul 12 2019 - 09:57:24 +0800)

Model: Rockchip RK3399 Evaluation Board
PreSerial: 2
DRAM: 2 GiB
System: init
Relocation Offset is: 7dbe2000
Using default environment
.....

Hit key to stop autoboot('CTRL+C'): 0
ANDROID: reboot reason: "recovery"
// Since it's RK format firmware, it can't be AVB format
Not AVB images, AVB skip
// Because it is RK format firmware, so here will prompt that load android format
firmware fails
// Because the current startup priority is: android format > RK format > distro
format
** Invalid Android Image header **
Android image load failed
Android boot failed, error -1.
// Currently in recovery mode
boot mode: recovery
// Boot RK-formatted firmware, load ramdis, kernel, fdt
=Booting Rockchip format image=
fdt @ 0x08300000 (0x00012dd0)
kernel @ 0x00280000 (0x0119e008)
ramdisk @ 0x0a200000 (0x00754540)

// The following is basically similar to the boot information for android-
formatted firmware
Fdt Ramdisk skip relocation
### Flattened Device Tree blob at 08300000
 Booting using the fdt blob at 0x8300000
 Using Device Tree in place at 0000000008300000, end 0000000008315dcf
Adding bank: 0x00200000 - 0x08400000 (size: 0x08200000)
Adding bank: 0x0a200000 - 0x80000000 (size: 0x75e00000)
Total: 508.11 ms

Starting kernel ...
```

```
[____ 0.000000] Booting Linux on physical CPU 0x0
[____ 0.000000] Initializing cgroup subsys cpuset
[____ 0.000000] Initializing cgroup subsys cpu
.....
```

8.18.2 Distro Firmware

```
U-Boot 2017.09-03352-gbl265b5 (Jul 12 2019 - 09:57:24 +0800)

Model: Rockchip RK3399 Evaluation Board
PreSerial: 2
DRAM: 2 GiB
System: init
Relocation Offset is: 7dbe2000
Using default environment

.....

// find mmc0, i.e. eMMCswitch to partitions #0, OK
mmc0(part 0) is current device
// Find the firmware for the 6th partition on the eMMC storage (in the GPT
partition table, 6 corresponds to the boot.img partition, which is indicated by
the "-bootable" attribute in the GPT)
Scanning mmc 0:6...
// Found the configuration file extlinux.conf
Found /extlinux/extlinux.conf
Retrieving file: /extlinux/extlinux.conf

// Loading kernel
205 bytes read in 82 ms (2 KiB/s)
1: rockchip-kernel-4.4
Retrieving file: /Image
13484040 bytes read in 1833 ms (7 MiB/s)

// Specified cmdline information when packaging
append: earlycon=uart8250,mmio32,0xff1a0000 console=ttyS2,1500000n8 rw
root=/dev/mmcblk0p7 rootwait rootfstype=ext4 init=/sbin/init

// Loading fdtLoad fdt
Retrieving file: /rk3399.dtb
61714 bytes read in 54 ms (1.1 MiB/s)

// ==> If there is no ramdisk at the time of packing, no ramdisk information will
be printed; otherwise it will be printed here as well.

### Flattened Device Tree blob at 01f00000
   Booting using the fdt blob at 0x1f00000
   Loading Device Tree to 000000007df14000, end 000000007df26111 ... OK

Starting kernel ...

[____ 0.000000] Booting Linux on physical CPU 0x0
[____ 0.000000] Initializing cgroup subsys cpuset
[____ 0.000000] Initializing cgroup subsys cpu
.....
```

8.18.3 No Valid Firmware

```
U-Boot 2017.09-03352-gb1265b5 (Jul 12 2019 - 09:57:24 +0800)

Model: Rockchip RK3399 Evaluation Board
PreSerial: 2
DRAM: 2 GiB
System: init
Relocation Offset is: 7dbe2000
Using default environment

.....

// Find mmc0, the eMMC
Find mmc0, the eMMC
Can't find boot message for firmware
switch to partitions Can't find boot message for firmware#0, OK
mmc0(part 0) is current device
// Find the firmware for the 6th partition on the eMMC storage (in the GPT
partition table, 6 corresponds to the boot.img partition, which is indicated by
the "-bootable" attribute in the GPT)
Scanning mmc 0:6...
// Found the configuration file extlinux.conf
Found /extlinux/extlinux.conf
Retrieving file: /extlinux/extlinux.conf

// Loading kernel Load kernel
205 bytes read in 82 ms (2 KiB/s)
1: rockchip-kernel-4.4
Retrieving file: /Image
13484040 bytes read in 1833 ms (7 MiB/s)

// Specified cmdline information when packaging
append: earlycon=uart8250,mmio32,0xff1a0000 console=ttyS2,1500000n8 rw
root=/dev/mmcblk0p7 rootwait rootfstype=ext4 init=/sbin/init

// Loading fdt Load fdt
Retrieving file: /rk3399.dtb
61714 bytes read in 54 ms (1.1 MiB/s)

// ==> If there is no ramdisk at the time of packing, no ramdisk information will
be printed; otherwise it will be printed here as well.

### Flattened Device Tree blob at 01f00000
Bootimg using the fdt blob at 0x1f00000
Loading Device Tree to 000000007df14000, end 000000007df26111 ... OK

Starting kernel ...

[ 0.000000] Booting Linux on physical CPU 0x0
[ 0.000000] Initializing cgroup subsys cpuset
[ 0.000000] Initializing cgroup subsys cpu
.....
U-Boot 2017.09-03352-gb1265b5 (Jul 12 2019 - 09:57:24 +0800)

Model: Rockchip RK3399 Evaluation Board
PreSerial: 2
```



```
DRAM: 2 GiB
System: init
Relocation Offset is: 7dbe2000
Using default environment

.....

Net: eth0: ethernet@fe300000
Hit key to stop autoboot('CTRL+C'): 0 ANDROID: reboot reason: "recovery"
// Not Android format firmware
Not AVB images, AVB skip
** Invalid Android Image header **
Android image load failed
Android boot failed, error -1.
boot mode: recovery

// Not RK format firmware
=Booting Rockchip format image=
kernel: invalid image tag(0x45435352)
boot_rockchip_image kernel part read error

// Not DISTRO format firmware. All of the latter prints come in the distro load
command because the distro command will try to get from mmc, nand, net,
// usb and all our predefined devices (see the macro definition in rockchip-
common.h: BOOT_TARGET_DEVICES).
// Looking for distro firmware, i.e. scanning one by one to search
switch to partitions #0, OK
mmc0(part 0) is current device
Failed to mount ext2 filesystem...
** Unrecognized filesystem type **
starting USB...
USB0: Register 2000140 NbrPorts 2
Starting the controller
USB XHCI 1.10
USB1: Register 2000140 NbrPorts 2
Starting the controller
USB XHCI 1.10
USB2: USB EHCI 1.00
USB3: USB OHCI 1.0
USB4: USB EHCI 1.00
USB5: USB OHCI 1.0
scanning bus 0 for devices... 1 USB Device(s) found
scanning bus 1 for devices... 1 USB Device(s) found
scanning bus 2 for devices... 1 USB Device(s) found
scanning bus 3 for devices... 1 USB Device(s) found
scanning bus 4 for devices... 1 USB Device(s) found
scanning bus 5 for devices... 1 USB Device(s) found
scanning usb for storage devices... 0 Storage Device(s) found

Device 0: unknown device
ethernet@fe300000 Waiting for PHY auto negotiation to complete..... TIMEOUT !
Could not initialize PHY ethernet@fe300000
missing environment variable: pxeuuid
missing environment variable: bootfile
Retrieving file: pxelinux.cfg/01-7a-1d-33-50-3d-a1
ethernet@fe300000 Waiting for PHY auto negotiation to complete..
.....
```

```
// Eventually the distro command scanned all possible storage media and couldn't  
find the firmware, so it stopped in U-Boot command line mode  
=>
```

9. Chapter-9 Test Case

10. Chapter-10 SPL

10.1 Firmware Boot

SPL replaces the miniloader in loading and booting trust.img and uboot.img. SPL currently supports booting two types of firmwares

- FIT firmware: enabled by default
- RKFW firmware: disabled by default, needs to be configured and enabled separately by the user;

10.1.1 FIT Firmware

FIT (flattened image tree) format is a relatively new firmware format supported by SPL, which supports multiple images to be packaged and verified, FIT uses DTS syntax to describe the packaged image, the description file is u-boot.its, and the final FIT firmware generated is u-boot.itb.

Advantages of FIT: reuse dts syntax and compilation rules, more flexible, firmware parsing can directly use libfdt library

u-boot.its file:

- /images : Statically defines all accessible resource configurations (last available, optional), similar to the role of dtb;
- /configurations : Each config node describes a set of bootable configurations, similar to a board-level dtb
- Use default = Specifies the currently selected default configuration;

Templates:

```
/dts-v1/;  
  
/ {  
  description = "Configuration to load ATF before U-Boot";  
  #address-cells = <1>;  
  
  images {  
    uboot@1 {  
      description = "U-Boot (64-bit);  
      data = /incbin/("u-boot-nodtb.bin");  
      type = "standalone";  
      os = "U-Boot";  
      arch = "arm64";  
      compression = "none";  
      load = <0x00200000>;  
    };  
  
    atf@1 {  
      description = "ARM Trusted Firmware";  
      data = /incbin/("bl31_0x00010000.bin");  
      type = "firmware";  
      arch = "arm64";
```

```

        os = "arm-trusted-firmware";
        compression = "none";
        load = <0x00010000>;
        entry = <0x00010000>;
    };

    atf@2 {
        description = "ARM Trusted Firmware";
        data = /incbin/("bl31_0xff091000.bin");
        type = "firmware";
        arch = "arm64";
        os = "arm-trusted-firmware";
        compression = "none";
        load = <0xff091000>;
    };

    optee@1 {
        description = "OP-TEE";
        data = /incbin/("bl32.bin");
        type = "firmware";
        arch = "arm64";
        os = "op-tee";
        compression = "none";
        load = <0x08400000>;
    };

    fdt@1 {
        description = "rk3328-evb.dtb";
        data = /incbin/("arch/arm/dts/rk3328-evb.dtb");
        type = "flat_dt";
        compression = "none";
    };
};

configurations {
    default = "config@1";
    config@1 {
        description = "rk3328-evb.dtb";
        firmware = "atf@1";
        loadables = "uboot@1", "atf@2", "optee@1";
        fdt = "fdt@1";
    };
};
};

```

u-boot.itb file:

```

mkimage + dtc
[u-boot.its] + [images] ==> [u-boot.itb].

```

The above is the process of generating the itb file. the FIT firmware can be understood as a special kind of DTB file, except that its content is image. the user can view the itb file with the ftdump command:

```

cjh@ubuntu:~/uboot-nextdev/u-boot$ ftdump u-boot.itb | less

/dts-v1/;

```

```

// magic:                0xd00dfeed
// totalsize:            0x497 (1175)
// off_dt_struct:        0x38
// off_dt_strings:        0x414
// off_mem_rsvmap:        0x28
// version:              17
// last_comp_version:     16
// boot_cpuid_phys:       0x0
// size_dt_strings:       0x83
// size_dt_struct:        0x3dc

/ {
    timestamp = <0x5d099c85>;
    description = "Configuration to load ATF before U-Boot";
    #address-cells = <0x00000001>;
    images {
        uboot@1 {
            data-size = <0x0009f8a8>;
            data-offset = <0x00000000>;
            description = "U-Boot (64-bit)";
            type = "standalone";
            os = "U-Boot";
            arch = "arm64";
            compression = "none";
            load = <0x00600000>;
        };
        atf@1 {
            data-size = <0x0000c048>; // This field is automatically added by
the compilation process to describe the atf@1 firmware size
            data-offset = <0x0009f8a8>; // This field is automatically added by
the compilation process to describe the atf@1 firmware offset
            description = "ARM Trusted Firmware";
            type = "firmware";
            arch = "arm64";
            os = "arm-trusted-firmware";
            compression = "none";
            load = <0x00010000>;
            entry = <0x00010000>;
        };
        atf@2 {
            data-size = <0x00002000>;
            data-offset = <0x000ab8f0>;
            description = "ARM Trusted Firmware";
            type = "firmware";
            arch = "arm64";
            os = "arm-trusted-firmware";
            compression = "none";
            load = <0xff82000>;
        };
        fdt@1 {
            data-size = <0x00005793>;
            data-offset = <0x000ad8f0>;
            description = "rk3308-evb.dtb";
            type = "flat_dt";
            .....
        };
        .....
    };
};

```

```
};
```

For more information on FIT, please refer to:

```
./doc/uImage.FIT/
```

10.1.2 RKFW Firmware

In order to replace the miniloader more directly without modifying the partitioning and packaging format of the later firmware, RK platform adds the RKFW format (i.e., independently partitioned firmware: trust.img and uboot.img) to the boot.

Configuration:

```
CONFIG_SPL_LOAD_RKFW           // Enable switch
CONFIG_RKFW_TRUST_SECTOR       // trust.img partition address, shall be
                                consistent with the definition of the partition table
CONFIG_RKFW_U_BOOT_SECTOR      // uboot.img partition address, shall be
                                consistent with the definition of the partition table
```

Code:

```
./include/spl_rkfw.h
./common/spl/spl_rkfw.c
```

10.1.3 Storage Priority

The boot priority of the storage device is specified in U-Boot dts via `u-boot, spl-boot-order`.

```
/ {
    __aliases__ {
        mmc0 = &emmc;
        mmc1 = &sdmmc;
    };

    __chosen__ {
        u-boot, spl-boot-order = &sdmmc, &nandc, &emmc;
        stdout-path = &uart2;
    };
    .....
};
```

10.2 Compilation and Packaging

10.2.1 Code Compilation

U-Boot compiles the same U-Boot code according to **different compilation paths** to obtain SPL firmware, and automatically generates the `CONFIG_SPL_BUILD` macro when compiling the SPL. U-Boot will continue to compile the SPL after compiling `u-boot.bin`, and create a separate output directory `./spl/`.

```
// compile u-boot
.....
DTC      arch/arm/dts/rk3399-puma-ddr1866.dtb
DTC      arch/arm/dts/rv1108-evb.dtb
make[2]: `arch/arm/dts/rk3328-evb.dtb' is up to date.
SHIPPED  dts/dt.dtb
FDTGREP  dts/dt-spl.dtb
CAT       u-boot-dtb.bin
MKIMAGE  u-boot.img
COPY     u-boot.dtb
MKIMAGE  u-boot-dtb.img
COPY     u-boot.bin

// Compile spl, with separate spl/ directory
LD       spl/arch/arm/cpu/built-in.o
CC       spl/board/rockchip/evb_rk3328/evb-rk3328.o
LD       spl/dts/built-in.o
CC       spl/common/init/board_init.o
COPY     tpl/u-boot-tpl.dtb
CC       spl/cmd/nvedit.o
CC       spl/env/common.o
CC       spl/env/env.o
.....
LD       spl/drivers/block/built-in.o
.....
```

At the end of the compilation you will get

```
./spl/u-boot-spl.bin
```

10.2.2 Firmware Packaging

10.3 System Module

10.3.1 GPT

SPL uses the GPT partition table.

Configurations:

```
CONFIG_SPL_LIBDISK_SUPPORT=y
CONFIG_SPL_EFI_PARTITION=y
CONFIG_PARTITION_TYPE_GUID=y
```


Drivers:

```
./disk/part.c  
./disk/part_efi.c
```

Interfaces:

```
int part_get_info(struct blk_desc *dev_desc, int part, disk_partition_t *info);  
int part_get_info_by_name(struct blk_desc *dev_desc,  
                           const char *name, disk_partition_t *info);
```

10.3.2 A/B System

SPL supports A/B system boot,

Configuration:

```
CONFIG_SPL_AB=y
```

Driver:

```
./common/spl/spl_ab.c
```

Interface:

```
int spl_get_current_slot(struct blk_desc *dev_desc, char *partition, char *slot);  
int spl_get_partitions_sector(struct blk_desc *dev_desc, char *partition, u32  
*sectors);
```

10.3.3 Boot Priority

- SPL uses the boot order defined by `u-boot, spl-boot-order`, located at `rkxxx-u-boot.dtsi`:

```
chosen {  
    stdout-path = &uart2;  
    u-boot, spl-boot-order = &sdmmc, &sfc, &nandc, &emmc;  
};
```

- Maskrom's boot priority:

```
_spi nor > spi nand > emmc > sd
```

- Pre-loader(SPL) boot priority:

```
sd > spi nor > spi nand > emmc
```

Maximizing the priority of the sd card makes it easier for the system to boot from the sd card.

10.3.4 ATAGS

SPL and U-Boot implement the passing of parameters through the ATAGS mechanism. The information passed is: the storage device started, the print serial port, and so on.

Configuration:

```
CONFIG_ROCKCHIP_PRELOADER_ATAGS=y
```

Driver:

```
./arch/arm/include/asm/arch-rockchip/rk_atags.h  
./arch/arm/mach-rockchip/rk_atags.c
```

Interface:

```
int atags_set_tag(u32 magic, void *tagdata);  
struct tag *atags_get_tag(u32 magic);
```

10.3.5 Kernel Boot

Usually kernel is loaded and booted by U-Boot, SPL can also support to load kernel, currently support to load android head version 2 boot.img, support RK format firmware.

Boot sequence

```
Maskrom -> ddr -> SPL -> Trust -> Kernel
```

10.3.6 Pinctrl

Configuration:

```
CONFIG_SPL_PINCTRL_GENERIC=y  
CONFIG_SPL_PINCTRL=y
```

Driver:

```
./drivers/pinctrl/pinctrl-uclass.c  
./drivers/pinctrl/pinctrl-generic.c  
./drivers/pinctrl/pinctrl-rockchip.c
```

DTS configuration:

Take sdmmc for example

```
&pinctrl {  
    u-boot, dm-spl;  
};  
  
&pcfg_pull_none_4ma {
```

```

____ u-boot, dm-spl;
};

&pcfg_pull_up_4ma {
____ u-boot, dm-spl;
};

&sdmmc {
____ u-boot, dm-spl;
};

&sdmmc_pin {
____ u-boot, dm-spl;
};

&sdmmc_clk {
____ u-boot, dm-spl;
};

&sdmmc_cmd {
____ u-boot, dm-spl;
};

&sdmmc_bus4 {
____ u-boot, dm-spl;
};

&sdmmc_pwren {
____ u-boot, dm-spl;
};
};

```

Notes:

To enable pinctrl for SPL, modify the `CONFIG_OF_SPL_REMOVE_PROPS` definition in `defconfig` to remove the `pinctrl-0 pinctrl-names` field.

10.3.7 Secure Boot

[TODO]

10.4 Driver Module

10.4.1 MMC

Configuration:

```
CONFIG_SPL_MMC_SUPPORT=y // Enabled by default
```

Driver:

```
./common/spl/spl_mmc.c
```

Interface:

```
int spl_mmc_load_image(struct spl_image_info *spl_image,
                      struct spl_boot_device *bootdev);
```

10.4.2 MTD Block

SPL unifies the nand, spi nand, and spi nor interfaces to the block layer.

Configuration:

```
// MTD driver support
CONFIG_MTD=y
CONFIG_CMD_MTD_BLK=y
CONFIG_SPL_MTD_SUPPORT=y
CONFIG_MTD_BLK=y
CONFIG_MTD_DEVICE=y

// spi nand driver support
CONFIG_MTD_SPI_NAND=y
CONFIG_ROCKCHIP_SFC=y
CONFIG_SPL_SPI_FLASH_SUPPORT=y
CONFIG_SPL_SPI_SUPPORT=y

// nand driver support
CONFIG_NAND=y
CONFIG_CMD_NAND=y
CONFIG_NAND_ROCKCHIP=y /* NandC v6 can be confirmed based on TRM NANDC-
>NANDC_NANDC_VER register, 0x00000801 */
//CONFIG_NAND_ROCKCHIP_V9=y /* NandC v9 can be confirmed based on TRM NANDC-
>NANDC_NANDC_VER register, 0x56393030, Take RK3326/PX30 as an example */
CONFIG_SPL_NAND_SUPPORT=y
CONFIG_SYS_NAND_U_BOOT_LOCATIONS=y
CONFIG_SYS_NAND_U_BOOT_OFFS=0x8000
CONFIG_SYS_NAND_U_BOOT_OFFS_REDUND=0x10000
// The nand page size needs to be defined according to the real size, if you use
NAND with a capacity greater than or equal to 512MB, you generally need to
configure it as 4096.
#define CONFIG_SYS_NAND_PAGE_SIZE 2048

// spi nor driver support
CONFIG_CMD_SF=y
CONFIG_CMD_SPI=y
CONFIG_SPI_FLASH=y
CONFIG_SF_DEFAULT_MODE=0x1
CONFIG_SF_DEFAULT_SPEED=50000000
CONFIG_SPI_FLASH_GIGADEVICE=y
CONFIG_SPI_FLASH_MACRONIX=y
CONFIG_SPI_FLASH_WINBOND=y
CONFIG_SPI_FLASH_MTD=y
CONFIG_ROCKCHIP_SFC=y
CONFIG_SPL_SPI_SUPPORT=y
CONFIG_SPL_MTD_SUPPORT=y
CONFIG_SPL_SPI_FLASH_SUPPORT=y
```

Driver:

```
./common/spl/spl_mtd_blk.c
```

Interface:

```
int spl_mtd_load_image(struct spl_image_info *spl_image,  
                      struct spl_boot_device *bootdev);
```

10.4.3 OTP

Used to store non-modifiable data, used in secure boot.

Configuration:

```
CONFIG_SPL_MISC=y.  
CONFIG_SPL_ROCKCHIP_SECURE_OTP=y.
```

Driver:

```
./drivers/misc/misc-uclass.c  
./drivers/misc/rockchip-secure-otp.S
```

Interface:

```
int misc_read(struct udevice *dev, int offset, void *buf, int size);  
int misc_write(struct udevice *dev, int offset, void *buf, int size);
```

10.4.4 Crypto

Secure-boot will use crypto to complete the hash, ras calculation.

Configuration:

```
CONFIG_SPL_DM_CRYPT=y.  
  
// The defconfig of each platform has enabled the corresponding configuration by  
default.  
CONFIG_SPL_ROCKCHIP_CRYPT_V1=y.  
or  
CONFIG_SPL_ROCKCHIP_CRYPT_V2=y.
```

Driver:

```
./drivers/crypto/crypto-uclass.c  
./drivers/crypto/rockchip/crypto_v1.c  
./drivers/crypto/rockchip/crypto_v2.c  
./drivers/crypto/rockchip/crypto_v2_pka.c  
./drivers/crypto/rockchip/crypto_v2_util.c
```

Interfaces:

```
u32 crypto_algo_nbits(u32 algo);  
struct udevice *crypto_get_device(u32 capability);  
int crypto_sha_init(struct udevice *dev, sha_context *ctx);  
int crypto_sha_update(struct udevice *dev, u32 *input, u32 len);  
int crypto_sha_final(struct udevice *dev, sha_context *ctx, u8 *output);  
int crypto_sha_csum(struct udevice *dev, sha_context *ctx,  
                    char *input, u32 input_len, u8 *output);  
int crypto_rsa_verify(struct udevice *dev, rsa_key *ctx, u8 *sign, u8 *output);
```

10.4.5 Uart

The SPL serial port is specified via the chosen node of `rkxxxx-u-boot.dtsi`. Take the rk3308 as an example:

```
chosen {  
    stdout-path = &uart2;  
};  
  
&uart2 {  
    u-boot,dm-pre-reloc;  
    clock-frequency = <24000000>;  
    status = "okay";  
};
```

11. Chapter-11 TPL

TPL is a loader at an earlier stage than U-Boot, TPL runs in SRAM and its role is to replace the ddr bin which is responsible for completing the initialization of DRAM. TPL is the open source version of the code and ddr bin is the closed source version of the code.

11.1 Compiling and Packaging

11.1.1 Configuration

- UART configuration

CONFIG_DEBUG_UART_BASE: UART base address

CONFIG_ROCKCHIP_UART_MUX_SEL_M: UART IOMUX GROUP.

Example:

RV1126 configures UART2 M2 for printing DEBUG LOG.

Method 1) By modifying the rv1126_defconfig file

```
CONFIG_DEBUG_UART_BASE=0xff570000  
CONFIG_ROCKCHIP_UART_MUX_SEL_M=2
```

Method 2) By making menuconfig

```
Device Drivers ---> Serial drivers ---> (0xff570000) Base address of UART  
ARM architecture ---> (2) UART mux select
```

- DRAM TYPE configuration

Configure the DRAM TYPE supported by the TPL via CONFIG_ROCKCHIP_TPL_INIT_DRAM_TYPE.

DDR TYPE	Configuration value
DDR2	2
DDR3	3
DDR4	0
LPDDR2	5
LPDDR3	6
LPDDR4	7

Example:

Configure RV1126 TPL DRAM TYPE to support DDR3.

Method 1) By modifying the rv1126_defconfig file

```
CONFIG_ROCKCHIP_TPL_INIT_DRAM_TYPE=3
```

Method 2) By making menuconfig; It is important to note that if make.sh is followed with chip model number when compiling, there will be a make xxxdefconfig action when you make, which will overwrite the changes in menuconfig. To prevent the changes in menuconfig from being overwritten, make.sh can be compiled without parameters.

```
Device Drivers ---> (3) TPL select DRAM type
```

Example:

make rv1126_defconfig or ./make.sh rv1126 -> make menuconfig to modify the relevant configuration -> ./make.sh.

- Quick boot configuration

If you need to compile and generate a tpl.bin that supports quick boot, you can do so by opening CONFIG_SPL_KERNEL_BOOT.

Currently only the RV1126/RV1109 platforms are supported.

- Wide-temperature support

If you need to compile and generate a tpl.bin that supports wide temperature, you can do so by opening CONFIG_ROCKCHIP_DRAM_EXTENDED_TEMP_SUPPORT.

Currently only the RV1126/RV1109 platforms are supported.

- Other parameter modifications

The ddr initialization source code is located in the drivers/ram/rockchip directory, other ddr related parameters such as frequency, drive strength, ODT strength, etc. need to be modified in the source code. For RV1126/RV1109, the ddr related parameters are centralized in “sdram_inc/rv1126/sdram-rv1126-loader_params.inc” in this directory, and the corresponding parameters can be modified directly in this file. Other platform parameters need to be modified in the corresponding sdram_xxx.c.

11.1.2 Compiling

U-Boot compiles the same U-Boot code according to different compilation paths to obtain the TPL firmware, and automatically generates the CONFIG_TPL_BUILD macro when compiling the TPL. U-Boot will continue to compile the TPL after compiling the u-boot.bin, and creates a separate output directory ./tpl/.

```
// Compile u-boot
.....
DTC      arch/arm/dts/rv1108-evb.dtb
DTC      arch/arm/dts/rk3399-puma-ddr1866.dtb
DTC      arch/arm/dts/rv1126-evb.dtb
FDTGREP  dts/dt.dtb
FDTGREP  dts/dt-spl.dtb
FDTGREP  dts/dt-tpl.dtb
CAT      u-boot-dtb.bin
MKIMAGE  u-boot.img
COPY     u-boot.dtb
MKIMAGE  u-boot-dtb.img
```



```

COPY    u-boot.bin
ALIGN   u-boot.bin

// Compile tpl, with a separate tpl/directory.
.....
CC      tpl/common/init/board_init.o
CC      tpl/disk/part.o
LD      tpl/common/init/built-in.o
.....
LD      tpl/u-boot-tpl
.....
OBJCOPY tpl/u-boot-tpl-nodtb.bin
COPY    tpl/u-boot-tpl.bin

```

At the end of the compilation you'll get:

```
./tpl/u-boot-tpl.bin
```

Example:

Compile RV1126 uboot.

```
./make.sh rv1126
```

11.1.3 Packaging

1. The u-boot-tpl.bin generated from compiling needs to replace the first 4 bytes with the tag of the corresponding platform to be a legal ddr bin, such as tag “110B” for RV1126/RV1109 platform. If you only need the ddr bin, you need to manually complete the tag replacement action, the action can refer to scripts/spl.sh script.

Example: Replace the tage of RV1126 u-boot-tpl.bin

```
dd bs=4 skip=1 if=tpl/u-boot-tpl.bin of=tpl/u-boot-tpl-tag.bin && sed -i
'1s/^/110B&/' tpl/u-boot-tpl-tag.bin
```

2. If you need to generate a complete Loader file that can be downloaded into the board, you can use the following commands to automatically replace the u-boot-tpl.bin tag and package it with spl.bin to form a complete Loader file.

```
./make.sh tpl
```

12. Chapter-12 FIT

12.1 Preface

This section describes the FIT format and details of secure/non-secure boot schemes based on the FIT format. For the sake of presentation, this section is mainly focused on boot.img, but the same applies to recovery.img.

12.2 Brief Introduction

12.2.1 Basic Introduction

FIT (flattened image tree) is a new firmware type of boot scheme supported by U-Boot, which supports any number of image packages and checksums. FIT uses its (image source file) to describe the image information, and then generates itb (flattened image tree blob) image by mkimage tool. The its file uses DTS syntax rules, which is very flexible and can be used directly with the libfdt library and related tools.

FIT is the default and preferred firmware format supported by U-Boot, and both SPL and U-Boot phases support booting to FIT-formatted firmware. For more information, please refer to:

```
./doc/uImage.FIT/
```

Because the official FIT function can not meet the actual product demand, so the RK platform has adapted and optimized the FIT. Therefore, the mkimage tool compiled by RK U-Boot must be used in the FIT program but not the mkimage that comes with the PC.

12.2.2 Example Introduction

The following is an introduction to u-boot.its and u-boot.itb as examples.

- /images : Statically defines all resources, equivalent to a dtsi file;
- /configurations : Each config node describes a set of bootable configurations, equivalent to a board-level dts file.
- default = : Specifies the config that is enabled by default;

```
/dts-v1/;

/_{
    description = "Simple image with OP-TEE support";
    #address-cells = <1>;

    images {
        uboot {
            description = "U-Boot";
            data = /incbin/("./u-boot-nodtb.bin");
            type = "standalone";
            os = "U-Boot";
```

```

        arch = "arm";
        compression = "none";
        load = <0x00400000>;
        hash {
            algo = "sha256";
        };
    };
    optee {
        description = "OP-TEE";
        data = /incbin/("./tee.bin");
        type = "firmware";
        arch = "arm";
        os = "op-tee";
        compression = "none";
        load = <0x8400000>;
        entry = <0x8400000>;
        hash {
            algo = "sha256";
        };
    };
    fdt {
        description = "U-Boot dtb";
        data = /incbin/("./u-boot.dtb");
        type = "flat_dt";
        compression = "none";
        hash {
            algo = "sha256";
        };
    };
};

// configurations Any number of different conf nodes can be defined under the
node, but in the actual product scenario we only need one conf.
configurations {
    default = "conf";
    conf {
        description = "Rockchip armv7 with OP-TEE";
        rollback-index = <0x0>;
        firmware = "optee";
        loadables = "uboot";
        fdt = "fdt";
        signature {
            algo = "sha256,rsa2048";
            padding = "pss";
            key-name-hint = "dev";
            sign-images = "fdt", "firmware", "loadables";
        };
    };
};
};
};

```

An itb file can be generated using the mkimage tool and the its file:

```

mkimage + dtc
[u-boot.its] + [images] =====> [u-boot.itb].

```

The fdt dump command allows you to view the contents of the itb file:

```
cjh@ubuntu:~/uboot-nextdev/u-boot$ fdt dump_fit/u-boot.itb | less
```

```
/dts-v1/;
// magic: 0xd00dfeed
// totalsize: 0x600 (1536)
// off_dt_struct: 0x48
// off_dt_strings: 0x48c
// off_mem_rsvmap: 0x28
// version: 17
// last_comp_version: 16
// boot_cpuid_phys: 0x0
// size_dt_strings: 0xc3
// size_dt_struct: 0x444

/memreserve/ 7f34d3411000 600;
/{
    version = <0x00000001>; // Add firmware version number
    totalsize = <0x000bb600>; // Add new field to describe the size
of the entire itb file
    timestamp = <0x5ecb3553>; // Add timestamp for current firmware
generation moment
    description = "Simple image with OP-TEE support";
    #address-cells = <0x00000001>;
    images {
        uboot {
            data-size = <0x0007ed54>; // Add new field to describe firmware
size
            data-position = <0x00000a00>; // Add new field to describe firmware
offsets
            description = "U-Boot";
            type = "standalone";
            os = "U-Boot";
            arch = "arm";
            compression = "none";
            load = <0x00400000>;
            hash {
                // Added sha256 checksum for firmware
                value = <0xeda8cd52 0x8f058118 0x00000003 0x35360000 0x6f707465
0x0000009f 0x00000091 0x00000000>;
                algo = "sha256";
            };
        };
    };
    optee {
        data-size = <0x0003a058>;
        data-position = <0x0007f800>;
        description = "OP-TEE";
        type = "firmware";
        arch = "arm";
        os = "op-tee";
        compression = "none";
        load = <0x08400000>;
        entry = <0x08400000>;
        hash {
            value = <0xa569b7fc 0x2450ed39 0x00000003 0x35360000 0x66647400
0x00001686 0x000b9a00 0x552d426f>;
            algo = "sha256";
        };
    };
};
```

```

    }.i;
    fdt {
        data-size = <0x00001686>;
        data-position = <0x000b9a00>;
        description = "U-Boot dtb";
        type = "flat_dt";
        compression = "none";
        hash {
            value = <0x0f718794 0x78ece7b2 0x00000003 0x35360000 0x00000001
0x6e730000 0x636f6e66 0x00000000>;
            algo = "sha256";
        }.i;
    }.i;
}.i;
configurations {
    default = "conf";
    conf {
        description = "Rockchip armv7 with OP-TEE";
        rollback-index = <0x00000001>; // Firmware anti-rollback version
number, defaults to 0 if not specified manually.
        firmware = "optee";
        loadables = "uboot";
        fdt = "fdt";
        signature {
            algo = "sha256,rsa2048";
            padding = "pss";
            key-name-hint = "dev";
            sign-images = "fdt", "firmware", "loadables";
        }.i;
    }.i;
}.i;
}.i;
}.i;
}.i;

```

12.2.3 ITB Structure

The itb is essentially a collection of fdt_blob + images files, with the following two packaging methods, and the RK platform solution adopts Structure 2.

[illegible]

12.3 Platform Configuration

12.3.1 Chip Support

It has been released as an official Feature on the SDK's platform: **Please refer to Home Page section for the support status of each chip feature.**

12.3.2 Code Configuration

Code coding:

```
// Framework Code:
./common/image.c
./common/image-fit.c
./common/spl/spl_fit.c

// Platform Code:
./arch/arm/mack-rockchip/fit.c
./cmd/bootfit.c

// Tool Code:
./tools/mkimage.c
./tools/fit_image.c
```

Configurations:

```
// U-Boot phase supports FIT
CONFIG_ROCKCHIP_FIT_IMAGE=y

// U-Boot phase: secure boot, anti-rollback, hardware crypto
CONFIG_FIT_SIGNATURE=y
CONFIG_FIT_ROLLBACK_PROTECT=y
CONFIG_DM_CRYPT=y
CONFIG_FIT_HW_CRYPT=y

// SPL phase: secure boot, anti-rollback, hardware crypto
CONFIG_SPL_FIT_SIGNATURE=y
CONFIG_SPL_FIT_ROLLBACK_PROTECT=y
CONFIG_SPL_DM_CRYPT=y
CONFIG_SPL_FIT_HW_CRYPT=y

// How many copies of uboot.itb does the uboot.img image contain, and how big is
a single copy of uboot.itb?
CONFIG_SPL_FIT_IMAGE_KB=2048
CONFIG_SPL_FIT_IMAGE_MULTIPLE=2

//The default output of uboot project after compilation is uboot.img in fit
format; otherwise it is the traditional RK formats uboot.img and trust.img.
CONFIG_ROCKCHIP_FIT_IMAGE_PACK=y
```

Since crypto may be different for different platforms, the configuration parameters for the RSA function are also different. Please refer to the general defconfig of the current platform for details.

```
CONFIG_RSA_N_SIZE  
CONFIG_RSA_E_SIZE  
CONFIG_RSA_C_SIZE
```

Generic defconfig: [chip]_defconfig, e.g. rv1126_defconfig, rk3568_defconfig.

If the FIT solution is a feature officially released as an SDK, then most of the base configuration is already enabled, and the options that users need to configure themselves are:

```
// U-Boot Secure Boot and Anti-Rollback Mechanisms  
CONFIG_FIT_SIGNATURE=y  
CONFIG_FIT_ROLLBACK_PROTECT=y  
  
// SPL Secure Boot and Anti-Rollback Mechanism  
CONFIG_SPL_FIT_SIGNATURE=y  
CONFIG_SPL_FIT_ROLLBACK_PROTECT=y
```

- CONFIG_FIT_SIGNATURE not enabled: uboot can support booting three formats of firmware at the same time: android, uimage, and fit (the released SDK will choose which ones to enable based on platform requirements).
- CONFIG_FIT_SIGNATURE enabled: uboot only supports booting fit firmware.

12.3.3 Mirror File

The final output on the FIT scheme is two FIT-formatted firmwares for downloading, uboot.img (without trust.img) and boot.img, and an SPL file for packaging into a loader.

- uboot.img file
uboot.itb = trust + u-boot.bin + mcu.bin(option)
uboot.img = uboot.itb * N (N is normally 2 copies)

The trust and mcu files come from the rkbin project, and the build script automatically indexes and retrieves them from the rkbin project.

- boot.img file
boot.itb = kernel + fdt + resource + ramdisk(optional)
boot.img = boot.itb * M (M is normally 1 copies)
- MCU configuration

Some platforms may come with MCU firmware, which can be enabled or disabled based on the TRUST ini configuration corresponding to different products. Example:

```
// File: RKTRUST/RV1126TOS_TB.ini, for quick boot products, MCU enabled  
[TOS]  
TOSTA=bin/rv11/rv1126_tee_ta_tb_v1.04.bin  
ADDR=0x00040000  
  
// MCU configuration format: firmware path, boot address, status (okay or disabled).  
// If disabled, mcu will not be packed into uboot.img.  
[MCU]  
MCU=bin/rv11/rv1126_mcu_v1.02.bin,0x108000,okay
```

- Firmware Compression

Currently some platforms can support the compression of sub-firmware inside uboot.img, the support is as follows:

Platform	Compression Format	Firmware
RV1126	gzip、none	u-boot.bin, trust, mcu(optional)

Users can enable this by adding attributes to the corresponding TRUST ini in the rkbin project. Example:

```
// RKTRUST/RV1126TOS_SPI_NOR_TINY.ini, for small capacity SPI Nor products.
.[TOS]
TOS=bin/rv11/rv1126_tee_v1.02.bin
ADDR=0x08400000
.[MCU]
MCU=bin/rv11/rv1126_mcu_v1.00.bin,0x208000,disabled

// Compression format: gzip or none, defaults to uncompressed if the
following configuration fields are not present.
.[COMPRESSION]
COMPRESSION=gzip
```

- SPL file

SPL file refers to the `spl/u-boot-spl.bin` generated after the compilation, which is responsible for booting the uboot.img in FIT format. Users need to use it to replace the non-open-source miniloader on the RK platform, and eventually package as loader.

- `./fit` directory

When U-Boot is done with compilation, it generates the `./fit` folder in the directory, which contains a number of intermediate files, as described in subsequent sections.

boot.img and uboot.img are compiled and generated under the sdk project and uboot project respectively. However, boot.img with secure boot support must be repackaged and signed under the U-Boot project, as described in the following sections.

12.3.4 ITS File

- The its file for uboot is `./fit/u-boot.its`, dynamically created by the script specified by `CONFIG SPL FIT GENERATOR` in defconfig, and visible after the firmware is compiled successfully.
- The its file for boot is located under the SDK project:

```
device/rockchip/[platform]/xxx.its // [platform] is the platform directory:
```

12.3.5 Related Tools


```
// Kernel packaging tools, which's automatically generated after compilation,
exist under both U-Boot and rkbin repositories(the one under U-Boot is generated
in real-time compilation).
./tools/mkimage
// 本Firmware Packaging Script
./make.sh
// Firmware re-signing script
scripts/fit-resign.sh
// Firmware Unpacking Script
scripts/fit-unpack.sh
// Firmware Replacement Script
./scripts/fit-repack.sh
```

The use of the scripting tools will be covered in subsequent chapters, here let's focus on the parameters of make.sh first.

Optional (users to decide whether to pass it on on a case-by-case basis)

- `--spl-new`: Passing this parameter means to use the currently compiled spl file to pack the loader; otherwise, use the spl file in the rkbin project.
- `--version-uboot [n]`: Specifies the firmware version number of uboot.img. n must be a decimal positive integer.
- `--version-boot [n]`: Specifies the firmware version number of boot.img. n must be a decimal positive integer;
- `--version-recovery [n]`: Specifies the firmware version number of recovery.img. n must be a decimal positive integer;

Required (when safe boot is enabled):

- `--rollback-index-uboot [n]`: Specifies the uboot.img firmware anti-rollback version number, n must be a positive decimal integer
- `--rollback-index-boot [n]`: Specifies the boot.img firmware anti-rollback version number. n must be a positive decimal integer;
- `--rollback-index-recovery [n]`: Specifies the recovery.img firmware anti-rollback version number. n must be a positive decimal integer;
- `--no-check`: Used when packaging secure firmware to skip the self-check of the secure firmware packaging script.

Notes:

1. Firmware Anti-Rollback Version Number: It is only allowed to be activated for use if Secure Boot is enabled, and the version number is saved in the OTP or other secure storage. Main function: To prevent the firmware version from being rolled back for vulnerability attacks.
2. Firmware version number: optional, defaults to 0 if not specified. Main function: just as a firmware version identifier to facilitate the user's version management of the firmware.

12.4 Non-secure Boot

12.4.1 uboot.img

Compile command:

```
./make.sh rv1126 --spl-new --uboot-version 10 // You may not specify --spl-new and --uboot-version
```

Compilation results:

```
.....  
CC      spl/common/spl/spl.o  
CC      spl/lib/display_options.o  
LD      spl/common/spl/built-in.o  
LD      spl/lib/built-in.o  
LD      spl/u-boot-spl  
OBJCOPY spl/u-boot-spl-nodtb.bin  
CAT      spl/u-boot-spl-dtb.bin  
COPY     spl/u-boot-spl.bin  
CFGCHK  u-boot.cfg  
  
out:rv1126_spl_loader_v1.00.100.bin  
fix opt:rv1126_spl_loader_v1.00.100.bin  
merge success(rv1126_spl_loader_v1.00.100.bin)  
/home4/cjh/uboot-nextdev  
  
// generate rv1126_spl_loader_v1.00.100.bin (Replaced the traditional miniloader of the RK platform with spl  
// loader ini file source  
pack loader(SPL) okay! Input: /home4/cjh/rkbin/RKBOOT/RV1126MINIALL.ini  
// Hints from the --spl-new parameter; users can choose not to add this parameter.  
pack loader with new: spl/u-boot-spl.bin  
  
// Generate uboot.img (with trust and uboot) with version 10  
Image(no-signed, version=10): uboot.img (FIT with uboot, trust...) is ready  
// trust ini file source  
pack uboot.img okay! Input: /home4/cjh/rkbin/RKTRUST/RV1126TOS.ini  
  
Platform RV1126 is build OK, with exist .config
```

Packaging backup: Specify multiple backups of uboot.img via defconfig configuration:

```
CONFIG_SPL_FIT_IMAGE_KB=2048 // the size of one itb  
CONFIG_SPL_FIT_IMAGE_MULTIPLE=2 // Number of copies packaged
```

SPL detects and boots U-Boot and trust according to this configuration, mainly to cope with the problem of unbootable firmware corruption caused by abnormal power loss during OTA upgrade.

12.4.2 boot.img

If the FIT solution is officially released as a feature of the SDK, a boot.img in FIT format will be generated after the SDK is compiled.

If you want to generate boot.img for secure boot, you have to put the boot.img generated by SDK under U-Boot project to repackage and re-sign the boot.img, because the signing tools, configurations, parameters, etc. of the secure firmware package are all originated from U-Boot project.

12.5 Secure Boot

The FIT program supports secure boot, related FEATURES are as follows:

- sha256 + rsa2048 + pkcs-v2.1(pss)_padding
- Firmware Anti-Rollback
- Firmware re-signing (remote signing)
- Crypto hardware acceleration

12.5.1 Principle

12.5.1.1 Checking Process

- Maskrom checks loader (including SPL, ddr, usbplug)
- SPL checks uboot.img (including trust, U-Boot...)
- U-Boot checks boot.img (including kernel, fdt, ramdisk...)

Currently only the sha256+rsa2048+pkcs-v2.1(pss)_padding security checksum mode is supported by default.

12.5.1.2 Key Storage

The RSA key is packaged by mkimage in u-boot.dtb and u-boot-spl.dtb, which are then packaged into u-boot.bin and u-boot-spl.bin.

The format of the RSA key in u-boot.dtb is as follows (ditto for u-boot-spl.dtb):

```
cjh@ubuntu:~/uboot-nextdev$ fdt dump u-boot.dtb | less
/dts-v1/;
....

/_{
    #address-cells = <0x00000001>;
    #size-cells = <0x00000001>;
    compatible = "rockchip,rv1126-evb", "rockchip,rv1126";
    model = "Rockchip RV1126 Evaluation Board";

    // Signature nodes are automatically inserted and generated by the mkimage
    tool. The nodes hold information such as RSA-SHA algorithm type, RSA core factor
    parameters, and so on.
    signature {
        key-dev {
            required = "conf";
            algo = "sha256,rsa2048";
```

```

        rsa,np = <0x00000000 0x00000000 0x00000000 0x00000000 0x00000000
0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000
0x00000000 0x00000000 0x00000000 0x1327f633 0x00000003 0x00000003 0x00000003
0xc7aead6a 0xb4c79f40 0xa82bdf76 0xfb2f8387 0xa1e06dce 0xd451a706 0xc7f865e3
0x3e2d7ca8 0x6a71762e 0x125f1828 0x36ab1a41 0xb7e9e852 0x7bd0011a 0x7279e0b8
0xf37e189c 0x8cf00963 0x00000100 0x00000000 0x00000000 0x00000000 0x00000000
0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000
0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000377 0x00000004
0x00000004 0x00000004 0x00000002 0x00000003 0x69616c40 0x00000003 0x6d634066
0x00000010 0x66633630 0x73797363>;

        rsa,c = <0x00000000>;

        rsa,r-squared = <0x00000000>;

        rsa,modulus = <0xc25ae693 0xc359f2a4 0xa866c89d 0xb7b1994f 0xf9f9f690
0x518d54a7 0xda0b83e8 0x06606e12 0x6ad1cbf9 0x92438edd 0x81e039c0 0x5d7322cc
0x124cdc80 0xa0c3288a 0x9265c3ae 0x6ac47a4b 0x00000003 0x00000000 0x00000000
0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000
0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000
0x00000008 0x00000003 0x00000003 0x00000003 0x00000002 0x73657300 0x2f736572
0x00000000 0x2f64776d 0x00000003 0x6d634066 0x00000001 0x30303000 0x726f636b
0x67726600 0x00000008 0x00000003 0x00000004 0x00000001 0x30303000 0x726f636b
0x706d7567 0x00000003 0x00001000 0x00000003 0x00000002 0x6e616765 0x30000000
0x726f636b 0x706d7500 0x00000008>;

        rsa,exponent-BN = <0x00000000 0x00000000 0x00000000 0x00000000
0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000
0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000003 0x00010001
0xe95771c5 0x00000800 0x64657600 0x616c6961 0x0000002c 0x30303030 0x00000034
0x30303000 0x2f64776d 0x00000002 0x65303030 0x0000001b 0x3132362d 0x00000003
0x00020000 0x00000003 0x00000002 0x65303230 0x0000001b 0x3132362d 0x6e000000
0xfe020000 0x00000042 0x0000006d 0x722d6d61 0x65303030 0x0000001b 0x3132362d
0x00000003 0x00001000 0x00000002 0x6e74726f 0x30000000 0x726f636b 0x706d7563
0x0000003e 0x00000004 0x00000004 0x00000004 0x00000000 0x00000050 0x636c6f63
0x40666634 0x00000014 0x2c727631 0x00000008>;

        rsa,exponent = <0x00000000 0x00000368>;

        rsa,n0-inverse = <0xe95771c5>;

        rsa,num-bits = <0x00000800>;

        key-name-hint = "dev";

    };

};

```

SPL supports downloading key hash, the key-dev of u-boot-spl.dtb will have extra `burn-key-hash = <0x00000001>;`.

12.5.1.3 Key Usage

Secure boot from Maskrom to kernel is unified using an RSA public key to complete the security check:

- Maskrom checks loader.

The RSA public key needs to be written into the loader's header using the PC tool `rk_sign_tool`. During secure booting, Maskrom first obtains the RSA public key from the loader firmware header and verifies its legitimacy; it then uses the key to verify the loader's firmware signature.

`rk_sign_tool` is available from the rkbin repository. U-Boot will automatically sign the loader.

- SPL checks U-Boot and trust.

SPL saves the RSA public key in u-boot-spl.dtb, and then u-boot-spl.dtb is packed into u-boot-spl.bin file (and finally packed into loader); SPL takes the RSA public key out of its own dtb file to perform a security check on the uboot.img during secure boot.

- U-Boot checks boot.

U-Boot saves the RSA public key in u-boot.dtb, and then u-boot.dtb will be packed into u-boot.bin file (and finally packed into uboot.img); U-Boot takes the RSA public key from its own dtb file to verify the boot.img during the secure boot.

Therefore, the RSA Key of the current level has already been verified by the previous loader as part of its own firmware, thus guaranteeing the security of the Key.

12.5.1.4 Signature Storage

The RSA signature result is saved in the itb file; and the signed content, specified by `hashed-nodes`, includes the attributes of the entire `conf` node, the nodes of the packaged firmware, and so on.

The following is the signature information for u-boot.itb, ditto for boot.itb:

```
cjh@ubuntu:~/uboot-nextdev$ fdt dump uboot.img | less
/dts-v1/;
.....

    configurations {
        default = "conf";
        conf {
            description = "Rockchip armv7 with OP-TEE";
            // Current firmware version number
            rollback-index = <0x0000001c>;
            firmware = "optee";
            loadables = "uboot";
            fdt = "fdt";

            // Signed content and signature result, automatically inserted by
            mkimage
            signature {
                hashed-strings = <0x00000000 0x000000da>;
                // Specify the content to be signed
                hashed-nodes = "/", "/configurations", "/configurations/conf",
                "/images/fdt", "/images/fdt/hash", "/images/optee", "/images/optee/hash",
                "/images/uboot", "/images/uboot/hash";
                // Time of signing, signer, version
                timestamp = <0x5e9427b4>;
                signer-version = "2017.09-g8bb63db-200413-dirty #cjh";
                signer-name = "mkimage";
                // signature results! ! (using sha256+rsa2048)
                value = <0x78397d5d 0xb9219a0b 0xa7cb91a7 0xe1f32867 0x62719d9b
                0x8901200c 0xfcbac03a 0x1295ccc8 0x1cff9608 0xdf5f69d2 0x21391225 0x7af10ca7
                0x5527864f 0xb13f527e 0xddf9ee62 0xea50199d 0x00000003 0x35362c72 0x00000004
                0x00000017 0x77617265 0x00000002 0x00000009 0x23616464 0x6d616765 0x73006172
                0x6f6e006c 0x72790064 0x61636b2d 0x7265006c 0x006b6579 0x69676e2d 0x706f7369
                0x7a650074 0x75650073 0x69676e65 0x73686564 0x642d7374 0x00000000 0x00000000
                0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000
                0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000
                0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000
                0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000
                0x00000000 0x00000000 0x00000000 0x00000000 0x00000000 0x00000000>;
```

```

_____ algo = "sha256,rsa2048";
_____ key-name-hint = "dev";
_____ sign-images = "fdt", "firmware", "loadables";
_____ }.i
_____ }.i
_____ }.i

```

12.5.1.5 Anti-rollback

- Secure boot supports specifying the current firmware version number for boot.img and uboot.img respectively, if the current firmware version number is less than the minimum version number on the machine, boot will not be allowed.
- Minimum version number update: After completing the security verification and confirming that the system can be booted normally, it is updated to the OTP or secure storage.

12.5.2 Preliminary Preparation

12.5.2.1 Key

Execute the following three commands under U-Boot project to generate the RSA key pair for signing. Normally, you only need to generate the key pair once, and then you will use this key pair to sign and verify the firmware, so please take good care of it.

```

// 1. Directory for keys: keys
mkdir -p keys

// 2. Use "rk_sign_tool" to generate privateKey.pem and publicKey.pem for RSA2048
(please refer to the manual of rk_sign tool), and rename them as: keys/dev.key
and keys/dev.pubkey respectively.

// 3. Generate a self-signed certificate using -x509 and a private key:
keys/dev.crt (essentially equivalent to a public key)
openssl req -batch -new -x509 -key keys/dev.key -out keys/dev.crt

```

If the error is reported there is no .rnd file in the user directory:

Can't load /home4/cjh//.rnd into RNG

140522933268928:error:2406F079:random number generator:RAND_load_file:Cannot open file:./crypto/rand/randfile.c:88:Filename=/home4/cjh//.rnd

Please create it manually first: touch ~/.rnd

ls keys/ view results:

```
dev.crt dev.key dev.pubkey
```

Note: The aforesaid names "keys", "dev.key", "dev.crt", "dev.pubkey" cannot be changed. Because these names are statically defined in the its file, if you change them, the package will fail.

12.5.2.2 Configuration

Enable the following configuration for U-Boot's defconfig:

```
// Required
CONFIG_FIT_SIGNATURE=y
CONFIG_SPL_FIT_SIGNATURE=y

// Optional
CONFIG_FIT_ROLLBACK_PROTECT=y // boot.img anti-rollback
CONFIG_SPL_FIT_ROLLBACK_PROTECT=y // uboot.img anti-rollback
```

It is recommended to check the configuration by make menuconfig and then update the original defconfig file by make savedefconfig. This can avoid imposing a defconfig configuration and resulting in incorrect dependencies, which may lead to compilation failures.

12.5.2.3 Firmware

Make a copy of the boot.img generated under the SDK project to the U-Boot root directory.

12.5.3 Compiling and Packaging

(1) Basic commands (no anti-rollback):

```
./make.sh rv1126 --spl-new --boot_img boot.img --recovery_img recovery.img
```

Compilation results:

```
.....

// After compilation, generate signed uboot.img and boot.img.
start to sign rv1126_spl_loader_v1.00.100.bin
.....
sign loader ok.
.....
Image(signed, version=0): uboot.img (FIT with uboot, trust...) is ready
Image(signed, version=0): recovery.img (FIT with kernel, fdt, resource...) is ready
Image(signed, version=0): boot.img (FIT with kernel, fdt, resource...) is ready
Image(signed): rv1126_spl_loader_v1.05.106.bin (with spl, ddr, usbplug) is ready
pack uboot.img okay! Input: /home4/cjh/rkbin/RKTRUST/RV1126TOS.ini

Platform RV1126 is build OK, with new .config(make rv1126-secure_defconfig).
```

(2) Extended command 1:

If anti-rollback is turned on, the rollback parameter must be appended to the aforesaid in (1). Example:

```
// Specify the minimum version numbers of uboot.img and boot.img as 10 and 12, respectively.
./make.sh rv1126 --spl-new --boot_img boot.img --recovery_img recovery.img --
rollback-index-uboot 10 --rollback-index-boot 12 --rollback-index-recovery 12
```

Compilation results:

```
.....

// After compilation, the signed uboot.img and boot.img are generated and contain
the anti-rollback version number.
start to sign rv1126_spl_loader_v1.00.100.bin
.....
sign loader ok.
.....
Image(signed, version=0, rollback-index=10): uboot.img (FIT with uboot, trust)
is ready
Image(signed, version=0, rollback-index=12): recovery.img (FIT with kernel, fdt,
resource...) is ready
Image(signed, version=0, rollback-index=12): boot.img (FIT with kernel, fdt,
resource...) is ready
Image(signed): rv1126_spl_loader_v1.00.100.bin (with spl, ddr, usbplug) is ready
```

(3) Extended command 2

If you want to download the public key hash to OTP/eFUSE, you must append the parameter `--burn-key-hash` to the (1) or (2) above. Example:

```
// Specify the minimum version numbers of uboot.img and boot.img as 10 and 12, respectively.
// it is require to download the public key hash into OTP/eFUSE at SPL stage
./make.sh rv1126 --spl-new --boot_img boot.img --recovery_img recovery.img --
rollback-index-uboot 10 --rollback-index-boot 12 --rollback-index-recovery 12 --
burn-key-hash
```

Compilation results:

```
.....

// enable burn-key-hash
### spl/u-boot-spl.dtb: burn-key-hash=1

// After compilation, the signed uboot.img and boot.img are generated and contain
the anti-rollback version number.
start to sign rv1126_spl_loader_v1.00.100.bin
.....
sign loader ok.
.....
Image(signed, version=0, rollback-index=10): uboot.img (FIT with uboot, trust)
is ready
Image(signed, version=0, rollback-index=12): recovery.img (FIT with kernel, fdt,
resource...) is ready
Image(signed, version=0, rollback-index=12): boot.img (FIT with kernel, fdt,
resource...) is ready
Image(signed): rv1126_spl_loader_v1.00.100.bin (with spl, ddr, usbplug) is ready
```


When powering up and booting, SPL will print: RSA: Write key hash successfully.

(4) Precautionary notes:

- `--boot_img`: Optional, specifies the boot.img to be signed.
- `--recovery_img`: Optional, specifies the recovery.img to be signed.
- `--rollback-index-uboot`, `--rollback-index-boot`, `--rollback-index-recovery`: Optional, specifies the anti-rollback version number.
- `--spl-new`: If the compiling command doesn't have this parameter, the loader will be packaged with the spl file in rkbin by default; otherwise, the loader will be packaged with the spl file of the current compilation.

Because the u-boot-spl.dtb needs to be packed into the RSA public key (from the user), the SDK released by RK will not submit the spl file in the rkbin repository to support secure boot. Therefore, the user has to specify this parameter when compiling. However, users can also submit their own spl version to the rkbin project, and after that they can compile the firmware without specifying this parameter, and use this stable version of the spl file every time.

- The compilation generates three firmwares: loader, uboot.img, and boot.img, any of which are allowed to be updated individually as long as the RSA key has not been changed.

12.5.4 Checking Principles

(1) Maskrom checks SPL

OTP without downloading key: Maskrom performs a non-secure boot process.

OTP with downloading key: Maskrom checks the key in the Loader, it must be the same as the one in the OTP to start the security check, if not, it won't let it start.

(2) SPL checks U-Boot

`CONFIG_SPL_FIT_SIGNATURE=y`: SPL will surely perform a security check on uboot.img, and only if the check succeeds the boot can be performed; And if uboot.img does not have a signature or the check fails, the boot won't be performed.

`CONFIG_SPL_FIT_SIGNATURE=n`: SPL itself does not contain secure boot related code and must not check uboot.img (no matter it is signed or not).

(3) U-Boot checks boot/recovery

`CONFIG_FIT_SIGNATURE=y`: U-Boot will definitely perform security checks on boot.img/recovery.img, and boot only when the checks are successful; boot.img/recovery.img is not signed or fails to be checked, and does not boot.

`CONFIG_FIT_SIGNATURE=n`: U-Boot itself contains no secure boot related code and must not check boot.img/recovery.img (no matter it is signed or not).

Note: Whether or not the current level will check the later level has nothing to do with whether or not the current level of firmware is signed. It only depends on whether it contains code for secure boot, i.e. whether the above configuration is set to y or not.

12.5.5 Booting Information

The following is the information for Secure Boot:

```
BW=32 Col=10 Bk=8 CS0 Row=15 CS=1 Die BW=16 Size=1024MB
out
U-Boot SPL board init
U-Boot SPL 2017.09-gacb99c5-200408-dirty #cjh (Apr 09 2020 - 20:51:21)
unrecognized JEDEC id bytes: 00, 00, 00

Trying to boot from MMC1
// SPL completes signature checking
sha256,rsa2048:dev+
// Anti-rollback detection: the current uboot.img firmware version number is 10,
the minimum version number of this machine is 9.
rollback index: 10 >= 9, OK
// SPL completes hash checkings for each sub-mirror
### Checking optee ... sha256+ OK
### Checking uboot ... sha256+ OK
### Checking fdt ... sha256+ OK

Jumping to U-Boot via OP-TEE
I/TC:
E/TC:0 0 plat_rockchip_pmu_init:2003 0
E/TC:0 0 plat_rockchip_pmu_init:2006 cpu off
E/TC:0 0 plat_rockchip_pmusram_prepare:1945 pmu sram prepare 0x14b10000 0x8400880
0x1c
E/TC:0 0 plat_rockchip_pmu_init:2020 pmu sram prepare
E/TC:0 0 plat_rockchip_pmu_init:2056 remap
I/TC: OP-TEE version: 3.6.0-233-g35ecf936 #1 Tue Mar 31 08:46:13 UTC 2020 arm
I/TC: Next entry point address: 0x00400000
I/TC: Initialized

U-Boot 2017.09-gacb99c5-200408-dirty #cjh (Apr 09 2020 - 20:51:21 +0800).

Model: Rockchip RV1126 Evaluation Board
PreSerial: 2
DRAM: 1023.5 MiB
System: init
Relocation Offset: 00000000, fdt: 3df404e0
Using default environment

dwmmc@ffc50000: 0
Bootdev(atags): mmc 0
MMC0: HS200, 200Mhz
PartType: EFI
boot mode: normal
conf: sha256,rsa2048:dev+
resource: sha256+
DTB: rk-kernel.dtb
FIT: signed, conf required
HASH(c): OK

I2C0 speed: 400000Hz
PMIC: RK8090 (on=0x10, off=0x00)
```

```
vdd_logic 800000 uV
vdd_arm 800000 uV
vdd_npu init 800000 uV
vdd_vepu init 800000 uV
.....

Hit key to stop autoboot('CTRL+C'): 0
### Booting FIT Image at 0x3d8122c0 with size 0x0052b200
Fdt Ramdisk skip relocation
### Loading kernel from FIT Image at 3d8122c0 ...
   Using 'conf' configuration
   // uboot completes signature checking
   Verifying Hash Integrity ... sha256,rsa2048:dev+ OK
   // Anti-rollback detection: the current boot.img firmware version number is
22, the minimum version number of this machine is 21
   Verifying Rollback-index ... 22 >= 21, OK
   Trying 'kernel' kernel subimage
     Description: Kernel for arm
     Type: Kernel Image
     Compression: uncompressed
     Data Start: 0x3d8234c0
     Data Size: 5349248 Bytes = 5.1 MiB
     Architecture: ARM
     OS: Linux
     Load Address: 0x02008000
     Entry Point: 0x02008000
     Hash algo: sha256
     Hash value:
64b4a0333f7862967be052a67ee3858884fcefefbf4565db5c3828a941a15f34a
   Verifying Hash Integrity ... sha256+ OK // Complete the kernel's hash
verifications
### Loading ramdisk from FIT Image at 3d8122c0 ...
   Using 'conf' configuration
   Trying 'ramdisk' ramdisk subimage
     Description: Ramdisk for arm
     Type: RAMDisk Image
     Compression: uncompressed
     Data Start: 0x3dd3d4c0
     Data Size: 0 Bytes = 0 Bytes
     Architecture: ARM
     OS: Linux
     Load Address: 0x0a200000
     Entry Point: unavailable
     Hash algo: sha256
     Hash value:
e3b0c44298fc1c149afb4c8996fb92427ae41e4649b934ca495991b7852b855
   Verifying Hash Integrity ... sha256+ OK // Complete the verification for Hash
of the ramdisk
   Loading ramdisk from 0x3dd3d4c0 to 0x0a200000
### Loading fdt from FIT Image at 3d8122c0 ...
   Using 'conf' configuration
   Trying 'fdt' fdt subimage
     Description: Device tree blob for arm
     Type: Flat Device Tree
     Compression: uncompressed
     Data Start: 0x3d812ec0
     Data Size: 66974 Bytes = 65.4 KiB
     Architecture: ARM
```

```

Load Address: 0x08300000
Hash algo: sha256
Hash value:
8fb1f170766270ed4f37cce4b082a51614cb346c223f96ddfe3526fafc5729d7
Verifying Hash Integrity ... sha256+ OK // Complete the verification for hash
of fdt
Loading fdt from 0x3d812ec0 to 0x08300000
Bootimg using the fdt blob at 0x8300000
Loading Kernel Image from 0x3d8234c0 to 0x02008000 ... OK
Using Device Tree in place at 08300000, end 0831359d
Adding bank: 0x00000000 - 0x08400000 (size: 0x08400000).
Adding bank: 0x0848a000 - 0x40000000 (size: 0x37b76000).
Total: 236.327 ms

Starting kernel ...

[ 0.000000] Booting Linux on physical CPU 0xf00
[ 0.000000] Linux version 4.19.111 (cjh@ubuntu) (gcc version 6.3.1 20170404
(Linaro GCC 6.3-2017.05)) #28 SMP PREEMPT Wed Mar 25 16:03:27 CST 2020
[ 0.000000] CPU: ARMv7 Processor [410fc075] revision 5 (ARMv7), cr=10c5387d

```

12.6 Remote Signature

From the above sections, it can be seen that the creation of secure firmware requires the user to complete it on the local PC, i.e. the user must be in possession of: the RSA key pair and the firmware. However, in practical scenarios, the user may need to upload the firmware to a remote server, which will sign it with the RSA private key, and then return the signed firmware to the local user. In this case, RK's FIT scheme needs to be realized by “re-signing”.

12.6.1 Implementation Idea

- Since it can only get the server's public key, users first uses the temporary private key + server public key to pack and sign the firmware once on the local PC, which will generate the secure firmware with the temporary signature and the signed data;

The purpose of the public key is to package the public key into a dtb file to be used during the secure boot process; the purpose of the private key is for the temporary signature.

- The user sends the signed data to the server (no need to send the whole firmware, which saves time), the server uses the private key to sign the signed data, and then returns the signature to the user;
- The user replaces the temporary signature in the secure firmware with this signature to obtain the final secure firmware for downloading.

12.6.2 Signed Data

The signed data mentioned in the above section contains: fdt blob configuration + submirror hash set.

- fdt blob node configuration
'hashed-nodes specifies a series of nodes whose contents are incorporated into the signed data.

```

cjh@ubuntu:~/uboot-nextdev$ fdt dump uboot.img | less
/dts-v1/;
.....

configurations {
    default = "conf";
    conf {
        description = "Rockchip armv7 with OP-TEE";
        rollback-index = <0x0000001c>;
        firmware = "optee";
        loadables = "uboot";
        fdt = "fdt";

        signature {
            hashed-strings = <0x00000000 0x000000da>;
            // The contents of these nodes are incorporated into the
            signed data
            hashed-nodes = "/", "/configurations/conf", "/images/fdt",
            "/images/fdt/hash", "/images/optee", "/images/optee/hash", "/images/uboot",
            "/images/uboot/hash";
            .....

```

- The set of submirror hashes.

mkimage automatically generates hash values for each submirror and appends them to the hash nodes. All sub-mirror hash values specified by sign-images are incorporated into the signed data (essentially, the hash nodes are specified via hashed-nodes). Example:

```

cjh@ubuntu:~/uboot-nextdev/u-boot$ fdt dump fit/u-boot.itb | less
/dts-v1/;
.....

/_ {
    totalsize = <0x000bb600>;
    timestamp = <0x5ecb3553>;
    description = "Simple image with OP-TEE support";
    #address-cells = <0x00000001>;
    images {
        uboot {
            data-size = <0x0007ed54>;
            data-position = <0x00000a00>;
            description = "U-Boot";
            type = "standalone";
            os = "U-Boot";
            arch = "arm";
            compression = "none";
            load = <0x00400000>;
            hash {
                // The hash of the uboot image, automatically calculated and
                generated by the mkimage tool
                value = <0xeda8cd52 0x8f058118 0x00000003 0x35360000
                0x6f707465 0x0000009f 0x00000091 0x00000000>;
                algo = "sha256";
            };
        };
    };
    .....

```

12.6.3 Detailed Steps

The RSA key pairs used to sign the firmware are: dev.key, dev.pubkey, and dev.crt. dev.key is held by the remote server as the private key, and the user has only dev.pubkey and dev.crt.

Step 1:

In local U-Boot project environment: user put dev.crt into keys directory, then use RK's "rk_sign_tool" tool to generate a random temporary private key, name it dev.key and put it into keys directory. Refer to the above section (but add --no-check to the compilation parameter) to generate the signed firmware uboot.img and boot.img (which won't actually be used in the end, what users need are the intermediate files).

Note: The compiling command should specify the parameter --no-check, otherwise the self-checking of the packing script will fail due to the mismatch between dev.key and dev.crt. For example:

```
./make.sh rv1126 --spl-new --boot_img boot.img --rollback-index-uboot 10 --  
rollback-index-boot 12 --no-check
```

In addition to generating the signed firmware uboot.img and boot.img, users can also get intermediate files in the fit/ directory

```
// Signed content (data2sign means: data to sign)  
fit/uboot.data2sign  
fit/boot.data2sign  
  
// Signed itb files (using a temporary private key), our img files are obtained  
from multiple backups of them  
fit/uboot.itb  
fit/boot.itb
```

Step 2:

The user sends uboot.data2sign to the remote server. Assuming that the remote server holds the private key dev.key, use the following command to sign and output the signing result: uboot.sig

```
openssl dgst -sha256 -sign dev.key -sigopt rsa_padding_mode:pss -out uboot.sig  
uboot.data2sign
```

The server returns the signature result file uboot.sig to the user, who uses uboot.sig to replace the temporary signature in uboot.itb:

```
./scripts/fit-resign.sh -f fit/uboot.itb -s uboot.sig // A new uboot.img will be  
generated and used for downloading.
```

Ditto for the boot.itb file. From this the user gets the final valid signed firmware uboot.img and boot.img.

Notes:

- The itb file specified by -f in fit-resign.sh is not an img file. The script will generate the img file after re-signing the itb.
- The itb file used to execute fit-resign.sh must have been compiled in step 1, i.e., the itb file and the data2sign file are in one-to-one correspondence because the data2sign information contains the timestamp at which the itb file was generated, i.e., /timestamp = <... > . So even if there are no current code

changes, recompiling to get a new uboot.itb and replacing uboot.sig into the new uboot.itb will still cause a secure boot failure!

- Since there is no private key, the loader needs to be sent separately to the server side for signing.

12.6.4 Other Solutions

Besides the “re-signing” method, is it possible to upload the whole firmware (boot.img, uboot.img) or discrete images (u-boot.bin, fdt, ramdisk, kernel ...) directly to the server for signing?

Considering the design principles and implementation of FIT, other solutions are difficult to implement.

Explanations are as follows :

- Solution 1: Upload non-secure boot.img, uboot.img to server for repackaging + signing
Problematic point: You also need to upload the configuration information, u-boot-spl.bin file, etc. under the local U-Boot compilation environment.
- Solution 2: Upload secure boot.img, uboot.img to server for repackaging + signing
Problematic point: The RSA public key has been packed when compiling the firmware locally, and the server will pack the RSA public key twice.
- Solution 3: Upload all discrete images (kernel, dtb, ramdisk, resource...) for packaging + signing
Problematic point: It is cumbersome with so many files to upload, and has the same problem as solution one.

The common problematic point of the above solutions: the server side must use RK's mkimage tool, which is likely to be updated by RK.

In conclusion, the current “re-signing” is the easiest, dependency-free, least error-prone solution: all the user need is uploading the signed data, and then the server uses the openssl command to sign it.

12.7 Firmware Unpacking

The user can unpack the firmware with the help of a script, such as boot.img:

```
cjh@ubuntu:~/uboot-nextdev$ ./scripts/fit-unpack.sh -f boot.img -o out
Unpack to directory out:
fdt : 82813 bytes... sha256+
kernel : 5844640 bytes... sha256+
ramdisk : 0 bytes... sha256+
resource : 120832 bytes... sha256+
```

If img contains multiple backups, the script only unpackages the first itb; sha256+ means the firmware is not corrupted, otherwise it shows sha256-.

12.8 Firmware Replacement

Users can batch replace sub-firmware with the help of scripts. For example: replace self-own bl31.elf into other's uboot_legacy.img:

1. Compile your own uboot.img with your own bl31.elf
2. Unpack uboot_legacy.img to the out/ directory with fit-unpack.sh

```

cjh@ubuntu:~/uboot-nextdev$ ./scripts/fit-unpack.sh -f uboot_legacy.img -o
out/

uboot_legacy.img: Device Tree Blob version 17, size=2560, boot CPU=0, string_
block size=197, DT structure block size=2204
Unpack to directory out:
  uboot                : 576352 bytes... sha256+
  atf-1                : 69089 bytes... sha256+
  atf-2                : 36864 bytes... sha256+
  atf-3                : 24576 bytes... sha256+
  optee                : 228134 bytes... sha256+
  fdt                  : 8867 bytes... sha256+

```

3. Delete all atf-xxx files from the out/ directory.
4. Use fit-repack.sh to replace all the sub-mirrors in out/ into your own uboot.img. At this point, the new uboot.img contains your own bl31 and the other sub-mirrors in uboot_legacy.img, which achieves the desired replacement effect.

```

cjh@ubuntu:~/uboot-nextdev$ ./scripts/fit-repack.sh -f uboot.img -d out/

uboot.img: Device Tree Blob version 17, size=2560, boot CPU=0, string_block
size=197, DT structure block size=2204
Unpack to directory out/repack/:
  uboot                : 576352 bytes... sha256+
  atf-1                : 69089 bytes... sha256+
  atf-2                : 36864 bytes... sha256+
  atf-3                : 24576 bytes... sha256+
  optee                : 228134 bytes... sha256+
  fdt                  : 8867 bytes... sha256+
  .....
Image(repack):  uboot.img is ready.

```

Principle Explanation:

The sub-mirror replacement strategy is not “replace my sub-mirror into his uboot.img”, but “replace his sub-mirror into my uboot.img”.

Reason: the atf-xxx in uboot.img comes from bl31.elf, the number of atf-xxx contained in the old and new bl31.elf may be different, and if it is different, it can't be replaced equally. Although the number of sub-mirrors other than atf-xxx such as u-boot, bl32, mcu, etc. are fixed, this reverse substitution strategy is used in order to support the replacement of bl31.elf.

The above describes the replacement of bl31.elf, and the same strategy is applicable for the replacement of other submirrors.

12.9 Safety Checking Step-by-Step

1. Enter the u-boot directory, open configs/rxxxxx_defconfig of the corresponding platform and select the following configuration:


```
// Required
CONFIG_FIT_SIGNATURE=y
CONFIG_SPL_FIT_SIGNATURE=y

// Optional
CONFIG_FIT_ROLLBACK_PROTECT=y // boot.img anti-rollback
CONFIG_SPL_FIT_ROLLBACK_PROTECT=y // uboot.img anti-rollback
```

2. Perform the following to generate keys:

```
mkdir -p keys
../rkbin/tools/rk_sign_tool kk --bits 2048 --out .
cp privateKey.pem keys/dev.key && cp publicKey.pem keys/dev.pubkey
openssl req -batch -new -x509 -key keys/dev.key -out keys/dev.crt
```

Note: This step can be performed just once, and then save these keys properly.

3. Compile and sign, take rv1126 as an example (if compiling and signing other chip firmware, such as rk3566, just change rv1126 to rk3566 in the following command):

```
// Linux: Copy boot.img and recovery.img to the u-boot file, execute the
following script to sign loader,uboot,boot,recovery, set the anti-version
rollback number of uboot,boot,recovery, and note that the anti-rollback version
number is configured according to the need.
./make.sh rv1126 --spl-new --boot_img boot.img --recovery_img recovery.img --
rollback-index-uboot 1 --rollback-index-boot 2

// Android: signature loader, uboot, set uboot anti-version rollback number, and
note that the anti-rollback version number is configured according to the need.
./make.sh rv1126 --spl-new --rollback-index-uboot 1
```

If the compilation appears:

```
Can't load XXXXXX//.rnd into RNG
```

Execute:

```
touch ~/.rnd
```

4. Public key hash downloading:

```
// Linux: Copy boot.img and recovery.img to the u-boot file, execute the
following script to sign loader,uboot,boot,recovery, set the anti-rollback
version number of uboot,boot,recovery, note that the anti-rollback version number
is configured according to the need to enable the downloading of the key hash
./make.sh rv1126 --spl-new --boot_img boot.img --recovery_img recovery.img --
rollback-index-uboot 1 --rollback-index-boot 2 --burn-key-hash

// Android: Sign loader,uboot, set the anti-rollback version number of uboot,
note that the anti-rollback version number is configured according to the need to
enable the downloading of the key hash
./make.sh rv1126 --spl-new --rollback-index-uboot 1 --burn-key-hash
```

Note: This step would configure `--burn-key-hash` after the entire product development has been verified, otherwise security is turned on. And only signed firmware can be updated during product development.

5. Other firmware signatures for Android :

Please refer to 《Rockchip_Developer_Guide_Secure_Boot_for_UBoot_Next_Dev_CN.md》

13. Chapter-13 Fast Boot

13.1 Chip Support

- rv1126

13.2 Storage Support

- eMMC
- spi nor

13.3 bootrom Support

Currently the spi nor driver of bootrom supports 4-wire DMA mode to load the lower level firmware, this support has been configured directly in the usbplug when burning firmware, customers do not need to configure again.

eMMC has not been optimized for this.

13.4 U-Boot SPL Support

Quick boot in FIT format is supported under U-Boot SPL, as well as keystroke entry into loader mode and low battery detection.

Configurations:

```
CONFIG_SPL_KERNEL_BOOT=y           // Enable quick boot function  
CONFIG_SPL_BLK_READ_PREPARE=y       // Enable preloading function  
CONFIG_SPL_MISC_DECOMPRESS=y       // Enable decompression function  
CONFIG_SPL_ROCKCHIP_HW_DECOMPRESS=y
```

U-Boot SPL supports preload function, after enabling the preload function, the firmware can be loaded while executing other programs. Currently it is mainly used to preload ramdisk.

For example, preloading a gzip-compressed ramdisk, the compression command:

```
cat ramdisk | gzip -n -f -9 > ramdisk.gz
```

The its file is configured as follows:

```
ramdisk {  
data = /incbin("./images-tb/ramdisk.gz");  
compression = "gzip"; // compression format  
type = "ramdisk";  
arch = "arm";  
os = "linux";  
}
```

```

preload = <1>; // preloaded symbol
comp = <0x5800000>; // loading address
load = <0x2800000>; // decompression address
decomp-async; // asynchronous decompression
hash {
    algo = "sha256";
    uboot-ignore = <1>; // No hash checks.
};
};

```

Compile firmware, e.g. compile rv1126 eMMC firmware:

```
./make.sh rv1126-emmc-tb && ./make.sh --spl
```

13.5 MCU Configuration

Currently the main role of mcu is to assist the system to boot up and initialize the ISP and other modules in advance. kernel will take over the control of these hardware modules after booting.

Configured within the chip file corresponding to rkbin/RKTRUST, using rv1126 as an example:

```

.[MCU]
MCU=bin/rv11/rv1126_mcu_v1.02.bin,0x108000,okay // Configure the corresponding
firmware location, boot address and enable flag

```

Address of mcu program:

```

https://10.10.10.29/admin/repos/rtos/rt-thread/rt-thread-amp
https://10.10.10.29/admin/repos/rk/mcu/hal

```

After U-Boot is compiled, it will package the mcu firmware into uboot.img. When the system boots, SPL will parse and load the mcu firmware from uboot.img.

13.6 Kernel Support

Configuration:

```

CONFIG_ROCKCHIP_THUNDER_BOOT=y // Enable quick boot function
CONFIG_ROCKCHIP_THUNDER_BOOT_MMC=y // Enable the support for emmc
quick boot optimization
CONFIG_ROCKCHIP_THUNDER_BOOT_SFC=y // Enable the support for spi
nor quick boot optimization
CONFIG_VIDEO_ROCKCHIP_THUNDER_BOOT_ISP=y // Enable the support for ISP
nor quick boot optimization

```

For quick booting, SPL does not modify the parameters of kernel dtb based on actual hardware parameters, so some parameters need to be configured by the user, specifically.

- memory.
- Size of ramdisk before and after decompression

For details please refer: [kernel/arch/arm/boot/dts/rv1126-thunder-boot.dtsi](#)

```
memory: memory {
    device_type = "memory";
    reg = <0x00000000 0x20000000>; //Need to be pre-defined based on real DDR
    capacity, SPL does not correct it
};

reserved-memory {
    trust0 {
        reg = <0x00000000 0x00200000>; // trust space
        no-map;
    };

    trust@200000 {
        reg = <0x00200000 0x00008000>;
    };

    ramoops@210000 {
        compatible = "ramoops";
        reg = <0x00210000 0x000f0000>;
        record-size = <0x20000>;
        console-size = <0x20000>;
        ftrace-size = <0x00000>;
        pmsg-size = <0x50000>;
    };

    rtos@300000 {
        reg = <0x00300000 0x00100000>; // Reserved for use on the client side,
        can be deleted if not in use
        no-map;
    };

    ramdisk_r: ramdisk@2800000 {
        reg = <0x02800000 (48 * 0x00100000)>; // Decompression source address,
        can be changed according to the actual size
    };

    ramdisk_c: ramdisk@5800000 {
        reg = <0x05800000 (20 * 0x00100000)>; // Compression source address, can
        be changed based on actual size
    };
};
```

Configuration for emmc:

```
/ {
    reserved-memory {
        mmc_ecsd: mmc@20f000 {
            reg = <0x0020f000 0x00001000>; // SPL upload ecsd region
            to kernel
        };

        mmc_idmac: mmc@500000 {
            reg = <0x00500000 0x00100000>; //When preloading the
            ramdisk, the memory area of idmac is reserved, and when the preloading is
            finished, the memory in this area is released.
        };
    };
};
```

```

_____}.i
_____}.i

thunder_boot_mmc: thunder-boot-mmc {
    compatible = "rockchip,thunder-boot-mmc";
    reg = <0xffc50000 0x4000>;
    memory-region-src = <&ramdisk_c>;
    memory-region-dst = <&ramdisk_r>;
    memory-region-idmac = <&mmc_idmac>;
_____}.i
}.i

```


Configuration for spi nor:

```

/_{.
thunder_boot_spi_nor: thunder-boot-spi-nor {
    compatible = "rockchip,thunder-boot-sfc";
    reg = <0xffc90000 0x4000>;
    memory-region-src = <&ramdisk_c>;
    memory-region-dst = <&ramdisk_r>;
_____}.i
}.i

```

13.7 Fast Boot Process



14. Chapter-14 Platform Definition

14.1 ATF/OPTEE

1. Minimum version of ATF/OPTEE for U-Boot charging standby requirements

Chips Type	Minimum Version Number
RV1108	N/A
RK1808	N/A
RK1806	N/A
RK3036	N/A
RK3128x	N/A
RK3126	rk3126_tee_ta_v1.39.bin
RK322x	N/A
RK3288	rk3288_tee_ta_v1.43.bin
RK3368	rk3368h_bl31_v2.22.elf
RK3328	N/A
RK3399	rk3399_bl31_v1.32.elf
RK3399Pro	rk3399_bl31_v1.32.elf
RK3399Pro-npu	rk3399_bl31_v1.32.elf
RK3308	rk3308_bl31_v2.00.elf rk3308_bl31_aarch32_v2.20.elf
PX30	px30_bl31_v1.05.elf
RK3326	rk3326_bl31_v1.05.elf
RV1126/RV1109	N/A
RK3568	rk3588_bl31_v1.26.elf rk3588_bl31_ultra_v2.06.elf
RK3566	rk3588_bl31_v1.26.elf rk3588_bl31_ultra_v2.06.elf
RK3588	rk3588_bl31_v1.24.elf
RV1106/RV1103	N/A
RK3528	N/A
RK3562	In-process
RK3576	rk3576_bl31_v1.04.elf
RV1106B/RV1103B	N/A
RK3506	In-process

14.2 Clock

1. CPU Clocking Support List

Chips	Clocking	Frequency enhancement processor
RV1108	N/A	N/A
RK1808	N/A	N/A
RK1806	N/A	N/A
RK3036	N/A	N/A
RK3128x	N/A	N/A
RK3126	N/A	N/A
RK322x	N/A	N/A
RK3288	N/A	N/A
RK3368	N/A	N/A
RK3328	N/A	N/A
RK3399	N/A	N/A
RK3399Pro	N/A	N/A
RK3399Pro-npu	N/A	N/A
RK3308	N/A	N/A
PX30	Ordinary clock	Voltage + Frequency
RK3326	Ordinary clock	Voltage + Frequency
RV1126/RV1109	N/A	N/A
RK3568	SCMI clock	Voltage + Frequency
RK3566	SCMI clock	Voltage + Frequency
RK3588	N/A	N/A
RV1106/RV1103	N/A	N/A
RK3528	SCMI clock	Voltage
RK3562	SCMI clock	Voltage
RK3576	N/A	N/A
RV1106B/RV1103B	N/A	N/A
RK3506	N/A	N/A

14.3 **Defconfig**

1. Defconfig support by platforms (subject to SDK release).

“[chip]_defconfig” or “[chip].config” are usually full-featured versions, the rest are feature-specific.

Chips	defconfig	Support kernel dtb	Remarks
RV1108	evb-rv1108_defconfig	N	generic version
RK1808	rk1808_defconfig	Y	generic version
RK1806	rk1806_defconfig	Y	generic version
RK3036	rk3036_defconfig	Y	generic version
RK3128x	rk3128x_defconfig	Y	generic version
RK3126	rk3126_defconfig	Y	generic version
RK322x	rk322x_defconfig	Y	generic version
RK3288	rk3288_defconfig	Y	generic version
RK3368	rk3368_defconfig	Y	generic version
RK3328	rk3328_defconfig	Y	generic version
RK3399	rk3399_defconfig	Y	generic version
RK3399Pro	rk3399pro_defconfig	Y	generic version
RK3399Pro-npu	rknpu-lion_defconfig	Y	generic version
RK3308	rk3308_defconfig rk3308-aarch32_defconfig	Y	generic version Support aarch32 mode
PX30	px30_defconfig	Y	generic version
RK3326	rk3326_defconfig rk3326-aarch32_defconfig	Y	generic version Support aarch32 mode
RV1126	rv1126_defconfig rv1126-ab.config rv1126-spi-nor-tiny_defconfig rv1126-ramboot.config rv1126-usbplug.config rv1126-dfu.config rv1126-ipc.config	Y	generic version generic version+supportA/B Spi Nor small capacity No memory device (memory boot) usbplug function Support dfu Use on ipc sdk
RV1126	rv1126-emmc-tb.config rv1126-lp3-emmc-tb.config rv1126-spi-nor-tb.config	Y	eMMC+DDR3 thunderboot eMMC+LP3 thunderboot Spi Nor+DDR3 thunderboot

Chips	defconfig	Support kernel dtb	Remarks
RK3568	rk3568_defconfig rk3568-dfu.config rk3568-nand.config rk3568-spl-spi-nand_defconfig rk3568-aarch32.config rk3568-usbplug.config		generic version Support dfu Support MLC/TLC/ eMMC SPI-nand dedicated SPL Support aarch32 mode Support usbplug mode
RK3566	rk3566.config rk3566-eink.config	Y	generic version E-book version
RK3588	rk3588_defconfig rk3588-ramboot.config rk3588-sata.config rk3588-aarch32.config rk3588-ipc.config	Y	generic version No memory device (memory boot) Dual storage support for sata booting Support for aarch32 mode Use on ipc sdk
RV1106/RV1103	rv1106_defconfig rv1106-emmc-tb_defconfig rv1106-spi-nor-tb_defconfig rv1106-spi-nor_defconfig rv1106-display.config rv1106-dfu.config rv1106-ipc.config	Y	generic version eMMC thunderboot Spi Nor thunderboot Spi Nor small capacity Support for boot logos Support dfu Use on ipc sdk
RK3528	rk3528_defconfig	Y	generic version
RK3562	rk3562_defconfig	Y	generic version
RK3576	rk3576_defconfig rk3576-usbplug.config rk3576-car.config rk3576-ab-car.config rk3576-eink.config	Y	generic version Open source usbplug In-vehicle version Support ab system in-vehicle version E-book version
RV1106B	rv1106b_defconfig rv1106b-emmc-tb_defconfig rv1106b-spi-nand-tb_defconfig	Y	generic version eMMC thunderboot Spi Nand thunderboot
RV1103B	rv1103b_defconfig rv1103b-optee.config rv1103b-spi-nor_defconfig	Y	generic version Support OP-TEE Spi Nor small capacity

Chips	defconfig	Support kernel dtb	Remarks
RK3506	rk3506_defconfig rk3506_tb.config rk3506-amp.config rk3506b.config	Y	generic version thunderboot version Use on amp sdk Use on RK3506B

14.4 DFU

1. DFU Feature Support List:

Chips	defconfig
RV1108	N/A
RK1808	N/A
RK1806	N/A
RK3036	N/A
RK3128x	N/A
RK3126	N/A
RK322x	N/A
RK3288	N/A
RK3368	N/A
RK3328	N/A
RK3399	N/A
RK3399Pro	N/A
RK3399Pro-npu	N/A
RK3308	N/A
PX30	N/A
RK3326	N/A
RV1126/RV1109	rv1126-dfu.config
RK3568	N/A
RK3566	N/A
RK3588	rk3568-dfu.config
RV1106/RV1103	rv1106-dfu.config
RK3528	N/A
RK3562	N/A
RK3576	N/A
RV1106B/RV1103B	N/A
RK3506	N/A

14.5 Optee

1. The applicability of the optee client interface across platforms

API	RV1109/RV1126	RK3566/RK3568	RK3588	RV1106/RV1103	RK3528	RK3562	RK3576	RV1106B/RV1103B	RK3506	others
trusty_read_vbootkey_hash	√	√	√	N/A	√	√	√	√	N/A	√
trusty_write_vbootkey_hash	√	√	√	N/A	√	√	√	√	N/A	√
trusty_read_vbootkey_enable_flag	√	√	√	N/A	√	√	√	√	N/A	√
trusty_write_oem_otp_key	√	√	√	N/A	√	√	√	√	N/A	N/A
trusty_oem_otp_key_is_written	√	√	√	N/A	√	√	√	√	N/A	N/A
trusty_set_oem_hr_otp_read_lock	N/A	N/A	√	N/A	√	√	√	N/A	N/A	N/A
trusty_oem_otp_key_cipher	√	√	√	N/A	√	√	√	√	N/A	N/A

15. Chapter-15 Remarks

15.1 SDK Compatibility

15.1.1 androidboot.mode Compatibility

For SDK versions earlier than Android 8.1, the following configurations must be enabled for the U-Boot to properly boot Android:

```
CONFIG_RKIMG_ANDROID_BOOTMODE_LEGACY
```

Please refer to the submission for the reason:

```
commit a7774f5911624928ed1d9cfed5453aab206c512e  
Author: Zhangbin Tong <zebulun.tong@rock-chips.com>  
Date: Thu Sep 6 17:35:16 2018 +0800  
  
common: boot_rkimg: set "androidboot.mode=" as "normal" or "charger"  
  
- The legacy setting rule is deprecated(Android SDK < 8.1).  
- Provide CONFIG_RKIMG_ANDROID_BOOTMODE_LEGACY to enable legacy setting.  
  
Change-Id: I5c8b442b02df068a0ab98ccc81a4f008ebe540c1  
Signed-off-by: Zhangbin Tong <zebulun.tong@rock-chips.com>  
Signed-off-by: Joseph Chen <chenjh@rock-chips.com>
```

15.1.2 MISC Compatibility

The purpose of misc.img is to serve as the boot interaction between U-Boot and Android, and the main content is BCB (Bootloader Control Block).

Due to the history of the RK platform, for SDK versions greater than or equal to Android-10.0, the BCB in misc.img must be stored in the misc partition at offset 0; for versions lower than Android-10.0, the BCB must be stored in the misc partition at offset 16KB.

Users don't need extra processing when they get the released SDK, U-Boot will adapt itself to be compatible. However, if users take the misc.img of different SDKs and mix them, problems may occur. The phenomenon is generally that Android will keep entering recovery mode.

16. Chapter-16 Tools

Paths to development tools related to this chapter (using the U-Boot root directory as a reference point):

```
./scripts/mkbootimg
./scripts/unpack_bootimg
./scripts/repack-bootimg
./scripts/unpack_resource.sh
./scripts/stacktrace.sh
./tools/patman/patman
./tools/buildman/buildman

../rkbin/tools/resource_tool
../rkbin/tools/loaderimage
../rkbin/tools/trust_merger
../rkbin/tools/boot_merger
```

16.1 trust_merger

Function: Pack bl30, bl31, bl32 bin files for 64-bit platforms according to ini configuration file and generate trust.img.

ini file:

Take RK3368TRUST.ini as an example:

```
[VERSION].
MAJOR=0          ----major version number
MINOR=1          ----minor version number
[BL30_OPTION]    ----bl30, Currently set to mcu bin
SEC=1            ----BL30 bin exists
PATH=tools/rk_tools/bin/rk33/rk3368bl30_v2.00.bin ----Specify the bin path
ADDR=0xff8c0000  ----Load and run addresses in firmware DDRs
[BL31_OPTION]    ----bl31, currently set to multi-core and power
management related bin
SEC=1            ----BL31 bin exists
PATH=tools/rk_tools/bin/rk33/rk3368bl31-20150401-v0.1.bin----Specify the bin path
ADDR=0x00008000  ----Load and run address in firmware DDR
[BL32_OPTION].
SEC=0            ----BL32 bin does not exist
[BL33_OPTION].
SEC=0            ----BL33 bin does not exist
[OUTPUT].
PATH=trust.img [OUTPUT] ----Output firmware name
```

Packing command:

```

/*
 * @<sha>: optional. sha related, refer to make.sh
 * @<rsa>: optional. rsa related, refer to make.sh
 * @<size>: optional, formats: --size [KB] [count].the size of the output file.
When omitted, the default is 2M for a single copy and 2 copies for a package.. 打
包2份
 * @[ini file]: mandatory. ini file
 */

./tools/trust_merger <sha> <rsa> <size> [ini file].

```

templates:

```

./tools/trust_merger --rsa 3 --sha 2 ./ RKTRUST/RK3399TRUST.ini
out:trust.img
merge success(trust.img).

```

unpacking command:

```

// @[input image]: Mandatory, firmware for unpacking, typically trust.img

./tools/trust_merger --unpack [input image].

```

Templates:

```

./tools/trust_merger --unpack trust.img

File Size = 4194304
Header Tag:BL3X
Header version:256
Header flag:35
SrcFileNum:4
SignOffset:992
Component 0:
ComponentID:BL31
StorageAddr:0x4
ImageSize:0x1c0
LoadAddr:0x10000
Component 1:
ComponentID:BL31
StorageAddr:0x1c4
ImageSize:0x10
LoadAddr:0xff8c0000
Component 2:
ComponentID:BL31
StorageAddr:0x1d4
ImageSize:0x48
LoadAddr:0xff8c2000
Component 3:
ComponentID:BL32
StorageAddr:0x21c
ImageSize:0x2e0
LoadAddr:0x8400000
unpack success

```

16.2 boot_merger

Function: Pack miniloader + ddr + usb plug according to ini configuration file, generate loader firmware.

ini file:

Take the RK3288MINIALL.ini file as an example:

```
[CHIP_NAME].
NAME=RK320A          ----Chip Name: "RK" plus the 4B chip type number
agreed with maskrom
[VERSION].
MAJOR=2              ----Major version number
MINOR=36             ----Minor version number
[CODE471_OPTION]     ----code471, currently set to ddr bin
NUM=1
Path1=tools/rk_tools/bin/rk32/rk3288_ddr_400MHz_v1.06.bin
[CODE472_OPTION]     ----code472, currently set to usbplug bin
NUM=1
Path1=tools/rk_tools/bin/rk32/rk3288_usbplug_v2.36.bin
[LOADER_OPTION].
NUM=2
LOADER1=FlashData    ----flash data, currently set to ddr bin
LOADER2=FlashBoot    ----flash boot, Currently set to miniloader bin
FlashData=tools/rk_tools/bin/rk32/rk3288_ddr_400MHz_v1.06.bin
FlashBoot=tools/rk_tools/bin/rk32/rk3288_miniloader_v2.36.bin
[OUTPUT]             ----Output file name
PATH=rk3288_loader_v1.06.236.bin
```

Packing command:

```
// @[ini file]: mandatory. ini file

./tools/boot_merger [ini file].
```

Template:

```
./tools/boot_merger ./RKBOOT/RK3399MINIALL.ini
out:rk3399_loader_v1.17.115.bin
fix_opt:rk3399_loader_v1.17.115.bin
merge success(rk3399_loader_v1.17.115.bin)
```

Unpacking command:

```
// @[input image]: Mandatory. Firmware for unpacking, usually a loader file

./tools/boot_merger --unpack [input image].
```

Template:

```

./tools/boot_merger --unpack rk3399_loader_v1.17.115.bin
unpack_entry(rk3399_dds_800MHz_v1.17)
unpack_entry(rk3399_usbplug_v1.15)
unpack_entry(FlashData)
unpack_entry(FlashBoot)
unpack success

```

16.3 loaderimage

Functionality:

- Package u-boot.bin to generate uboot.img
- Package tee bin for 32-bit platforms to generate trust.img

Package u-boot:

```

/*
 * @[input bin]: Required. bin source file
 * @[output image]: Required. Output File
 * @[load_addr]: Required. the load Address
 * @<size>: Optional, Format: --size [KB] [count]. Output file size, when it is
omitted, defaulted as 1M for one copy, and four copies for a package.
 */

./tools/loaderimage --pack --uboot [input bin] [output image] [load_addr] <size>

```

Template

```

./tools/loaderimage --pack --uboot ./u-boot.bin uboot.img 0x60000000 --size 1024
2

load addr is 0x60000000!
pack input u-boot.bin
pack file size: 701981
crc = 0xc595eb85
uboot version: U-Boot 2017.09-02593-gb6e59d9 (Feb 18 2019 - 13:58:53)
pack uboot.img success!

```

Unpacks u-boot:

```

/*
 * @[input image]: Required. Unpacking source files
 * @[output bin]: Required. Unpack the output file, any name will do
 */

./tools/loaderimage --unpack --uboot [input image] [output bin]

```

Templates:

```

./tools/loaderimage --unpack --uboot uboot.img uboot.bin
unpack input uboot.img
unpack uboot.bin success!

```

Packaging trust:

```
/*
 * @[input bin]: Required. bin file
 * @[output image]: Required, output File
 * @[load_addr]: Required, the load Address
 * @<size>: Optional, Format: --size [KB] [count]. Output file size, when it is
omitted, defaulted as 1M for one copy, and four copies for a package.
 */

./tools/loaderimage --pack --trustos [input bin] [output image] [load_addr]_
<size>
```

Templates:

```
./tools/loaderimage --pack --trustos ./bin/rk32/rk322x_tee_v2.00.bin trust.img \
_____ 0x80000000 --size 1024 2

load addr is 0x80000000!
pack input bin/rk32/rk322x_tee_v2.00.bin
pack file size: 333896
crc = 0x2de93b46
pack trust.img success!
```

Unpacking trust:

```
/*
 * @[input image]: Required. Unpacking source files
 * @[output bin]: Required. the output file after unoacking, any name will do
 */

./tools/loaderimage --unpack --trustos [input image] [output bin]
```

Templates

```
./tools/loaderimage --unpack --trustos trust.img tee.bin
unpack input trust.img
unpack tee.bin success!
```

16.4 resource_tool

Function: Pack any resource file to generate resource.img.

Packing command:

```
./tools/resource_tool [--pack] [--image=<resource.img>] <file list>
```

Templates:

```
./scripts/resource_tool ./arch/arm/boot/dts/rk3126-evb.dtb logo.bmp_
logo_kernel.bmp
Pack to resource.img succeeded!
```

Unpacking command:

```
./tools/resource_tool --unpack --image=<resource.img> [output dir].
```

Templates:

```
./tools/resource_tool --unpack --image=resource.img ./out/

Dump header:
partition version:0.0
header size:1
index tbl:
_____ offset:1          entry size:1    entry num:3
Dump Index table:
entry(0):
_____ path:rk-kernel.dtb
_____ offset:4           size:33728
entry(1):
_____ path:logo.bmp
_____ offset:70          size:170326
entry(2):
_____ path:logo_kernel.bmp
_____ offset:403         size:19160
Unack resource.img to ./out succeeded!
```

16.5 mkimage

Function: Generate Loader firmware in SPL mode.

For example, the following command generates the IDBLOCK format required by Rockchip's bootrom. This command also modifies the first 4 bytes of u-boot-tpl.bin to be the ID required by the bootrom:

```
./tools/mkimage -n rk3328 -T rksd -d tpl/u-boot-tpl.bin idbloader.img
```

Detailed reference:

```
./doc/mkimage.1
```

16.6 stacktrace.sh

Function: parse the call stack information, please refer to RK Architecture chapter.

16.7 mkbootimg

Function: Package firmware to generate boot and recovery.img, source files to come in android project.

Templates:

```
./scripts/mkbootimg --kernel zImage --second resource.img --ramdisk ramdisk.img -  
-out boot.img
```

16.8 unpack_bootimg

Function: used for boot and recovery.img unpacking, source files come in android project.

Templates:

```
./scripts/unpack_bootimg --boot_img boot.img --out out/
```

16.9 repack-bootimg

Function: Replace the firmware in boot and recovery.img.

Templates:

```
// For example, replace only the kernel  
./scripts/repack-bootimg --boot_img boot.img --kernel zImage -o boot_repack.img  
  
//Example: Replace only resource  
./scripts/repack-bootimg --boot_img boot.img --second resource.img -o  
boot_repack.img
```

16.10 pack_resource.sh

Function: Packs the charge images from the `./tools/images/` directory into resource.img.

Templates:

```
./scripts/pack_resource.sh resource.img  
  
Pack ./tools/images/ & resource.img to resource.img ...  
Unpacking old image(resource.img):  
rk-kernel.dtb 1  
Pack to resource.img succeeded!  
Packed resources:  
rk-kernel.dtb battery_1.bmp battery_2.bmp battery_3.bmp battery_4.bmp  
battery_5.bmp battery_fail.bmp battery_0.bmp 8  
  
resource.img is packed ready
```

16.11 buildman

Function: Batch compile code, ideal for verifying that commits to the current platform affect other platforms.

Detailed reference:


```
./tools/buildman/README
```

To use buildman you need to set the toolchain path in advance and edit the '~/.buildman' file:

```
[toolchain]
arm: ~/prebuilts/gcc/linux-x86/arm/gcc-linaro-6.3.1-2017.05-x86_64_arm-linux-
gnueabihf/
aarch64: ~/prebuilts/gcc/linux-x86/aarch64/gcc-linaro-6.3.1-2017.05-
x86_64_aarch64-linux-gnu/
```

Typical use cases, such as compiling U-Boot code for all Rockchip platforms:

```
./tools/buildman/buildman rockchip
```

The ideal results are as follows:

```
$ ./tools/buildman/buildman rockchip
boards.cfg is up to date. Nothing to do.
Building current source for 34 boards (4 threads, 1 job per thread)
 34      0      0 /34      evb-rk3326
```

The first is the number of platforms that pass completely (green), the second is the number of platforms with warning output (yellow), and the third is the number of platforms that fail to compile with error (red). If there are warnings or errors during the compilation process, they will be displayed in the terminal.

16.12 patman

Function: a tool written in python, by calling other tools to complete the patch checking and submission, it is a very good and necessary tool to do patch Upstream (U-Boot, Kernel). Key functions:

- Automatically format patches based on parameters;
- Call checkpatch to check;
- make extractions from commit information and convert them into cover-letter, patch version, version changes, etc. required for upstream mailing list;
- Automatically removes the change-id from the commit;
- Automatically extracts the required recipients for each patch based on Maintainer and file submission information;
- Send out all patches according to '~/.gitconfig' or './.gitconfig' configuration.

Detailed reference

```
./tools/patman/README
```

Use the '-h' option to see all command options:

```
$ patman -h
Usage: patman [options].
```

Create patches from commits in a branch, check them and email them as specified by tags you place in the commits. Use -n to do a dry run first.

Options:

```
-h, --help          show this help message and exit
-H, --full-help     Display the README file
-c COUNT, --count=COUNT
                    Automatically create patches from top n commits
-i, --ignore-errors Send patches email even if patch errors are found
-m, --no-maintainers Don't cc the file maintainers automatically
-n, --dry-run       Do a dry run (create but don't email patches)
-p PROJECT, --project=PROJECT
                    Project name; affects default option values and
                    aliases [default: u-boot].
-r IN_REPLY_TO, --in-reply-to=IN_REPLY_TO
                    Message ID that this series is in reply to
-s START, --start=START
                    Commit to start creating patches from (0 = HEAD).
-t, --ignore-bad-tags
                    Ignore bad tags / aliases
--test             run tests
-v, --verbose       Verbose output of errors and warnings
--cc-cmd=CC_CMD    Output cc list for patch file (used by git).
--no-check         Don't check for patch compliance
--no-tags          Don't process subject tags as aliaes
-T, --thread       Create patches as a single thread
```

Typical use case: commit the latest 3 patches

```
patman -t -c3
```

After running the command, checkpatch will automatically abort if there is any error or warning, you need to modify the patch to solve the problem and run it again.

其他常用选项Other common options

- '-t', in '-t' headers, any text before “:” are treated as TAGs, most of which are not recognized by patman and require the '-t' option;
- '-i', if there are some warnings (e.g. more than 80 characters) that we don't think need to be fixed, you can just add the '-i' option to submit the patch;
- '-s', if the patch you want to commit is not at the top of the current tree, you can skip the top N patches with '-s';
- '-n', if you don't want to commit a patch, but just want to verify that the latest patch passes checkpatch, you can use the '-n' option;

Patchman generates the information needed for the upstream mailing list according to the keywords in the commit message.

Typical commit:

```
commit 72aa9e3085e64e785680c3fa50a28651a8961feb
Author: Kever Yang <kever.yang@rock-chips.com>
Date:   Wed Sep 6 09:22:42 2017 +0800

    spl: add support to booting with OP-TEE

    OP-TEE is an open source trusted OS, in armv7, its loading and
    running are like this:
    loading:
    - SPL load both OP-TEE and U-Boot
```

```
running:
- SPL run into OP-TEE in secure mode;
- OP-TEE run into U-Boot in non-secure mode;

More detail:
<https://github.com/OP-TEE/optee\_os>
and search for 'boot arguments' for detail entry parameter in:
core/arch/arm/kernel/generic_entry_a32.S

Cover-letter:
rockchip: add tpl and OPTEE support for rk3229

Add some generic options for TPL support for arm 32bit, and then
and TPL support for rk3229(cortex-A7), and then add OPTEE support
in SPL.

Tested on latest u-boot-rockchip master.

END

Series-version: 4
Series-changes: 4
- use NULL instead of '0'
- add fdt_addr as arg2 of entry.

Series-changes: 2
- Using new image type for op-tee

Change-Id: I3fd2b8305ba8fa9ea687ab7f3fd1ffd2fac9ece6
Signed-off-by: Kever Yang <kever.yang@rock-chips.com>
```

When this patch is sent via the patman command, a Cover-letter is generated:

```
[PATCH v4 00/11] rockchip: add tpl and OPTEE support for rk3229
```

The title of the corresponding patch is as follows, containing the version information and the number of the current patch in the series:

```
[PATCH v4,07/11] spl: add support to booting with OP-TEE
```

Patch commit messages are already processed, with change-id removed, cover-letter removed, and version-changes converted to non-text information:

```
OP-TEE is an open source trusted OS, in armv7, its loading and
running are like this:
loading:
- SPL load both OP-TEE and U-Boot
running:
- SPL run into OP-TEE in secure mode;
- OP-TEE run into U-Boot in non-secure mode;

More detail:
<https://github.com/OP-TEE/optee\_os>
and search for 'boot arguments' for detail entry parameter in:
core/arch/arm/kernel/generic_entry_a32.S
```

Signed-off-by: Kever Yang <kever.yang@rock-chips.com>

Changes in v4:

- use NULL instead of '0'
- add fdt_addr as arg2 of entry.

Changes in v3: None

Changes in v2:

- Using new image type for op-tee

common/spl/Kconfig_____|_ 7 ++++++
common/spl/Makefile_____|_ 1 +
common/spl/spl.c_____|_ 9 +++++++
common/spl/spl_optee.S |_ 13 ++++++
include/spl.h_____|_ 13 ++++++
5 files changed, 43 insertions(+)
create mode 100644 common/spl/spl_optee.S

Please refer to the README for more information on the use of keywords such as “Series-prefix”, “Series-cc”, etc.

17. Chapter-17 Appendix

17.1 Download address

17.1.1 RKBIN

- RK internal engineer: Log in to gerrit and search: “rk/rkbin”
- External engineer:
 - Download the full SDK released by RK, or
 - Download from the Github : <https://github.com/rockchip-linux/rkbin>

17.1.2 GCC

- RK internal engineer: Log in to gerrit and search: “gcc-linaro-6.3.1”
- External Engineers: Download the full SDK released by RK or Linaro website.

17.2 Terminology

- U-Boot: [Universal Boot Loader](#)
- AOSP: [Android Open-Source Project](#)
- AVB: Android Verified Boot
- DTB: [Device Tree Binary](#)
- DTS: [Device Tree Source](#)
- Fastboot: [Originally a way to update firmware for Android, it is now widely used in the embedded space](#)
- GPT: [GUID Partition Table](#)
- MMC: [Multi Media Card](#), Includes: eMMC, SD card, etc.
- SPL: Secondary Program Loader
- TPL: Tertiary Program Loader
- DTB: noun, Device tree blob
- DTB: noun, Device tree blob for stacking
- DTC: noun, Device tree compiler
- DTO: noun, Device tree stacking operation
- DTS: noun, Device tree source file
- FDT: noun, Flattened device tree
- SCMI: [System Control and Management Interface](#)