

Fuse blocks viewed from forward baggage compartment, with access panel open.
The top of the access panel when closed is at the bottom of this view.

1	2	3	4	5	6	7	8	9	10
Essential Bus									
11	12	13	14	15	16	17	18	19	20

21	22	23	24	25	26	27	28	29	30
Main									
31	32	33	34	35	36	37	38	39	40

ESSENTIAL BUS

1	3A		Fuel gauges
2	1A		wire DM8 LED Flood
3	1A	fuse F24	wire E11 EIS DTS data out
4	3A		GTX 327 Power
5	3A		wire DM3 Gooseneck light
6	10A		GNS 430W COM Power
7	5A		GNS 430W GPS Power
8	3A	fuse F10	wire F15 & F16, trim power
9			
10	3A	fuse F14	wire E1 EIS 4000 Power
11			
12			
13			
14			
15			
16			
17			
18	1A		Annuncitor wire 11
19			Stick Grip Trigger
20	10A	fuse F25	Wire P8 Ess Bus Alternate Feed

21	3A	fuse ??
22	3A	fuse F22
23	3A	fuse ??
24	5A	fuse F16
25	3A	
26	10A	
27	1A	
28	7.5A	
29	10A	fuse F5
30	5A	fuse F11
31	10A	
32	2A	
33		
34	2A	fuse F26
35	7.5A	
36	7.5A	
37	10A	fuse F6
38	15A	fuse F3
39		
40		

MAIN BUS

Microair 760 Power
wire D1 EFIS Main Power
PMA 4000/Lighting (Eng Inst, CDI)
wire WL1 Wing Leveler Power
Tach, MP
wire FP1 Boost Pump Power
wire FP3 Boost Pump Relay
wire S1 Starter Contactor
wire L7 Strobe Power
wire F20 Flap Power
Ess Bus Feed
wire DF1 Defrost Fan
Narco 122D Power
CO1 CO Monitor
L10 Landing Light
L11 Taxi Light
wire L1 Nav Light Power
wire PH1 Pitot Heat
wire E6 Hobbs Meter and Oil Press
wire A1 Alt Field CB

BATTERY BUS

The following Battery Bus fuses are in a fuse block on the right baggage bay rib, below the battery:

1	3A	fuse F13	Electronic Ignition
2	3A	fuse F23	EFIS Emer Power
3	2A	fuse F7	Turn and Bank
4	10A	fuse F29	Aux power receptacle (cigar lighter)