



Notes:

1. If the Battery Bus voltage exceeds XX volts, the Crowbar Over Voltage Protection will short to ground. The Standby Alternator Control CB will open, which will force the Standby Alternator Control Relay to open, stopping output from the Standby Alternator.