


> Connection




> Error And Maintenance

When the driver detects the fault, it will stop the machine and indicate the error code through the LED (red, green) or external keyboard. Users can check and repair according to the error code.


● Green light blink once = 5 ● Red light blink once = 1
Error code = Green light blinking times+Red light blinking times

Error Code	Error Name	Error Indication	Error Cause	Treatment Method
1	Hardware accelerated overcurrent	0 green 1 red	1. Excessive acceleration and deceleration	1. Increase time of acceleration/deceleration
2	Hardware deceleration overcurrent	0 green 2 red	2. Low voltage	2. Check input voltage
3	Hardware constant overcurrent	0 green 3 red	3. The power of driver is low	3. Change to higher power driver
4	Software accelerated overcurrent	0 green 4 red	4. Shock load	4. Check whether load is normal
5	Software deceleration overcurrent	0 green 5 red	5. Interphase short circuit	5. Check/change cables or motor
6	Software constant overcurrent	1 green 1 red	6. Strong external interference sources exist	6. Check whether there is strong external interference
7	Overvoltage when accelerating	1 green 2 red	1. High input voltage	1. Check input voltage
8	Overvoltage when decelerating	1 green 3 red	2. Fast forward reverse switching	2. Increase the time gap of switching
9	Overvoltage when constant	1 green 4 red	3. Being pulled by an external power protection	3. Add external braking device
10	Bus under-voltage	1 green 5 red	1. Low supply voltage 2. Acceleration too fast, external power protection 3. Supply voltage drop 4. Driver hardware exception	1. Check power supply 2. Set motor rated current 3. Reduce load, check motor and related devices 4. Seek technical support
11	Motor overload	2 green 1 red	1. Low supply voltage 2. Excessive motor power 3. Motor locked-rotor or sudden load change	1. Check power supply 2. Set motor rated current 3. Reduce load, check motor and related devices
12	Driver overload	2 green 2 red	1. Low supply voltage 2. Excessive acceleration time 3. Overload	1. Check power supply 2. Increase time of acceleration 3. Change to higher power driver
13	Hall error	2 green 3 red	1. Hall line break 2. Strong external interference sources exist	1. Check hall connection cable 2. Check whether there is strong external interference source
14	Locked-rotor	2 green 4 red	1. Overload 2. Motor stuck	1. Check the mechanical connections of the motor 2. Check motor connection cable
19	Current detection error	3 green 4 red	1. Drive hardware damage	1. Change the driver
27	Parameter storage error	5 green 2 red	1. Reach upper limit of erasing time for once power on	1. Power on again
29	Overcurrent feedback error	5 green 4 red	1. Drive hardware damage	1. Change the driver
30	Output phase loss error	5 green 5 red	1. U/V/W output phase loss 2. Drive hardware damage	1. Check the cable connection of U/V/W 2. Change the driver

Internal Power (NPN)
Connection Diagram



External Power (NPN)
Connection Diagram



External Power (PNP)
Connection Diagram

