


Setting up LightBurn – Windows

What You'll Need:

- ☐ Windows Computer
- ☐ USB Thumb Drive
- ☐ Internet Connection
- ☐ USB Cable
- ☐ LightBurn License Key

Software and Driver Installation

- 1 Go to <https://lightburnsoftware.com> and click on **Download / Trial**.



- 2 Select your version of Windows from the list to initiate the download.


[Windows 64-bit version](#)

[Windows 32-bit version](#)

Note:


If you're not sure which version you have, type the words **System Information** into the Search field located at the bottom left corner of your Taskbar. Look for **System Type** to determine if you have version 32 or 64.

- 3 Double-click to launch the Lightburn .exe file.




If you receive the message "Do you want to allow this app to make changes to your device?" Click **Yes**.


- 4 Click **Next** to install LightBurn into the Program Files folder.




- 5 Click **Next** to create a LightBurn folder and shortcut in the Start Menu.



- 6 Click **Next** to create a shortcut to Lightburn on your desktop.




- 7 Click **Install** to continue.




Setting up LightBurn – Windows

- 8 If applicable, check the box to confirm you have read and accept the Microsoft Visual license terms, and click **Install**.




- 9 When the installation is complete, click **Finish**.




- 10 If applicable, check the box to confirm you agree to the Microsoft Visual license terms and conditions, and click **Install**.




- 11 Check both **Install FTDI serial driver** and **Launch LightBurn**. Click **Finish**.




- 12 Click **Extract** to unpack the Windows driver and launch the installer.



- 13 Click **Next** to continue.




- 14 Click **Allow access** to allow LightBurn to communicate on the selected networks.




LightBurn will automatically launch.

Setting up LightBurn – Windows


- 15 Copy and paste your LightBurn License Key, which can be found in your Getting Started email. Then click the **Activate License** button, and click **OK**.




- 2 If the Devices Window is open, click **Import**. If not, click the **Devices** button in the Laser Window, and then click **Import**.



- 3 Navigate to the **USB Drive** on your computer, and open the **Settings** folder.



- 4 Select the file ending in **USB.ldev**, and click **Open**.



Connecting via USB


- 1 Plug the USB thumb drive that came with your laser into an open USB port on your computer.




Setting up LightBurn - Windows



- 5 Select the new USB device from the Devices list and click **OK**.



- 6 In the Laser Window, select the new USB device from the dropdown menu.



- 7 Plug one end of the USB cable that came with your laser, directly into an open USB port on your computer.




Note:

USB cables longer than 10 feet, and USB hubs, are not recommended.




- 8 Plug the other end of the supplied USB cable into the bottom USB port, on the right side of the machine.

- 9 In the Laser Window, right-click the **Devices** button to reset the connection. It should now say **Ready**.



Congratulations! LightBurn is now paired with your laser via USB.





Setting up LightBurn - Windows

Connect via WiFi


- 1 Plug the USB thumb drive that came with your laser into an open USB port on your computer.




- 2 In the Laser window, click the **Devices** button.




- 3 In the Devices window, click the **Import** button.



- 4 Navigate to the **USB Drive** on your computer, and open the **Settings** folder.




- 5 Select the file ending in **WiFi.lbdev**, and click **Open**.




Setting up LightBurn - Windows


- 6 Select the new WiFi device from the Devices list and click **OK**.



- 7 In the Laser Window, select the new WiFi device from the dropdown menu.



- 8 In Windows, click on the WiFi symbol at the bottom, right-hand corner of your Taskbar.




- 9 Select your laser from the list of available WiFi connections and click **Connect**.

Note:

You will not be able to access the internet via WiFi when connected to the laser.

- 10 In the Laser Window, right-click the **Devices** button to reset the connection. It should now say **Ready**.



Congratulations! LightBurn is now paired with your laser via WiFi. You are now ready to create wirelessly!

