



# Install or recover a management node

HCI

NetApp

August 20, 2020

This PDF was generated from [https://docs.netapp.com/us-en/hci/docs/task\\_mnode\\_install.html](https://docs.netapp.com/us-en/hci/docs/task_mnode_install.html) on August 20, 2020.  
Always check [docs.netapp.com](https://docs.netapp.com) for the latest.

# Table of Contents

- Install or recover a management node ..... 1
  - Install a management node ..... 1
  - Configure a storage Network Interface Controller (NIC) ..... 6
  - Recover a management node ..... 8

# Install or recover a management node

## Install a management node

You can manually install the management node for your cluster running NetApp Element software using the appropriate image for your configuration.

This manual process is intended for SolidFire all-flash storage administrators and NetApp HCI administrators who are not using the NetApp Deployment Engine for management node installation.

*What you'll need*

- Your cluster version is running NetApp Element software 11.3 or later.
- Your installation uses IPv4. The management node 11.3 does not support IPv6.



If you need to IPv6 support, you can use the management node 11.1.

- You have permission to download software from the NetApp Support Site.
- You have identified the management node image type that is correct for your platform:

| Platform          | Installation image type |
|-------------------|-------------------------|
| Microsoft Hyper-V | .iso                    |
| KVM               | .iso                    |
| VMware vSphere    | .iso, .ova              |
| Citrix XenServer  | .iso                    |
| OpenStack         | .iso                    |

*About this task*

Prior to following this procedure, you should have an understanding of [persistent volumes](#) and whether or not you want to use them.

*Steps*

1. [Download ISO or OVA and deploy the VM](#)
2. [Create the management node admin and configure the network](#)
3. [Configure the management node](#)
4. [Configure controller assets](#)
5. (NetApp HCI only) [Configure compute node assets](#)

## Download ISO or OVA and deploy the VM

1. Download the OVA or ISO for your installation from the NetApp Support Site:

Element software: <https://mysupport.netapp.com/site/products/all/details/element-software/downloads-tab>

NetApp HCI: <https://mysupport.netapp.com/site/products/all/details/netapp-hci/downloads-tab>

- a. Click **Download Latest Release** and accept the EULA.
  - b. Select the management node image you want to download.
2. If you downloaded the OVA, follow these steps:
    - a. Deploy the OVA.
    - b. If your storage cluster is on a separate subnet from your management node (eth0) and you want to use persistent volumes, add a second network interface controller (NIC) to the VM on the storage subnet (for example, eth1) or ensure that the management network can route to the storage network.
  3. If you downloaded the ISO, follow these steps:
    - a. Create a new 64-bit virtual machine from your hypervisor with the following configuration:
      - Six virtual CPUs
      - 12GB RAM
      - 400GB virtual disk, thin provisioned
      - One virtual network interface with internet access and access to the storage MVIP.
      - (Optional for SolidFire all-flash storage) One virtual network interface with management network access to the storage cluster. If your storage cluster is on a separate subnet from your management node (eth0) and you want to use persistent volumes, add a second network interface controller (NIC) to the VM on the storage subnet (eth1) or ensure that the management network can route to the storage network.



Do not power on the virtual machine prior to the step indicating to do so later in this procedure.

- b. Attach the ISO to the virtual machine and boot to the .iso install image.



Installing a management node using the image might result in 30-second delay before the splash screen appears.

4. Power on the virtual machine for the management node after the installation completes.

## Create the management node admin and configure the network

1. Using the terminal user interface (TUI), create a management node admin user.



To move through the menu options, press the Up or Down arrow keys. To move through the buttons, press Tab. To move from the buttons to the fields, press Tab. To navigate between fields, press the Up or Down arrow keys.

2. Configure the management node network (eth0).



If you need an additional NIC to isolate storage traffic, see instructions on configuring another NIC: [Configure a storage Network Interface Controller \(NIC\)](#).

## Configure the management node

1. SSH into the management node.
2. Using SSH, run the following command to gain root privileges. Enter your password when prompted:

```
sudo su
```

3. Ensure time is synced (NTP) between the management node and the storage cluster.



In vSphere, the **Synchronize guest time with host** box should be checked in the VM options. Do not disable this option if you make future changes to the VM.

4. Configure and run the management node setup command:



You will be prompted to enter passwords in a secure prompt. If your cluster is behind a proxy server, you must configure the proxy settings so you can reach a public network.

```
/sf/packages/mnode/setup-mnode --mnode_admin_user [username] --storage_mvip [mvip] --storage_username [username] --telemetry_active [true]
```

- a. Replace the value in [ ] brackets (including the brackets) for each of the following required parameters:



The abbreviated form of the command name is in parentheses ( ) and can be substituted for the full name.

- **--mnode\_admin\_user (-mu) [username]**: The username for the management node administrator account. This is likely to be the username for the user account you used to log into the management node.
- **--storage\_mvip (-sm) [MVIP address]**: The management virtual IP address (MVIP) of the

storage cluster running Element software.

- **--storage\_username (-su) [username]:** The storage cluster administrator username for the cluster specified by the **--storage\_mvip** parameter.
- **--telemetry\_active (-t) [true]:** Retain the value true that enables data collection for analytics by Active IQ.

b. (Optional): Add Active IQ endpoint parameters to the command:

- **--remote\_host (-rh) [AIQ\_endpoint]:** The endpoint where Active IQ telemetry data is sent to be processed. If the parameter is not included, the default endpoint is used.

c. (Optional): Add the following persistent volume parameters. Do not modify or delete the account and volumes created for persistent volumes functionality or a loss in management capability will result.

- **--use\_persistent\_volumes (-pv) [true/false, default: false]:** Enable or disable persistent volumes. Enter the value true to enable persistent volumes functionality.
- **--persistent\_volumes\_account (-pva) [account\_name]:** If **--use\_persistent\_volumes** is set to true, use this parameter and enter the storage account name that will be used for persistent volumes.



Use a unique account name for persistent volumes that is different from any existing account name on the cluster. It is critically important to keep the account for persistent volumes separate from the rest of your environment.

- **--persistent\_volumes\_mvip (-pvm) [mvip]:** Enter the management virtual IP address (MVIP) of the storage cluster running Element software that will be used with persistent volumes. This is only required if multiple storage clusters are managed by the management node. If multiple clusters are not managed, the default cluster MVIP will be used.

d. Configure a proxy server:

- **--use\_proxy (-up) [true/false, default: false]:** Enable or disable the use of the proxy. This parameter is required to configure a proxy server.
- **--proxy\_hostname\_or\_ip (-pi) [host]:** The proxy hostname or IP. This is required if you want to use a proxy. If you specify this, you will be prompted to input **--proxy\_port**.
- **--proxy\_username (-pu) [username]:** The proxy username. This parameter is optional.
- **--proxy\_password (-pp) [password]:** The proxy password. This parameter is optional.
- **--proxy\_port (-pq) [port, default: 0]:** The proxy port. If you specify this, you will be prompted to input the proxy host name or IP (**--proxy\_hostname\_or\_ip**).
- **--proxy\_ssh\_port (-ps) [port, default: 443]:** The SSH proxy port. This defaults to port 443.

e. (Optional) Use parameter help if you need additional information about each parameter:

- **--help (-h):** Returns information about each parameter. Parameters are defined as required

or optional based on initial deployment. Upgrade and redeployment parameter requirements might vary.

- f. Run the `setup-mnode` command.

## Configure controller assets

1. Locate the installation ID:
  - a. From a browser, log into the management node REST API UI:
  - b. Go to the storage MVIP and log in. This action causes the certificate to be accepted for the next step.
  - c. Open the inventory service REST API UI on the management node:

```
https://[management node IP]/inventory/1/
```

- d. Click **Authorize** and complete the following:
  - i. Enter the cluster user name and password.
  - ii. Enter the client ID as `mnode-client`.
  - iii. Click **Authorize** to begin a session.
- e. From the REST API UI, click **GET /installations**.
- f. Click **Try it out**.
- g. Click **Execute**.
- h. From the code 200 response body, copy and save the `id` for the installation for use in a later step.

Your installation has a base asset configuration that was created during installation or upgrade.

2. (NetApp HCI only) Locate the hardware tag for your compute node in vSphere:
  - a. Select the host in the vSphere Web Client navigator.
  - b. Click the **Monitor** tab, and click **Hardware Health**.
  - c. The node BIOS manufacturer and model number are listed. Copy and save the value for `tag` for use in a later step.
3. Add a vCenter controller asset for NetApp HCI monitoring (NetApp HCI installations only) and Hybrid Cloud Control (for all installations) to the management node known assets:
  - a. Access the mnode service API UI on the management node by entering the management node IP address followed by `/mnode`:

```
https://[management node IP]/mnode
```

- b. Click **Authorize** or any lock icon and complete the following:
  - i. Enter the cluster user name and password.
  - ii. Enter the client ID as `mnode-client`.
  - iii. Click **Authorize** to begin a session.
  - iv. Close the window.
- c. Click **POST /assets/{asset\_id}/controllers** to add a controller sub-asset.
- d. Click **Try it out**.
- e. Enter the parent base asset ID you copied to your clipboard in the **asset\_id** field.
- f. Enter the required payload values with type `vCenter` and vCenter credentials.
- g. Click **Execute**.

## (NetApp HCI only) Configure compute node assets

1. (For NetApp HCI only) Add a compute node asset to the management node known assets:
  - a. Click **POST /assets/{asset\_id}/compute-nodes** to add a compute node sub-asset with credentials for the compute node asset.
  - b. Click **Try it out**.
  - c. Enter the parent base asset ID you copied to your clipboard in the **asset\_id** field.
  - d. In the payload, enter the required payload values as defined in the Model tab. Enter `ESXi Host` as `type` and enter the hardware tag you saved during a previous step for `hardware_tag`.
  - e. Click **Execute**.

## Find more Information

- [Persistent volumes](#)
- [Add an asset to the management node](#)
- [Configure a storage NIC](#)
- [NetApp HCI Documentation Center](#)
- [NetApp HCI Resources Page](#)

## Configure a storage Network Interface Controller (NIC)

If you are using an additional NIC for storage, you can SSH in to the management node or use the vCenter console and run a curl command to set up that network interface.

*Before you begin*



- You know your eth0 IP address.
- Your cluster version is running NetApp Element software 11.3 or later.
- You have deployed a management node 11.3 or later.

### Steps

1. Open an SSH or vCenter console.
2. Replace the values in the following command template and run the command:



Values are represented by **\$** for each of the required parameters for your new storage network interface. The **cluster** object in the following template is required and can be used for management node host name renaming. The **--insecure** or **-k** options should not be used in production environments.

```
curl -u $mnode_user_name:$mnode_password --insecure -X POST \
https://$mnode_IP:442/json-rpc/10.0 \
-H 'Content-Type: application/json' \
-H 'cache-control: no-cache' \
-d '{
  "params": {
    "network": {
      "$eth1": {
        "#default" : false,
        "address" : "$storage_IP",
        "auto" : true,
        "family" : "inet",
        "method" : "static",
        "mtu" : "9000",
        "netmask" : "$subnet_mask",
        "status" : "Up"
      }
    },
    "cluster": {
      "name": "$mnode_host_name"
    }
  },
  "method": "SetConfig"
}
```

## Find more Information

- [Add an asset to the management node](#)
- [NetApp HCI Documentation Center](#)

- [NetApp HCI Resources Page](#)

## Recover a management node

You can manually recover and redeploy the management node for your cluster running NetApp Element software if your previous management node used persistent volumes.

You can deploy a new OVA and run a redeploy script to pull configuration data from a previously installed management node running version 11.3 and later.

### *Before you begin*

- Your previous management node was running NetApp Element software version 11.3 or later with persistent volumes functionality engaged.
- You know the MVIP and SVIP of the cluster containing the persistent volumes.
- Your cluster version is running NetApp Element software 11.3 or later.
- Your installation uses IPv4. The management node 11.3 does not support IPv6.
- You have permission to download software from the NetApp Support Site.
- You have identified the management node image type that is correct for your platform:

| Platform          | Installation image type |
|-------------------|-------------------------|
| Microsoft Hyper-V | .iso                    |
| KVM               | .iso                    |
| VMware vSphere    | .iso, .ova              |
| Citrix XenServer  | .iso                    |
| OpenStack         | .iso                    |

### *About this task*

Prior to completing this procedure, you should have an understanding of [persistent volumes](#) and whether or not you want to use them.

- [Download ISO or OVA and deploy the VM](#)
- [Configure the network](#)
- [Configure the management node](#)

## Download ISO or OVA and deploy the VM

1. Download the OVA or ISO for your installation from the NetApp Support Site:

Element software: <https://mysupport.netapp.com/site/products/all/details/element-software/downloads-tab>

NetApp HCI: <https://mysupport.netapp.com/site/products/all/details/netapp-hci/downloads-tab>

- a. Click **Download Latest Release** and accept the EULA.
  - b. Select the management node image you want to download.
2. If you downloaded the OVA, follow these steps:
- a. Deploy the OVA.
  - b. If your storage cluster is on a separate subnet from your management node (eth0) and you want to use persistent volumes, add a second network interface controller (NIC) to the VM on the storage subnet (for example, eth1) or ensure that the management network can route to the storage network.
3. If you downloaded the ISO, follow these steps:
- a. Create a new 64-bit virtual machine from your hypervisor with the following configuration:
    - Six virtual CPUs
    - 12GB RAM
    - 400GB virtual disk, thin provisioned
    - One virtual network interface with internet access and access to the storage MVIP.
    - (Optional for SolidFire all-flash storage) One virtual network interface with management network access to the storage cluster. If your storage cluster is on a separate subnet from your management node (eth0) and you want to use persistent volumes, add a second network interface controller (NIC) to the VM on the storage subnet (eth1) or ensure that the management network can route to the storage network.



Do not power on the virtual machine prior to the step indicating to do so later in this procedure.

- b. Attach the ISO to the virtual machine and boot to the .iso install image.



Installing a management node using the image might result in 30-second delay before the splash screen appears.

4. Power on the virtual machine for the management node after the installation completes.

## Configure the network

1. Using the terminal user interface (TUI), create a management node admin user.



To move through the menu options, press the Up or Down arrow keys. To move through the buttons, press Tab. To move from the buttons to the fields, press Tab. To navigate between fields, press the Up or Down arrow keys.

2. Configure the management node network (eth0).



If you need an additional NIC to isolate storage traffic, see instructions on configuring another NIC: [Configure a storage Network Interface Controller \(NIC\)](#).

## Configure the management node

1. SSH into the management node or use the console provided by your hypervisor.
2. Using SSH, run the following command to gain root privileges. Enter your password when prompted:

```
sudo su
```

3. Ensure time is synced (NTP) between the management node and the storage cluster.



In vSphere, the **Synchronize guest time with host** box should be checked in the VM options. Do not disable this option if you make future changes to the VM.

4. Configure and run the management node redeploy command to connect to persistent volumes hosted on the cluster and start services with previous management node configuration data:



You will be prompted to enter passwords in a secure prompt. If your cluster is behind a proxy server, you must configure the proxy settings so you can reach a public network.

```
/sf/packages/mnode/redeploy-mnode --mnode_admin_user [username]
```

- a. Replace the value in [ ] brackets (including the brackets) for each of the following required parameters:



The abbreviated form of the command name is in parentheses ( ) and can be substituted for the full name. You can add the following required parameters or allow the script to prompt you for the information.

- **--mnode\_admin\_user (-mu) [username]**: The username for the management node administrator account. This is likely to be the username for the user account you used to log into the management node.

- **--storage\_mvip (-sm) [MVIP address]:** The management virtual IP address (MVIP) of the storage cluster running Element software with the persistent volumes that contain management node data for recovery.
  - **--storage\_username (-su) [username]:** The storage cluster administrator username for the cluster specified by the **--storage\_mvip** parameter.
  - **--persistent\_volumes\_account (-pva) [account\_name]:** Enter the storage account name from the cluster containing the persistent volumes. This is the exact name of the storage user account that owns the volumes in the cluster.
- b. (Optional) Use parameter help if you need additional information about each parameter:
- **--help (-h):** Returns information about each parameter. Parameters are defined as required or optional based on initial deployment. Upgrade and redeployment parameter requirements might vary.
- c. Run the **redeploy-mnode** command.

## Find more Information

- [Persistent volumes](#)
- [NetApp HCI Documentation Center](#)
- [NetApp HCI Resources Page](#)

## Copyright Information

Copyright © 2020 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system-without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

## Trademark Information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.