

Subject: How to enable ARM CC floating compiler for Shasta

1. go to Shasta_fw/tools/arm
2. copy and paste Default_TOOLS.ini
3. rename the newly copied file to TOOLS.ini

Inside the TOOLS.ini will contain the ARM compiler remote server.

