



# Data Collector Reference - Infrastructure

## Cloud Insights

NetApp

April 24, 2020

This PDF was generated from [https://docs.netapp.com/us-en/cloudinsights/concept\\_data\\_collector\\_reference.html](https://docs.netapp.com/us-en/cloudinsights/concept_data_collector_reference.html) on April 24, 2020. Always check docs.netapp.com for the latest.



# Table of Contents

Data Collector Reference - Infrastructure .....	1
Vendor-Specific Reference .....	1
Configuring the Amazon EC2 data collector .....	1
Configuring the Azure compute data collector .....	4
Broadcom .....	5
Ceph storage data collector .....	9
Cisco MDS Fabric Switches data collector .....	11
Dell .....	14
Dell EMC .....	15
Fujitsu Eternus data collector .....	37
NetApp Google Compute data collector .....	39
HP Enterprise .....	39
Hitachi Data Systems .....	48
Infinidat InfiniBox data collector .....	55
Huawei OceanStor data collector .....	56
IBM .....	57
Lenovo data collector .....	66
Microsoft .....	67
NetApp .....	70
Nutanix NX data collector .....	85
OpenStack data collector .....	87
Oracle ZFS Storage Appliance data collector .....	89
Pure Storage FlashArray data collector .....	90
Red Hat Virtualization data collector .....	92
Configuring the VMware VSphere data collector .....	93

# Data Collector Reference - Infrastructure

## Vendor-Specific Reference

The topics in this section provide vendor-specific reference information. In most cases, configuring a data collector is straightforward. In some cases, you may need additional information or commands to properly configure the data collector.

Click on a **vendor** in the menu to the left to see information for their data collectors.

## Configuring the Amazon EC2 data collector

Cloud Insights uses the Amazon EC2 data collector to acquire inventory and performance data from EC2 instances.

### Requirements

In order to collect data from Amazon EC2 devices, you must have the following information:

- You must have the IAM Access Key ID
- You must have the Secret Access Key for your Amazon EC2 cloud account
- You must have the "list organization" privilege
- Port 433 HTTPS
- EC2 Instances can be reported as a Virtual Machine, or (less naturally) a Host. EBS Volumes can be reported as both a VirtualDisk used by the VM, as well as a DataStore providing the Capacity for the VirtualDisk.

Access keys consist of an access key ID (for example, AKIAIOSFODNN7EXAMPLE) and a secret access key (for example, wJalrXUtnFEMI/K7MDENG/bPxRfiCYEXAMPLEKEY). You use access keys to sign programmatic requests that you make to EC2 if you use the Amazon EC2 SDKs, REST, or Query API operations. These keys are provided with your contract from Amazon.

### Configuration

Enter data into the data collector fields according to the table below:

Field	Description
AWS Region	Choose AWS region

Field	Description
IAM Role	AWS IAM Role if running on EC2 instance to retrieve IAM temporary access key, secret and token. Required if you do not use IAM Access Key ID and Secret Access Key fields. See below for more information on <a href="#">IAM Roles</a> .
AWS IAM Access Key ID	Enter AWS IAM Access Key ID. Required if you do not use IAM Role.
AWS IAM Secret Access Key	Enter AWS IAM Secret Access Key. Required if you do not use IAM Role.
I understand AWS bills me for API requests	Check this to verify your understanding that AWS bills you for API requests made by Cloud Insights polling.

## Advanced Configuration

Field	Description
Include Extra Regions	Specify additional regions to include in polling.
Cross Account Role	Role for accessing resources in different AWS accounts.
Inventory Poll Interval (min)	The default is 60
Choose 'Exclude' or 'Include' to Apply to Filter VMs by Tags	Specify whether to include or exclude VM's by Tags when collecting data. If 'Include' is selected, the Tag Key field can not be empty.
Tag Keys and Values on which to Filter VMs	Click + <b>Filter Tag</b> to choose which VMs (and associated disks) to include/exclude by filtering for keys and values that match keys and values of tags on the VM. Tag Key is required, Tag Value is optional. When Tag Value is empty, the VM is filtered as long as it matches the Tag Key.
Performance Poll Interval (sec)	The default is 1800

## Mapping Amazon tags to Cloud Insights annotations

The Amazon EC2 data collector includes an option that allows you to populate Cloud Insights annotations with tags configured on EC2. The annotations must be named exactly as the EC2 tags. Cloud Insights will always populate same-named text-type annotations, and will make a "best attempt" to populate annotations of other types (number, boolean, etc). If your annotation is of a different type and the data collector fails to populate it, it may be necessary to remove the annotation and re-create it as a text type.

Note that AWS is case-sensitive, while Cloud Insights is case-insensitive. So if you create an annotation named "OWNER" in Cloud Insights, and tags named "OWNER", "Owner", and "owner" in EC2, all of the EC2 variations of "owner" will map to Cloud Insight's "OWNER" annotation.

#### *Related Information*

- [Managing Access Keys for IAM Users](#)

## **Include Extra Regions**

In the AWS Data Collector **Advanced Configuration** section, you can set the **Include extra regions** field to include additional regions, separated by comma or semi-colon. By default, this field is set to **us-.\***, which collects on all US AWS regions. To collect on *all* regions, set this field to **.\***.

If the **Include extra regions** field is empty, the data collector will collect on assets specified in the **AWS Region** field as specified in the **Configuration** section.

## **Collecting from AWS Child Accounts**

Cloud Insights supports collection of child accounts for AWS within a single AWS data collector. Configuration for this collection is performed in the AWS environment:

- You must configure each child account to have an AWS Role that allows the master account ID to access EC2 details from the children account.
- Each child account must have the role name configured as the same string.
- Enter this role name string into the Cloud Insights AWS Data Collector **Advanced Configuration** section, in the **Cross account role** field.

Best Practice: It is highly recommended to assign the AWS predefined *AmazonEC2ReadOnlyAccess* policy to the ECS master account. Also, the user configured in the data source should have at least the predefined *AWSOrganizationsReadOnlyAccess* policy assigned, in order to query AWS.

Please see the following for information on configuring your environment to allow Cloud Insights to collect from AWS child accounts:

[Tutorial: Delegate Access Across AWS Accounts Using IAM Roles](#)

[AWS Setup: Providing Access to an IAM User in Another AWS Account That You Own](#)

[Creating a Role to Delegate Permissions to an IAM User](#)

## **IAM Roles**

When using *IAM Role* security, you must ensure that the role you create or specify has the appropriate permissions needed to access your resources.

For example, if you create an IAM role named *InstanceEc2ReadOnly*, you must set up the policy to grant EC2 read-only list access permission to all EC2 resources for this IAM role. Additionally, you must

grant STS (Security Token Service) access so that this role is allowed to assume roles cross accounts.

After you create an IAM role, you can attach it when you create a new EC2 instance or any existing EC2 instance.

After you attach the IAM role *InstanceEc2ReadOnly* to an EC2 instance, you will be able to retrieve the temporary credential through instance metadata by IAM role name and use it to access AWS resources by any application running on this EC2 instance.

Note: IAM role can be used only when the Acquisition Unit is running in an AWS instance.

## Troubleshooting

Additional information on this Data Collector may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

# Configuring the Azure compute data collector

Cloud Insights uses the Azure compute data collector to acquire inventory and performance data from Azure compute instances.

## Requirements

You need the following information to configure this data collector.

- Port requirement: 443 HTTPS
- Azure Management Rest IP (management.azure.com)
- Azure service principal client ID (user account)
- Azure service principal authentication key (user password)
- You need to set up an Azure account for Cloud Insights discovery.

Once the account is properly configured and you register the application in Azure, you will have the credentials required to discover the Azure instance with Cloud Insights. The following link describes how to set up the account for discovery:

<https://docs.microsoft.com/en-us/azure/active-directory/develop/howto-create-service-principal-portal>

## Configuration

Enter data into the data collector fields according to the table below:

Field	Description
Azure Service Principal Client ID	Sign-in ID to Azure

Field	Description
Azure tenant ID	Microsoft tenant ID
Azure Service Principal Authentication Key	Login authentication key
I understand Microsoft bills me for API requests	Check this to verify your understanding that Microsoft bills you for API requests made by Insight polling.

## Advanced Configuration

Field	Description
Inventory Poll Interval (min)	The default is 60
Choose 'Exclude' or 'Include' to Apply to Filter VMs by Tags	Specify whether to include or exclude VM's by Tags when collecting data. If 'Include' is selected, the Tag Key field can not be empty.
Tag Keys and Values on which to Filter VMs	Click + <b>Filter Tag</b> to choose which VMs (and associated disks) to include/exclude by filtering for keys and values that match keys and values of tags on the VM. Tag Key is required, Tag Value is optional. When Tag Value is empty, the VM is filtered as long as it matches the Tag Key.
Performance Poll Interval (sec)	The default is 300

## Troubleshooting

Additional information on this Data Collector may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

## Broadcom

### Brocade Network Advisor data collector

Cloud Insights uses the Brocade Network Advisor data collector to acquire inventory and performance data from Brocade switches.

### Terminology

Cloud Insights acquires the following inventory information from the Brocade Network Advisor data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Switch	Switch
Port	Port
Virtual Fabric, Physical Fabric	Fabric
Logical Switch	Logical Switch

Note: These are common terminology mappings only and might not represent every case for this data collector.

## Requirements

The following are required to configure this data collector:

- Brocade Network Advisor Server IP address
- User name and password to an administrator account
- Port requirement: HTTP/HTTPS 443

## Configuration

Field	Description
Brocade Network Advisor Server IP	IP address of the Network Advisor Server
User Name	User name for the switch
User Name	Administrator user name
Password	Administrator password

## Advanced configuration

Field	Description
Connection Type	HTTPS (default port 443) or HTTP (default port 80)
Override Connection Port	If blank, use the default port in the Connection Type field, otherwise enter the connection port to use
Password	Password for the switch
Inventory poll interval (min)	The default is 40
Report Access Gateway	Check to include devices in Access Gateway mode
Performance Poll Interval (sec)	The default is 1800

## Troubleshooting

Some things to try if you encounter problems with this data collector:



## Inventory

Problem:	Try this:
Receive a message that more than 1 node is logged into the Access Gateway port, or data collector fails to discover Access Gateway device.	Check that the NPV device is operating correctly and that all connected WWNs are expected. Do not directly acquire the NPV device. Instead, acquisition of the core fabric switch will collect the NPV device data.

Additional information may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

## Brocade FC Switch data collector

Cloud Insights uses the Brocade FC Switch (SSH) data source to discover inventory for Brocade or rebranded switch devices running Factored Operating System (FOS) firmware 4.2 and later. Devices in both FC switch and Access Gateway modes are supported.

## Terminology

Cloud Insights acquires the following inventory information from the Brocade FC Switch data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Switch	Switch
Port	Port
Virtual Fabric, Physical Fabric	Fabric
Zone	Zone
Logical Switch	Logical Switch
Virtual Volume	Volume
LSAN Zone	IVR Zone

Note: These are common terminology mappings only and might not represent every case for this data collector.

## Requirements

- There must be IP connectivity to all switches in the fabric. If you select the Discover all switches in the fabric check box, Cloud Insights identifies all the switches in the fabric; however, it needs IP connectivity to these additional switches to discover them.
- The same account is needed globally across all switches in the fabric. You can use PuTTY (open source terminal emulator) to confirm access.

- Ports 161 and 162 must be open to all switches in the fabric for SNMP performance polling.
- SNMP read-only Community String

## Configuration

Field	Description
Switch IP	IP address or fully-qualified domain name of the EFC Server
User Name	User name for the switch
Password	Password for the switch
SNMP	SNMP version
SNMP Community String	SNMP read-only community string used to access the switch
SNMP User Name	SNMP user name
SNMP Password	SNMP password

## Advanced configuration

Field	Description
Fabric name	Fabric name to be reported by the data collector. Leave blank to report the fabric name as WWN.
Inventory Poll Interval (min)	Interval between inventory polls. The default is 15.
Excluded Devices	Comma-separated list of device IDs to exclude from polling
Admin Domains Active	Select if using Admin Domains
Retrieve MPR Data	Select to acquire routing data from your multiprotocol router.
Enable Trapping	Select to enable acquisition upon receiving an SNMP trap from the device. If you select enable trapping, you must also activate SNMP.
Minimum Time Between Traps (sec)	Minimum time between acquisition attempts triggered by traps. The default is 10.
Discover all switches in the fabric	Select to discover all switches in the fabric
Choose Favoring HBA vs. Zone Aliases	Choose whether to favor HBA or zone aliases
Performance Poll Interval (sec)	Interval between performance polls. The default is 300.

Field	Description
SNMP Auth Protocol	SNMP authentication protocol (SNMP v3 only)
SNMP Privacy Password	SNMP privacy password (SNMP v3 only)
SNMP Retries	Number of SNMP retry attempts

## Troubleshooting

Some things to try if you encounter problems with this data collector:

## Inventory

Problem:	Try this:
Error: “Cloud Insights received Invalid Chassis Role”	Check that the user configured in this data source has been granted the chassis role permission.
Error: "Mismatched Chassis IP Address"	Change the data source configuration to use chassis IP address.
Receive a message that more than 1 node is logged into the Access Gateway port	Check that the NPV device is operating correctly and that all connected WWNs are expected. Do not directly acquire the NPV device. Instead, acquisition of the core fabric switch will collect the NPV device data.

Additional information may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

# Ceph storage data collector

Cloud Insights uses the Ceph storage data collector to discover inventory data from the Ceph storage platform.

## Terminology

Cloud Insights acquires inventory information with the Ceph storage data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Pool	Storage Pool
FileSystem	Internal Volume
OSD	Backend LUN

Note: These are common terminology mappings only and might not represent every case for this data

source.

## Requirements

- The Ceph administrator IP address
- Administrator user name and password
- Port requirement: SSH Port 22

## Configuration

Field	Description
Ceph admin IP address	Ip address for the for the Ceph storage
User name	User name for the Ceph storage system administrator user account
Password	Password for the administrator user account

## Advanced configuration

Field	Description
Inventory poll interval (min)	Interval between inventory polls. The default is 60 minutes.
SSH port	The default is port 22.

## Troubleshooting

Some things to try if you encounter problems with this data collector:

### Inventory

Problem:	Try this:
Command missing	Verify that the user has permissions to run the commands noted below on the device * Verify that the ceph adminstration tools are installed, please run the following command: rpm -q ceph-common.x86_64 * Verify credentials used in the wizard match device credentials

Problem:	Try this:
Invalid configuration	<ul style="list-style-type: none"> <li>* Verify that the pools are configured in the system, try running the following command: <code>ceph osd lspools -f json-pretty</code></li> <li>* Verify credentials used in the wizard match device credentials</li> </ul>

Additional information may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

## Cisco MDS Fabric Switches data collector

Cloud Insights uses the Cisco MDS Fabric Switches data collector to discover inventory for Cisco MDS Fabric Switches as well as a variety of Cisco Nexus FCoE switches on which the FC service is enabled.

Additionally, you can discover many models of Cisco devices running in NPV mode with this data collector.

### Terminology

Cloud Insights acquires the following inventory information from the Cisco FC Switch data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Field	Description
Switch	Switch
Port	Port
VSAN	Fabric
Zone	Zone
Logical Switch	Logical Switch
Name Server Entry	Name Server Entry
Inter-VSAN Routing (IVR) Zone	IVR Zone

Note: These are common terminology mappings only and might not represent every case for this data collector.

### Requirements

- An IP address of one switch in the fabric or individual switches
- Chassis discovery, to enable fabric discovery

- If using SNMP V2, read-only community string
- Port 161 is used to access the device

## Configuration

Field	Description
Cisco Switch IP	IP address or fully-qualified domain name of the switch
SNMP Version	Select V1, V2, or V3. V2 or later is required for performance acquisition.
SNMP Community String	SNMP read-only community string used to access the switch (not applicable for SNMP v3)
User Name	User name for the switch (SNMP v3 only)
Password	Password used for the switch (SNMPv3 only)

## Advanced configuration

Field	Description
Inventory Poll Interval (min)	Interval between inventory polls (default 40 minutes)
SNMP Auth Protocol	SNMP authentication protocol (SNMPv3 only)
SNMP Privacy Protocol	SNMP privacy protocol (SNMPv3 only)
SNMP Privacy Password	SNMP Privacy Password
SNMP Retries	Number of SNMP retry attempts
SNMP Timeout (ms)	SNMP timeout (default 5000 ms)
Enable Trapping	Select to enable trapping. If you enable trapping, you must also activate SNMP notifications.
Minimum Time Between Traps (sec)	Minimum time between acquisition attempts triggered by traps (default 10 seconds)
Discover All Fabric Switches	Select to discover all switches in the fabric
Excluded Devices	Comma-separated list of device IPs to exclude from polling
Included Devices	Comma-separated list of device IPs to include in polling
Check Device Type	Select to accept only those devices that explicitly advertise themselves as Cisco devices

Field	Description
First Alias Type	<p>Provide a first preference for resolution of the alias. Choose from the following:</p> <p><b>Device Alias</b> This is a user-friendly name for a port WWN (pWWN) that can be used in all configuration commands, as required. All switches in the Cisco MDS 9000 Family support Distributed Device Alias Services (device aliases).</p> <p><b>None</b> Do not report any alias.</p> <p><b>Port Description</b> A description to help identify the port in a list of ports.</p> <p><b>Zone Alias (all)</b> A user-friendly name for a port that can be used only for the active configuration. This is the default.</p>
Second Alias Type	Provide a second preference for resolution of the alias
Third Alias Type	Provide a third preference for resolution of the alias
Enable SANTap Proxy Mode Support	Select if your Cisco switch is using SANTap in proxy mode. If you are using EMC RecoverPoint, then you are probably using SANTap.
Performance Poll Interval (sec)	Interval between performance polls (default 300 seconds)

## Troubleshooting

Some things to try if you encounter problems with this data collector:

### Inventory

<b>Problem:</b>	<b>Try this:</b>
Error: Failed to discover chassis - no switches have been discovered	<ul style="list-style-type: none"> <li>• Ping the device with the IP configured</li> <li>• Login to the device using Cisco Device Manager GUI</li> <li>• Login to the device using CLI</li> <li>• Try to run SNMP walk</li> </ul>
Error: Device is not a Cisco MDS switch	<ul style="list-style-type: none"> <li>• Make sure the data source IP configured for the device is correct</li> <li>• Login to the device using Cisco Device Manager GUI</li> <li>• Login to the device using CLI</li> </ul>
Error: Cloud Insights is not able to obtain the switch's WWN.	This may not be a FC or FCoE switch, and as such may not be supported. Make sure the IP/FQDN configured in the datasource is truly a FC/FCoE switch.
Error: Found more than one nodes logged into NPV switch port	Disable direct acquisition of the NPV switch
Error: Could not connect to the switch	<ul style="list-style-type: none"> <li>• Make sure the device is UP</li> <li>• Check the IP address and listening port</li> <li>• Ping the device</li> <li>• Login to the device using Cisco Device Manager GUI</li> <li>• Login to the device using CLI</li> <li>• Run SNMP walk</li> </ul>

## Performance

<b>Problem:</b>	<b>Try this:</b>
Error: Performance acquisition not supported by SNMP v1	<ul style="list-style-type: none"> <li>• Edit Data Source and disable Switch Performance</li> <li>• Modify Data Source and switch configuration to use SNMP v2 or higher</li> </ul>

Additional information may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

# Dell

## Dell XC Series data collector

Cloud Insights uses this data collector to discover inventory and performance information for the Dell XC Series storage arrays.



## Configuration

Field	Description
Prism External IP Address	IP address of the XC server
User Name	User name for the XC server
Password	Password used for the XC server

## Advanced configuration

Field	Description
TCP Port	Port used for TCP communication with the XC server
Inventory Poll Interval (min)	Interval between inventory polls. The default is 60 minutes.
Performance Poll Interval (min)	Interval between performance polls. The default is 300 seconds.

## Troubleshooting

Additional information may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

# Dell EMC

## DELL EMC Data Domain data collector

This data collector gathers inventory and performance information from DELL EMC Data Domain deduplication storage systems. To configure this data collector, there are specific configuration instructions and usage recommendations you must follow.

## Terminology

Cloud Insights acquires the following inventory information from the Data Domain data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Disk	Disk
Array	Storage
FC Port	Port

Vendor/Model Term	Cloud Insights Term
File System	Internal Volume
Quota	Quota
NFS and CIFS share	FileShare

Note: These are common terminology mappings only and might not represent every case for this data collector.

## Requirements

You need the following information to configure this data collector:

- IP address of the Data Domain device
- Read-only user name and password to the Data Domain storage
- SSH port 22

## Configuration

Field	Description
IP address	The IP address or fully-qualified domain name of the Data Domain storage array
User name	The user name for the Data Domain storage array
Password	The password for the Data Domain storage array

## Advanced configuration

Field	Description
Inventory Poll Interval (min)	Interval between inventory polls. The default is 20.
SSH Port	SSH service port

## Troubleshooting

Additional information on this Data Collector may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

## Dell EMC Isilon data collector

Cloud Insights uses the Isilon SSH data collector to acquire inventory and performance data from EMC Isilon scale-out NAS storage.

## Terminology

Cloud Insights acquires the following inventory information from the Isilon data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Drive	Disk
Cluster	Storage
Node	Storage Node
File System	Internal Volume

Note: These are common terminology mappings only and might not represent every case for this data collector.

## Requirements

You need the following information to configure this data collector:

- Administrator permissions to the Isilon storage
- IP address of the Isilon cluster
- SSH access to port 22

## Configuration

Field	Description
IP address	The IP address or fully-qualified domain name of the Isilon cluster
User Name	User name for the Isilon cluster
Password	Password used for the Isilon cluster

## Advanced configuration

Field	Description
Inventory Poll Interval (min)	Interval between inventory polls. The default is 20.
Performance Poll Interval (sec)	Interval between performance polls. The default is 300.
SSH Port	SSH service port. The default is 22.

## Troubleshooting

Some things to try if you encounter problems with this data collector:

### Inventory

Problem:	Try this:
"Invalid login credentials" with error messages "Commands not enabled for role-based administration require root user access"	<ul style="list-style-type: none"><li>* Verify that the user has permissions to run the following commands on the device:<ul style="list-style-type: none"><li>&gt; isi version osrelease</li><li>&gt; isi status -q</li><li>&gt; isi status -n</li><li>&gt; isi devices -d %s</li><li>&gt; isi license</li></ul></li><li>* Verify credentials used in the wizard are matching device credentials</li></ul>
"Internal Error" with error messages "Command <Your command> run failed with permission: <Your current permission>. Sudo command run permission issue"	Verify that the user has sudo permissions to run the following command on the device

Additional information may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

## Dell EMC RecoverPoint data collector

The EMC RecoverPoint data collector gathers inventory information from EMC recoverPoint storage. For configuration, the data collector requires the IP address of the storage processors and a read-only user name and password.

The EMC RecoverPoint data collector gathers the volume-to-volume replication relationships that RecoverPoint coordinates across other storage arrays. Cloud Insights shows a storage array for each RecoverPoint cluster, and collects inventory data for nodes and storage ports on that cluster. No storage pool or volume data is collected.

### Requirements

The following information is required to configure this data collector:

- IP address or fully-qualified domain name of storage processor
- Read-only user name and password
- REST API access via port 443

## Configuration

Field	Description
Address of RecoverPoint	IP address or fully-qualified domain name of RecoverPoint cluster
User Name	User name for the RecoverPoint cluster
Password	Password used for the RecoverPoint cluster

## Advanced configuration

Field	Description
TCP Port	TCP Port used to connect to Recoverpoint cluster
Inventory Poll Interval (minutes)	Interval between inventory polls. The default is 20 minutes.
Excluded Clusters	Comma-separated list of cluster IDs or names to exclude when polling.

## Troubleshooting

Additional information on this Data Collector may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

## DELL EMC ScaleIO data collector

The ScaleIO data collector collects inventory information from ScaleIO storage. For configuration, this data collector requires the ScaleIO gateway address and an admin user name and password.

## Terminology

Cloud Insights acquires the following inventory information from the ScaleIO data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
MDM (Meta Data Manager) Cluster	Storage
SDS (ScaleIO Data Server)	Storage Node
Storage Pool	Storage Pool
Volume	Volume
Device	Disk

Note: These are common terminology mappings only and might not represent every case for this data collector.

## Requirements

- Read-only access to the Admin user account
- Port requirement: HTTPS Port 443

## Configuration

Field	Description
ScaleIO Gateway(s)	IP addresses or FQDNs of ScaleIO gateways, separated by comma (,) or semicolon (;)
User Name	Admin user name used to log in to the ScaleIO device
Password	Password used to log in to the ScaleIO device

## Advanced configuration

Click the Inventory check box to enable inventory collection.

Field	Description
HTTPS port	443
Inventory poll interval (min)	The default is 60.
Connection Timeout (sec)	The default is 60.

## Troubleshooting

Additional information may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

## Configuring the EMC Unity (formerly VNXe) data collector

The DELL EMC Unity data collector provides inventory support for VNXe unified storage arrays. Cloud Insights currently supports iSCSI and NAS protocols.

## Requirements

- The Unity data collector is CLI based; you must install the Unisphere for Unity CLI, (uemcli.exe) onto the acquisition unit where your VNXe data collector resides.
- uemcli.exe uses HTTPS as the transport protocol, so the acquisition unit will need to be able to initiate HTTPS connections to the Unity.
- IP address or fully-qualified domain name of the Unity device

- You must have at least a read-only user for use by the data collector.
- IP address of the managing Solutions enabler server.
- HTTPS on Port 443 is required
- The EMC Unity data collector provides NAS and iSCSI support for inventory; fibre channel volumes will be discovered, but Cloud Insights does not report on FC mapping, masking, or storage ports.

## Terminology

Cloud Insights acquires the following inventory information from the Unity data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Disk	Disk
Storage Array	Storage
Processor	Storage Node
Storage Pool	Storage Pool
General iSCSI Block info, VMWare VMFS	Share
Replication Remote System	Synchronization
iSCSI Node	iSCSI Target Node
iSCSI Initiator	iSCSI Target Initiator

Note: These are common terminology mappings only and might not represent every case for this data source.

## Configuration

Field	Description
Unity Storage	IP address or fully-qualified domain name of the Unity device
User Name	User name for the Unity device
Password	Password for the Unity device
Full Path to the Executable UEMCLI	Full path to the folder containing the <i>uemcli.exe</i> executable

## Advanced configuration

Field	Description
Inventory Poll Interval (min)	Interval between inventory polls. The default is 40 minutes
Unity CLI Port	Port used for the Unity CLI
Performance poll interval (sec)	The default is 300.

## Troubleshooting

Some things to try if you encounter problems with this data collector:

### Inventory

Problem:	Try this:
"Failed to execute external utility" with error messages "Failed to find Unisphere executable uemcli"	<ul style="list-style-type: none"> <li>* Verify correct IP address, username, and password</li> <li>* Confirm that Unisphere CLI is installed on the Cloud Insights Acquisition Unit</li> <li>* Confirm that Unisphere CLI installation directory is correct in the datasource configuration</li> <li>* Confirm that the IP of the VNXe is correct in the configuration of the datasource. From the Cloud Insights Acquisition Unit, open a CMD and change to to the configured installation directory: \${INSTALLDIR}. Try to make a connection with the VNXe device by typing: uemcli -d &lt;Your IP&gt; -u &lt;Your ID&gt; /sys/general show</li> </ul>

Additional information may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

## Dell EMC VMAX and PowerMax Family of Devices data collector

Cloud Insights discovers EMC VMAX and PowerMax storage arrays by using Solutions Enabler symcli commands in conjunction with an existing Solutions Enabler server in your environment. The existing Solutions Enabler server has connectivity to the VMAX/PowerMax storage array through access to gatekeeper volumes.

### Requirements

Before configuring this data collector, you should ensure that Cloud Insights has TCP connectivity to port 2707 on the existing Solutions Enabler server. Cloud Insights discovers all the Symmetrix arrays



that are "Local" to this server, as seen in "symcfg list" output from that server.

- The EMC Solutions Enabler (CLI) with SMI-S provider application must be installed and the version must match or be earlier than the version running on the Solutions Enabler Server.
- A properly configured {installdir}\EMC\SYMAPI\config\netcnfg file is required. This file defines service names for Solutions Enabler servers, as well as the access method (SECURE / NOSECURE /ANY).
- If you require read/write latency at the storage node level, the SMI-S Provider must communicate with a running instance of the UNISPHERE for VMAX application.
- IP address of the managing Solutions Enabler server
- Administrator permissions on the Solutions Enabler (SE) Server
- Read-only user name and password to the SE software
- Solutions Enabler Server 6.5X requirements:
  - MI-S provider 3.3.1 for SMIS-S V1.2 installed
  - After install, run \Program Files\EMC\SYMCLI\bin>stordaemon start storsrvd
- The UNISPHERE for VMAX application must be running and collecting statistics for the EMC VMAX and PowerMax sstorage arrays that are managed by the SMI-S Provider installation
- Access validation: Verify that the SMI-S provider is running: telnet <se\_server> 5988

## Terminology

Cloud Insights acquires the following inventory information from the EMC VMAX/PowerMax data source. For each asset type acquired, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Disk	Disk
Disk Group	Disk Group
Storage	Array Storage
Director	Storage Node
Device Pool, Storage Resource Pool (SRP)	Storage Pool
Device TDev	Volume

Note: These are common terminology mappings only and might not represent every case for this data collector.

## Configuration

**Note:** If SMI-S user authentication is not enabled, the default values in the Cloud Insights data collector

are ignored.

Field	Description
Service Name	Service name as specified in <i>netcnfg</i> file
Full path to CLI	Full path to the folder containing the Symmetrix CLI
SMI-S Host IP Address	IP address of the SMI-S host

### Advanced Configuration

Field	Description
Inventory Poll Interval (min)	Interval between inventory polls. The default is 40 minutes.
Choose 'Exclude' or 'Include' to specify a list	Specify whether to include or exclude the array list below when collecting data.
Inventory Filter Device List	Comma-separated list of device IDs to include or exclude

Field	Description
Connection Caching	<p>Choose connection caching method:</p> <p>* LOCAL means that the Cloud Insights Acquisition service is running on the Solutions Enabler server, which has Fibre Channel connectivity to the Symmetrix arrays you seek to discover, and has access to gatekeeper volumes. This might be seen in some Remote Acquisition Unit (RAU) configurations.</p> <p>* REMOTE_CACHED is the default and should be used in most cases. This uses the NETCNFG file settings to connect using IP to the Solutions Enabler server, which must have Fibre Channel connectivity to the Symmetrix arrays you seek to discover, and has access to Gatekeeper volumes.</p> <p>* In the event that REMOTE_CACHED options make CLI commands fail, use the REMOTE option. Keep in mind that it will slow down the acquisition process (possibly to hours or even days in extreme cases). The NETCNFG file settings are still used for an IP connection to the Solutions Enabler server that has Fibre Channel connectivity to the Symmetrix arrays being discovered.</p> <p><b>Note:</b> This setting does not change Cloud Insights behavior with respect to the arrays listed as REMOTE by the "symcfg list" output. Cloud Insights gathers data only on devices shown as LOCAL by this command.</p>
SMI-S Protocol	Protocol used to connect to the SMI-S provider. Also displays the default port used.
Override SMIS-Port	If blank, use the default port in the Connection Type field, otherwise enter the connection port to use
SMI-S User Name	User name for the SMI-S Provider Host
SMI-S Password	User name for the SMI-S Provider Host
Performance Polling Interval (sec)	Interval between performance polls (default 1000 seconds)

Field	Description
hoose 'Exclude' or 'Include' to specify a list	Specify whether to include or exclude the array list below when collecting performance data
Performance Filter Device List	Comma-separated list of device IDs to include or exclude

## Troubleshooting

Some things to try if you encounter problems with this data collector:

## Inventory

Problem:	Try this:
Error: The feature being requested is not currently licensed	Install the SYMAPI server license.
Error: No devices were found	Make sure Symmetrix devices are configured to be managed by the the Solutions Enabler server: - Run symcfg list -v to see the list of configured Symmetrix devices.
Error: A requested network service was not found in the service file	Make sure the Solutions Enabler Service Name is defined the netcnfg file for Solutions Enabler. This file is usually located under SYMAPI\config\ in the Solutions Enabler client installation.
Error: The remote client/server handshake failed	Check the most recent storsrvd.log* files on the Solutions Enabler host we are trying to discover.
Error: Common name in client certificate not valid	Edit the <i>hosts</i> file on the Solutions Enabler server so that the Acquisition Unit's hostname resolves to the IP address as reported in the storsrvd.log on the Solutions Enabler server.
Error: The function could not obtain memory	Make sure there is enough free memory available in the system to execute Solutions Enabler
Error: Solutions Enabler was unable to serve all data required.	Investigate the health status and load profile of Solutions Enabler

<b>Problem:</b>	<b>Try this:</b>
<p>Error:</p> <ul style="list-style-type: none"> <li>• The "symcfg list -tdev" CLI command may return incorrect data when collected with Solutions Enabler 7.x from a Solutions Enabler server 8.x.</li> <li>• The "symcfg list -srp" CLI command may return incorrect data when collected with Solutions Enabler 8.1.0 or earlier from a Solutions Enabler server 8.3 or later.</li> </ul>	<p>Be sure you are using the same Solutions Enabler major release</p>

Additional information may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

## Dell EMC VNX Block Storage (NaviCLI) data collector

Cloud Insights uses the Dell EMC VNX Block Storage (NaviSec) data collector (formerly CLARiiON) to acquire inventory and performance data.

### Terminology

Cloud Insights acquires the following inventory information from the EMC VNX Block Storage data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

<b>Vendor/Model Term</b>	<b>Cloud Insights Term</b>
Disk	Disk
Storage	Storage
Storage Processor	Storage Node
This Pool, RAID Group	Storage Pool
LUN	Volume

Note: These are common terminology mappings only and might not represent every case for this data source.

### Requirements

The following requirements must be met in order to collect data:

- An IP address of each VNX block storage processor
- Read-only Navisphere username and password to the VNX block storage arrays
- NaviSecCli must be installed on the Cloud Insights AU
- Access validation: Run NaviSecCLI from the Cloud Insights AU to each array using the username

and password.

- Port requirements: 80, 443
- NaviSecCLI version should correspond with the newest FLARE code on your array
- For performance, statistics logging must be enabled.

### NaviSphere command line interface syntax

naviseccli.exe -h <IP address> -user <user> -password <password> -scope <scope>, use 0 for global scope> -port <use 443 by default> command

### Configuration

Field	Description
VNX Block Storage IP Address	IP address or fully-qualified domain name of the VNX block storage
User Name	Name used to log into the VNX block storage device.
Password	Password used to log into the VNX block storage device.
CLI Path to naviseccli.exe	Full path to the folder containing the <i>naviseccli.exe</i> executable

### Advanced Configuration

Field	Description
Inventory Poll Interval (min)	Interval between inventory polls. Default is 40 minutes.
Scope	The secure client scope. The default is Global.
Performance Poll Interval (sec)	Interval between performance polls. The default is 300 seconds.

### Troubleshooting

Some things to try if you encounter problems with this data collector:

#### Inventory

Problem:	Try this:
<p>Error:</p> <ul style="list-style-type: none"> <li>• Agent Not Running</li> <li>• Failed to find naviseccli</li> <li>• Failed to execute any command</li> </ul>	<ul style="list-style-type: none"> <li>• Confirm that NaviSphere CLI is installed on the Cloud Insight Acquisition Unit</li> <li>• You have not selected the "Use secure client" option in the data collector configuration wizard and do not have a non-secure version of Navisphere CLI installed.</li> <li>• Confirm that NaviSphere CLI installation directory is correct in the data collector configuration</li> <li>• Confirm that the IP of the VNX block storage is correct in the data collector configuration: <ul style="list-style-type: none"> <li>• From the Cloud Insights Acquisition Unit: <ul style="list-style-type: none"> <li>- Open a CMD.</li> <li>- Change the directory to the configured installation directory</li> <li>- Try to make a connection with the VNX block storage device by typing “navicli -h {ip} getagent” (replace the {ip} with the actual IP)</li> </ul> </li> </ul> </li> </ul>
<p>Error: 4.29 emc235848 emc241018 getall Failed to parse host alias info</p>	<p>This is likely caused by a FLARE 29 corruption issue of the host initiator database on the array itself. See EMC knowledge base articles: emc235848, emc241018. You can also check <a href="https://now.netapp.com/Knowledgebase/solutionarea.asp?id=kb58128">https://now.netapp.com/Knowledgebase/solutionarea.asp?id=kb58128</a></p>
<p>Error: Unable to retrieve Meta LUNs. Error Executing java -jar navicli.jar</p>	<ul style="list-style-type: none"> <li>• Modify the data collector configuration to use the secure client (recommended)</li> <li>• Install navicli.jar in the CLI path to navicli.exe OR naviseccli.exe</li> <li>• Note: navicli.jar is deprecated as of EMC Navisphere version 6.26</li> <li>• The navicli.jar may be available on <a href="http://powerlink.emc.com">http://powerlink.emc.com</a></li> </ul>
<p>Error: Storage Pools not reporting disks on Service Processor at configured IP address</p>	<p>Configure the data collector with both Service Processor IPs, separated by a comma</p>

<b>Problem:</b>	<b>Try this:</b>
Error: Revision mismatch error	<ul style="list-style-type: none"> <li>• This is usually caused by updating the firmware on the VNX block storage device, but not updating the installation of NaviCLI.exe. This also might be caused by having different devices with different firmwares, but only one CLI installed (with a different firmware version).</li> <li>• Verify that the device and the host are both running identical versions of the software: <ul style="list-style-type: none"> <li>- From the Cloud Insights Acquisition Unit, open a command line window</li> <li>- Change the directory to the configured installation directory</li> <li>- Make a connection with the CLARiiON device by typing “navicli -h \${ip} getagent”</li> <li>- Look for the version number on the first couple of lines. Example: “Agent Rev: 6.16.2 (0.1)”</li> <li>- Look for and compare the version on the first line. Example: “Navisphere CLI Revision 6.07.00.04.07”</li> </ul> </li> </ul>
Error: Unsupported Configuration - No Fibre Channel Ports	The device is not configured with any Fibre Channel ports. Currently, only FC configurations are supported. Verify this version/firmware is supported.

Additional information may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

## DELL EMC VNX File (formerly Celerra Unified Storage System) data collector

This data collector acquires inventory information from the VNX File Storage System. For configuration, this data collector requires the IP address of the storage processors and a read-only user name and password.

### Terminology

Cloud Insights acquires the following inventory information from the VNX File data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

<b>Vendor/Model Term</b>	<b>Cloud Insights Term</b>
Celerra Network Server/Celerra Storage Pool	Storage Pool
File System	Internal Volume



Vendor/Model Term	Cloud Insights Term
Data Mover	Controller
File System mounted on a data mover	File Share
CIFS and NFS Exports	Share
Disk Volume	Backend LUN

Note: These are common terminology mappings only and might not represent every case for this data collector.

## Requirements

You need the following to configure this data collector:

- The IP address of the storage processor
- Read-only user name and password
- SSH port 22

## Configuration

Field	Description
VNX File IP Address	IP address or fully-qualified domain name of the VNX File device
User Name	Name used to log in to the VNX File device
Password	Password used to log in to the VNX File device

## Advanced configuration

Field	Description
Inventory Poll Interval (minutes)	Interval between inventory polls. The default is 20 minutes.

## Troubleshooting

Some things to try if you encounter problems with this data collector:

## Inventory

Problem:	Try this:
Error: Unable to proceed while DART update in progress	Possible solution: Pause the data collector and wait for the DART upgrade to complete before attempting another acquisition request.

Additional information may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

## Configuring the EMC VNX Unified data collector

For configuration, the EMC VNX Unified (SSH) data collector requires the IP address of the Control Station and a read-only username and password.

### Terminology

Cloud Insights acquires the following inventory information from the EMC VNX Unified data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Field	Description
Disk	Disk
Disk Folder	Disk Group
File system	Internal Volume
Storage	Storage
Storage Processor	Storage Node
Storage Pool, RAID Group	Storage Pool
LUN	Volume
Data Mover	Controller
File System mounted on a data mover	File Share
CIFS and NFS Exports	Share
Disk Volume	Backend LUN

### Requirements

You need the following to configure the VNX (SSH) data collector:

- VNX IP address & Credentials to the Celerra Control Station.
- Read-only username and password.
- The data collector is able to run NaviCLI/NaviSecCLI commands against the backend array utilizing the DART OS NAS heads

### Configuration

Field	Description
VNX IP Address	IP address or fully-qualified domain name of the VNX Control Station
User Name	User name for the VNX Control Station
Password	Password for the VNX Control Station

### Advanced configuration

Field	Description
Inventory Poll Interval (min)	Interval between inventory polls. The default is 40 minutes.
Performance Poll Interval (sec).	Interval between performance polls. The default is 300 seconds.

### Troubleshooting

Additional information on this Data Collector may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

## Configuring the EMC VPLEX data collector

This data collector acquires inventory and performance data from EMC VPLEX storage systems. For configuration, the data collector requires an IP address of the VPLEX server and an administrative level domain account.

### Terminology

Cloud Insightst acquires the following inventory information from the VPLEX data collector. For each asset type acquired, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Cluster	Storage
Engine	Storage Node
Device, System Extent	Backend Storage Pool
Virtual Volume	Volume
Front-End Port, Back-End Port	Port
Distributed Device	Storage Synchronization
Storage View	Volume Map, Volume Mask

Vendor/Model Term	Cloud Insights Term
Storage Volume	Backend LUN
ITLs	Backend Path

Note: These are common terminology mappings only and might not represent every case for this data collector.

## Requirements

- An IP address of the VPLEX Management Console
- Administrative level domain account for the VPLEX server
- Port 443 (HTTPS). Requires outbound connectivity to TCP port 443 on the VPLEX management station.
- For performance, read-only username and password for ssh/scp access.
- For performance, port 22 is required.

## Configuration

Field	Description
IP address of VPLEX Management Console	IP address or fully-qualified domain name of the VPLEX Management Console
User Name	User name for VPLEX CLI
Password	Password used for VPLEX CLI
Performance Remote IP Address	Performance Remote IP address of the VPLEX Management Console
Performance Remote User Name	Performance Remote user name of VPLEX Management Console
Performance Remote Password	Performance Remote Password of VPLEX Management Console

## Advanced configuration

Field	Description
Communication Port	Port used for VPLEX CLI. The default is 443.
Inventory Poll Interval (min)	The default is 20 minutes.
Number of connection retries	The default is 3.
Performance Poll Interval (sec)	Interval between performance polls. The default is 600 seconds.

Field	Description
Number of Retries	The default is 2.

## Troubleshooting

Some things to try if you encounter problems with this data collector:

## Inventory

Problem:	Try this:
Error: User authentication failed.	Make sure your credentials for this device are correct.

## Performance

Problem:	Try this:
Error: VPLEX performance for version below 5.3 is not supported.	Upgrade VPLEX to 5.3 or above
Error: No enough data collected.	<ul style="list-style-type: none"> <li>• Check collection timestamp in log file and modify polling interval accordingly</li> <li>• Wait for longer time</li> </ul>
Error: Perpetual Log files not being updated.	Please contact EMC support to enable updating the perpetual log files
Error: Performance polling interval is too big.	Check collection timestamp in log file <code>{logfile}</code> and modify polling interval accordingly
Error: Performance Remote IP address of VPLEX Management Console is not configured.	Edit the data source to set Performance Remote IP address of VPLEX Management Console.
Error: No performance data reported from director	<ul style="list-style-type: none"> <li>• Check that the system performance monitors are running correctly</li> <li>• Please contact EMC support to enable updating the system performance monitor log files</li> </ul>

Additional information may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

## Dell EMC XtremeIO data collector

The EMC XtremIO data collector acquires inventory and performance data from the EMC XtremIO storage system.

## Requirements

To configure the EMC XtremIO (HTTP) data collector, you must have:

- The XtremIO Management Server (XMS) Host address
- An account with administrator privileges
- Access to port 443 (HTTPS)

## Terminology

Cloud Insights acquires the following inventory information from the EMC XtremIO data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data source, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Disk (SSD)	Disk
Cluster	Storage
Controller	Storage Node
Volume	Volume
LUN Map	Volume Map
Target FC Initiator	Volume Mask

Note: These are common terminology mappings only and might not represent every case for this data source.

## Requirements

- The XtremIO Management Server (XMS) Host IP address
- Administrator user name and password for the XtremIO

## Configuration

Field	Description
XMS Host	IP address or fully-qualified domain name of the XtremIO Management Server
User name	User name for the XtremIO Management Server
Password	Password for the XtremIO Management Server

## Advanced configuration

Field	Description
TCP port	TCP Port used to connect to XTremIO Management Server. The default is 443.
Inventory poll interval (min)	Interval between inventory polls. The default is 60 minutes.
Performance poll interval (sec)	Interval between performance polls. The default is 300 seconds.

## Troubleshooting

Additional information on this Data Collector may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

# Fujitsu Eternus data collector

The Fujitsu Eternus data collector acquires inventory data using administration-level access to the storage system.

## Terminology

Cloud Insights acquires the following inventory information from the Fujitsu Eternus storage. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Disk	Disk
Storage	Storage
Thin Pool, Flexible Tier Pool, Raid Group	Storage Pool
Standard Volume, Snap Data Volume (SDV), Snap Data Pool Volume (SDPV), Thin Provisioning Volume (TPV), Flexible Tier Volume (FTV), Wide Striping Volume (WSV)	Volume
Channel adapter	Controller

Note: These are common terminology mappings only and might not represent every case for this data collector.

## Requirements

The following are required to configure this data collector:

- An IP address of the Eternus storage, which cannot be comma delimited
- SSH Administration-level user name and password
- Port 22
- Ensure that the page scroll is disabled (clienv-show-more-scroll disable)

## Configuration

Field	Description
IP Address of Eternus Storage	IP address of the Eternus storage
User Name	User name for Eternus storage
Password	Password for the Eternus storage

## Advanced configuration

Field	Description
Inventory Poll Interval (min)	The default is 20 minutes.

## Troubleshooting

Some things to try if you encounter problems with this data collector:

### Inventory

Problem:	Try this:
"Error retrieving data" with error messages "Error Finding Prompt CLI" or "Error finding prompt at the end of shell results"	<p>Likely caused by: Storage system has page scrolling enabled.</p> <p>Possible solution:</p> <ul style="list-style-type: none"> <li>* Try to disable page scrolling by running the following command: set clienv-show-more -scroll disable</li> </ul>
"Connecting error" with error messages "Failed to instantiate an SSH connection to storage" or "Failed to instantiate a connection to VirtualCenter"	<p>Likely causes:</p> <ul style="list-style-type: none"> <li>* Incorrect credentials.</li> <li>* Incorrect IP address.</li> <li>* Network problem.</li> <li>* Storage may be down or unresponsive.</li> </ul> <p>Possible solutions:</p> <ul style="list-style-type: none"> <li>* Verify credentials and IP address entered.</li> <li>* Try to communicate with storage using SSH Client.</li> </ul>

Additional information may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).



# NetApp Google Compute data collector

This data collector supports inventory collection from Google Compute cloud platform configurations.

## Configuration

Field	Description
Project ID	Project ID for the Google Cloud Platform configuration
Client ID	Client ID for the Google Cloud Platform configuration
Copy and paste the contents of your Google Credential File here	Copy your Google credentials for the Cloud Platform account to this field

## Advanced configuration

Field	Description
Inventory Poll Interval (min)	Default is 60 minutes
Choose 'Exclude' or 'Include' to Apply to Filter VMs by Labels	Specify whether to include or exclude VM's by Labels when collecting data. If 'Include' is selected, the Label Key field can not be empty.
Label Keys and Values on which to Filter VMs	Click + <b>Filter Label</b> to choose which VMs (and associated disks) to include/exclude by filtering for keys and values that match keys and values of labels on the VM. Label Key is required, Label Value is optional. When Label Value is empty, the VM is filtered as long as it matches the Label Key.

## Troubleshooting

Additional information on this Data Collector may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

# HP Enterprise

## 3PAR StoreServ Storage data collector

Cloud Insights uses the 3PAR StoreServ data collector to discover inventory and performance for HP 3PAR StoreServ storage arrays.

## Terminology

Cloud Insights acquires the following inventory information from the 3PAR StoreServ data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Field	Description
Physical Disk	Disk
Storage System	Storage
Controller Node	Storage Node
Common Provisioning Group	Storage Pool
Virtual Volume	Volume

Note: These are common terminology mappings only and might not represent every case for this data collector.

## Requirements

The following are required to configure this data collector:

- IP address or FQDN of the InServ cluster
- For inventory, read-only user name and password to the StoreServ Server
- For performance, read-write user name and password to the StoreServ Server
- Port requirements: 22 (inventory collection), 5988 or 5989 (performance collection) [Note: 3PAR Performance is supported for StoreServ OS 3.x+]
- For performance collection confirm that SMI-S is enabled by logging into the 3PAR array via SSH.

## Configuration

Field	Description
Storage IP address	Storage IP address or fully-qualified domain name of the StoreServ cluster
User Name	User name for the StoreServ Server
Password	Password used for the StoreServ Server
SMI-S User Name	User name for the SMI-S Provider Host
SMI-S Password	Password used for the SMI-S Provider Host

## Advanced configuration

Field	Description
Inventory Poll Interval (min)	Interval between inventory polls. The default is 40 minutes.
SMI-S Connectivity	Protocol used to connect to the SMI-S provider
Override SMI-S Default Port	If blank, use the default port from SMI-S Connectivity, otherwise enter the connection port to use
Performance Poll Interval (sec)	Interval between performance polls. The default is 300 seconds.

## Troubleshooting

Some things to try if you encounter problems with this data collector:

### Inventory

Problem:	Try this:
"showsys" command doesn't return any result.	Run "showsys" and "showversion -a" from the command line and check if the version is supported by 3PAR.

### Performance

Problem:	Try this:
Failed to connect or login. Provider initialization failed.	An all-numeric array name can cause problems with SMI-S server. Try changing the array name.
SMI-S user configured does not have any domain	Grant appropriate domain privileges to the configured SMI-S user

Additional information may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

## HP Enterprise Command View data collector

The HP Enterprise Command View data collector supports the Command View Device Manager server. Cloud Insights communicates with the Command View Server using the standard Command View API to collect inventory and performance data.

## Terminology

Cloud Insights acquires the following inventory information from the HP Enterprise Command View

data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
PDEV	Disk
Journal Pool	Disk Group
Storage Array	Storage
Port Controller	Storage Node
Array Group, DP Pool	Storage Pool
Logical Unit, LDEV	Volume

Note: These are common terminology mappings only and might not represent every case for this data collector.

## Inventory requirements

You must have the following in order to collect inventory data:

- IP address of the Command View Device Manager server
- Read-only user name and password for the Command View Device Manager software and peer privileges
- Port requirement: 2001

## Performance requirements

The following requirements must be met in order to collect performance data:

- HDS USP, USP V, and VSP performance
  - Performance Monitor must be licensed.
  - Monitoring switch must be enabled.
  - The Export Tool (Export.exe) must be copied to the Cloud Insights AU.
  - The Export Tool version must match the microcode version of the target array.
- AMS performance:
  - Performance Monitor must be licensed.
  - The Storage Navigator Modular 2 (SNM2) CLI utility be installed on the Cloud Insights AU.

## Configuration

Field	Description
Command View Server	IP address or fully-qualified domain name of the Command View server
User Name	User name for the Command View server.
Password	Password used for the Command View server.
Devices - VSP G1000 (R800), VSP (R700), HUS VM (HM700) and USP storages	Device list for VSP G1000 (R800), VSP (R700), HUS VM (HM700) and USP storages. Each storage requires:  <ul style="list-style-type: none"> <li>* Array's IP: IP address of the storage</li> <li>* User Name: User name for the storage</li> <li>* Password: Password for the storage</li> <li>* Folder Containing Export Utility JAR Files</li> </ul>
SNM2Devices - WMS/SMS/AMS Storages	Device list for WMS/SMS/AMS storages. Each storage requires:  <ul style="list-style-type: none"> <li>* Array's IP: IP address of the storage</li> <li>* Storage Navigator CLI Path: SNM2 CLI path</li> <li>* Account Authentication Valid: Select to choose valid account authentication</li> <li>* User Name: User name for the storage</li> <li>* Password: Password for the storage</li> </ul>
Choose Tuning Manager for Performance	Override other performance options
Tuning Manager Host	IP address or fully-qualified domain name of tuning manager
Tuning Manager Port	Port used for Tuning Manager
Tuning Manager Username	User name for Tuning Manager
Tuning Manager Password	Password for Tuning Manager

Note: In HDS USP, USP V, and VSP, any disk can belong to more than one array group.

### Advanced configuration

Field	Description
Command View Server Port	Port used for the Command View Server
HTTPs Enabled	Select to enable HTTPs
Inventory Poll Interval (min)	Interval between inventory polls. The default is 40.

Choose 'Exclude' or 'Include' to specify a list	Specify whether to include or exclude the array list below when collecting data.
Exclude or Include Devices	Comma-separated list of device ID's or array names to include or exclude
Query Host Manager	Select to query host manager
Performance Polling Interval (sec)	Interval between performance polls. The default is 300.

## Troubleshooting

Some things to try if you encounter problems with this data collector:

## Inventory

<b>Problem:</b>	<b>Try this:</b>
Error: User does not have enough permission	Use a different user account that has more privilege or increase the privilege of user account configured in the data collector
Error: Storages list is empty. Either devices are not configured or the user does not have enough permission	<ul style="list-style-type: none"> <li>* Use DeviceManager to check if the devices are configured.</li> <li>* Use a different user account that has more privilege, or increase the privilege of the user account</li> </ul>
Error: HDS storage array was not refreshed for some days	Investigate why this array is not being refreshed in HP CommandView AE.

## Performance

Problem:	Try this:
<p>Error:</p> <ul style="list-style-type: none"> <li>* Error executing export utility</li> <li>* Error executing external command</li> </ul>	<ul style="list-style-type: none"> <li>* Confirm that Export Utility is installed on the Cloud Insights Acquisition Unit</li> <li>* Confirm that Export Utility location is correct in the data collector configuration</li> <li>* Confirm that the IP of the USP/R600 array is correct in the configuration of the data collector</li> <li>* Confirm that the User name and password are correct in the configuration of the data collector</li> <li>* Confirm that Export Utility version is compatible with storage array micro code version</li> <li>* From the Cloud Insights Acquisition Unit, open a CMD prompt and do the following: <ul style="list-style-type: none"> <li>- Change the directory to the configured installation directory</li> <li>- Try to make a connection with the configured storage array by executing batch file runWin.bat</li> </ul> </li> </ul>
<p>Error: Export tool login failed for target IP</p>	<ul style="list-style-type: none"> <li>* Confirm that username/password is correct</li> <li>* Create a user ID mainly for this HDS data collector</li> <li>* Confirm that no other data collectors are configured to acquire this array</li> </ul>
<p>Error: Export tools logged "Unable to get time range for monitoring".</p>	<ul style="list-style-type: none"> <li>* Confirm performance monitoring is enabled on the array.</li> <li>* Try invoking the export tools outside of Cloud Insights to confirm the problem lies outside of Cloud Insights.</li> </ul>
<p>Error:</p> <ul style="list-style-type: none"> <li>* Configuration error: Storage Array not supported by Export Utility</li> <li>* Configuration error: Storage Array not supported by Storage Navigator Modular CLI</li> </ul>	<ul style="list-style-type: none"> <li>* Configure only supported storage arrays.</li> <li>* Use “Filter Device List” to exclude unsupported storage arrays.</li> </ul>
<p>Error:</p> <ul style="list-style-type: none"> <li>* Error executing external command</li> <li>* Configuration error: Storage Array not reported by Inventory</li> <li>* Configuration error:export folder does not contains jar files</li> </ul>	<ul style="list-style-type: none"> <li>* Check Export utility location.</li> <li>* Check if Storage Array in question is configured in Command View server</li> <li>* Set Performance poll interval as multiple of 60 seconds.</li> </ul>

<b>Problem:</b>	<b>Try this:</b>
Error: * Error Storage navigator CLI * Error executing auperform command * Error executing external command	* Confirm that Storage Navigator Modular CLI is installed on the Cloud Insights Acquisition Unit * Confirm that Storage Navigator Modular CLI location is correct in the data collector configuration * Confirm that the IP of the WMS/SMS/SMS array is correct in the configuration of the data collector * Confirm that Storage Navigator Modular CLI version is compatible with micro code version of storage array configured in the data collector * From the Cloud Insights Acquisition Unit, open a CMD prompt and do the following: - Change the directory to the configured installation directory - Try to make a connection with the configured storage array by executing following command “auunitref.exe”
Error: Configuration error: Storage Array not reported by Inventory	Check if Storage Array in question is configured in Command View server
Error: * No Array is registered with the Storage Navigator Modular 2 CLI * Array is not registered with the Storage Navigator Modular 2 CLI * Configuration error: Storage Array not registered with StorageNavigator Modular CLI	* Open Command prompt and change directory to the configured path * Run the command “set=STONAVM_HOME=.” * Run the command “auunitref” * Confirm that the command output contains details of the array with IP * If the output does not contain the array details then register the array with Storage Navigator CLI: - Open Command prompt and change directory to the configured path - Run the command “set=STONAVM_HOME=.” - Run command “auunitaddauto -ip \${ip}”. Replace \${ip} with real IP

Additional information may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

## HPE Nimble data collector

The HPE Nimble data collector supports inventory and performance data for HPE Nimble storage arrays.



## Terminology

Cloud Insights acquires the following inventory information from the HPE Nimble data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Array	Storage
Disk	Disk
Volume	Volume
Pool	Storage Pool
Initiator	Storage Host Alias
Controller	Storage Node
Fibre Channel Interface	Controller

Note: These are common terminology mappings only and might not represent every case for this data collector.

## Requirements

You must have the following in order to collect data from the Nimble storage array:

- The array must be installed and configured, and reachable from the client through its fully qualified domain name (FQDN) or array management IP address.
- The array must be running NimbleOS 2.3.x or later.
- You must have a valid user name and password to the array.
- Port 5392 must be open on the array.

## Configuration

Field	Description
Array Management IP Address	Fully qualified domain name (FQDN) or array management IP address.
User Name	User name for the Nimble array
Password	Password for the Nimble array

## Advanced configuration

Field	Description
Port	Port used by Nimble REST API. The default is 5392.

Inventory Poll Interval (min)	Interval between inventory polls. The default is 60 minutes.
-------------------------------	--

Note: The default performance poll interval is 300 seconds and can not be changed. This is the only interval supported by Nimble.

## Hitachi Data Systems

### Hitachi Vantara Command Suite data collector

The Hitachi Vantara Command Suite data collector supports the HiCommand Device Manager server. Cloud Insights communicates with the HiCommand Device Manager server using the standard HiCommand API.

#### Terminology

Cloud Insights acquires the following inventory information from the Hitachi Vantara Command Suite data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
PDEV	Disk
Journal Pool	Disk Group
Storage Array	Storage
Port Controller	Storage Node
Array Group, HDS Pool	Storage Pool
Logical Unit, LDEV	Volume

Note: These are common terminology mappings only and might not represent every case for this data collector.

#### Inventory Requirements

You must have the following in order to collect inventory data:

- IP address of the HiCommand Device Manager server
- Read-only user name and password for the HiCommand Device Manager software and peer privileges
- Port requirements: 2001 (http) or 2443 (https)
- Log into HiCommand Device Manager software using username and password

- Verify access to HiCommand Device Manager [http://<HiCommand\\_Device\\_Manager\\_IP>:2001/service/StorageManager](http://<HiCommand_Device_Manager_IP>:2001/service/StorageManager)

## Performance requirements

The following requirements must be met in order to collect performance data:

- HDS USP, USP V, and VSP performance
  - Performance Monitor must be licensed.
  - Monitoring switch must be enabled.
  - The Export Tool (Export.exe) must be copied to the Cloud Insights AU.
  - The Export Tool version must match the microcode version of the target array.
- AMS performance:
  - NetApp strongly recommends creating a dedicated service account on AMS arrays for Cloud Insights to use to retrieve performance data. Storage Navigator only allows a user account one concurrent login to the array. Having Cloud Insights use the same user account as management scripts or HiCommand may result in Cloud Insights, management scripts, or HiCommand being unable to communicate to the array due to the one concurrent user account login limit
  - Performance Monitor must be licensed.
  - The Storage Navigator Modular 2 (SNM2) CLI utility needs to be installed on the Cloud Insights AU.

## Configuration

Field	Description
HiCommand Server	IP address or fully-qualified domain name of the HiCommand Device Manager server
User Name	User name for the HiCommand Device Manager server.
Password	Password used for the HiCommand Device Manager server.
Devices - VSP G1000 (R800), VSP (R700), HUS VM (HM700) and USP storages	<p>Device list for VSP G1000 (R800), VSP (R700), HUS VM (HM700) and USP storages. Each storage requires:</p> <ul style="list-style-type: none"> <li>* Array's IP: IP address of the storage</li> <li>* User Name: User name for the storage</li> <li>* Password: Password for the storage</li> <li>* Folder Containing Export Utility JAR Files</li> </ul>

Field	Description
SNM2Devices - WMS/SMS/AMS Storages	Device list for WMS/SMS/AMS storages. Each storage requires:  * Array's IP: IP address of the storage * Storage Navigator CLI Path: SNM2 CLI path * Account Authentication Valid: Select to choose valid account authentication * User Name: User name for the storage * Password: Password for the storage
Choose Tuning Manager for Performance	Override other performance options
Tuning Manager Host	IP address or fully-qualified domain name of tuning manager
Override Tuning Manager Port	If blank, use the default port in the Choose Tuning Manager for Performance field, otherwise enter the port to use
Tuning Manager Username	User name for Tuning Manager
Tuning Manager Password	Password for Tuning Manager

Note: In HDS USP, USP V, and VSP, any disk can belong to more than one array group.

### Advanced configuration

Field	Description
Connection Type	HTTPS or HTTP, also displays the default port
HiCommand Server Port	Port used for the HiCommand Device Manager
Inventory Poll Interval (min)	Interval between inventory polls. The default is 40.
Choose 'Exclude' or 'Include' to specify a list	Specify whether to include or exclude the array list below when collecting data.
Filter device List	Comma-separated list of device ID's or array names to include or exclude
Performance Poll Interval (sec)	Interval between performance polls. The default is 300.
Export timeout in seconds	Export utility timeout. The default is 300.

### Troubleshooting

Some things to try if you encounter problems with this data collector:

## Inventory

Problem:	Try this:
Error: User does not have enough permission	Use a different user account that has more privilege or increase the privilege of user account configured in the data collector
Error: Storages list is empty. Either devices are not configured or the user does not have enough permission	<ul style="list-style-type: none"><li>* Use DeviceManager to check if the devices are configured.</li><li>* Use a different user account that has more privilege, or increase the privilege of the user account</li></ul>
Error: HDS storage array was not refreshed for some days	Investigate why this array is not being refreshed in HDS HiCommand.

## Performance

Problem:	Try this:
Error: <ul style="list-style-type: none"><li>* Error executing export utility</li><li>* Error executing external command</li></ul>	<ul style="list-style-type: none"><li>* Confirm that Export Utility is installed on the Cloud Insights Acquisition Unit</li><li>* Confirm that Export Utility location is correct in the data collector configuration</li><li>* Confirm that the IP of the USP/R600 array is correct in the configuration of the data collector</li><li>* Confirm that the User name and password are correct in the configuration of the data collector</li><li>* Confirm that Export Utility version is compatible with storage array micro code version</li><li>* From the Cloud Insights Acquisition Unit, open a CMD prompt and do the following:<ul style="list-style-type: none"><li>- Change the directory to the configured installation directory</li><li>- Try to make a connection with the configured storage array by executing batch file runWin.bat</li></ul></li></ul>
Error: Export tool login failed for target IP	<ul style="list-style-type: none"><li>* Confirm that username/password is correct</li><li>* Create a user ID mainly for this HDS data collector</li><li>* Confirm that no other data collectors are configured to acquire this array</li></ul>

<b>Problem:</b>	<b>Try this:</b>
Error: Export tools logged "Unable to get time range for monitoring".	<ul style="list-style-type: none"> <li>* Confirm performance monitoring is enabled on the array.</li> <li>* Try invoking the export tools outside of Cloud Insights to confirm the problem lies outside of Cloud Insights.</li> </ul>
Error: * Configuration error: Storage Array not supported by Export Utility * Configuration error: Storage Array not supported by Storage Navigator Modular CLI	<ul style="list-style-type: none"> <li>* Configure only supported storage arrays.</li> <li>* Use “Filter Device List” to exclude unsupported storage arrays.</li> </ul>
Error: * Error executing external command * Configuration error: Storage Array not reported by Inventory * Configuration error:export folder does not contains jar files	<ul style="list-style-type: none"> <li>* Check Export utility location.</li> <li>* Check if Storage Array in question is configured in HiCommand server</li> <li>* Set Performance poll interval as multiple of 60 seconds.</li> </ul>
Error: * Error Storage navigator CLI * Error executing auperform command * Error executing external command	<ul style="list-style-type: none"> <li>* Confirm that Storage Navigator Modular CLI is installed on the Cloud Insights Acquisition Unit</li> <li>* Confirm that Storage Navigator Modular CLI location is correct in the data collector configuration</li> <li>* Confirm that the IP of the WMS/SMS/SMS array is correct in the configuration of the data collector</li> <li>* Confirm that Storage Navigator Modular CLI version is compatible with micro code version of storage array configured in the data collector</li> <li>* From the Cloud Insights Acquisition Unit, open a CMD prompt and do the following:               <ul style="list-style-type: none"> <li>- Change the directory to the configured installation directory</li> <li>- Try to make a connection with the configured storage array by executing following command “auunitref.exe”</li> </ul> </li> </ul>
Error: Configuration error: Storage Array not reported by Inventory	Check if Storage Array in question is configured in HiCommand server

Problem:	Try this:
Error: * No Array is registered with the Storage Navigator Modular 2 CLI * Array is not registered with the Storage Navigator Modular 2 CLI * Configuration error: Storage Array not registered with StorageNavigator Modular CLI	* Open Command prompt and change directory to the configured path * Run the command “set=STONAVM_HOME=.” * Run the command “auunitref” * Confirm that the command output contains details of the array with IP * If the output does not contain the array details then register the array with Storage Navigator CLI: - Open Command prompt and change directory to the configured path - Run the command “set=STONAVM_HOME=.” - Run command “auunitaddauto -ip \${ip}”. Replace \${ip} with real IP

Additional information may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

## Configuring the Hitachi Vantara NAS data collector

The Hitachi Vantara NAS data collector is an inventory and configuration data collector that supports discovery of HDS NAS clusters. Cloud Insights supports discovering NFS and CIFS shares, file systems (Internal Volumes), and spans (Storage Pools).

### Terminology

Cloud Insights acquires the following inventory information from the HNAS data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Tier	Disk Group
Cluster	Storage
Node	Storage Node
Span	Storage Pool
System Drive	Backend Lun
Files System	Internal Volume

Note: These are common terminology mappings only and might not represent every case for this data collector.

## Requirements

- Device IP address
- Port 22, SSH protocol
- Username and password - privilege level: Supervisor
- Note: This data collector is SSH based, so the AU that hosts it must be able to initiate SSH sessions to TCP 22 on the HNAS itself, or the Systems Management Unit (SMU) that the cluster is connected to.

## Configuration

Field	Description
HNAS Host	IP address or fully-qualified domain name of HNAS Management Host
User Name	User name for HNAS CLI
Password	Password used for HNAS CLI

## Advanced configuration

Field	Description
Inventory Poll Interval (min)	Interval between inventory polls. The default is 30 minutes.

## Troubleshooting

Some things to try if you encounter problems with this data collector:

## Inventory

Problem:	Try this:
"Error connecting" with error messages "Error setting up shell channel:" or "Error opening shell channel"	Likely caused by network connectivity issues or SSH is misconfigured. Confirm connection with alternate SSH client
"Timeout" or "Error retrieving data" with error messages "Command: XXX has timed out."	* Try the command with alternate SSH client * Increase timeout
"Error connecting " or "Invalid login credentials" with error messages "Could not communicate with the device:"	* Check IP address * Check user name and password * Confirm connection with alternate SSH client

Additional information may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).



# Infinidat InfiniBox data collector

The Infinidat InfiniBox (HTTP) data collector is used to collect inventory information from the Infinidat InfiniBox storage system.

## Terminology

Cloud Insights acquires the following inventory information from the Infinidat InfiniBox data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Storage Pool	Storage Pool
Node	Controller
Filesystem	Internal Volume
Filesystem	File Share
Filesystem Exports	Share

## Requirements

The following are requirements when configuring this data collector.

- IP address or FQDN of InfiniBox management Node
- Admin userid and password
- Port 443 via REST API

## Configuration

Field	Description
InfiniBox Host	IP address or fully-qualified domain name of the InfiniBox Management Node
User Name	User name for InfiniBox Management Node
Password	Password for the InfiniBox Management Node

## Advanced configuration

Field	Description
TCP Port	TCP Port used to connect to InfiniBox Server. The default is 443.
Inventory Poll Interval	Interval between inventory polls. The default is 60 minutes.

## Troubleshooting

Additional information on this Data Collector may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

## Huawei OceanStor data collector

Cloud Insights uses the Huawei OceanStor (REST/HTTPS) data collector to discover inventory and performance for Huawei OceanStor and OceanStor Dorado storage.

## Terminology

Cloud Insights acquires the following inventory and performance information from the Huawei OceanStor. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Storage Pool	Storage Pool
File System	Internal Volume
Controller	Storage Node
FC Port (Mapped)	Volume Map
Host FC Initiator (Mapped)	Volume Mask
NFS/CIFS Share	Share
iSCSI Link Target	iSCSI Target Node
iSCSI Link Initiator	iSCSI Initiator Node
Disk	Disk
LUN	Volume

## Requirements

The following requirements are required to configure this data collector:

- Device IP address
- Credentials to access OceanStor device manager
- Port 8088 must be available

## Configuration

Field	Description
OceanStor Host IP Address	IP address or fully-qualified domain name of the OceanStor Device Manager
User Name	Name used to log into the OceanStor Device Manager
Password	Password used to log into the OceanStor Device Manager

## Advanced Configuration

Field	Description
TCP Port	TCP Port used to connect to OceanStor Device Manager. The default is 8088.
Inventory Poll Interval (min)	Interval between inventory polls. The default is 60 minutes.
Performance poll interval (sec).	The default is 300 seconds.

## Troubleshooting

Additional information on this Data Collector may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

# IBM

## IBM CS data collector

Cloud Insights uses this data collector to discover inventory and performance data for IBM CS storage systems.

## Terminology

Cloud Insights acquires the following inventory information from the IBM CS data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Storage Pool	Storage Pool
Container	Internal Volume
Container	File Share
NFS Share	Share

Note: These are common terminology mappings only and might not represent every case for this data collector.

## Requirements

- The external data services IP address for the cluster
- Administrator user name and password
- Port 9440

## Configuration

Field	Description
Prism External IP Address	The external data services IP address for the cluster
User name	User name for the Admin account
Password	Password for the Admin account

## Advanced configuration

Field	Description
TCP port	TCP Port used to connect to the IBM CS array. The default is 9440.
Inventory poll interval (min)	Interval between inventory polls. The default is 60 minutes.
Performance poll interval(sec)	Interval between performance polls. The default is 300 seconds.

## Troubleshooting

Additional information on this Data Collector may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

## IBM System Storage DS8000 Series data collector

The IBM DS (CLI) data collector supports inventory and performance data acquisition for DS6xxx and DS8xxx devices.

DS3xxx, DS4xxx, and DS5xxx devices are supported by the [NetApp E-Series data collector](#). You should refer to the Cloud Insights support matrix for supported models and firmware versions.

### Terminology

Cloud Insights acquires the following inventory information from the IBM DS data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Disk Drive Module	Disk
Storage Image	Storage
Extent Pool	Storage Node
Fixed Block Volume	Volume
Host FC Initiator (Mapped)	Volume Mask

Note: These are common terminology mappings only and might not represent every case for this data collector.

### Requirements

You need the following to configure this data collector:

- IP address of each DS array
- Read-only username and password on each DS array
- Third-party software installed on the Cloud Insights AU: IBM *dscli*
- Access validation: Run *dscli* commands using the username and password
- Port requirements: 80, 443, & 1750

### Configuration

Field	Description
DS Storage	IP address or fully-qualified domain name of the DS device
User Name	User name for the DS CLI
Password	Password for the DS CLI

Field	Description
<i>dscli</i> executable path	Full path to the <i>dscli</i> executable

### Advanced configuration

Field	Description
Inventory Poll Interval (min)	Interval between inventory polls (min). The default is 40.
Storage Display Name	Name of the IBM DS storage array
Inventory Exclude Devices	Comma-separated list of device serial numbers to exclude from inventory collection
Performance Poll Interval (sec)	The default is 300.
Performance Filter Type	Include: Data collected only from devices on list. Exclude: No data from these devices is collected
Performance Filter Device List	Comma-separated list of device IDs to include or exclude from performance collection

### Troubleshooting

Some things to try if you encounter problems with this data collector:

#### Inventory

Problem:	Try this:
Error containing: CMUC00192E, CMUC00191E or CMUC00190E	<ul style="list-style-type: none"> <li>* Verify credentials and IP address entered.</li> <li>* Try to communicate with the array through web management console <a href="https://\${ip}:8452/DS8000/Console">https://\${ip}:8452/DS8000/Console</a>. Replace the \${ip} with data collector configured IP.</li> </ul>
Error: * Cannot run program * Error executing command	<ul style="list-style-type: none"> <li>* From Cloud Insights Acquisition Unit Open a CMD</li> <li>* Open CLI.CFG file in CLI's home dir/lib and check property JAVA_INSTALL, edit the value to match your environment</li> <li>* Display Java version installed on this machine, typing: "java -version"</li> <li>* Ping the IP address of the IBM Storage device specified in CLI command issued.</li> <li>* If all the above worked fine then manually run a CLI command</li> </ul>

Additional information may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

## Configuring the IBM PowerVM data collector

The IBM PowerVM (SSH) data collector is used to collect information about virtual partitions running on IBM POWER hardware instances managed by a hardware management console (HMC).

### Terminology

Cloud Insights acquires inventory information from the virtual partitions running on IBM POWER hardware instances. For each asset type acquired, the most common terminology used for the asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
hdisk	Virtual Disk
Managed System	Host
LPAR, VIO Server	Virtual Machine
Volume Group	Data Store
Physical Volume	LUN

Note: These are common terminology mappings only and might not represent every case for this data collector.

### Requirements

The following requirements must be met to configure and use this data collector:

- IP address of the Hardware Management Console (HMC)
- User name and password that provide access to Hardware Management Console (HMC) through SSH
- Port requirement SSH-22
- View permission on all management systems and logical partition security domains

The user must also have View permission on HMC configurations and the ability to collect VPD information for the HMC console security grouping. The user must also be allowed Virtual IO Server Command access under the Logical Partition security grouping. It is a best practice to start from a role of an operator and then remove all roles. Read-only users on the HMC do not have privileges to run proxied commands on AIX hosts.

- IBM best practice is to have the devices monitored by two or more HMCs. Be aware that this may cause OnCommand Insight to report duplicated devices, therefore it is highly recommended to add

redundant devices to the "Exclude Devices" list in the Advanced Configuration for this data collector.

## Configuration

Field	Description
Hardware Management Console (HMC) IP Address	IP address or fully-qualified domain name of the PowerVM Hardware Management Console
HMC User	User name for the Hardware Management Console
Password	Password used for the Hardware Management Console

## Advanced configuration

Field	Description
Inventory Poll Interval (min)	Interval between inventory polls. The default is 20 minutes.
SSH Port	Port used for SSH to the PowerVM
Password	Password used for the Hardware Management Console
Number of Retries	Number of inventory retry attempts
Exclude Devices	Comma-separated list of device IDs or display names to exclude

## Troubleshooting

Additional information on this Data Collector may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

## Configuring the IBM SAN Volume Controller data collector

The IBM SAN Volume Controller (SVC) data collector collects inventory and performance data using SSH, supporting a variety of devices that run the SVC operating system.

The list of supported devices includes models such as the SVC, the v7000, the v5000, and the v3700. Refer to the Cloud Insights support matrix for supported models and firmware versions.



## Terminology

Cloud Insights acquires the following inventory information from the IBM SVC data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Drive	Disk
Cluster	Storage
Node	Storage Node
Mdisk Group	Storage Pool
Vdisk	Volume
Mdisk	Backend LUNs and paths

Note: These are common terminology mappings only and might not represent every case for this data collector.

## Inventory Requirements

- IP address of each SVC cluster
- Port 22 available
- Read-only user name and password

## Performance Requirements

- SVC Console, which is mandatory for any SVC cluster and required for the SVC discovery foundation package.
- Credentials will require administrative access level only for copying performance files from cluster nodes to the config node.
- Enable data collection by connecting to the SVC cluster by SSH and running: `svctask startstats -interval 1`

Note: Alternatively, enable data collection using the SVC management user interface.

## Configuration

Field	Description
Cluster IP Addresses	IP addresses or fully-qualified domain names of the SVC storage
Inventory User Name	User name for the SVC CLI
Inventory Password	Password for the SVC CLI

## Advanced configuration

Field	Description
Inventory Poll Interval (min)	Interval between inventory polls. The default is 40 minutes.
Performance Poll Interval (sec)	Interval between performance polls. The default is 300 seconds.
To clean up dumped stats files	Select this checkbox to clean up dumped stats files

## Troubleshooting

Some things to try if you encounter problems with this data collector:

Problem:	Try this:
Error: "The command cannot be initiated because it was not run on the configuration node."	The command must be executed on the configuration node.

Some things to try if you encounter problems with this data collector:

Problem:	Try this:
Error: "The command cannot be initiated because it was not run on the configuration node."	The command must be executed on the configuration node.

Additional information on this Data Collector may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

## Configuring the IBM XIV/A9000 data collector

IBM XIV and A9000 (CLI) data collector uses the XIV command-line interface to collect inventory data while performance collection is accomplished by making SMI-S calls to the XIV/A9000 array, which runs a SMI-S provider on port 7778.

## Terminology

Vendor/Model Term	Cloud Insights Term
Disk	Disk
Storage System	Storage
Storage Pool	Storage Pool
Volume	Volume

## Requirements

The following requirements must be met to configure and use this data collector:

- Port requirement: TCP port 7778
- Read-only user name and password
- The XIV CLI must be installed on the AU

## Performance requirements

The following are requirements for performance collection:

- SMI-S Agent 1.4 or higher
- SMI-S compatible CIMService running on array. Most XIV arrays have a CIMServer installed by default.
- User login must be provided for the CIMServer. The login must have full read access to the array configuration and properties.
- SMI-S namespace. Default is root/ibm. This is configurable in the CIMServer.
- Port Requirements: 5988 for HTTP, 5989 for HTTPS.
- Refer to the following link on how to create an account for SMI-S performance collection:  
[http://publib.boulder.ibm.com/infocenter/tivihelp/v4r1/index.jsp?topic=%2Fcom.ibm.tpc\\_V41.doc%2Ffqz0\\_t\\_adding\\_cim\\_agent.html](http://publib.boulder.ibm.com/infocenter/tivihelp/v4r1/index.jsp?topic=%2Fcom.ibm.tpc_V41.doc%2Ffqz0_t_adding_cim_agent.html)

## Configuration

Field	Description
XIV IP address	IP address or fully-qualified domain name of the XIV storage
User Name	User name for the XIV storage
Password	Password for the XIV storage
Full Path to XIV CLI Directory	Full path to the folder containing the XIV CLI
SMI-S Host IP Address	IP address of the SMI-S host

## Advanced configuration

Field	Description
Inventory Poll Interval (min)	Interval between inventory polls. The default is 40 minutes.
SMI-S Protocol	Protocol used to connect to the SMI-S provider. Also displays the default port.

Field	Description
Override SMI-S Port	If blank, use the default port in the Connection Type field, otherwise enter the connection port to use
Username	User name for the SMI-S Provider Host
Password	Password for the SMI-S Provider Host
Performance Poll Interval (sec)	Interval between performance polls. The default is 300 seconds.

## Troubleshooting

Additional information on this Data Collector may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

## Lenovo data collector

Cloud Insights uses the Lenovo data collector to discover inventory and performance data for Lenovo HX storage systems.

## Terminology

Cloud Insights acquires the following inventory information from the Lenovo data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Storage Pool	Storage Pool
Nutanix Container	Internal Volume
Nutanix Container	File Share
NFS Share	Share

Note: These are common terminology mappings only and might not represent every case for this data collector.

## Requirements

- Prism External IP Address
- Administrator user name and password
- TCP Port requirement: 9440

## Configuration

Field	Description
Prism External IP Address	The external data services IP address for the cluster
User name	User name for the Admin account
Password	Password for the Admin account

## Advanced configuration

Field	Description
TCP port	TCP Port used to connect to array. The default is 9440.
Inventory poll interval (min)	Interval between inventory polls. The default is 60 minutes.
Performance poll interval (sec)	Interval between performance polls. The default is 300 seconds.

## Troubleshooting

Additional information on this Data Collector may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

# Microsoft

## Configuring the Azure NetApp Files data collector

Cloud Insights uses the Azure NetApp Files data collector to acquire inventory and performance data.

### Requirements

You need the following information to configure this data collector.

- Port requirement: 443 HTTPS
- Azure Management Rest IP (management.azure.com)
- Azure service principal client ID (user account)
- Azure service principal authentication key (user password)
- You need to set up an Azure account for Cloud Insights discovery.

Once the account is properly configured and you register the application in Azure, you will have the credentials required to discover the Azure instance with Cloud Insights. The following link describes how to set up the account for discovery:

<https://docs.microsoft.com/en-us/azure/active-directory/develop/howto-create-service-principal-portal>

## Configuration

Enter data into the data collector fields according to the table below:

Field	Description
Azure Service Principal Client ID	Sign-in ID to Azure
Azure Tenant ID	Azure Tenant ID
Azure Service Principal Authentication Key	Login authentication key
I understand Microsoft bills me for API requests	Check this to verify your understanding that Microsoft bills you for API requests made by Insight polling.

## Advanced Configuration

Field	Description
Inventory Poll Interval (min)	The default is 60

## Troubleshooting

Additional information on this Data Collector may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

## Microsoft Hyper-V data collector

The Microsoft Hyper-V data collector acquires inventory and performance data from the virtualized server computing environment.

## Terminology

Cloud Insights acquires the following inventory information from the Microsoft Hyper-V (WMI). For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Virtual Hard Disk	Virtual Disk
Host	Host

Vendor/Model Term	Cloud Insights Term
Virtual Machine	Virtual Machine
Cluster Shared Volumes (CSV), Partition Volume	Data Store
Internet SCSI Device, Multi Path SCSI LUN	LUN
Fiber Channel Port	Port

Note: These are common terminology mappings only and might not represent every case for this data collector.

## Requirements

The following are required to configure this data collector:

- IP address of Clustering group node
- Local Administrator user & password on the hypervisor
- Administrative-level user account
- Windows Management Instrumentation (WMI) command, which is the default that is installed by Windows.
- Port requirements: Port 135 via WMI & Dynamic TCP ports assigned 1024-65535 for Windows 2003 and older and 49152-65535 for Windows 2008.



The Hyper-V data collector requires a Windows Acquisition Unit.

## Configuration

Field	Description
Physical Host IP Address	The IP address or fully-qualified domain name for the physical host (hypervisor)
User Name	Administrator user name for the hypervisor
Password	Password for the hypervisor
NT Domain	The DNS name used by the nodes in the cluster

## Advanced configuration

Field	Description
Inventory Poll Interval (min)	The default is 20 minutes.

## Troubleshooting

Additional information on this Data Collector may be found from the [Support](#) page or in the [Data](#)

# NetApp

## NetApp Cloud Volumes data collector

The NetApp Cloud Volumes data collector supports inventory collection from Cloud Volumes configurations.

### Configuration

Field	Description
Cloud Volumes API URL	URL for API connection to Cloud Volumes
API Key	Cloud Volumes API key
Secret Key	Cloud Volumes secret key

### Advanced configuration

Field	Description
Inventory Poll Interval (min)	Default is 60 minutes

### Troubleshooting

Additional information on this Data Collector may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

## NetApp ONTAP Data Management Software Data Collector

This data collector acquires inventory and performance data from storage systems running Clustered Data ONTAP using read-only API calls from an administrator account.

### Terminology

Cloud Insights acquires inventory and performance data from the Clustered Data ONTAP data collector. For each asset type acquired, the most common terminology used for the asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Disk	Disk
Raid Group	Disk Group



Vendor/Model Term	Cloud Insights Term
Cluster	Storage
Node	Storage Node
Aggregate	Storage Pool
LUN	Volume
Volume	Internal Volume

## Requirements

The following are requirements to configure and use this data collector:

- You must have access to an Administrator account used for read-only API calls.
- Username (with read-only role name to ontapi application to the default Vserver) and password to log into NetApp cluster)
- Port requirements: 80 or 433
- License requirements:
  - FCP license and mapped/masked volumes required for discovery

## Configuration

Field	Description
NetApp Management IP	IP address or fully-qualified domain name of the NetApp cluster
User Name	User name for NetApp cluster
Password	Password for NetApp cluster

## Advanced configuration

Field	Description
Communication Port	Port used for NetApp API
Inventory Poll Interval (min)	Default is 60 minutes.
Performance Poll Interval (sec)	Default is 900 seconds.

## Troubleshooting

Some things to try if you encounter problems with this data collector:

## Inventory

Problem:	Try this:
Receive 401 HTTP response or 13003 ZAPI error code and ZAPI returns “Insufficient privileges” or “not authorized for this command”	Check username and password, and user privileges/permissions.
Cluster version is < 8.1	Cluster minimum supported version is 8.1. Upgrade to minimum supported version.
ZAPI returns "cluster role is not cluster_mgmt LIF"	AU needs to talk to cluster management IP. Check the IP and change to a different IP if necessary
Error: “7 Mode filers are not supported”	This can happen if you use this data collector to discover 7 mode filer. Change IP to point to cdot filer instead.
ZAPI command fails after retry	AU has communication problem with the cluster. Check network, port number, and IP address. User should also try to run a command from command line from the AU machine.
AU failed to connect to ZAPI via HTTP	Check whether ZAPI port accepts plaintext. If AU tries to send plaintext to an SSL socket, the communication fails.
Communication fails with SSLException	AU is attempting to send SSL to a plaintext port on a filer. Check whether the ZAPI port accepts SSL, or use a different port.
Additional Connection errors:  ZAPI response has error code 13001, “database is not open”  ZAPI error code is 60 and response contains “API did not finish on time”  ZAPI response contains “initialize_session() returned NULL environment”  ZAPI error code is 14007 and response contains “Node is not healthy”	Check network, port number, and IP address. User should also try to run a command from command line from the AU machine.

## Performance

Problem:	Try this:
“Failed to collect performance from ZAPI” error	<p>This is usually due to perf stat not running. Try the following command on each node:</p> <pre>&gt; system node systemshell -node * -command "spmctl -h cmd -stop; spmctl -h cmd -exec"</pre>

Additional information may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

## NetApp Data ONTAP operating in 7-Mode data collector

For storage systems using Data ONTAP software operating in 7-Mode, you use the 7-mode data collector, which uses the CLI to obtain capacity and performance data.

### Terminology

Cloud Insights acquires the following inventory information from the NetApp 7-mode data collector. For each asset type acquired, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Disk	Disk
Raid Group	Disk Group
Filer	Storage
Filer	Storage Node
Aggregate	Storage Pool
LUN	Volume
Volume	Internal Volume

Note: These are common terminology mappings only and might not represent every case for this data collector.

### Requirements

You need the following to configure and use this data collector:

- IP addresses of the FAS storage controller and partner.
- Port 443
- A custom admin level username and password for controller and partner controller with the following role capabilities for 7-Mode:
  - "api-\*": Use this to allow OnCommand Insight to execute all NetApp storage API commands.

- "login-http-admin": Use this to allow OnCommand Insight to connect to the NetApp storage via HTTP.
- "security-api-vfiler": Use this to allow OnCommand Insight to execute NetApp storage API commands to retrieve vFiler unit information.
- "cli-options": Use this to read storage system options.
- "cli-lun": Access these commands for managing LUNs. Displays the status (LUN path, size, online/offline state, and shared state) of the given LUN or class of LUNs.
- "cli-df": Use this to display free disk space.
- "cli-ifconfig": Use this to display interfaces and IP addresses.

## Configuration

Field	Description
Address of storage system	IP address or fully-qualified domain name for the NetApp storage system
User Name	User name for the NetApp storage system
Password	Password for the NetApp storage system
Address of HA Partner in Cluster	IP address or fully-qualified domain name for the HA Partner
User Name of HA Partner in Cluster	User name for the HA partner
Password of HA Partner Filer in Cluster	Password for the HA Partner

## Advanced configuration

Field	Description
Inventory Poll Interval (min)	Interval between inventory polls. The default is 20 minutes.
Connection Type	HTTPS or HTTP, also displays the default port
Override Connection Port	If blank, use the default port in the Connection Type field, otherwise enter the connection port to use
Performance Poll Interval (sec)	Interval between performance polls. The default is 300 seconds.

## Storage systems connection

As an alternative to using the default administrative user for this data collector, you can configure a user with administrative rights directly on the NetApp storage systems so that this data collector can acquire data from NetApp storage systems.

Connecting to NetApp storage systems requires that the user, who is specified when acquiring the main pfiler (on which the storage system exist), meet the following conditions:

- The user must be on vfiler0 (root filer/pfiler).

Storage systems are acquired when acquiring the main pfiler.

- The following commands define the user role capabilities:
  - "api-\*": Use this to allow Cloud Insights to execute all NetApp storage API commands.

This command is required to use the ZAPI.

- "login-http-admin": Use this to allow Cloud Insights to connect to the NetApp storage via HTTP. This command is required to use the ZAPI.
- "security-api-vfiler": Use this to allow Cloud Insights to execute NetApp storage API commands to retrieve vFile unit information.
- "cli-options": For "options" command and used for partner IP and enabled licenses.
- "cli-lun": Access these command for managing LUNs. Displays the status (LUN path, size, online/offline state, and shared state) of the given LUN or class of LUNs.
- "cli-df": For "df -s", "df -r", "df -A -r" commands and used to display free space.
- "cli-ifconfig": For "ifconfig -a" command and used for getting filer IP address.
- "cli-rdfile": For "rdfile /etc/netgroup" command and used for getting netgroups.
- "cli-date": For "date" command and used to get full date for getting Snapshot copies.
- "cli-snap": For "snap list" command and used for getting Snapshot copies.

If cli-date or cli-snap permissions are not provided, acquisition can finish, but Snapshot copies are not reported.

To acquire a 7-Mode data source successfully and generate no warnings on the storage system, you should use one of the following command strings to define your user roles. The second string listed here is a streamlined version of the first:

- login-http-admin,api-\*,security-api-vfile,cli-rdfile,cli-options,cli-df,cli-lun,cli-ifconfig,cli-date,cli-snap,\_
- login-http-admin,api-\*,security-api-vfile,cli-

## Troubleshooting

Some things to try if you encounter problems with this data collector:

## Inventory

<b>Problem:</b>	<b>Try this:</b>
Receive 401 HTTP response or 13003 ZAPI error code and ZAPI returns “Insufficient privileges” or “not authorized for this command”	Check username and password, and user privileges/permissions.
“Failed to execute command” error	<p>Check whether the user has the following permission on the device:</p> <ul style="list-style-type: none"> <li>• api-*</li> <li>• cli-date</li> <li>• cli-df</li> <li>• cli-ifconfig</li> <li>• cli-lun</li> <li>• cli-operations</li> <li>• cli-rdfile</li> <li>• cli-snap</li> <li>• login-http-admin</li> <li>• security-api-vfiler</li> </ul> <p>Also check if the ONTAP version is supported by Cloud Insights and verify if the credentials used match device credentials</p>
Cluster version is < 8.1	Cluster minimum supported version is 8.1. Upgrade to minimum supported version.
ZAPI returns "cluster role is not cluster_mgmt LIF"	AU needs to talk to cluster management IP. Check the IP and change to a different IP if necessary
Error: “7 Mode filers are not supported”	This can happen if you use this data collector to discover 7 mode filer. Change IP to point to cdot filer instead.
ZAPI command fails after retry	AU has communication problem with the cluster. Check network, port number, and IP address. User should also try to run a command from command line from the AU machine.
AU failed to connect to ZAPI	Check IP/port connectivity and assert ZAPI configuration.
AU failed to connect to ZAPI via HTTP	Check whether ZAPI port accepts plaintext. If AU tries to send plaintext to an SSL socket, the communication fails.
Communication fails with SSLException	AU is attempting to send SSL to a plaintext port on a filer. Check whether the ZAPI port accepts SSL, or use a different port.

<b>Problem:</b>	<b>Try this:</b>
<p>Additional Connection errors:</p> <p>ZAPI response has error code 13001, “database is not open”</p> <p>ZAPI error code is 60 and response contains “API did not finish on time”</p> <p>ZAPI response contains “initialize_session() returned NULL environment”</p> <p>ZAPI error code is 14007 and response contains “Node is not healthy”</p>	<p>Check network, port number, and IP address. User should also try to run a command from command line from the AU machine.</p>
Socket timeout error with ZAPI	Check filer connectivity and/or increase timeout.
“C Mode clusters are not supported by the 7 Mode data source” error	Check IP and change the IP to a 7 Mode cluster.
“Failed to connect to vFiler” error	<p>Check that the acquiring user capabilities include the following at a minimum:</p> <p>api-*</p> <p>security-api-vfiler</p> <p>login-http-admin</p> <p>Confirm that filer is running minimum ONTAPI version 1.7.</p>

Additional information may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

## NetApp E-Series data collector

The NetApp E-Series data collector gathers inventory and performance data. The collector supports firmware 7.x+ using the same configurations and reporting the same data.

### Terminology

Cloud insight acquires the following inventory information from the NetApp E-Series data collector. For each asset type acquired, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

<b>Vendor/Model Term</b>	<b>Cloud Insights Term</b>
Disk	Disk
Volume Group	Disk Group

Vendor/Model Term	Cloud Insights Term
Storage Array	Storage
Controller	Storage Node
Volume Group	Storage Pool
Volume	Volume

Note: These are common terminology mappings only and might not represent every case for this data collector.

## E-Series Terminology (Landing Page)

The following terms apply to objects or references that you might find on NetApp E-Series asset landing pages. Many of these terms apply to other data collectors as well.

### E-Series Storage

- Model – model name of the device.
- Vendor – same Vendor name you would see if you were configuring a new datasource
- Serial number – The array serial number. On cluster architecture storage systems like NetApp Clustered Data Ontap, this serial number may be less useful than the individual “Storage Nodes” serial numbers
- IP – generally will be the IP(s) or hostname(s) as configured in the data source
- Microcode version – firmware
- Raw Capacity – base 2 summation of all the physical disks in the system, regardless of their role
- Latency – a representation of what the host facing workloads are experiencing, across both reads and writes. Ideally, Cloud Insights is sourcing this value directly, but this is often not the case. In lieu of the array offering this up, Cloud Insights is generally performing an IOPs-weighted calculation derived from the individual volumes’ statistics.
- Throughput – the array’s total host facing throughput. Ideally sourced directly from the array, if unavailable, Cloud Insights is summing the volumes’ throughput to derive this value
- Management – this may contain a hyperlink for the management interface of the device. Created programmatically by the Cloud Insights datasource as part of inventory reporting

### E-Series Storage Pool

- Storage – what storage array this pool lives on. Mandatory
- Type – a descriptive value from a list of an enumerated list of possibilities. Most commonly will be “Thin Provisioning” or “RAID Group”
- Node – if this storage array’s architecture is such that pools belong to a specific storage node, its



name will be seen here as a hyperlink to its own landing page

- Uses Flash Pool – Yes/No value
- Redundancy – RAID level or protection scheme. E-Series reports “RAID 7” for DDP pools
- Capacity – the values here are the logical used, usable capacity and the logical total capacity, and the percentage used across these. These value both include E-Series “preservation” capacity, resulting both in numbers and the percentage being higher than what the E-Series own user interface may show
- Over-committed capacity – If via efficiency technologies you have allocated a sum total of volume or internal volume capacities larger than the logical capacity of the storage pool, the percentage value here will be greater than 0%.
- Snapshot – snapshot capacities used and total, if your storage pool architecture dedicates part of its capacity to segments areas exclusively for snapshots
- Utilization – a percentage value showing the highest disk busy percentage of any disk contributing capacity to this storage pool. Disk utilization does not necessarily have a strong correlation with array performance – utilization may be high due to disk rebuilds, deduplication activities, etc in the absence of host driven workloads. Also, many arrays’ replication implementations may drive disk utilization while not showing as volume workload.
- IOPS – the sum IOPS of all the disks contributing capacity to this storage pool. If disk IOPS is not available on a given platform, this value will be sourced from the sum of volume IOPS for all the volumes sitting on this storage pool
- Throughput – the sum throughput of all the disks contributing capacity to this storage pool. If disk throughput is not available on a given platform, this value will be sourced from the sum of volume throughput for all the volumes sitting on this storage pool

#### **E-Series Storage Node**

- Storage – what storage array this node is part of. Mandatory
- HA Partner – on platforms where a node will fail over to one and only one other node, it will generally be seen here
- State – health of the node. Only available when the array is healthy enough to be inventoried by a data source
- Model – model name of the node
- Version – version name of the device.
- Serial number – The node serial number
- Memory – base 2 memory if available
- Utilization – Generally a CPU utilization number, or in the case of NetApp Ontap, a controller stress index. Utilization is not currently available for NetApp E-Series
- IOPS – a number representing the host driven IOPS on this controller. Ideally sourced directly from the array, if unavailable, it will be calculated by summing all the IOPS for volumes that belong

exclusively to this node.

- Latency – a number representing the typical host latency or response time on this controller. Ideally sourced directly from the array, if unavailable, it will be calculated by performing an IOPs weighted calculation from volumes that belong exclusively to this node.
- Throughput – a number representing the host driven throughput on this controller. Ideally sourced directly from the array, if unavailable, it will be calculated by summing all the throughput for volumes that belong exclusively to this node.
- Processors – CPU count

## Requirements

- The IP address of each controller on the array
- Port requirement 2463

## Configuration

Field	Description
Comma-separated list of Array SANtricity Controller IPs	IP addresses and/or fully-qualified domain names for the array controllers

## Advanced configuration

Field	Description
Inventory Poll Interval (min)	Default is 30 minutes
Performance Poll Interval up to 3600 seconds	Default is 300 seconds

## Troubleshooting

Additional information on this Data Collector may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

## Configuring the NetApp HCI Management server data collector

The NetApp HCI Management server data collector collects NetApp HCI Host information and requires read-only privileges on all objects within the Management server.

This data collector acquires from the **NetApp HCI Management server only**. To collect data from the storage system, you must also configure the [NetApp SolidFire](#) data collector.

## Terminology

Cloud Insights acquires the following inventory information from this data collector. For each asset type acquired, the most common terminology used for the asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Virtual disk	Disk
Host	Host
Virtual machine	Virtual machine
Data store	Data store
LUN	Volume
Fibre channel port	Port

These are common terminology mappings only and might not represent every case for this data collector.

## Requirements

The following information is required to configure this data collector:

- IP address of the NetApp HCI Management server
- Read-only username and password for the NetApp HCI Management server
- Read only privileges on all objects in the NetApp HCI Management server.
- SDK access on the NetApp HCI Management server – normally already set up.
- Port requirements: http-80 https-443
- Validate access:
  - Log into the NetApp HCI Management server using above username and password
  - Verify SDK enabled: telnet <vc\_ip> 443

## Setup and connection

Field	Description
Name	Unique name for the data collector
Acquisition unit	Name of acquisition unit

## Configuration

Field	Description
NetApp HCI Storage Cluster MVIP	Management Virtual IP Address
SolidFire Management Node (mNode)	Management Node IP Address
User name	User name used to access the NetApp HCI Management server
Password	Password used to access the NetApp HCI Management server
VCenter User Name	User name for VCenter
VCenter Password	Password for VCenter

### Advanced configuration

In the advanced configuration screen, check the **VM Performance** box to collect performance data. Inventory collection is enabled by default.

The following fields can be configured:

Field	Description
Inventory poll interval (min)	Default is 20
Filter VMs by	Select CLUSTER, DATACENTER, or ESX HOST
Choose 'Exclude' or 'Include' to Specify a List	Specify Whether to Include or Exclude VMs
Filter Device List	List of VMs to filter (comma separated, or semicolon separated if comma is used in the value) for for Filtering by ESX_HOST, CLUSTER, and DATACENTER Only
Performance poll interval (sec)	Default is 300

### Troubleshooting

Some things to try if you encounter problems with this data collector:

#### Inventory

Problem:	Try this:
Error: Include list to filter VMs cannot be empty	If Include List is selected, please list valid DataCenter, Cluster, or Host names to filter VMs

<b>Problem:</b>	<b>Try this:</b>
Error: Failed to instantiate a connection to VirtualCenter at IP	Possible solutions:  * Verify credentials and IP address entered. * Try to communicate with Virtual Center using Infrastructure Client. * Try to communicate with Virtual Center using Managed Object Browser (e.g MOB).
Error: VirtualCenter at IP has non-conform certificate that JVM requires	Possible solutions:  * Recommended: Re-generate certificate for Virtual Center by using stronger (e.g. 1024-bit) RSA key. * Not Recommended: Modify the JVM java.security configuration to leverage the constraint jdk.certpath.disabledAlgorithms to allow 512-bit RSA key. See JDK 7 update 40 release notes at "http://www.oracle.com/technetwork/java/javase/7u40-relnotes-2004172.html"

Additional information may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

## NetApp SolidFire All-Flash Array data collector

The NetApp SolidFire All-Flash Array data collector supports inventory and performance collection from both iSCSI and Fibre Channel SolidFire configurations.

The SolidFire data collector utilizes the SolidFire REST API. The acquisition unit where the data collector resides needs to be able to initiate HTTPS connections to TCP port 443 on the SolidFire cluster management IP address. The data collector needs credentials capable of making REST API queries on the SolidFire cluster.

### Terminology

Cloud Insights acquires the following inventory information from the NetApp SolidFire All-Flash Array data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

<b>Vendor/Model Term</b>	<b>Cloud Insights Term</b>
Drive	Disk
Cluster	Storage

Vendor/Model Term	Cloud Insights Term
Node	Storage Node
Volume	Volume
Fibre channel port	Port
Volume Access Group, LUN Assignment	Volume Map
iSCSI Session	Volume Mask

Note: These are common terminology mappings only and might not represent every case for this data collector.

## Requirements

The following are requirements for configuring this data collector:

- Management Virtual IP Address
- Read-only username and credentials
- Port 443

## Configuration

Field	Description
Management Virtual IP Address (MVIP)	Management Virtual IP address of the SolidFire Cluster
User Name	Name used to log into the SolidFire cluster
Password	Password used to log into the SolidFire cluster

## Advanced configuration

Field	Description
Connection Type	Choose connection type
Communication Port	Port used for NetApp API
Inventory Poll Interval (min)	Default is 20 minutes
Performance Poll Interval (sec)	Default is 300 seconds

## Troubleshooting

When SolidFire reports an error it is displayed in Cloud Insights as follows:

*An error message was received from a SolidFire device while trying to retrieve data. The call was <method> (<parameterString> ). The error message from the device was (check the device manual):*

<message>

Where:

- The <method> is an HTTP method, such as GET or PUT.
- The <parameterString> is a comma separated list of parameters that were included in the REST call.
- The <message> is whatever the device returned as the error message.

Additional information on this Data Collector may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

## NetApp StorageGrid data collector

The NetApp StorageGrid data collector supports inventory collection from StorageGrid configurations.

### Configuration

Field	Description
StorageGrid Host IP Address	Management Virtual IP address of the StorageGrid appliance
User Name	Name used to log into the StorageGrid appliance
Password	Password used to log into the StorageGrid appliance

### Advanced configuration

Field	Description
Inventory Poll Interval (min)	Default is 60 minutes

### Troubleshooting

Additional information on this Data Collector may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

## Nutanix NX data collector

Cloud Insights uses the Nutanix data collector to discover inventory and performance data for Nutanix NX storage systems.

## Terminology

Cloud Insights acquires the following inventory information from the Nutanix data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Storage Pool	Storage Pool
Nutanix Container	Internal Volume
Nutanix Container	File Share
NFS Share	Share

Note: These are common terminology mappings only and might not represent every case for this data collector.

## Requirements

- The external data services IP address for the cluster.
- Administrator user name and password
- Port requirement: HTTPS 443

## Configuration

Field	Description
Prism External IP Address	The external data services IP address for the cluster
User name	User name for the Admin account
Password	Password for the Admin account

## Advanced configuration

Field	Description
TCP port	TCP Port used to connect to Nutanix array. The default is 9440.
Inventory poll interval (min)	Interval between inventory polls. The default is 60 minutes.
Performance poll interval(sec)	Interval between performance polls. The default is 300 seconds.



## Troubleshooting

Additional information on this Data Collector may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

## OpenStack data collector

The OpenStack (REST API / KVM) data collector acquires inventory data for all OpenStack instances, and optionally, VM performance data.

### Requirements

- IP address of the OpenStack controller
  - OpenStack admin role credential and sudo access to the Linux KVM hypervisor. If you are not using the admin account or admin equivalent privileges, you will need to use trial and error to identify the default policies to relax for your data collector userid.
  - The OpenStack Ceilometer module must be installed and configured for performance collection. Configuring the Ceilometer is done by editing the nova.conf file for each hypervisor and then restarting the Nova Compute service on each hypervisor. The option name changes for different releases of OpenStack:
    - Icehouse
    - Juno
    - Kilo
    - Liberty
    - Mitaka
    - Newton
    - Ocata
  - For CPU stats, “compute\_monitors=ComputeDriverCPUMonitor” needs to be turned on in /etc/nova/nova.conf on compute nodes.
  - Port requirements:
    - 5000 for http and 13000 for https, for the Keystone service
    - 22 for KVM SSH
    - 8774 for Nova Compute Service
    - 8776 for Cinder Block Service
    - 8777 for Ceilometer Performance Service
    - 9292 for Glance Image Service
- Note** The port binds to the specific service, and the service may run on the controller or

another host in larger environments.

## Configuration

Field	Description
OpenStack Controller IP Address	IP address or fully-qualified domain name of the OpenStack Controller
OpenStack Administrator	User name for an OpenStack Admin
OpenStack Password	Password used for the OpenStack Admin
OpenStack Administrator Tenant	OpenStack Administrator Tenant name
KVM Sudo User	KVM Sudo User name
Choose 'Password' or 'OpenSSH Key File' to specify credential type	Credential type used to connect to the device via SSH
Full Path to Inventory Private Key	Full Path to Inventory Private Key
KVM Sudo Password	KVM Sudo Password

## Advanced configuration

Field	Description
Enable hypervisor inventory discovery through SSH	Check this to enable hypervisor inventory discovery through SSH
OpenStack Admin URL port	OpenStack Admin URL port
Use HTTPS	Check to use secure HTTP
SSH Port	Port used for SSH
SSH Process Retries	Number of inventory retry attempts
Inventory Poll Interval (min)	Interval between inventory polls. The default is 20 minutes.

## Troubleshooting

Some things to try if you encounter problems with this data collector:

### Inventory

Problem:	Try this:
"Configuration error" with error messages start with "Policy doesn't allow" or "You are not authorized"	* Check ip address * Check User name and password

Additional information may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

## Oracle ZFS Storage Appliance data collector

Cloud Insights uses the Oracle ZFS Storage Appliance data collector to gather inventory and performance data.

### Terminology

Cloud Insights acquires inventory information with the ceph data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Disk (SSD)	Disk
Cluster	Storage
Controller	Storage Node
LUN	Volume
LUN Map	Volume Map
Initiator,Target	Volume Mask
Share	Internal Volume

Note: These are common terminology mappings only and might not represent every case for this data source.

### Requirements

- Host names for the ZFS Controller-1 and the ZFS Controller-2
- Administrator user name and password
- Port requirement: 215 HTTP/HTTPS

### Configuration

Field	Description
ZFS Controller-1 Hostname	Host name for storage controller 1
ZFS Controller-2 Hostname	Host name for storage controller 2
User name	User name for the storage system administrator user account
Password	Password for the administrator user account

## Advanced configuration

Field	Description
Connection Type	HTTPS or HTTP, also displays the default port
Override Connection Port	If blank, use the default port in the Connection Type field, otherwise enter the connection port to use
Inventory poll interval	The default is port 60 seconds
Performance Poll Interval (sec)	The default is 300.

## Troubleshooting

Some things to try if you encounter problems with this data collector:

### Inventory

Problem:	Try this:
"Invalid login credentials"	validate Zfs user account and password
"Configuration error" with error message "REST Service is disabled"	Verify REST service is enabled on this device.
"Configuration error " with error message "User unauthorized for command"	<p>Likely due to certain roles (for example, 'advanced_analytics') are not included for the configured user &lt;userName&gt;.</p> <p>Possible Solution:</p> <ul style="list-style-type: none"><li>* Correct the Analytics (statistic) scope for the user \${user} with the read only role:</li><li>- From the Configuration → Users screen, put your mouse over the role and double click to allow editing</li><li>- Select "Analytics" from the Scope drop down menu. A list of the possible properties appears.</li><li>- Click the top most check box and it will select all three properties.</li><li>- Click the Add button on the right side.</li><li>- Click the Apply button at the top right of the pop-up window. The pop-up window will close.</li></ul>

Additional information may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

## Pure Storage FlashArray data collector

Cloud Insights uses the Pure Storage FlashArray data collector to gather inventory and performance data.

## Terminology

For each asset type acquired by Cloud Insights, the most common terminology used for the asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Drive (SSD)	Disk
Array	Storage
Controller	Storage Node
Volume	Volume
LUN Map	Volume Map
Initiator,Target	Volume Mask

Note: These are common terminology mappings only and might not represent every case for this data collector.

## Requirements

- Storage system IP address
- User name and password for the Administrator account of the Pure storage system.
- Port requirement: HTTP/HTTPS 80/443

## Configuration

Field	Description
FlashArray Host IP Address	IP address of the storage system
User name	User name with admin privileges
Password for the admin privileged account	Password

## Advanced configuration

Field	Description
Connection type	Choose HTTP or HTTPS. Also displays the default port.

Field	Description
Override TCP port	If blank, use the default port in the Connection Type field, otherwise enter the connection port to use
Inventory poll interval (min)	The default is 60 minutes
Performance Poll Interval (sec)	The default is 300

## Troubleshooting

Some things to try if you encounter problems with this data collector:

### Inventory

Problem:	Try this:
"Invalid login credentials" with error messages "Policy doesn't allow" or "You are not authorized"	Validate Pure user account and password via Pure http interface

Additional information may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

## Red Hat Virtualization data collector

Cloud Insights uses the Red Hat Virtualization data collector to gather inventory data from virtualized Linux and Microsoft Windows workloads.

## Terminology

For each asset type acquired by Cloud Insights, the most common terminology used for the asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Disk	Virtual Disk
Host	Host
Virtual Machine	Virtual Machine
Storage Domain	Data Store
Logical Unit	LUN

Note: These are common terminology mappings only and might not represent every case for this data collector.

## Requirements

- IP address of the RHEV server over port 443 via REST API
- Read-only username and password
- RHEV Version 3.0+

## Configuration

Field	Description
RHEV Server IP Address	IP address of the storage system
User name	User name with admin privileges
Password for the admin privileged account	Password

## Advanced configuration

Field	Description
HTTPS Communication Port	Port used for HTTPS communication to RHEV
Inventory poll interval (min)	The default is 20 minutes.

## Troubleshooting

Additional information on this Data Collector may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

## Configuring the VMware vSphere data collector

The data collector for VMware vSphere collects ESX Host information and requires read-only privileges on all objects within the Virtual Center.

## Terminology

Cloud Insights acquires the following inventory information from the VMware vSphere data collector. For each asset type acquired, the most common terminology used for the asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Virtual disk	Disk
Host	Host
Virtual machine	Virtual machine

Vendor/Model Term	Cloud Insights Term
Data store	Data store
LUN	Volume
Fibre channel port	Port

These are common terminology mappings only and might not represent every case for this data collector.

## Requirements

The following information is required to configure this data collector:

- IP address of the Virtual Center server
- Read-only username and password in Virtual Center
- We require read only privileges on all objects within Virtual Center.
- SDK access on the Virtual Center server – normally already setup.
- 3rd party software installed on OnCommand Insight Server / RAU: none
- Port requirements: http-80 https-443
- Validate access:
  - Log into Virtual Center Client using above username and password
  - Verify SDK enabled: telnet <vc\_ip> 443

## Setup and connection

Field	Description
Name	Unique name for the data collector
Acquisition unit	Name of acquisition unit

## Configuration

Field	Description
Virtual center IP Address	IP address of the Virtual Center
User name	User name used to access the Virtual Center
Password	Password used to access the Virtual Center

## Advanced configuration

In the advanced configuration screen, check the **VM Performance** box to collect performance data.



Inventory collection is enabled by default.  
The following fields can be configured:

Field	Description
Inventory poll interval (min)	Default is 20
Filter VMs	Select CLUSTER, DATACENTER, or ESX HOST
Choose 'Exclude' or 'Include' to Specify a List	Create a filter list (CLUSTER, DATACENTER, and/or ESX_HOST)
Number of retries	Default is 3
Communication port	Default is 443
Performance poll interval (sec)	Default is 300

## Troubleshooting

Some things to try if you encounter problems with this data collector:

### Inventory

Problem:	Try this:
Error: Include list to filter VMs cannot be empty	If Include List is selected, please list valid DataCenter, Cluster, or Host names to filter VMs
Error: Failed to instantiate a connection to VirtualCenter at IP	Possible solutions:  * Verify credentials and IP address entered. * Try to communicate with Virtual Center using VMware Infrastructure Client. * Try to communicate with Virtual Center using Managed Object Browser (e.g MOB).
Error: VirtualCenter at IP has non-conform certificate that JVM requires	Possible solutions:  * Recommended: Re-generate certificate for Virtual Center by using stronger (e.g. 1024-bit) RSA key. * Not Recommended: Modify the JVM java.security configuration to leverage the constraint jdk.certpath.disabledAlgorithms to allow 512-bit RSA key. See JDK 7 update 40 release notes at " <a href="http://www.oracle.com/technetwork/java/javase/7u40-relnotes-2004172.html">http://www.oracle.com/technetwork/java/javase/7u40-relnotes-2004172.html</a> "

Additional information may be found from the [Support](#) page or in the [Data Collector Support Matrix](#).

## Copyright Information

Copyright © 2019–2020 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system-without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

## Trademark Information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.