



- Create and access a list of your products
- Manage your Dell EMC sites, products, and product-level contacts using Company Administration.

[Products](#)[Solutions](#)[Services](#)[Support](#)[Back](#)[Support Home](#)[Support Library](#)[Support Services & Contracts](#)[Drivers & Downloads](#)[Manuals & Documentation](#)[Diagnostics & Tools](#)[Self-Repair & Parts](#)[Service Requests & Dispatch Status](#)[Order Support](#)[Contact Technical Support](#)[Community](#)[Contact Us](#)[Sign In](#)[Create an Account](#)[Premier Sign In](#)[Partner Program Sign In](#)[UK/EN](#)[Back](#)[Home](#) / [Support](#) / [Knowledge Base Article](#)

Article Number: 000126390

[Print](#)[Email](#)[English](#) ▼

How to Use the Jumper to Reset the BIOS or UEFI Password on Your Dell Desktop

Summary: This article provides information about how to reset the BIOS or UEFI password using the motherboard jumper on a Dell desktop.

This article may have been automatically translated. If you have any feedback regarding its quality, please let us know using the form at the bottom of this page.

Article Content

Symptoms

NOTE: This process will not clear a Windows Operating System password, nor will it clear passwords on a Dell portable computer. This is only to clear System BIOS passwords on Dell Desktop and Mini-Tower systems.

NOTE: The BIOS is the program that activates the hardware that is required to start your computer. The jumper is a small plastic covering that is found inside your computer.

If you are prompted for the Basic Input/Output System (BIOS) password at startup (before the operating system loads) or the BIOS or CMOS setup is locked, and you do not know or have forgotten the password, you cannot use your computer or change BIOS settings. Use these instructions to reset the BIOS password manually using the jumper.

Cause

Cause information is not available.

Resolution

Before you begin, perform the safety steps in the order below.

WARNING: These steps are for your personal safety and the protection of the equipment.



1. Turn off the computer and unplug the power cable.
2. Wait for 5 seconds.
3. Disconnect all external devices.

4. Disconnect any telephone or network cables from your computer.
5. Press and hold the **Power button** for 10 seconds while your computer is unplugged to discharge static electricity from the system.
6. Before touching anything inside your computer, ground yourself with a wrist-grounding strap or by touching an unpainted metal surface, such as the metal at the back of your computer. While you work, periodically touch an unpainted metal surface to dissipate static electricity.

To use the jumper to reset the BIOS password

① **NOTE:** On the [Dell Manuals](#) website, download the product documentation or service manual for your computer. Refer to the *System Board Components* section for a labeled illustration of the jumpers on the system board.

1. Ensure that your work surface is flat and clean to prevent scratching your computer's cover.
2. With your computer still turned off and unplugged, remove your computer's cover.
 1. To locate the password jumper on the motherboard, look for the letters PWD, PSWD, or PSWDCLR.
3. Choose an option:

If there are 2 metals pins under the jumper

1. Remove the jumper from the pins, replace the computer cover, reconnect the power cable and monitor, and turn on the computer.
2. After the Windows login screen appears, turn off the computer.
3. Again, disconnect the power cable and monitor. Press and hold the power button for 10 seconds to release static electricity from the system.
4. Remove your computer cover.
5. Replace the jumper in its original position covering the 2 pins. This will enable password feature.
6. Replace the computer cover.
7. Reconnect the power cable and other connections and turn on the computer.

If there are 3 pins under the jumper, see Figure 1 below.




Figure 1 - Generic motherboard illustration showing a 3-pin password jumper, your motherboard may vary, see the [product documentation](#) for your system for specific instructions.

1. Remembering which two pins are covered, remove the jumper from those pins.
2. Reinstall the jumper in a different position. For example, if you removed the jumper from pins 2 and 3, reinstall the jumper over pins 1 and 2.
3. Replace the computer cover and reconnect the power cable and monitor.
4. Turn on the computer and wait 5 s. Then press and hold the **Power button** until the computer turns off again.
5. Disconnect the power cable and monitor again. Press and hold the **Power button** for 10 s to release static electricity from the system.
6. Replace the jumper over the original 2 pins.
7. Replace the computer cover.
8. Reconnect the power cable and other connections and turn on the computer.

You can now assign a new system and/or setup password. For more password information, refer to the Passwords section of your computer's [service manual](#).

Additional Information

Recommended Articles



Here are some recommended articles related to this topic that might be of interest to you.

- [How to Perform a BIOS or CMOS Reset and Clear the NVRAM on Dell Computers](#)
- [How to Reset or Clear the BIOS Password](#)
- [How to Reset Real Time Clock \(RTC\) to Recover Your Dell Desktop System](#)
- [Dell Support for Lost BIOS Password](#)
- [General Hard Drive and BIOS Password Information](#)

Article Properties

Affected Product

Desktops & All-in-Ones

Last Published Date

24 Jul 2023

Version

4

Article Type

Solution

Contact Support

Rate This Article

Accurate

Useful

Easy to Understand

Was this article helpful?

☐ Yes ☐ No

Additional Information (optional)

0/3000 characters

Letters, numbers and any special characters except < > () \

Submit Feedback

Your Recently Viewed Articles



[How to Reset or Clear the BIOS Password](#)

[Back to Top](#)

Site Map

Account

Account

My Account

Order Status

My Products

Dell Rewards Balance

Support

Support

Support Home

Contact Technical Support

Returns

Connect with Us

Connect with Us

Community

Contact Us

Site Map

Our Offerings

Our Offerings

Our Company

Our Company

Our Partners

Our Partners

Resources

Resources

APEX

Who We Are

Find a Partner

Blog

Products

Careers

OEM Solutions

Dell Rewards

Solutions

Dell Technologies Capital

Partner Program

Events

Services

Investors

Email Sign-Up

Deals

Newsroom

Dell Learning Centre

Perspectives

Privacy Centre

Recycling

Resource Library

ESG & Impact

Trial Software Downloads

Customer Stories

Dell Technologies

Dell Premier

Copyright © 2024 Dell Inc.

Terms & Conditions

Privacy Statement

Cookies, Ads & Emails

Legal & Regulatory

Anti-Slavery & Human Trafficking

Carbon Reduction Plan

Contact Support

↑