



# **Install and setup**

## **ONTAP Systems**

NetApp  
June 27, 2022

This PDF was generated from <https://docs.netapp.com/us-en/ontap-systems/fas2700/install-setup.html> on June 27, 2022. Always check docs.netapp.com for the latest.

# Table of Contents

- Install and setup ..... 1
  - Start here: Choose your installation and setup experience ..... 1
  - Quick guide - AFF A220 and FAS2700 ..... 1
  - Videos - AFF A220 and FAS2700 ..... 1
  - Detailed guide - AFF A220 and FAS2700 ..... 2

# Install and setup

## Start here: Choose your installation and setup experience

For most configurations, you can choose from different content formats.

- [Quick steps](#)

A printable PDF of step-by-step instructions with live links to additional content.

- [Video steps](#)

Video step-by-step instructions.

- [Detailed steps](#)

Online step-by-step instructions with live links to additional content.

If your system is in a MetroCluster IP configuration, see the [Install MetroCluster IP Configuration](#) instructions.

## Quick guide - AFF A220 and FAS2700

This guide gives graphic instructions for a typical installation of your system from racking and cabling, through initial system bring-up. Use this guide if you are familiar with installing NetApp systems.

Access the *Installation and Setup Instructions* PDF poster:

[AFF A220/FAS2700 Systems Installation and Setup Instructions](#)

## Videos - AFF A220 and FAS2700

There are two videos; one showing how to rack and cable your system and one showing an example of using the System Manager Guided Setup to perform initial system configuration.

### Video one of two: Hardware installation and cabling

The following video shows how to install and cable your new system.

[NetApp video: AFF A220 and FAS2700 Systems: Installation and Setup Instructions](#)

### Video two of two: Performing end-to-end software configuration

The following video shows end-to-end software configuration for systems running ONTAP 9.2 and later.

[NetApp video: Software configuration for vSphere NAS datastores for FAS/AFF systems running ONTAP 9.2](#)

# Detailed guide - AFF A220 and FAS2700

This guide gives detailed step-by-step instructions for installing a typical NetApp system. Use this guide if you want more detailed installation instructions.

## Step 1: Prepare for installation

To install your FAS2700 or AFF A220 system, you need to create an account on the NetApp Support Site, register your system, and get license keys. You also need to inventory the appropriate number and type of cables for your system and collect specific network information.

You need to have access to the Hardware Universe for information about site requirements as well as additional information on your configured system. You might also want to have access to the Release Notes for your version of ONTAP for more information about this system.

[NetApp Hardware Universe](#)

[Find the Release Notes for your version of ONTAP 9](#)

You need to provide the following at your site:

- Rack space for the storage system
- Phillips #2 screwdriver
- Additional networking cables to connect your system to your network switch and laptop or console with a Web browser
- A laptop or console with an RJ-45 connection and access to a Web browser

### Steps

1. Unpack the contents of all boxes.
2. Record the system serial number from the controllers.



3. Set up your account:
  - a. Log in to your existing account or create an account.
  - b. Register your system.

[NetApp Product Registration](#)

4. Download and install Config Advisor on your laptop.

[NetApp Downloads: Config Advisor](#)

5. Inventory and make a note of the number and types of cables you received.

The following table identifies the types of cables you might receive. If you receive a cable not listed in the table, see the Hardware Universe to locate the cable and identify its use.

Type of cable...	Part number and length	Connector type	For...
10 GbE cable (order dependent)	X6566B-05-R6 (112-00297), 0.5m X6566B-2-R6 (112-00299), 2m		Cluster interconnect network
10 GbE cable (order dependent)	Part number X6566B-2-R6 (112-00299), 2m or X6566B-3-R6 (112-00300), 3m X6566B-5-R6 (112-00301), 5m		Data
Optical network cables (order dependent)	X6553-R6 (112-00188), 2m X6536-R6 (112-00090), 5m X6554-R6(112-00189), 15m		FC host network
Cat 6, RJ-45 (order dependent)	Part numbers X6585-R6 (112-00291), 3m X6562-R6 (112-00196), 5m		Management network and Ethernet data
Storage (order dependent)	Part number X66030A (112-00435), 0.5m X66031A (112-00436), 1m X66032A (112-00437), 2m X66033A (112-00438), 3m		Storage
Micro-USB console cable	Not applicable		Console connection during software setup on non-Windows or Mac laptop/console
Power cables	Not applicable		Powering up the system

6. Download and complete the *Cluster configuration worksheet*.

[Cluster Configuration Worksheet](#)

## Step 2: Install the hardware

You need to install your system in a 4-post rack or NetApp system cabinet, as applicable.

### Steps

1. Install the rail kits, as needed.

2. Install and secure your system using the instructions included with the rail kit.



You need to be aware of the safety concerns associated with the weight of the system.



3. Attach cable management devices (as shown).



4. Place the bezel on the front of the system.

### Step 3: Cable controllers to your network

You can cable the controllers to your network by using the two-node switchless cluster method or by using the cluster interconnect network.

#### Option 1: Cable a two-node switchless cluster, unified network configuration

Management network, UTA2 data network, and management ports on the controllers are connected to switches. The cluster interconnect ports are cabled on both controllers.

You must have contacted your network administrator for information about connecting the system to the switches.

Be sure to check the illustration arrow for the proper cable connector pull-tab orientation.



As you insert the connector, you should feel it click into place; if you do not feel it click, remove it, turn it around and try again.

#### Steps

1. You can use the graphic or the step-by step instructions to complete the cabling between the controllers

and to the switches:



Step	Perform on each controller
1	<p>Cable the cluster interconnect ports to each other with the cluster interconnect cable:</p> <ul style="list-style-type: none"><li>• e0a to e0a</li><li>• e0b to e0b</li></ul> <p> Cluster interconnect cables</p> 

Step	Perform on each controller
<div data-bbox="183 153 245 195" data-label="Text">2</div>	<p data-bbox="513 153 1482 222">Use one of the following cable types to cable the UTA2 data ports to your host network:</p> <p data-bbox="513 254 654 285">An FC host</p> <ul data-bbox="537 317 829 506" style="list-style-type: none"> <li>• 0c and 0d</li> <li>• <b>or</b> 0e and 0f A 10GbE</li> <li>• e0c and e0d</li> <li>• <b>or</b> e0e and e0f</li> </ul> <div data-bbox="545 569 597 625" data-label="Image"></div> <p data-bbox="659 548 1442 646">You can connect one port pair as CNA and one port pair as FC, or you can connect both port pairs as CNA or both port pairs as FC.</p> <div data-bbox="516 720 711 821">  <p>Optical network cables</p> </div> <div data-bbox="781 768 1052 821"> <p>SFP for optical cables</p>  </div> <div data-bbox="1117 720 1312 821">  <p>10GbE network cables</p> </div> 
<div data-bbox="183 1266 245 1308" data-label="Text">3</div>	<p data-bbox="513 1266 1406 1329">Cable the e0M ports to the management network switches with the RJ45 cables:</p> <div data-bbox="643 1434 813 1493">  <p>Ethernet cables</p> </div> 
	<p data-bbox="513 1808 1073 1839">DO NOT plug in the power cords at this point.</p>



2. To cable your storage, see [Cabling controllers to drive shelves](#)

## Option 2: Cable a switched cluster, unified network configuration

Management network, UTA2 data network, and management ports on the controllers are connected to switches. The cluster interconnect ports are cabled to the cluster interconnect switches.

You must have contacted your network administrator for information about connecting the system to the switches.

Be sure to check the illustration arrow for the proper cable connector pull-tab orientation.



As you insert the connector, you should feel it click into place; if you do not feel it click, remove it, turn it around and try again.

## Steps

1. You can use the graphic or the step-by step instructions to complete the cabling between the controllers and the switches:



Step	Perform on each controller module
<div data-bbox="183 153 245 195" data-label="Text">1</div>	<p data-bbox="513 159 1385 222">Cable e0a and e0b to the cluster interconnect switches with the cluster interconnect cable:</p> <div data-bbox="639 296 1360 617" data-label="Diagram"> </div>
<div data-bbox="183 699 245 741" data-label="Text">2</div>	<p data-bbox="513 705 1477 768">Use one of the following cable types to cable the UTA2 data ports to your host network:</p> <p data-bbox="513 804 654 835">An FC host</p> <ul data-bbox="537 867 716 951" style="list-style-type: none"> <li>• 0c and 0d</li> <li>• <b>or</b> 0e and 0f</li> </ul> <p data-bbox="513 982 626 1014">A 10GbE</p> <ul data-bbox="537 1052 745 1136" style="list-style-type: none"> <li>• e0c and e0d</li> <li>• <b>or</b> e0e and e0f</li> </ul> <div data-bbox="545 1199 597 1255" data-label="Image"> </div> <p data-bbox="659 1178 1442 1272">You can connect one port pair as CNA and one port pair as FC, or you can connect both port pairs as CNA or both port pairs as FC.</p> <div data-bbox="516 1346 1317 1818" data-label="Diagram"> </div>

Step	Perform on each controller module
3	<p>Cable the e0M ports to the management network switches with the RJ45 cables:</p> 
	DO NOT plug in the power cords at this point.

2. To cable your storage, see [Cabling controllers to drive shelves](#)

### Option 3: Cable a two-node switchless cluster, Ethernet network configuration

Management network, Ethernet data network, and management ports on the controllers are connected to switches. The cluster interconnect ports are cabled on both controllers.

You must have contacted your network administrator for information about connecting the system to the switches.

Be sure to check the illustration arrow for the proper cable connector pull-tab orientation.



As you insert the connector, you should feel it click into place; if you do not feel it click, remove it, turn it around and try again.

### Steps

1. You can use the graphic or the step-by step instructions to complete the cabling between the controllers and to the switches:



Step	Perform on each controller
<div data-bbox="183 495 245 537" data-label="Text">1</div>	<p data-bbox="513 495 1484 558">Cable the cluster interconnect ports to each other with the cluster interconnect cable:</p> <ul data-bbox="537 600 691 674" style="list-style-type: none"> <li>• e0a to e0a</li> <li>• e0b to e0b</li> </ul> <div data-bbox="680 705 964 768" data-label="Image"> <p data-bbox="680 747 964 768">Cluster interconnect cables</p> </div> <div data-bbox="680 789 1365 1020" data-label="Diagram"> </div>
<div data-bbox="183 1104 245 1146" data-label="Text">2</div>	<p data-bbox="513 1104 1406 1167">Use the Cat 6 RJ45 cable to cable the e0c through e0f ports to your host network:</p> <div data-bbox="639 1241 850 1304" data-label="Image"> <p data-bbox="639 1283 850 1304">CAT6 RJ-45 cables</p> </div> <div data-bbox="639 1241 1357 1535" data-label="Diagram"> </div>

Step	Perform on each controller
3	<p>Cable the e0M ports to the management network switches with the RJ45 cables:</p> 
	DO NOT plug in the power cords at this point.

2. To cable your storage, see [Cabling controllers to drive shelves](#)

#### Option 4: Cable a switched cluster, Ethernet network configuration

Management network, Ethernet data network, and management ports on the controllers are connected to switches. The cluster interconnect ports are cabled to the cluster interconnect switches.

You must have contacted your network administrator for information about connecting the system to the switches.

Be sure to check the illustration arrow for the proper cable connector pull-tab orientation.



As you insert the connector, you should feel it click into place; if you do not feel it click, remove it, turn it around and try again.

#### Steps

1. You can use the graphic or the step-by step instructions to complete the cabling between the controllers and the switches:



## Step

## Perform on each controller module

1

Cable e0a and e0b to the cluster interconnect switches with the cluster interconnect cable:



2

Use the Cat 6 RJ45 cable to cable the e0c through e0f ports to your host network:



Step	Perform on each controller module
3	<p>Cable the e0M ports to the management network switches with the RJ45 cables:</p>  <p>The diagram shows a top-down view of two controller modules. Purple lines represent Ethernet cables connecting the e0M ports on the front of each module to network switches. A circular inset provides a close-up of an e0M port with an RJ45 cable plugged in. The label 'Ethernet cables' is placed above the main diagram.</p>
	<p>DO NOT plug in the power cords at this point.</p>

2. To cable your storage, see [Cabling controllers to drive shelves](#)


## Step 4: Cable controllers to drive shelves

You must cable the controllers to your shelves using the onboard storage ports. NetApp recommends MP-HA cabling for systems with external storage. If you have a SAS tape drive, you can use single-path cabling. If you have no external shelves, MP-HA cabling to internal drives is optional (not shown) if the SAS cables are ordered with the system.

### Option 1: Cable storage on an HA pair with external drive shelves

You must cable the shelf-to-shelf connections, and then cable both controllers to the drive shelves.

Be sure to check the illustration arrow for the proper cable connector pull-tab orientation.



### Steps

1. Cable the HA pair with external drive shelves:



The example uses DS224C. Cabling is similar with other supported drive shelves.





Step	Perform on each controller
1	<p>Cable the shelf-to-shelf ports.</p> <ul style="list-style-type: none"> <li>• Port 3 on IOM A to port 1 on the IOM A on the shelf directly below.</li> <li>• Port 3 on IOM B to port 1 on the IOM B on the shelf directly below.</li> </ul>  mini-SAS HD to mini-SAS HD cables
2	<p>Connect each node to IOM A in the stack.</p> <ul style="list-style-type: none"> <li>• Controller 1 port 0b to IOM A port 3 on last drive shelf in the stack.</li> <li>• Controller 2 port 0a to IOM A port 1 on the first drive shelf in the stack.</li> </ul>  mini-SAS HD to mini-SAS HD cables
3	<p>Connect each node to IOM B in the stack</p> <ul style="list-style-type: none"> <li>• Controller 1 port 0a to IOM B port 1 on first drive shelf in the stack.</li> <li>• Controller 2 port 0b to IOM B port 3 on the last drive shelf in the stack.</li> </ul>  mini-SAS HD to mini-SAS HD cables

If you have more than one drive shelf stack, see the *Installation and Cabling Guide* for your drive shelf type.

### Installing and cabling

2. To complete setting up your system, see [Completing system setup and configuration](#)



## Step 5: Complete system setup and configuration

You can complete the system setup and configuration using cluster discovery with only a connection to the switch and laptop, or by connecting directly to a controller in the system and then connecting to the management switch.

### Option 1: Complete system setup if network discovery is enabled

If you have network discovery enabled on your laptop, you can complete system setup and configuration using automatic cluster discovery.

#### Steps

1. Use the following animation to set one or more drive shelf IDs

[Setting drive shelf IDs](#)

2. Plug the power cords into the controller power supplies, and then connect them to power sources on different circuits.
3. Turn on the power switches to both nodes.



Initial booting may take up to eight minutes.

4. Make sure that your laptop has network discovery enabled.

See your laptop's online help for more information.

5. Use the following animation to connect your laptop to the Management switch.

[Connecting your laptop to the Management switch](#)

6. Select an ONTAP icon listed to discover:



- a. Open File Explorer.
- b. Click network in the left pane.
- c. Right click and select refresh.
- d. Double-click either ONTAP icon and accept any certificates displayed on your screen.



XXXXX is the system serial number for the target node.

System Manager opens.

7. Use System Manager guided setup to configure your system using the data you collected in the *NetApp ONTAP Configuration Guide*.

#### [ONTAP Configuration Guide](#)

8. Verify the health of your system by running Config Advisor.
9. After you have completed the initial configuration, go to the [ONTAP & ONTAP System Manager Documentation Resources](#) page for information about configuring additional features in ONTAP.

### Option 2: Completing system setup and configuration if network discovery is not enabled

If network discovery is not enabled on your laptop, you must complete the configuration and setup using this task.

#### Steps

1. Cable and configure your laptop or console:
  - a. Set the console port on the laptop or console to 115,200 baud with N-8-1.



See your laptop or console's online help for how to configure the console port.

- b. Connect the console cable to the laptop or console, and connect the console port on the controller using the console cable that came with your system.



c. Connect the laptop or console to the switch on the management subnet.



d. Assign a TCP/IP address to the laptop or console, using one that is on the management subnet.

2. Use the following animation to set one or more drive shelf IDs:

#### Setting drive shelf IDs

3. Plug the power cords into the controller power supplies, and then connect them to power sources on different circuits.
4. Turn on the power switches to both nodes.



Initial booting may take up to eight minutes.

5. Assign an initial node management IP address to one of the nodes.

If the management network has DHCP...	Then...
Configured	Record the IP address assigned to the new controllers.

If the management network has DHCP...	Then...
Not configured	<p>a. Open a console session using PuTTY, a terminal server, or the equivalent for your environment.</p> <div>  <p>Check your laptop or console's online help if you do not know how to configure PuTTY.</p> </div> <p>b. Enter the management IP address when prompted by the script.</p>

6. Using System Manager on your laptop or console, configure your cluster:

- a. Point your browser to the node management IP address.



The format for the address is <https://x.x.x.x>.

- b. Configure the system using the data you collected in the *NetApp ONTAP Configuration guide*.

[ONTAP Configuration Guide](#)

7. Verify the health of your system by running Config Advisor.

8. After you have completed the initial configuration, go to the [ONTAP & ONTAP System Manager Documentation Resources](#) page for information about configuring additional features in ONTAP.

## Copyright Information

Copyright © 2022 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

## Trademark Information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.