

VNC oem commands

Item	Description	Command
1	Set VNC Password to 12345678	ipmitool -H <ip> -I lanplus -U admin -P admin raw 0x32 0x17 1 0x31 0x32 0x33 0x34 0x35 0x36 0x37 0x38
2	Reset VNC Password	ipmitool -H <ip> -I lanplus -U admin -P admin raw 0x32 0x17 1
3	Set VNC Connection Type	ipmitool -H <ip> -I lanplus -U admin -P admin raw 0x32 0x17 0 7

Note

1. Max password length: 8
2. Connection type:
 - bit0 - stunnel
 - bit1 - ssh
 - bit2 - non secure/password