

Type 546, 546S, and 546NS Electro-Pneumatic Transducers

Contents

| | | | |
|--|----|--|----|
| Introduction | 1 | Repair Kits for Type 546, 546S, and 546NS Transducers | 12 |
| Scope of Manual | 1 | Type 546, 546S, & 546NS Transducers | 13 |
| Description | 1 | Torque Motor | 13 |
| Specifications | 2 | Type 82 Relay | 14 |
| Installation | 2 | Diagnostic Connections | 15 |
| Mounting | 2 | Mounting Parts | 15 |
| Pressure Connections | 4 | Loop Schematics | 17 |
| Diagnostic Connections | 4 | CSA Schematics | 17 |
| Electrical Connections | 4 | FM Schematics | 19 |
| Operating Information | 5 | Introduction | |
| Adjustments | 5 | Scope of Manual | |
| Calibration | 6 | This instruction manual provides installation, opera- tion, maintenance, and parts ordering information for the Type 546, 546S, and 546NS transducers and Type 82 relay. Refer to separate manuals for instruc- tions covering equipment used with the transducer. | |
| Equipment Required | 6 | Only personnel qualified through training or experience should install, operate, and maintain this transducer. If there are any questions concerning these instructions, contact your Fisher Controls sales office or sales rep- resentative before proceeding. | |
| Calibration Procedure | 6 | Description | |
| Recalibration | 7 | The Type 546 or 546NS transducer (figure 1) receives either a voltage (Vdc) or a current (mAdc) input signal and transmits a proportional pneumatic output pres- sure to a final control element. The Type 546S trans- ducer receives a current (mAdc) input signal and transmits a proportional pneumatic output pressure. A typical application is in electronic control loops where the final control element, generally a control valve, is pneumatically operated. The input signal, output pres- sure range, and electrical classification, if approved, of each transducer is indicated on the nameplate at- tached to the cover (figure 2). | |
| Changing Output Pressure Range | 7 | | |
| Reversing the Action | 7 | | |
| Split Range Operation | 7 | | |
| Principle of Operation | 8 | | |
| Maintenance | 9 | | |
| Troubleshooting | 9 | | |
| Electrical | 9 | | |
| Pneumatic | 10 | | |
| Alignment | 10 | | |
| Span Adjustment | 10 | | |
| Torque Motor Frame | 11 | | |
| Armature Travel Stop | 11 | | |
| Coil | 11 | | |
| Type 82 Relay Removal and Replacement | 11 | | |
| Type 82 Relay Maintenance | 11 | | |
| Replacing the Feedback Bellows Assembly | 12 | | |
| Parts Ordering | 12 | | |
| Parts List | 12 | | |



Type 546, 546S, and 546NS




Figure 1. Type 546 Mounted on a Type 657 Pneumatic Diaphragm Actuator




Figure 2. Typical Nameplate

The Type 546S transducer is approved as being intrinsically safe when used with certain barrier systems. Refer to the Loop Schematics section of this manual.

The Type 546NS transducer meets typical requirements of the nuclear power industry. The Type 546NS construction includes materials that provide superior performance in elevated temperature and radiation environments.

The O-rings are EPDM (ethylene propylene) and the diaphragms are EPDM/Nomex. EPDM⁽¹⁾ demonstrates superior temperature capability and shelf life over nitrile. The Nomex diaphragm fabric demonstrates improved strength retention at elevated temperature and radiation conditions.

In addition, the Type 546NS transducer is qualified “commercial grade dedicated” under Fisher’s 10CFR50, Appendix B, quality assurance program. These can be supplied as 10CFR, Part 21 items.

Specifications

Specifications for the Type 546, 546S, and 546NS are listed in table 1.

Installation



WARNING

If a flammable or hazardous gas is being used as the supply pressure medium and the transducer is in an enclosed area, personal injury or property damage might result from fire or explosion of accumulated gas. To avoid such injury or damage, provide adequate ventilation.

Mounting

When a Type 546, 546S, or 546NS transducer is ordered as part of a control valve assembly, the factory mounts the transducer on the actuator and connects the necessary tubing, then adjusts the transducer as specified on the order.

Transducers also can be ordered separately for mounting on a control valve assembly already in service. The transducer may be ordered with or without mounting parts. Mounting parts include the appropriate bracket and bolts for attaching the unit to an actuator boss (with tapped holes) or for attaching it to the diaphragm casing. If preferred, mounting parts are available for mounting the transducer on a 2-inch (51 mm) diameter pipestand, a flat surface, or a bulkhead.

Tubing is not included if the transducer is not factory mounted. Use 3/8-inch (9.5 mm) outside diameter tubing for all supply and output connections. Tubing length between the transducer output and the final control element should be as short as possible to minimize its effect on control loop stability.

1. Use a clean, dry, oil-free air supply with instruments containing EPDM components. EPDM is subject to degradation when exposed to petroleum-based lubricants.

Type 546, 546S, and 546NS

Table 1. Specifications

Available Configurations

Type 546: Electro-pneumatic signal transducer with explosion-proof case and cover

Type 546S: Similar to Type 546 except designed for intrinsically safe, non-incendive, or dust-ignition applications

Type 546NS: Similar to Type 546 except provided with EPDM elastomers for use in elevated temperature and radiation environments

All transducer types can be ordered with or without a 67 Series filter regulator. A 2 inch (51 mm) circular supply pressure gauge may be mounted on the regulator

Input Signals⁽¹⁾

Type 546 and 546NS: 1 to 5 mAdc, 4 to 20 mAdc, 10 to 50 mAdc, 1 to 9 Vdc, or two-way split range using any half of one of the standard input signal spans

Type 546S: ■ 4 to 20 mAdc, or ■ For Factory Mutual only, a two-way split range using either half of the 16 mAdc span. Signal must not exceed 30 Vdc, 20 mAdc

Internal Resistance of Torque Motor

1 to 5 mAdc Input Signal: 2500 ±120 ohms (standard) or 12,000 ±50 ohms (temperature-compensated circuit)

4 to 20 mAdc Input Signal: 176 ±10 ohms

10 to 50 mAdc Input Signal: 90 ±10 ohms

1 to 9 Vdc Input Signal: 1300 ±50 ohms (temperature-compensated circuit)

Output Signals⁽¹⁾

Ranges:⁽¹⁾

For 546 and 546NS: 3 to 15 psig (0.2 to 1.0 bar), 6 to 30 psig (0.4 to 2.0 bar), 3 to 27 psig (0.2 to 1.9 bar), 0 to 18 psig (0 to 1.2 bar), or 0 to 33 psig (0 to 2.3 bar)

For 546S: 3 to 15 psig (0.2 to 1.0 bar), 6 to 30 psig (0.4 to 2.0 bar), 3 to 27 psig (0.2 to 1.9 bar), or 0 to 33 psig (0 to 2.3 bar)

Action: Type 546 and 546NS are field-reversible between direct and reverse action. The Type 546S is available with either direct or reverse action but cannot be reversed in the field.

Supply Pressure⁽¹⁾

Recommended: 5 psig (0.3 bar) higher than upper range limit of output signal

Maximum: 50 psig (3.5 bar)

Maximum Steady-State Air Consumption^(1,2)

At 20 psig (1.4 bar) Supply Pressure: 0.35 scfm (0.6 normal m³/hr)

At 35 psig (2.4 bar) Supply Pressure: 0.50 scfm (0.8 normal m³/hr)

Maximum Output Air Capacity⁽²⁾

At 20 psig (1.4 bar) Supply Pressure: 8.0 scfm (13.4 normal m³/hr)

At 35 psig (2.4 bar) Supply Pressure: 11.5 scfm (19.3 normal m³/hr)

Performance⁽³⁾

Actuator Loading Time: See figure 7

Reference Accuracy: ±0.75% of output signal span

Independent Linearity:⁽¹⁾ ±0.50% of output signal span

Open Loop Gain:⁽¹⁾ 26

Frequency Response:⁽¹⁾ Gain is attenuated 3 dB at 20 Hz with transducer output signal piped to a typical instrument bellows with 12 inches (305 mm) of 1/4 inch tubing

Operative Ambient Temperature Limits⁽¹⁾

–40 to +150°F (–40 to 66°C)

Electrical and Enclosure Classification

Refer to the Hazardous Area Classification bulletins and the transducer nameplate (see figure 2)

Housing: NEMA 3R and CSA ENC 3 rating (NEMA 3R mounting orientation requires vent location to be below horizontal. Vent is shown in figure 10, key 69)

Adjustments

Zero and Span Adjustments: Screwdriver adjustments located inside case (see figure 5)

Connections

Supply Pressure: 1/4-inch NPT female located on side of case, (or located on the Type 67 AFR filter-regulator if mounted)

Output Pressure: 1/4-inch NPT female located on side of case

Vent: 1/4-inch NPT female with screen located on relay

Electrical: 1/2-inch NPT female located on bottom of case

Approximate Weight (Transducer Only)

9 pounds (4.1 kg)

1. These terms are defined in ISA Standard S51.1-1979.

2. Scfm—Standard cubic feet per minute (60°F and 14.7 psia). Normal m³/hr—Normal cubic meters per hour (0°C and 1.01325 bar absolute).

3. Performance values are obtained using a Type 546 or Type 546S transducer with a 4 to 20 mAdc input signal and a 3 to 15 psig (0.2 to 1 bar) or a 6 to 30 psig (0.4 to 2 bar) output signal. Ambient temperature is 73°F (24°C). A transducer with other input or output signals might exceed these values. Reference accuracies of ±3.5% can be expected with output ranges starting near zero psig.

Type 546, 546S, and 546NS




Figure 3. Diagnostic Connections

Pressure Connections

Note

The supply source must be clean, dry, oil-free,⁽¹⁾ non-corrosive air or gas at an unfailing pressure at least 5 psig (0.3 bar) higher than the upper limit of the transducer output pressure range. This means that for an output pressure range of 3 to 15 psig (0.2 to 1.0 bar) the supply pressure should be at least 20 psig (1.4 bar); for a 6 to 30 psig (0.4 to 2.0 bar) range, the supply pressure should be at least 35 psig (2.4 bar). The supply pressure to the filter regulator should not be more than 250 psig (17.3 bar) at a maximum temperature of 150°F (66°C).

If specified, the filter regulator is mounted on the transducer case. A pressure gauge on the regulator shows the supply pressure to the transducer.

1. Connect a supply pressure source to the 1/4-inch NPT IN connection on the filter regulator (if furnished) or to the 1/4-inch NPT SUPPLY connection on the transducer case (if a regulator is not furnished).
2. Run 3/8-inch (9.5 mm) outside diameter tubing from the 1/4-inch NPT OUTPUT connection on the transducer case to the input connection on the pneumatic actuator or valve positioner. This connection is made at the factory if the unit is shipped mounted on an actuator as shown in figure 1.

Diagnostic Connections

To support diagnostic testing of valve/actuator/positioner packages, special connectors and hardware are available. Typical connector installations are shown in figure 3. The hardware used includes a 1/4-inch NPT pipe nipple and pipe tee with a 1/8-inch NPT pipe

bushing for the connector. The connector consists of 1/8-inch NPT body and body protector.

Note

If the transducer is used in a valve assembly with a positioner, no connections for diagnostic testing are required for the transducer. Install the connections for diagnostic testing at the positioner.

Install the connectors and hardware between the transducer and the actuator.

1. Before assembling the pipe nipple, pipe tee, pipe bushings, actuator piping, and connector body, apply sealant to all threads.
2. Turn the pipe tee to position the connector body and body protector for easy access when doing diagnostic testing.

Electrical Connections



For explosion-proof applications, disconnect power before removing the transducer cover.

For explosion-proof applications, install rigid metal conduit and a conduit seal no more than 18 inches (457 mm) from the transducer. Personal injury or property damage may result from explosion if the seal is not installed.

For intrinsically safe installations, refer to factory drawings or to instructions provided by the barrier manufacturer for proper wiring and installation.

Type 546, 546S, and 546NS




Figure 4. Typical Circuit Drawings

The electrical connections are made in the transducer case. A 1/2-inch NPT conduit connection is provided in the bottom of the case. Use a suitable conduit seal for hazardous locations. The wires that carry the input signal from the control device are connected to the terminal mounting bracket assembly (key 53, figure 9).

WARNING

To avoid personal injury or equipment damage, do not reverse the action of a Type 546S transducer in the field. Diodes in the input circuit (see figure 4) will short if a reversed input signal is applied. If the diodes are shorted, they are capable of producing a spark which might ignite a hazardous atmosphere causing a fire or explosion. A Type 546S transducer must be ordered from the factory as either direct or reverse acting.

For a direct-acting unit (i.e., increasing current produces an increasing output pressure), connect the positive wire from the control device to the positive terminal of the transducer and the negative wire to the negative terminal. For a reverse-acting unit (i.e., increasing current produces a decreasing output pressure), connect the positive wire from the control device to the negative terminal and the negative wire to the positive terminal. Typical circuits are shown in figure 4.

Note

Use a lubricant (key 95, figure 8) on the case-cover threads to prevent thread damage.

Operating Information

WARNING

Personal injury or property damage may result from fire or explosion if power is applied to the transducer with the cover removed in a hazardous area.

If the transducer is installed in an application where explosion-proof classification is required, perform the following steps when any procedure in this section requires removal of the cover:

- Disconnect the electrical signal from the transducer.
- Remove the transducer to a non-hazardous area.
- Perform procedures as described in this section.
- Reinstall the transducer, and ensure the cover is secured before turning on the electrical signal.

For intrinsically safe areas, current monitoring during operation must be with a meter approved for use in hazardous areas.

Adjustments

Adjust the filter regulator to provide the proper supply pressure to the transducer, then adjust the transducer span and zero (see figures 5 and 6) to match the application requirements and be within specifications.

The zero adjustment is used to set the output pressure so that it corresponds to the proper value of the input

Type 546, 546S, and 546NS




Figure 5. Zero and Span Adjustments (Cover Removed)

signal. For example, if the output range is 3 to 15 psig (0.2 to 1.0 bar) and the input range is 1 to 5 mAdc and the unit is direct-acting, use the zero adjustment to set the output pressure at 3 psig (0.2 bar) when the input signal is 1 mAdc. Use the span adjustment to set the output pressure span so that full output pressure change results for a full change in the input signal. In this example, the output pressure change would be 12 psi (0.8 bar). Thus, the output pressure should start at 3 psig and increase to 15 psig (1.0 bar) as the input signal is changed from 1 to 5 mAdc.

A span adjustment will affect the zero. Therefore, follow any span adjustment with a zero adjustment. Provide a suitable gauge to measure the pressure.

Calibration

Equipment Required

Choose a current or voltage source that is capable, without switching ranges, of driving the transducer through its entire input range. Switching ranges on a current or voltage source will produce spikes or mid-scale reverses in the input signal presented to the transducer, causing errors.

Calibration Procedure

Note

The following calibration procedure is for a Type 546, 546S, or 546NS transducer with a 4 to 20 mAdc input signal range and a 3 to 15 psig (0.2 to 1.0 bar) output range. Calibrate transducers with

other inputs and outputs in a similar manner.

1. Check the supply pressure to ensure it agrees with the minimum pressure on the transducer nameplate.
2. Adjust the input current to 4.00 mAdc.
3. Turn the zero screw until the output pressure is 3.00 ± 0.09 psig (0.2 ± 0.006 bar).
4. Adjust the input to 20.00 mAdc.
5. If the output pressure is less than 14.91 psig (1.028 bar), turn the span screw clockwise to increase the span. If the output pressure is greater than 15.09 psig (1.040 bar), turn the span screw counterclockwise to decrease the span.

Note

Do not watch the output gauge while turning the span screw because the change in output is not a good indication of the change in span. While turning the span adjustment screw, the output pressure may move in the opposite direction than expected. For example, while turning the span screw in the INCREASING SPAN direction, the output pressure might decrease. This should be disregarded since even though the output pressure decreases, the output span is increasing.

6. Repeat steps 2 through 5 until the output pressure is within one-third of the accuracy limits at 4 and 20 mAdc. One-third of the accuracy limits for a 3 to 15 psig (0.2 to 1.0 bar) output range is $\frac{1}{3} \times (\pm 0.0075) \times (15.00 - 3.00) = \pm 0.03$ psig (± 2 mbar). Calibrate for maximum accuracy at the target end points [3.00 and 15.00 psig (0.20 and 1.00 bar)]. This allows for error at other calibration points in between.
7. Run the transducer through three calibration cycles before recording data. The cycles should be run from exactly 4.00 to 20.00 mAdc in a slow ramping fashion (no large step inputs).
8. After returning from 20.00 mAdc during the last exercise cycle, move back upscale to the midpoint (12.00 mAdc) and record the first data point. Table 2 is an example of recorded data.
9. Record at the other calibration points desired by moving upscale to 20.00 mAdc then down scale to 4.00 mAdc, then back upscale to 12.00 mAdc. Refer to table 2 for common calibration points.

Type 546, 546S, and 546NS

Table 2. Typical Calibration Data

| TRANSDUCER INPUT mA dc | ACTUAL OUTPUT PRESSURE | | TARGET OUTPUT PRESSURE | |
|---------------------------|------------------------|-------|------------------------|-------|
| | Psig | Bar | Psig | Bar |
| 12.00 | 8.89 | 0.612 | 9.00 | 0.620 |
| 16.00 | 11.95 | 0.823 | 12.00 | 0.826 |
| 20.00 | 15.02 | 1.035 | 15.00 | 1.033 |
| 16.00 | 12.02 | 0.828 | 12.00 | 0.826 |
| 12.00 | 8.96 | 0.617 | 9.00 | 0.620 |
| 8.00 | 6.00 | 0.413 | 6.00 | 0.413 |
| 4.00 | 3.01 | 0.207 | 3.00 | 0.206 |
| 8.00 | 5.95 | 0.409 | 6.00 | 0.413 |
| 12.00 | 8.97 | 0.618 | 9.00 | 0.620 |

Note

During the calibration cycle, use care to avoid overshoot. In other words, if data is to be recorded at an 8.00 mAdc input while moving upscale and you accidentally pass 8.00 to some higher value, run the test again starting at step 7 with the three exercise cycles. Do not reverse direction and move down scale to 8.00 mAdc.

10. After completing the calibration cycle and recording data, verify that all data is within $\pm 0.75\%$ accuracy limits. If not, the transducer may need to be recalibrated to move the end points slightly to bring the entire calibration curve within the accuracy limits.

Recalibration

Table 2 shows typical recorded data where recalibration is necessary.

The 8.89 psig (0.612 bar) value at 12.00 mAdc is outside the accuracy limit of ± 0.09 from the target value. This data point can be raised by recalibrating the transducer and raising the end points enough to bring this low value within -0.09 psig (-0.6 mbar) of 9.00 psig (0.62 bar). A reasonable recalibration would be 3.05 and 15.05 psig (0.21 and 1.04 bar) at 4.00 mAdc and 20.00 mAdc, respectively. Recalibrate the instrument and recheck the calibration data as described in steps 7 through 10.

If the transducer remains outside of accuracy specifications after altering the calibration end points as much as possible, return the transducer to the factory or consult your Fisher Controls sales office or sales representative.

For transducers inaccurate to less than 5 percent of output span, relay repair or replacement may correct the problem. Refer to the alignment procedures in the Troubleshooting section to correct the operation of a faulty transducer. Also check for air leaks at the tubing, nozzle, relay, and bellows.

If the accuracy error is greater than 5 percent of output span, check the clearance between the armature and the coils. These parts are referenced as key 40

and key 42, respectively, in the Parts List section. The armature and the white plastic coil bobbin should be approximately 1/64 inch (0.4 mm) apart. If the parts are in contact, loosen the machine screws that hold the bobbin and reposition the bobbin.

Changing Output Pressure Range

Changing the output pressure range from 3 to 15 psig (0.2 to 1.0 bar) to 6 to 30 psig (0.4 to 2.0 bar) or vice versa requires changing the feedback bellows (key 57, figure 9). To do this, refer to the replacing the feedback bellows assembly procedures in the Maintenance section.

Reversing the Action

Reversing the action of a Type 546 or 546NS transducer requires no special parts. The direction of armature rotation is dependent upon the direction of the current flow. Therefore, simply reverse the input current leads to the transducer to obtain the opposite action. Whenever the action is changed, readjust the zero of the transducer as outlined in the adjustments procedures.



WARNING

To avoid personal injury or equipment damage, do not reverse the action of a Type 546S transducer in the field. Diodes in the input circuit (see figure 4) will short if a reversed input signal is applied. If the diodes are shorted, they are capable of producing a spark which might ignite a hazardous atmosphere causing a fire or explosion. A Type 546S transducer must be ordered from the factory as either direct or reverse acting.

Split Range Operation

Type 546, 546S, and 546NS transducers are suitable for two-way split range operation. In a two-way split

Type 546, 546S, and 546NS

Table 3. Feedback Bellows Output Pressure Range

| OPERATION | INPUT SIGNAL, DC | BELLOWS SIZE | | | | | |
|-------------|---|--------------|------------|---------|------------|---------|------------|
| | | Full | | Half | | Quarter | |
| | | Psig | Bar | Psig | Bar | Psig | Bar |
| Full Range | 1 to 9 V ⁽¹⁾ 1 to 5 mA ⁽²⁾ 4 to 20 mA 10 to 50 mA | 3 to 15 | 0.2 to 1.0 | 6 to 30 | 0.4 to 2.0 | --- | --- |
| Split Range | 4 to 12 mA or 12 to 20 mA 10 to 30 mA or 30 to 50 mA 1 to 5 Vdc or 5 to 9 Vdc | --- | --- | 3 to 15 | 0.2 to 1.0 | 6 to 30 | 0.4 to 2.0 |


1. Temperature compensated circuit.
2. Not appropriate for split range applications because of the high resistance of 1 to 5 mA dc coils. If split range operation is desired, consult your Fisher Controls sales office or sales representative.

the milliampere (mA) or voltage output signal of a single control device is split between two transducers electrically connected in series. Although each transducer receives the full signal, it is calibrated to provide a full output pressure range of 3 to 15 psig (0.2 to 1.0 bar) or 6 to 30 psig (0.4 to 2.0 bar) to the control valve with one-half the input signal. Since the transducer operates on only one-half of the normal input span, the feedback bellows must be changed to compensate for the shorter span. Change the bellows as described in the replacing feedback bellows assembly procedure in the Maintenance section. Table 3 indicates which bellows is required for your conditions. Reset the span and zero adjustments to the split range values. Note that these transducers cannot provide a three-way split range.

Principle of Operation

Refer to the schematic drawing in figure 6. Assume that the transducer is direct-acting. An increase in the dc signal to the coils increases the magnetic field around the coils. This field increases the magnetic strength in the armature and the magnetic attraction across the air gap between the armature and the pole pieces.

The pole pieces are already polarized by the permanent magnet. The armature polarity is as shown in the schematic. The magnetic attraction will therefore be downward at the nozzle end and upward at the feedback bellows end, resulting in a torque that rotates the armature about the fixed torsion rod to cover the nozzle. The resulting restriction produces an increased pressure in the nozzle, in the upper chamber of the relay, and in the feedback bellows. The relay responds to the increase in nozzle pressure to increase the output pressure to the actuator and control valve. The increased pressure in the feedback bellows creates a force that acts on the armature to move it back to an equilibrium position. In this way, the new nozzle pressure is compared to the input current by the force-balance principle.



CP4285-A
A1505-3/IL

Figure 6. Transducer Schematic

The relay operates in the following manner. The nozzle pressure acts on the large top diaphragm to force the center spacer assembly (mounted between the two diaphragms) downward against the valve plug, closing the exhaust port and opening the supply port. Supply air then flows through the open port to the output load. The output pressure continues to increase until the relay diaphragm assembly is pushed back to its original position by the force of the pressure acting on the small diaphragm. When this occurs, the valve plug is closed again.

When a decreasing dc signal is received, the magnetic attraction across the air gap is reduced. The armature rotates to uncover the nozzle, relay, and feedback bellows. The relay diaphragm assembly moves upward, and the exhaust port opens to bleed the output pressure to atmosphere.

Type 546, 546S, and 546NS




Figure 7. Output-Time Relationship for Type 546, 546S, and 546NS Transducers

The output decreases until the diaphragm assembly is forced back to its original position and the exhaust port is closed again. The reduced pressure in the feedback bellows diminishes the force to return the armature to the equilibrium position.

Figure 7 shows output-time relationship curves for loading and exhausting an actuator. Exhausting times are nominally 25 percent of the loading times.

Reverse-acting transducers operate in a similar manner except that when the dc input signal increases, the output pressure from the relay decreases. Conversely, a decreasing input signal increases the output pressure.

Maintenance

WARNING

For explosion proof applications, disconnect power before opening the transducer cover. Personal injury or property damage may result if power is not disconnected.

CAUTION

The presence of Fisher Controls personnel and also approval agency personnel may be required if you service (other than normal, routine maintenance, such as calibration) or replace components on a transducer that carries a third-party approval. When you replace components, use only components specified by the factory. Substitution with other

components may void the third-party approval. Also, always use proper component replacement techniques, as presented in this manual. Improper techniques can cause poor quality repairs and impair the safety features of the device.

Maintenance of the transducer consists of relay repair or replacement, and replacement of the feedback bellows. These procedures are described at the end of this section. Due to the care Fisher Controls takes in meeting all manufacturing requirements (heat treating, dimensional tolerance, etc.), use only replacement parts manufactured or furnished by Fisher Controls International.

Figure 9 shows the torque motor and associated parts. Shaded key numbers indicate parts that should not be disassembled from the torque motor because the magnetism in the torque motor magnets will decrease permanently.

Certain troubleshooting and alignment procedures are described in the following steps. These may serve as a guide to correct some problems. Improper supply pressure and mechanical defects in pneumatic and electrical connections should be apparent upon inspection and repaired as appropriate.

CAUTION

Never disassemble the torque motor assembly because the magnetism in the torque motor magnets will decrease permanently. Shaded key numbers indicate parts that should not be disassembled from the torque motor (see figure 9). If troubleshooting or alignment attempts indicate either a faulty torque motor or the necessity of disassembling the torque motor, return the entire transducer to the factory, or consult your Fisher Controls sales office or sales representative.

Troubleshooting

This section contains some checks for operational difficulties that may be encountered. If correcting the difficulties is not possible, contact your Fisher Controls sales office, service center, or sales representative.

Electrical

1. Check the output of the control device. Make sure that it is reaching the transducer.
2. Check the dc input signal. It should be the same as the range stamped on the transducer nameplate.

Type 546, 546S, and 546NS

3. Check the resistance of the transducer circuit to see that it coincides with the value listed on the circuit identification tag located on the torque motor.
4. Check the terminal lugs for proper connections. If reverse action of the transducer is observed, simply reverse the input leads as indicated in the Reversing the Action procedures in the Operating Information section.

Pneumatic



CAUTION

Do not attempt to remove the nozzle (key 19, figure 9) for any reason. Nozzle removal requires disassembling the torque motor. Disassembling the torque motor will permanently reduce the strength of the magnets, causing improper operation. Also, do not adjust the baffle (key 18, figure 9). The spacing between the baffle and nozzle is preset and locked at the factory to obtain optimum performance of the transducer.

1. Connect supply pressure and a pressure gauge to monitor the output. Check the operation of the transducer as follows:
 - a. Force the baffle (key 18, figure 9) against the nozzle. The output pressure should build up to approximately the supply pressure. If it does not, check for a leak in the pneumatic system or a burr on the nozzle.
 - b. Force the baffle away from the nozzle. The output pressure should drop to less than 1 psig (0.07 bar). If it does not, check the flame arrestors in the transducer case (see figure 8). If the flame arrestors require cleaning, first remove the torque motor assembly from the case by removing four machine screws (key 9, figure 8). Then, clean the flame arrestors by blowing them out with air pressure.
2. Check zero and span adjustment for proper setting. Refer to the adjustments procedure.
3. Check the supply pressure. It should be at least 5 psig (0.3 bar) above the upper limit of the output pressure range.
4. Check the filter regulator for moisture in the drip-well. Drain off any moisture, and clean the filter element if necessary.
5. If the transducer cycles, be sure there are no sharp bends in the copper capillary feedback tubing (key 56, figure 9) and that the tubing is not plugged.
6. Check the nozzle. If it is clogged, remove the entire torque motor assembly from the case by removing four machine screws (key 9, figure 8). Run a wire through the nozzle from the underside of the assembly.
7. Erratic operation may be caused by metal chips in the air gap between the armature and the pole pieces. Blow any chips out of the torque motor assembly with low pressure air.
8. If a problem persists, check the relay as described in the Type 82 Relay Maintenance procedures in this section.

Alignment

The following alignment procedures can be used in conjunction with troubleshooting procedures to correct the operation of a faulty transducer.

Span Adjustment

Refer to figure 9 for key number locations, unless otherwise directed.

If setting the required span is not possible, additional span adjustment can be obtained by shifting the entire span adjustment assembly (key 55) at the flexure pivot end. The alignment procedure is as follows:

1. Shut off the dc input signal and supply pressure to the transducer.
2. Disconnect the external lead wires from the terminal mounting bracket assembly (key 53).
3. Loosen the four machine screws (key 9, figure 8) that hold the torque motor assembly to the case. Remove the entire torque motor assembly from the case.
4. Loosen the two flexure pivot screws (key 25) that hold the flexure pivot to the torque motor assembly base.
5. Slide the span adjustment assembly in or out as required. Sliding it in toward the base decreases the span; sliding it out away from the base increases the span.
6. Tighten the flexure pivot screws. Replace the torque motor assembly, and tighten the screws (key 9, figure 8). Make sure that the O-ring (key 37) is in place. Connect the external lead wires, and turn on the air supply.
7. Make final adjustment of the span with the span adjustment screw.

Type 546, 546S, and 546NS

Torque Motor Frame

The top pole piece plate (key 50, figure 9) of the torque motor can become twisted with respect to the bottom pole piece plate (key 51, figure 9). If this happens, return the transducer to the factory, service center, or contact your Fisher Controls sales office or sales representative.

Armature Travel Stop

The armature travel stop (key 52, figure 9) must be in place to prevent overstressing the armature and coil support (key 41, figure 9) due to over-travel. The clearance between the armature and travel stop should be 0.005 inches (0.13 mm).

The two screws at the base of the travel stop can be loosened if an alignment is necessary.

Coil

The coil assembly (key 42, figure 9) consists of a nylon bobbin wound with wire. The coils are not attached to the armature itself, and therefore, they must not touch the armature, or armature movements will be restricted. If this problem exists, loosen the two screws that attach each coil assembly to the armature and coil support. Sight down the armature and realign the coil assemblies for clearance with the armature. Tighten the screws.



WARNING

The following maintenance procedures require that the transducer be taken out of service. This requires that certain precautions be taken to avoid personal injury or equipment damage caused by sudden release of pressure or explosion of accumulated gas. Prior to maintenance:

- **Disconnect electrical power before removing the transducer cover (especially in explosion proof or hazardous applications).**
- **Shut off or disconnect pressure lines to the transducer.**
- **Disconnect any operating lines providing air pressure, electrical power, or a control signal to the actuator. Be sure the actuator cannot suddenly open or close the valve.**

- **Use bypass valves or completely shut off the process to isolate the valve from process pressure. Relieve process pressure on both sides of the valve. Drain the process media from both sides of the valve.**

- **Vent the power actuator loading pressure and relieve any actuator spring precompression.**

- **Use lock-out procedures to be sure that the above measures stay in effect while you work on the equipment.**

Type 82 Relay Removal and Replacement

Use the following procedure when removing and replacing a relay assembly. Refer to figure 10 for key number locations, unless otherwise directed.

1. Loosen the two mounting screws (key 68), and remove the relay assembly from the transducer case (key 1, figure 8).
2. To install the replacement relay assembly, install the two relay mounting screws (key 68) into the relay assembly. Apply lubricant (key 96) to the O-rings, and make sure the O-rings (keys 72, 73, and 74) are in place on the relay assembly.
3. Install the relay assembly on the transducer case. Tighten the mounting screws.
4. With the torque motor installed, apply supply pressure to the transducer case, and check the relay assembly for leaks with a soap solution.

Type 82 Relay Maintenance

Use the procedure below to repair the relay assembly. Refer to figure 10 for key number locations.

Obtain the relay repair kit listed in the parts list. This kit provides the parts, alignment tool, and an instruction sheet used when repairing the relay assembly.

1. Remove the two screws (key 77), valve plug spring seat (key 64), valve plug spring (key 70) and valve plug (key 63).
2. Remove the six screws (key 76, not shown) and separate the relay body (key 60), casing spacer (key 61), and relay casing (key 62) by inserting a screwdriver between the external casting lugs. Twist the screwdriver to separate parts.
3. Remove the upper diaphragm (key 66), lower diaphragm assembly (key 65), and relay spring (key 71). Clean and inspect relay parts before replacing them.
4. Remove the restriction assembly (key 67) and replace the O-rings (keys 74 and 75). Apply lubricant (key 96) to the O-rings before installing the restriction assembly into the relay body.

Type 546, 546S, and 546NS

5. The restriction hole (see figure 10) in the restriction assembly is 0.016 inches (0.41 mm) in diameter. Clean the hole with solvent and blow dry with compressed air. If the hole is plugged, insert a wire in the hole. Then, clean with solvent and blow dry with compressed air. Do not enlarge the hole. Reinstall the restriction assembly in the relay body. Do not overtighten.

6. The restriction hole in the relay body is 0.020 inches (0.51 mm) in diameter. If the hole is plugged, insert a wire into the hole and clean it out. Do not enlarge the hole.

7. Insert the new lower diaphragm assembly through the casing spacer, replace the relay spring, and position the parts on the relay body. Position the new upper diaphragm on the relay casing and position the relay casing on the upper diaphragm. Ensure that the exterior casing lugs on the relay body, casing spacer, and relay casing are aligned.

8. Invert the relay and install the six screws (key 76), but do not tighten.

9. Insert the alignment tool through the brass supply seat in the relay body, and into the exhaust seat of the lower diaphragm assembly to align the parts.

10. Ensure the diaphragms are flat between the relay body, casing spacer, and relay casing. Tighten the six screws (key 76).

11. Remove the alignment tool, and reassemble the valve plug, valve plug spring, valve plug spring seat and the two screws (key 77).

12. Install the two relay mounting screws (key 68) into the relay assembly. Apply lubricant (key 96) to the O-rings, and make sure the O-rings (keys 72, 73, and 74) are in place on the relay assembly.

13. Install the relay assembly on the transducer case. Tighten the mounting screws.

14. With the torque motor installed, apply supply pressure to the transducer case, and check the relay assembly for leaks with a soap solution.

Replacing the Feedback Bellows Assembly

Refer to figure 9 for key number locations.

1. Loosen the hex nut (key 31).

2. Remove the bellows screw (key 56) and O-ring (key 36) under the head of the bellows screw.

3. Pull the bellows assembly (key 57) out. The armature is slotted to allow removal of the bellows assembly.

4. Inspect and, if necessary, replace the two O-rings (key 36). Make sure the O-rings under the bellows assembly are in place.

5. Choose the correct bellows assembly as outlined in table 3. Install the new bellows assembly. Make sure that the O-ring (key 36) is in place.

6. Install the bellows screw and O-ring, and tighten the screw. Be sure the bellows assembly is not distorted in any direction. Tighten the hex nut (key 31).

7. Refer to the adjusting zero and span procedures in the Adjustments section.

Parts Ordering

Whenever corresponding with the sales office or sales representative about this equipment, mention the serial number of the unit. This serial number can be found on the nameplate (figure 2). When ordering replacement parts, also state the complete 11-character part number of each part needed as found in the following parts list.

Note

In the torque motor assembly drawing (figure 9), there are many shaded key numbers. The shading indicates that these parts should not be disassembled and that they are not available as individual items. Consequently, no part numbers are shown for these parts in the list below.

Parts List

Repair Kits for Type 546, 546S, and 546NS Transducers

| Description | Part Number |
|--|-------------|
| Type 546 and 546S Transducer Repair Kit Kit includes keys 6, 12, 36, 37, and 58 | R546X000022 |
| Type 546NS Transducer Repair Kit Kit includes keys 6, 12, 36, 37, and 58 | R546X000032 |
| Type 82 Relay Repair Kit (for Type 546 and 546S only) This kit includes keys 63, 65, 66, 69, 70, 72, 73, 74, 75. Kit also includes instruction sheet and alignment tool | R82X0000022 |
| Type 82 Relay Replacement Assembly (for Type 546 and 546S) Assembly includes two mounting screws (Key 68) | 10A8593X082 |
| Type 82 Relay Replacement Assembly (for Type 546NS) Assembly includes two mounting screws (key 68) | 10A8593X142 |

Type 546, 546S, and 546NS




Figure 8. Type 546 Transducer Assembly

| Key | Description | Part Number | Key | Description | Part Number |
|---|---|-------------|--------------------------------|--|-------------|
| Type 546, 546S, & 546NS Transducers (figure 8) | | | 96 | Lubricant, Molykote 33 (not furnished with unit) | |
| 1 | Transducer Case Ass'y, aluminum | 1P4210000A2 | 106 | Protective plug, polyethylene (2 req'd) | 1E878406992 |
| 2 | Case Cover, aluminum | 3P4213000A2 | 107 | Street Elbow, use with integrally mounted filter regulator w/o-60 dual scale gauge | 1A913221992 |
| 3 | Protective Plug, plastic | 1M3590X0012 | 108 | Pipe Plug, steel | |
| 4 | Tagging Plate (optional) Stainless steel (SST) | 13B6776X012 | | For regulator w/o gauge | 1A767524662 |
| 5 | Nameplate, Standard, SST | | Torque Motor (figure 9) | | |
| 6* | O-Ring | | 15 ⁽²⁾ | Adjusting Screw | --- |
| | For Type 546 and 546S, nitrile | 1D444806992 | 16 ⁽²⁾ | Spring Seat | --- |
| | For Type 546NS, EPDM Duro 80A | 14B7744X012 | 17 ⁽²⁾ | Spring-Zero Adjustment | --- |
| 8* | Pressure Gauge | | | For Type 546 & 546S, | --- |
| | Triple scale | | | For Type 546NS, SST | --- |
| | 0-30 psig/0-.2 MPa/0-2 bar | 11B8582X012 | 18 ⁽²⁾ | Baffle | --- |
| | 0-60 psig/0-.4 MPa/0-4 bar | 11B8582X022 | 19 ⁽²⁾ | Nozzle | --- |
| | Dual scale | | 20 ⁽²⁾ | Hook-Up Wire Ass'y | --- |
| | 0-30 psig/0-2 Kg/cm ² | 11B8582X042 | 21 ⁽²⁾ | Hook-Up Wire Ass'y | --- |
| | 0-60 psig/0-4 Kg/cm ² | 11B8579X072 | 22 ⁽²⁾ | Hook-Up Wire (not shown) | --- |
| 9 | Machine Screw, brass pl (4 req'd) | 17B0404X012 | 25 ⁽²⁾ | Machine Screw | --- |
| 10 | Screw, steel pl | 1P426928982 | 26 ⁽²⁾ | Cap Screw | --- |
| 11 | Cap Screw, steel pl (2 req'd) use with integrally mounted filter regulator only | 1C197024052 | 27 ⁽²⁾ | Cap Screw | --- |
| 12* | O-Ring, use with integrally mounted filter regulator only | | 28 ⁽²⁾ | Machine Screw | --- |
| | For Type 546 and 546S, nitrile | 1E591406992 | 29 ⁽²⁾ | O-Ring | --- |
| | For Type 546NS, EPDM Duro 80A | 14B7748X012 | | For Type 546 & 546S, nitrile | --- |
| 13 | Pipe Nipple, steel pl, | | | For Type 546NS, EPDM Duro 80A | --- |
| | For filter regulator only (not shown) | 1C678926232 | 31 | Hex Nut, brass pl | 1N107318992 |
| 92 | Wire Retainer, steel pl (2 req'd) | 17B7757X012 | 32 ⁽²⁾ | Washer | --- |
| 95 | Lubricant, | | 33 | Washer, brass pl | 1P425315052 |
| | For 546 and 546S use Lubriplate Mag 1 (not furnished with unit) | | 34 ⁽²⁾ | Washer | --- |
| | For 546NS use Molykote 33 (not furnished with unit) | | 35 ⁽²⁾ | Washer | --- |
| | | | 36* | O-Ring (2 req'd) | --- |
| | | | | For Type 546 and 546S, nitrile | 1D687506992 |
| | | | | For Type 546NS, EPDM Duro 80A | 14B7743X012 |

*Recommended spare parts
2. Parts are not field repairable. The torque motor assembly should never be disassembled because the magnetism in the torque motor will decrease permanently. Shaded key numbers shown in figure 9 indicate parts that should not be disassembled.

Type 546, 546S, and 546NS




Figure 9. Torque Motor Assembly


| Key | Description | Part Number |
|--------------------|--|--|
| 37* | O-Ring For Type 546 and 546S, nitrile For Type 546NS, EPDM Duro 80A | 1C782206992 14B7747X012 |
| 38 ⁽²⁾ | E-Ring | --- |
| 40 ⁽²⁾ | Armature | --- |
| 41 ⁽²⁾ | Coil Support | --- |
| 42 ⁽²⁾ | Coil Ass'y | --- |
| 48 ⁽²⁾ | Magnet | --- |
| 49 ⁽²⁾ | Pole Piece | --- |
| 50 ⁽²⁾ | Top Pole Piece Plate | --- |
| 51 ⁽²⁾ | Bottom Pole Piece Plate | --- |
| 52 ⁽²⁾ | Travel Stop | --- |
| 53 ⁽²⁾ | Terminal Mounting Bracket Ass'y | --- |
| 55 ⁽²⁾ | Span Adjustment Ass'y ⁽³⁾ | --- |
| 56 | Bellows Screw, brass | 12B2577X012 |
| 57* | Bellows Ass'y, brass Full Size, 27/32 inch (21 mm) O.D. Half Size, 1/2 inch (13 mm) O.D. Quarter Size, 3/8 inch (9.5 mm) O.D. | 1U3958000A2 1U3975000A2 1R6521000A2 1P4242000A2 |
| 58 | Tubing Ass'y, brass/copper | --- |
| 94 | Sealant, Zink Plate 770 (not furnished with unit) | --- |
| 96 | Lubricant, Molykote 33 (not furnished with unit) | --- |
| 103 | Set Screw, SST/nylon (not shown) | 11B2218X012 |
| 105 ⁽²⁾ | Spacer | --- |

| Key | Description | Part Number |
|---|--|-------------|
| Type 82 Relay (figure 10) | | |
| Note | | |
| The following parts are for repairing the Type 546 and 546S relays only. The Type 546NS relay is not repairable. If the relay is defective, order a Type 82 Relay Replacement Assembly for a Type 546NS transducer. | | |
| 60 | Relay Body, aluminum/brass | 3P4192X0022 |
| 61 | Casing Spacer, aluminum | 2P419347052 |
| 62 | Relay Casing, aluminum | 2P419447052 |
| 63* | Valve Plug, brass | 1P419514012 |
| 64 | Spring Seat, brass | 1P419615102 |
| 65* | Lower Diaphragm Ass'y | 1P4197X0032 |
| 66* | Upper Diaphragm, nitrile | 26A5657X012 |
| 67 | Restriction Ass'y | 1U8160X0012 |
| 68 | Relay Mounting Screw, steel pl (2 req'd) | 1P420324102 |
| 69* | Screen, Monel | 0L078343062 |
| 70* | Valve Plug Spring, SST | 1P420437022 |
| 71 | Relay Spring, steel pl | 15A3181X012 |
| 72* | O-Ring nitrile | 1P420606992 |
| 73* | O-Ring, nitrile (2 req'd) | 1P420706992 |
| 74* | O-Ring, nitrile (2 req'd) | 1D687506992 |
| 75* | O-Ring, nitrile | 1D134606992 |

*Recommended spare parts

3. The span adjustment assembly for the Type 546NS uses a bronze passive lock, rather than nylon, and a locking hex nut.

Type 546, 546S, and 546NS



□ APPLY LUBRICANT/
SEALANT

NOTE:
KEY 76 IS NOT SHOWN

A1504-1 / IL

Figure 10. Type 82 Relay.

| Key | Description | Part Number |
|-----|---|-------------|
| 76 | Machine Screw, steel pl (6 req'd) (not shown) | 10B6513X012 |
| 77 | Machine Screw, steel pl (2 req'd) | 59061140X22 |
| 96 | Lubricant, Molykote 33 (not furnished with unit) | |




Figure 11. Typical Actuator Mounting

Diagnostic Connections

FlowScanner™ diagnostic system hook-up
Includes pipe tee, pipe nipple, pipe bushings,
connector body, and body protector. See figure 3
for part identification. Also, part number provides
correct quantities of each item.

Note

**If the transducer is used in a valve assembly
with a positioner, no hook-up for diagnostic test-
ing is required for the transducer. The hook-up
for diagnostic testing should be installed at the
positioner.**

| | |
|--------------------------|-------------|
| For units with gauges | |
| SST fittings | 12B8041X012 |
| Brass fittings | 12B8041X022 |
| For units without gauges | |
| SST fittings | 12B8041X032 |
| Brass fittings | 12B8041X042 |

Mounting Parts (figures 11 & 12)

| | | |
|----|----------------------------------|-------------|
| 79 | Elbow, brass | |
| | Yoke mounting, | |
| | Types 513, 657, 1051, 1052, 1061 | |
| | all sizes | 15A6002X162 |
| | Yoke mounting (2 req'd) | |
| | Type 470, 480, 585, 585C, 667 | |
| | all sizes | 15A6002X162 |

| Key | Description | Part Number |
|-----|--|-------------|
| 79 | Elbow, brass (cont'd) | |
| | Yoke mounting, | |
| | Types 513, 657, 1051, 1052, 1061 | |
| | all sizes | 15A6002X162 |
| | Casing mounting | |
| | Type 1250, 657, 667, 1051, 1052 | |
| | all sizes | 15A6002X162 |
| 80 | Connector, brass | |
| | Yoke mounting | |
| | Type 513, 657, 1051, 1052, 1061 | |
| | all sizes | 15A6002X202 |
| | Casing mounting | |
| | 1250, 657, 667, 1051, 1052 | |
| | all sizes | 15A6002X202 |
| 81 | Mounting Plate, steel | |
| | Yoke mounting | |
| | Type 470, 480, 513, 585, 585C, 656, | |
| | 657, 667, all sizes | |
| | Type 1051 size 33 all positions, | |
| | size 40 and 60 position 1, | |
| | Type 1052 size 33 all positions, | |
| | sizes 40 thru 70 position 1 | |
| | Type 1061 size 30 all positions, | |
| | sizes 40 thru 100 position 1 | 3P426825022 |
| | Type 1250 and 1250R | 30B1265X022 |
| | Type 1051 size 40 and 60 position 3 | |
| | Type 1052 sizes 40 thru 70 position 3 | |
| | Type 1061 sizes 40 thru 100 position 3 | 2R1552X0022 |
| | Type 657, 657NS, 667, 667NS, all sizes | |
| | for seismic mounting of 546NS | 35A4153X012 |

Type 546, 546S, and 546NS




Figure 12. Typical Casing Mounting


| Key | Description | Part Number | Key | Description | Part Number |
|-----|--|-------------|-----|---|---|
| 81 | Mounting Plate, steel (cont'd) Casing mounting Type 657 & 667, all sizes except size 80 Type 1051, 1052, all sizes, all positions | 1F401225072 | 83 | Cap Screw Casing mounting (2 req'd) Type 1051, 1052, all sizes, all positions | 1A582824052 |
| | Pipestand mounting | 3P426825022 | 85 | Washer, steel pl Yoke mounting (4 req'd) All types, all sizes, except Type 1250 & 1250R Casing mounting (2 req'd) Pipestand mounting (4 req'd) Yoke mounting Type 1250 & 1250R, none required | 1B865928982 |
| | Surface mounting | 2R100125022 | 86 | Cap Screw, steel pl (2 req'd) Yoke mounting Type 470, Sizes 60 through 130 Type 490, all sizes Type 657NS & 667NS, Sizes 70, 80 Type 1051 & 1052, size 33, positions 1 & 3 Type 480, all sizes Type 585 & 585C, Sizes 25 & 50 Type 656, Size 30 Type 1051 & 1052, size 33, positions 2 & 4 | 1C870224052 1C5958X0022 1A352624052 1B989624052 1K747624052 |
| | Bulkhead mounting | 22A7618X012 | | Casing mounting Type 657 & 667, Sizes 30 through 60 Type 657 & 667, Size 70 | 1A582824052 1A368324052 |
| 82 | Cap Screw, steel pl Yoke mounting (4 req'd) Type 470 size 23 thru 40, 63 & 64 Type 480 all sizes Type 513 all sizes Type 656 size 40 thru 60 Type 657 & 667 size 30 thru 80 Type 1051 size 40 & 60 all positions Type 1052 sizes 40 thru 70 all positions Type 1061 all sizes all positions | 1A381624052 | 87 | Spacer, steel (2 req'd) Yoke mounting Type 470, Sizes 60 through 130 Type 490, all sizes Type 657NS & 667NS, Sizes 70, 80 Type 656, Sizes 30 Type 585, Sizes 25 & 50 Type 1051 & 1052, size 33, positions 1 & 3 Type 1051 & 1052, size 33, positions 2 & 4 | 1K766824092 1R801924092 1F906724092 1V102624052 1L200624092 |
| | Yoke mounting (2 req'd) Type 470, size 60 thru 130, except 63 & 64 Type 585, sizes 25 & 50 Type 585C, all sizes Type 656, size 30 Type 657NS & 667NS, sizes 70 & 80 Type 1250 & 1250R Type 1051 size 33 all positions Type 1052 size 33 all positions | 1A381624052 | | Surface mounting | 18A1696X012 |
| | Casing mounting (2 req'd) All types, all sizes | 1A381624052 | 88 | Mounting Bracket, steel Yoke mounting Type 480, all sizes | 3L276725092 |
| | Pipestand mounting (2 req'd) | 1A381624052 | 89 | Hex Nut, steel pl (2 req'd) Yoke mounting Type 480, all sizes | 1A352724122 |
| | Surface mounting (2 req'd) | 1N789132992 | 90 | Pipe Clamp, steel pl Pipestand mounting | 1P427028982 |
| | Bulkhead mounting (2 req'd) | 1A381624052 | 97 | U-Bolt, steel pl (2 req'd) Type 1250 & 1250R, all sizes | 19A7930X012 |
| | | | 98 | Hex Nut, steel pl (4 req'd) Type 1250 & 1250R, all sizes | 19A4838X022 |
| | | | 99 | Lock washer, SST Yoke mounting (4 req'd) Type 585C, size 25 & 50 Type 1250 & 1250R, all sizes Yoke mounting (2 req'd) Type 1051 & 1052, size 33, all positions | 1C225728982 10B6610X012 1C225728982 |
| | | | 101 | Washer (2 req'd) Casing mounting Type 1051, 1052, all sizes, all positions | 1H723125072 |

Type 546, 546S, and 546NS

Loop Schematics

This section includes loop schematics required for wiring of intrinsically safe installations. If you have any questions, contact your Fisher Controls sales representative or sales office.

CSA Schematics



TYPE 546S: CSA PARAMETRIC RATINGS

| | | |
|---------------|----------------------------------|----------------------------------|
| GROUP A,B,C,D | CSA RATING 33V MAX, 581 OHM MIN. | SINGLE INSTRUMENT |
| GROUP A,B,C,D | CSA RATING 30V MAX, 411 OHM MIN. | SINGLE INSTRUMENT |
| GROUP A,B,C,D | CSA RATING 28V MAX, 346 OHM MIN. | SINGLE INSTRUMENT |
| GROUP A,B,C,D | CSA RATING 26V MAX, 342 OHM MIN. | SINGLE INSTRUMENT |
| GROUP A,B,C,D | CSA RATING 22V MAX, 150 OHM MIN. | SINGLE INSTRUMENT |
| GROUP C,D | CSA RATING 30V MAX, 150 OHM MIN. | SINGLE INSTRUMENT |
| GROUP C,D | CSA RATING 33V MAX, 150 OHM MIN. | SINGLE INSTRUMENT OR SPLIT RANGE |

| APPROVED BARRIER | BARRIER TYPE | MANUF. INST. MANUAL | SCHEM. NO. | METER OPTION | APPLICABLE HAZARDOUS LOCATIONS | CSA BARRIER RATING |
|------------------|--------------------|---------------------|------------|--------------|--------------------------------|--------------------|
| TAYLOR | 5850FL84100 | IB-21E600 | 1 | 43M/44M | CLASS I, DIV 1, GROUPS A,B,C,D | 25.75V, 350 OHMS |
| TAYLOR | 5851FL84100 | IB-21E600 | 1 | 43M/44M | CLASS I, DIV 1, GROUPS A,B,C,D | 25.75V, 350 OHMS |
| TAYLOR | 1130FG21000 | IB-17E211 | 1 | 43M/44M | CLASS I, DIV 1, GROUPS C,D | 30V, 266 OHMS |
| TAYLOR | 1135FG21000 | IB-17E212 | 1 | 43M/44M | CLASS I, DIV 1, GROUPS C,D | 30V, 266 OHMS |
| TAYLOR | 1150FZ81010 | IB-17E220 | 1 | 43M/44M | CLASS I, DIV 1, GROUPS A,B,C,D | 26V, 342 OHMS |
| FOXBORO | 2A0-V21-CGB | MI 200-255 | 3 | 43M/44M | CLASS I, DIV 1, GROUPS A,B,C,D | |
| FOXBORO | 2A0-V31-CGB | MI 200-255 | 3 | 43M/44M | CLASS I, DIV 1, GROUPS A,B,C,D | |
| FOXBORO | 2A0-V51-CGB | MI 200-255 | 3 | 43M/44M | CLASS I, DIV 1, GROUPS A,B,C,D | |
| FOXBORO | 2A0-V41-CGB | MI 200-255 | 3 | 43M/44M | CLASS I, DIV 1, GROUPS A,B,C,D | |
| FOXBORO | 3A2-D21-CS-E/CGB-A | MI 200-255 | 3 | 43M/44M | CLASS I, DIV 1, GROUPS A,B,C,D | |
| FOXBORO | 3A2-D31-CS-E/CGB-A | MI 200-255 | 3 | 43M/44M | CLASS I, DIV 1, GROUPS A,B,C,D | |
| FOXBORO | 2AS-131-CGB | MI 200-255 | 3 | 43M/44M | CLASS I, DIV 1, GROUPS A,B,C,D | |


THE LOOPS MUST BE CONNECTED ACCORDING TO THE BARRIER MANUFACTURER'S INSTRUCTIONS.

FOR GUIDANCE ON INSTALLATION, SEE ANSI/ISA RP12.6.

WB-10/ 10

Type 546, 546S, and 546NS

CSA Schematics (Continued)



| APPROVED BARRIER | BARRIER TYPE | MANUF. INST. MANUAL | SCHEM. NO. | METER OPTION | APPLICABLE HAZARDOUS LOCATIONS | CSA BARRIER RATING |
|------------------|--------------------------|---------------------|------------|--------------|--------------------------------|----------------------------|
| STAHL | 8903/51-200/050/7 | 89 036 01 31 0 | 2 | 43M/44M | CLASS I, DIV 1, GROUPS A,B,C,D | 20.41V, 300 OHMS |
| STAHL | 8901/33-293/000/7 | 89 016 03 31 0 | | | | 28.1V, 470 OHMS |
| STAHL | 8901/31-199/100/7 | 89 016 03 31 0 | 1,4 | 43M/44M | CLASS I, DIV 1, GROUPS A,B,C,D | 19V, 220 OHMS |
| STAHL | 8903/31-200/050/7 | 89 036 01 31 0 | 1,4 | 43M/44M | CLASS I, DIV 1, GROUPS A,B,C,D | 19.95V, 286.7 OHMS |
| STAHL | 8903/31-263/050/7 | 89 036 01 31 0 | 1 | 43M/44M | CLASS I, DIV 1, GROUPS A,B,C,D | 26.5V, 386 OHMS |
| STAHL | 8901/31-280-165/8 | 89 016 03 31 0 | 2 | 43M/44M | CLASS I, DIV 1, GROUPS C,D | 27.3V, 179 OHMS |
| STAHL | 8901/33-293/000/7 | 89 016 03 31 0 | | | | 28.1V, 470 OHMS |
| MTL | 187+ | PS-300-13 | 3 | 43M/44M | CLASS I, DIV 1, GROUPS C,D | 28V, 300 OHMS; 30V (DIODE) |
| MTL | 128+ | PS-300-13 | 1 | 43M/44M | CLASS I, DIV 1, GROUPS C,D | 28V, 300 OHMS |
| MTL | 122+ | PS-300-13 | 1 | 43M/44M | CLASS I, DIV 1, GROUPS A,B,C,D | 22V, 150 OHMS |
| MTL | 787+ | PS-700-2 | 3 | 43M/44M | CLASS I, DIV 1, GROUPS C,D | 28V, 300 OHMS; 28V (DIODE) |
| MTL | 728+ | PS-700-2 | 1 | 43M/44M | CLASS I, DIV 1, GROUPS C,D | 28V, 300 OHMS |
| MTL | 722+ | PS-700-2 | 1 | 43M/44M | CLASS I, DIV 1, GROUPS A,B,C,D | 22V, 150 OHMS |
| BAILEY | 766610AAV1 | 4576K16-034 | 3 | NONE | CLASS I, DIV 1, GROUPS C,D | 27V, 345 OHMS |
| HONEYWELL | 38545-0000-0110-113-C505 | S 385-22 | 1 | 43M/44M | CLASS I, DIV 1, GROUPS A,B,C,D | 20V, 150 OHMS |
| HONEYWELL | 38545-000-0110-111-C505 | S 385-22 | 1 | 43M/44M | CLASS I, DIV 1, GROUPS C,D | 28V, 200 OHMS |
| HONEYWELL | 38545-000-0110-111-C505 | S 385-22 | 2 | 43M/44M | CLASS I, DIV 1, GROUPS C,D | 28V, 200 OHMS |
| HONEYWELL | 38545-0000-0110-112-C505 | | | | | 28V, 200 OHMS |


THE LOOPS MUST BE CONNECTED ACCORDING TO THE BARRIER MANUFACTURER'S INSTRUCTIONS.

FOR GUIDANCE ON INSTALLATION, SEE ANSI/ISA RP12.6.

WB-10/ 10

Type 546, 546S, and 546NS

FM Schematics



TYPE 546S

ENTITY PARAMETERS

$V_{max} = 33.3Vdc$ $I_{max} = 175mA$ $C_i = 0$ $L_i = 0$

NOTES:

-LOOPS MUST BE CONNECTED ACCORDING TO THE BARRIER MANUFACTURERS INSTRUCTION

-SEE ANSI/ISA RP12.6 FOR GUIDANCE IN INSTALLATION

-BARRIER PARAMETERS MUST MEET THE FOLLOWING REQUIREMENTS:

V_{oc} OR $V_T \leq V_{max}$ I_{sc} OR $I_T \leq I_{max}$ $C_o(\mu F) > 0.0$ $L_o(mH) > 0.0$

-THE C_o AND L_o PARAMETERS FOR THE BARRIER MUST BE GREATER THAN THE SUM OF THE CONNECTING CABLE PARAMETERS AND C_i AND L_i OF THE I.S. APPARATUS

-MAXIMUM SAFE AREA VOLTAGE SHOULD NOT EXCEED $250 V_{rms}$


-RESISTANCE BETWEEN BARRIER GROUND AND EARTH GROUND MUST BE LESS THAN ONE OHM

-CL I, DIV 2 APPLICATIONS MUST BE INSTALLED AS SPECIFIED IN NEC SECTION 501-4 (b) WHEN BARRIERS ARE NOT USED

NORMAL OPERATING CONDITIONS 30 VDC, 20 mADC

NO CHANGE IN PART OR VENDOR OF PART ALLOWED
WITHOUT PRIOR APPROVAL OF: FM

Type 546, 546S, and 546NS



SUPPLY AND RETURN BARRIERS
MUST BE APPROVED BY FMRC
FOR USE IN THIS CONFIGURATION

TYPE 546S

ENTITY PARAMETERS

$V_{max} = 33.3Vdc$ $I_{max} = 175mA$ $C_i = 0$ $L_i = 0$

NOTES:

-LOOPS MUST BE CONNECTED ACCORDING TO THE BARRIER MANUFACTURERS INSTRUCTION

-SEE ANSI/ISA RP12.6 FOR GUIDANCE IN INSTALLATION

-BARRIER PARAMETERS MUST MEET THE FOLLOWING REQUIREMENTS:

V_{oc} OR $V_T \leq V_{max}$ I_{sc} OR $I_T \leq I_{max}$ $C_o(\mu F) > 0.0$ $L_o(mH) > 0.0$

-THE C_o AND L_o PARAMETERS FOR THE BARRIER MUST BE GREATER THAN THE SUM OF THE CONNECTING CABLE PARAMETERS AND C_i AND L_i OF THE I.S. APPARATUS

-MAXIMUM SAFE AREA VOLTAGE SHOULD NOT EXCEED $250 V_{rms}$

-RESISTANCE BETWEEN BARRIER GROUND AND EARTH GROUND MUST BE LESS THAN ONE OHM

-CL I, DIV 2 APPLICATIONS MUST BE INSTALLED AS SPECIFIED IN NEC SECTION 501-4 (b) WHEN BARRIERS ARE NOT USED

NORMAL OPERATING CONDITIONS 30 VDC, 20 mADC

NO CHANGE IN PART OR VENDOR OF PART ALLOWED
WITHOUT PRIOR APPROVAL OF FM

26A5936-H Sheet 2 of 2



Fisher-Rosemount satisfies all obligations coming from legislation to harmonise product requirements in the European Union.

Fisher, Fisher-Rosemount, and Managing The Process Better are marks owned by Fisher Controls International, Inc. or Fisher-Rosemount Systems, Inc. All other marks are the property of their respective owners.

©Fisher Controls International, Inc. 1977, 1997; All Rights Reserved

The contents of this publication are presented for informational purposes only, and while every effort has been made to ensure their accuracy, they are not to be construed as warranties or guarantees, express or implied, regarding the products or services described herein or their use or applicability. We reserve the right to modify or improve the designs or specifications of such products at any time without notice.

For information, contact Fisher Controls:
Marshalltown, Iowa 50158 USA
Cernay 68700 France
Sao Paulo 05424 Brazil
Singapore 128461

