

Functions

Assuming DFR_Key keypad;

DFR_Key() - Constructor

Initializes default refreshRate, keyPin, threshold, time, and key inputs.

keypad.setRate(int r)

Sets the key sample rate at once every 'r' milliseconds.

Default: 10ms

keypad.getKey()

Returns an integer value based on what key is currently pressed. Return values are as follows:

- + Wait: -1
- + No Key: 0
- + Select: 1
- + Left: 2
- + Up: 3
- + Down: 4
- + Right: 5