

Prepared William Yang	Title TDC FVT4 Test Station Setup Manual		
Approved	Date 29/07/2018	Revision 1.0	File on File Server

# TDC FVT4 Test Station Setup Manual

Prepared William Yang	Title TDC FVT4 Test Station Setup Manual		
Approved	Date 29/07/2018	Revision 1.0	File on File Server

## **REVISION HISTORY**

Version	Date	Author	Comment
1.0	7/28/2018	William Yang	First draft

## **TABLE OF CONTENTS**

<b><u>1. Purpose .....</u></b>	<b><u>3</u></b>
<b><u>2. Scope .....</u></b>	<b><u>3</u></b>
<b><u>3. Abbreviations and Explanation .....</u></b>	<b><u>3</u></b>
<b><u>4. TDC FVT4 Test Station Instruction .....</u></b>	<b><u>3</u></b>
4.1. FVT4 instruction .....	3
4.2. FVT4 3D View .....	4
4.3. Component Location .....	5
<b><u>5. Hardware Installation .....</u></b>	<b><u>7</u></b>
5.1. Test PC Install .....	7
<b><u>6. Software Installation .....</u></b>	<b><u>8</u></b>
6.1. Install TDC_FVT4 Software package. ....	8
6.2. Install necessary software package. ....	8
6.3. Intall Driver .....	8
<b><u>7. Software Configuration .....</u></b>	<b><u>9</u></b>
7.1. Setting MAIN configuration .....	9
7.2. Setting Equipment configuration .....	10
7.3. Setting Test Sequence configuration .....	11
7.4. Manual setting by open configuration file. ....	11
<b><u>8. Test Station Check .....</u></b>	<b><u>12</u></b>
8.1. Power on test station. ....	12
8.2. Test Station Function Manual Check .....	12
8.3. Begin to do test. ....	13
<b><u>9. Reference document .....</u></b>	<b><u>13</u></b>

Prepared William Yang	Title TDC FVT4 Test Station Setup Manual		
Approved	Date 29/07/2018	Revision 1.0	File on File Server

## 1. Purpose

This document will introduce how to setup the hardware and software in TDC FVT4 station.

## 2. Scope

This file only applicable to all related personnel who want to setup or using TDC FVT4 station.

## 3. Abbreviations and Explanation

- AOI: Automatically optical inspection.
- TSI: Top side inspection.
- ICT: In circuit test.
- FVT: Functional verification test.
- FNI: Final inspection.
- OBA: Open box audit.
- FPY: First pass yield.
- TE: Test Engineer.
- A-B-A: Exchange experiment for Defected component
- LSL: Lower Specification Limit
- USL: Upper Specification Limit
- GRR: Gauge Repeatability and Reproducibility
- ANOVA: analysis of variance

## 4. TDC FVT4 Test Station Instruction

### 4.1. FVT4 instruction


FVT4 test station is a special test station for Michelin TDC product and the major function includes:

- A. FW Flash.
- B. Charging check
- C. Bluetooth Check
- D. RF ID Check
- E. Trad Depth Calibration (Distance Calibration)
- F. Pressure Calibration (Cancel it due to new pressure sensor was very precise).
- G. Trad Depth test
- H. Pressure test

Prepared William Yang	Title TDC FVT4 Test Station Setup Manual		
Approved	Date 29/07/2018	Revision 1.0	File on File Server

## 4.2. FVT4 3D View


Front View



Rear View




Tread Depth Calibration / Test Part mechanical construction





Prepared William Yang	Title TDC FVT4 Test Station Setup Manual		
Approved	Date 29/07/2018	Revision 1.0	File on File Server

## 4.3. Component Location





Prepared William Yang	Title TDC FVT4 Test Station Setup Manual		
Approved	Date 29/07/2018	Revision 1.0	File on File Server



Prepared William Yang	Title TDC FVT4 Test Station Setup Manual		
Approved	Date 29/07/2018	Revision 1.0	File on File Server

## 5. Hardware Installation

### 5.1. Test PC Install

A. Put the PC and screen in test station

PC SCREEN

TEST PC



A. Connect the two USB cable to PC's normal USB port.



Prepared William Yang	Title TDC FVT4 Test Station Setup Manual		
Approved	Date 29/07/2018	Revision 1.0	File on File Server

## 6. Software Installation

### 6.1. Install TDC\_FVT4 Software package.

1. Please install TDC\_FVT4\_V1.0\_Software\_Installation.exe.

### 6.2. Install necessary software package.

1. Please install Microsoft Visual C++ 2017 Redistributable.  
You can get it from folder . \KICKMAKER\TDC\FVT4\V1.0\Package\ after software package installed or download from internet.
2. Please install STM32 ST-LINK Utility\_v3.4.0  
You can get it from folder . \KICKMAKER\TDC\FVT4\V1.0\Tools\ after software package installed or download from internet.

### 6.3. Intall Driver

1. Install Test bench driver.
2. Install USB-RS485 driver.
3. Install ST-LINK V2 Driver
4. Install BT-Dongle Driver

You can found all of drivers from \KICKMAKER\TDC\FVT4\V1.0\Drivers\ after software package installed




Prepared William Yang	Title TDC FVT4 Test Station Setup Manual		
Approved	Date 29/07/2018	Revision 1.0	File on File Server


## 7. Software Configuration

### 7.1. Setting MAIN configuration

1. Open test software.
2. Click – Config - Main on menu bar



3. A Main configuration interface will pop up on the screen like this:



4. Please setting each main parameter base on actually situations.  
The parameter with “Trace\_Path” and “Trace\_Path\_Copy” will save storage the log files, please make sure you setting a correct / existing folder, or the test software will cannot running.
5. After all parameter setting, please click SAVE button to save and exit Main configuration interface.

Prepared William Yang	Title TDC FVT4 Test Station Setup Manual		
Approved	Date 29/07/2018	Revision 1.0	File on File Server

## 7.2. Setting Equipment configuration

1. Click – Config - Equipment on menu bar in test software interface
2. A Equipment configuration interface will pop up on the screen like this:

Config - Equipment.ini

Product\_Communication

Equipment\_Name: STM32 ST-LINK

Communication\_Type: USB

PID: 5678

VID: 1234

Distance\_Gauge

Equipment\_Name: XSEW-AHB 152V0-Distance Gauge

Communication\_Type: RS485

Serial\_Port: COM8

Baud\_Rate: 115200

Slave\_ID: 01

Pressure\_Gauge

Equipment\_Name: XSEW-AHB 152V0-Pressure Gauge

Communication\_Type: RS485

Serial\_Port: COM8

Baud\_Rate: 115200

Slave\_ID: 02

BlueTooth

Equipment\_Name: LY50A02 - Silicon Labs CP210X USB to UART Bridge

Communication\_Type: RS232

Serial\_Port: COM3

Baud\_Rate: 9600

SAVE CANCEL

USB - RS485 Converter COM port ID.


BT-Dongle COM Port ID :

3. Please setting each main parameter base on actually situations.
  - A. Only USB-RS485 converter COM port and BT-Dongle COM port ID need update base on actually situations, no need update other parameter.
  - B. Distance gauge and Pressure gauge will use same COM port, but Slave\_ID different.
4. After all parameter set corrected, please click SAVE button to save and exit configuration interface.

Prepared William Yang	Title TDC FVT4 Test Station Setup Manual		
Approved	Date 29/07/2018	Revision 1.0	File on File Server

### 7.3. Setting Test Sequence configuration

1. Click – Config - Sequence on menu bar in test software interface
2. A Sequence configuration interface will pop up on the screen like this:



3. Please setting each main parameter base on actually situations.
  - A. For Mass production, please make sure every available test step setting to “Enable”.
4. After all parameter set corrected, please click SAVE button to save and exit configuration interface.

### 7.4. Manual setting by open configuration file.

Except setting the parameter in test software interface, you also can be setting each parameter by open Config file in folder:

C:\KICKMAKER\TDC\FVT4\V1.0\Config\



**WARNING: Don't change anything without authorized by KICKAMER test team.**

Prepared William Yang	Title TDC FVT4 Test Station Setup Manual		
Approved	Date 29/07/2018	Revision 1.0	File on File Server

## 8. Test Station Check

### 8.1. Power on test station.


1. Power on main power switcher
2. Power on test bench.
3. Pull – out Emergency Stop Button.



**WARNING:** If you found any abnormal, please push down Emergency Stop Button without any hesitate, test station will power down after Emergency Stop Button push down.

### 8.2. Test Station Function Manual Check

1. Open test software and click Maintenance – TestBench in Menu bar.
2. A test bench maintenance interface will pop up on screen :



3. Check step motor and linear slider.  
Click Move\_Left / Move\_Right button, the linear slider should move to left and right.  
Click Move\_Stop button, the linear slider should stop moving.
4. Check distance gauge  
Click ON button in Distance\_Gauge\_Monitor, the distance value should display in Distance\_Gauge\_Monitor area.
5. Check pressure gauge  
Click ON button in Pressure\_Gauge\_Monitor, the distance value should display in Pressure\_Gauge\_Monitor area.
6. Check High pressure

Prepared William Yang	Title TDC FVT4 Test Station Setup Manual		
Approved	Date 29/07/2018	Revision 1.0	File on File Server

- A. Click OPEN with Inflator relay, then click Inflator\_Start, the Inflator should be running. Then you can see the value in Pressure\_Gauge\_Monitor increase till 14 bar.
  - B. Connect TDC pressure air tube to TDC product, then click TDC\_Relay Open button, the high pressure will connect to TDC, the TDC will show the actually pressure value.
  - C. Click Inflator\_Stop button, inflator will stop.
7. Check pressure release.  
Click Pressure\_Release\_Relay on button, the high pressure will released, you can see the value in Pressure\_Gauge\_Monitor dropping.
8. Check TDC Charging.
- A. Connect the TDC by Type-C cable.
  - B. Then click Charging\_Relay Open button.
  - C. You can see the TDC begin charging.
9. Check TDC power on.
- A. Connect the TDC by Type-C cable
  - B. Power off TDC.
  - C. Click Key\_On\_Relay.
  - D. The TDC will automatic power on.
10. Flashing check
- A. Select a FW file by click open in FW\_File\_Path.
  - B. Click FLASH button.
  - C. Test station will flash FW by ST-Link V2.

### 8.3. Begin to do test.

If every check result was pass, we can begin to do test.

If check result was failed, please check Hardware / Software setting till problem solved.

## 9. Reference document

[MICHELIN TDC Project Hardware Test Plan V1.1 03122018.pdf](#)

[TDC FVT4 Calibration Test Fixture Specification Ver1.0.pdf](#)

[FVT4 Calibration Electric Design V3.pdf](#)